


Operating instructions Compax3 T30

Programmable motion control according to IEC61131-3



Release as from R09-63

192-120104N15
C3IxxT30
Oktober 2014

Windows NT®, Windows 2000™, Windows XP™, Windows Vista, Windows 7 are trademarks of Microsoft Corporation.

Nonwarranty clause

We checked the contents of this publication for compliance with the associated hard and software. We can, however, not exclude discrepancies and do therefore not accept any liability for the exact compliance. The information in this publication is regularly checked, necessary corrections will be part of the subsequent publications.

Production site:



Parker Hannifin Manufacturing Germany GmbH & Co. KG
 Electromechanical Automation Europe [EME]
 Robert-Bosch-Strasse 22
 77656 Offenburg (Germany)
 Tel.: + 49 (0781) 509-0
 Fax: + 49 (0781) 509-98176
 Internet: www.parker.com/eme <http://www.parker.com/eme>
 E-mail: sales.automation@parker.com <mailto:EM-Motion@parker.com>

Parker Hannifin GmbH - registered office: Bielefeld HRB 35489
 Management Board: Ellen Raahede Secher, Dr.-Ing. Hans-Jürgen Haas, Günter Schrank, Kees Veraart - Chairman of the board: Hansgeorg Greuner

Italy: Parker Hannifin Manufacturing Srl • SSD SBC • Electromechanical Automation • Via Gounod, 1
 I-20092 Cinisello Balsamo (MI), Italy
 Tel.: +39 (0)2 361081 • Fax: +39 (0)2 36108400
 E-mail: sales.automation@parker.com <mailto:sales.sbc@parker.com> • Internet: www.parker.com/eme <http://www.parker.com/eme>

USA: Parker Hannifin Corporation • Electromechanical Automation
 5500 Business Park Drive • Rohnert Park, CA 94928
 Phone #: (800) 358-9068 • FAX #: (707) 584-3715
 E-mail: CMR_help@parker.com mailto:emn_support@parker.com • Internet: www.compumotor.com <http://www.compumotor.com>

NOTICE

Status of the Manuals:

Help and PDFs are updated simultaneously. In case of doubt the HTML help shows the actual state in comparison to PDF edition.

For additional HTML help please refer to our website. **Motion control according to IEC61131-3** [http://www.Parker.com/Literature/Electromechanical Europe/user guides/C3T30.chm](http://www.Parker.com/Literature/Electromechanical%20Europe/user%20guides/C3T30.chm)

Inhalt

1. Introduction	9
1.1 Device assignment	9
1.2 ProfiNet Certificate	10
1.3 Scope of delivery	11
1.4 Type specification plate	12
1.5 Packaging, transport, storage	13
1.6 Safety instructions.....	14
1.6.1. General hazards.....	14
1.6.2. Safety-conscious working	14
1.6.3. Special safety instructions	15
1.7 Warranty conditions	16
1.8 Conditions of utilization	17
1.8.1. Conditions of utilization for CE-conform operation.....	17
1.8.2. Conditions of utilization for UL certification Compax3S.....	20
1.8.3. Conditions of utilization for UL approval Compax3M.....	21
1.8.4. Conditions of utilization for UL approval PSUP	22
1.8.5. Conditions of utilization for UL certification Compax3H.....	23
1.8.6. Current on the mains PE (leakage current).....	24
1.8.7. Supply networks	24
2. IEC 61131-3 - Positioning with function modules based on PLCopen 25	
3. Compax3 device description	27
3.1 Meaning of the status LEDs - Compax3 axis controller	27
3.2 Meaning of the status LEDs - PSUP (mains module).....	28
3.3 Connections of Compax3S	29
3.3.1. Compax3S connectors.....	29
3.3.2. Connector and pin assignment C3S.....	30
3.3.3. Control voltage 24VDC / enable connector X4 C3S	32
3.3.4. Motor / Motor brake C3S connector X3	33
3.3.5. Compax3Sxxx V2.....	34
3.3.6. Compax3Sxxx V4.....	36
3.4 Installation instructions Compax3M	38
3.5 PSUP/Compax3M Connections	40
3.5.1. Front connector	40
3.5.2. Connections on the device bottom.....	41
3.5.3. Connections of the axis combination.....	42
3.5.4. Control voltage 24VDC PSUP (mains module)	43
3.5.5. Mains supply PSUP (mains module) X41	44
3.5.6. Braking resistor / temperature switch PSUP (mains module)	46
3.5.7. Motor / motor brake Compax3M (axis controller)	48
3.5.8. X14 Safety technology option S1 for Compax3M (axis controller).....	49
3.5.9. Safety technology option S3 for Compax3M (axis controller).....	49
3.6 Connections of Compax3H	50
3.6.1. Compax3H plugs/connections	50
3.6.2. Connection of the power voltage.....	51
3.6.3. Compax3H connections front plate	52

3.6.4.	Plug and pin assignment C3H.....	53
3.6.5.	Motor / Motor brake C3H.....	55
3.6.6.	Control voltage 24 VDC C3H.....	56
3.6.7.	Mains connection Compax3H.....	56
3.6.8.	Braking resistor / supply voltage C3H.....	57
3.7	Communication interfaces.....	58
3.7.1.	RS232 / RS485 interface (plug X10).....	58
3.7.2.	Communication Compax3M.....	59
3.7.3.	Profibus connector X23 on Interface I20.....	61
3.7.4.	Profinet connector X23, X24 on Interface I32.....	62
3.7.5.	CANopen connector X23 Interface I21.....	64
3.7.6.	DeviceNet Stecker X23.....	66
3.7.7.	Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24.....	67
3.8	Signal interfaces.....	71
3.8.1.	Resolver / Feedback (connector X13).....	71
3.8.2.	Analogue / encoder (plug X11).....	73
3.8.3.	Digital inputs/outputs (plug X12).....	74
3.9	Mounting and dimensions.....	76
3.9.1.	Mounting and dimensions Compax3S.....	76
3.9.2.	Mounting and dimensions PSUP/C3M.....	80
3.9.3.	Mounting and dimensions C3H.....	82
3.10	Safety function - STO (=safe torque off).....	85
3.10.1.	General Description.....	85
3.10.2.	STO (= safe torque off) with Compax3S.....	88
3.10.3.	STO (= safe torque off) with Compax3m (Option S1).....	98
4.	Setting up Compax3.....	107
4.1	Configuration.....	107
4.1.1.	Selection of the supply voltage used.....	108
4.1.2.	Motor selection.....	109
4.1.3.	Optimize motor reference point and switching frequency of the motor current.....	109
4.1.4.	Ballast resistor.....	112
4.1.5.	General drive.....	113
4.1.6.	Defining the reference system.....	113
4.1.7.	Defining jerk / ramps.....	138
4.1.8.	Limit and monitoring settings.....	138
4.1.9.	Encoder simulation.....	140
4.1.10.	Recipe table.....	141
4.1.11.	Error response.....	141
4.1.12.	Configuration name / comments.....	142
4.2	Configuring the signal source.....	143
4.2.1.	Signal source of the load feedback system.....	143
4.2.2.	Physical Source.....	143
4.2.3.	Internal virtual master.....	147
4.2.4.	Fieldbus master.....	147
4.2.5.	HEDA Master signal source.....	147
4.3	Load control.....	149
4.3.1.	Configuration of load control.....	150
4.3.2.	Error: Position difference between load mounted and motor feedback too high.....	151
4.3.3.	Load control signal image.....	151
4.4	Optimization.....	152
4.4.1.	Optimization window.....	152

4.4.2.	Scope	153
4.4.3.	Controller optimization	160
4.4.4.	Signal filtering with external command value	220
4.4.5.	Input simulation	223
4.4.6.	Setup mode	224
4.4.7.	Load identification	227
4.4.8.	Alignment of the analog inputs	229
4.4.9.	C3 ServoSignalAnalyzer	231
4.4.10.	ProfileViewer for the optimization of the motion profile	265
4.4.11.	Turning the motor holding brake on and off.....	267

5. Motion control268

5.1	Programming based on IEC61131-3.....	268
5.1.1.	Compax3 ServoManager: IEC61131-3 programming.....	269
5.1.2.	Prerequisites	269
5.1.3.	CoDeSys / Compax3 target system (Target Package).....	269
5.1.4.	Languages supported	270
5.1.5.	Function range supported	270
5.1.6.	Data types supported	273
5.1.7.	Retain Variables	273
5.1.8.	Recipe table with 9 columns and 32 (120) lines	273
5.1.9.	Maximum program size.....	274
5.1.10.	Cycle time.....	274
5.1.11.	Access to the Compax3 object directory	274
5.1.12.	Compilation, debugging and down/upload of IEC61131 programs.....	275
5.1.13.	General rules / timing	275
5.1.14.	Library constants.....	277
5.2	Status diagram based on PLCopen.....	278
5.3	Control functions	279
5.3.1.	Activation of the drive (MC_Power)	280
5.3.2.	Stop (MC_Stop).....	282
5.3.3.	Opening the brake (C3_OpenBrake).....	284
5.4	Reading values.....	285
5.4.1.	Reading the current position (MC_ReadActualPosition)	285
5.4.2.	Read access to the (C3_ReadArray) array	287
5.4.3.	Reading the device status (MC_ReadStatus)	288
5.5	Positioning functions (standard).....	289
5.5.1.	Dynamic positioning	289
5.5.2.	Value range for positioning parameters.....	289
5.5.3.	Absolute positioning (MC_MoveAbsolute)	290
5.5.4.	Relative positioning (MC_MoveRelative)	295
5.5.5.	Additive positioning (MC_MoveAdditive).....	298
5.5.6.	Endless positioning (MC_MoveVelocity)	300
5.5.7.	Manual operation (C3_Jog).....	302
5.5.8.	Machine zero (MC_Home)	304
5.5.9.	Electronic gearbox (MC_GearIn).....	306
5.5.10.	Current setting operation (C3_Current)	309
5.5.11.	Torque / force control (C3_TorqueControl)	310
5.6	Error handling	312
5.6.1.	Acknowledging errors (MC_Reset).....	312
5.6.2.	Reading axis errors (MC_ReadAxisError).....	313
5.6.3.	Set error reaction (C3_SetErrorReaction)	314
5.6.4.	Switching off error messages (C3_ErrorMask)	315
5.7	Process image.....	316

5.7.1.	Reading digital inputs (C3_Input)	316
5.7.2.	Write digital outputs (C3_Output)	316
5.7.3.	Reading/writing optional inputs/outputs.....	316
5.7.4.	Memorizing the signals with the trigger event (C3_TouchProbe)	319
5.7.5.	Integration of Parker I/Os (PIOs)	322
5.8	Interface to C3 powerPLmC	327
5.8.1.	Interface module "PLmC_Interface"	327
5.8.2.	Cyclic data channel for C3T30 and C3T40	328
5.8.3.	Example: C3 powerPLmC Program & Compax3 Program	330
5.9	IEC examples.....	332
5.9.1.	Example in CFC: Using Compax3-specific function modules and Compax3 objects	332
5.9.2.	Example in CFC: Positioning 1.....	333
5.9.3.	Example in CFC: Positioning 2.....	334
5.9.4.	Example in CFC: Positioning with set selection	335
5.9.5.	Example in CFC: Cycle mode.....	336
5.9.6.	Example in ST: Cycle mode with a Move module	337
5.10	Profibus: Simulate Profidrive profile (C3_ProfiDrive_Statemachine)	339
5.11	Emulate CanOpen DS402 (C3_DS402_Statemachine)	341
6.	Communication	342
6.1	Compax3 communication variants.....	342
6.1.1.	PC <-> Compax3 (RS232).....	343
6.1.2.	PC <-> Compax3 (RS485).....	345
6.1.3.	PC <-> C3M device combination (USB)	346
6.1.4.	USB-RS485 Moxa Uport 1130 adapter	347
6.1.5.	ETHERNET-RS485 NetCOM 113 adapter	348
6.1.6.	Modem MB-Connectline MDH 500 / MDH 504	349
6.1.7.	C3 settings for RS485 two wire operation.....	350
6.1.8.	C3 settings for RS485 four wire operation	351
6.2	COM port protocol	352
6.2.1.	RS485 settings values.....	352
6.2.2.	ASCII - record	352
6.2.3.	Binary record	353
6.3	Remote diagnosis via Modem.....	357
6.3.1.	Structure	357
6.3.2.	Configuration of local modem 1	358
6.3.3.	Configuration of remote modem 2	359
6.3.4.	Recommendations for preparing the modem operation	359
6.4	Profibus/Profinet.....	360
6.4.1.	Typical application with Bus and IEC61131	360
6.4.2.	Profibus / Profinet configuration.....	360
6.4.3.	Cyclic process data channel	362
6.4.4.	Acyclic parameter channel	363
6.5	CANopen.....	371
6.5.1.	CANopen - Configuration.....	371
6.5.2.	Supporting IEC modules.....	373
6.5.3.	CANopen communication profile.....	380
6.5.4.	Acyclic parameter channel	385
6.6	DeviceNet.....	387
6.6.1.	DeviceNet Configuration.....	387
6.6.2.	DeviceNet object classes.....	388

6.6.3.	Data formats of the bus objects	389
6.7	Ethernet Powerlink / EtherCAT	390
6.7.1.	Configuring Ethernet Powerlink / EtherCAT	390
6.8	HEDA Bus	392
6.8.1.	HEDA standard mode	393
6.8.2.	HEDA expansion (HEDA advanced)	395
6.8.3.	Coupling objects	413
6.9	Normalization factors	414
7.	Compax3 - Objects	415
7.1	Object overview sorted by object name (T30)	416
7.2	T30 Objects for the Process-Data-Channel / the Messages	426
7.3	Object overview sorted by object groups (T30)	428
7.3.1.	C3 Objects	428
7.3.2.	C3Array Objects	430
7.3.3.	C3Plus Objects	431
7.3.4.	C3 objects (without CoDeSys objects)	434
8.	Status values	438
8.1	D/A-Monitor	438
9.	Error	439
10.	Order code	440
10.1	Order code device: Compax3	441
10.2	Order code for mains module: PSUP	442
10.3	Order code for accessories	442
10.3.1.	Order code for feedback cables	443
10.3.2.	Order Code braking resistors	443
10.3.3.	Order code mains filter (C3S)	444
10.3.4.	Order code capacitor module	444
10.3.5.	Interface cable order code	445
10.3.6.	Order Code input/output terminals (PIO)	445
10.3.7.	Order note	446
11.	Compax3 Accessories	447
11.1	Parker servo motors	447
11.1.1.	Direct drives	447
11.1.2.	Rotary servo motors	449
11.2	EMC measures	450
11.2.1.	Mains filter	450
11.2.2.	Motor output filter	455
11.2.3.	Mains chokes	457
11.3	Connections to the motor	458
11.3.1.	Resolver cable	459
11.3.2.	SinCos© cable	460
11.3.3.	EnDat cable	460
11.3.4.	Motor cable	461
11.3.5.	Encoder cable	462
11.4	External braking resistors	463
11.4.1.	Permissible braking pulse powers of the braking resistors	464

11.4.2.	Dimensions of the braking resistors	473
11.5	Capacitor module C4	476
11.6	Operator control module BDM	477
11.7	EAM06: terminal block for inputs and outputs	477
11.8	Interface cable	480
11.8.1.	RS232 - cable / SSK1	480
11.8.2.	RS485 cable to Pop / SSK27	481
11.8.3.	I/O-interface X12 / X22 / SSK22	482
11.8.4.	Ref X11 / SSK21	482
11.8.5.	Encoder coupling of 2 Compax3 axes / SSK29	483
11.8.6.	Modem cable SSK31	484
11.8.7.	Adapter cable SSK32/20	484
11.9	Options M1x	485
11.9.1.	Input/output option M12	485
11.9.2.	HEDA (motion bus) - Option M11	486
11.9.3.	Option M10 = HEDA (M11) & I/Os (M12)	487
11.9.4.	Analog current inputs and voltage inputs (Option M21)	488
11.10	Profibus plug BUS08/01	490
11.11	CAN - plug BUS10/01	491
11.12	PIO: External Inputs/Outputs	492
11.12.1.	Order Code input/output terminals (PIO)	492
12.	Technical Data	493
13.	Index	510

1. Introduction

In this chapter you can read about:

Device assignment	9
ProfiNet Certificate	10
Scope of delivery	11
Type specification plate	12
Packaging, transport, storage	13
Safety instructions	14
Warranty conditions	16
Conditions of utilization	17

1.1 Device assignment

This manual is valid for the following devices:

- ◆ Compax3S025V2 + supplement
- ◆ Compax3S063V2 + supplement
- ◆ Compax3S100V2 + supplement
- ◆ Compax3S150V2 + supplement
- ◆ Compax3S015V4 + supplement
- ◆ Compax3S038V4 + supplement
- ◆ Compax3S075V4 + supplement
- ◆ Compax3S150V4 + supplement
- ◆ Compax3S300V4 + supplement
- ◆ Compax3H050V4 + supplement
- ◆ Compax3H090V4 + supplement
- ◆ Compax3H125V4 + supplement
- ◆ Compax3H155V4 + supplement
- ◆ Compax3M050D6 + supplement - Safety Option S1
- ◆ Compax3M100D6 + supplement - Safety Option S1
- ◆ Compax3M150D6 + supplement - Safety Option S1
- ◆ Compax3M300D6 + supplement - Safety Option S1
- ◆ PSUP10D6
- ◆ PSUP20D6
- ◆ PSUP30D6

With the supplement:

- ◆ F10 (Resolver)
- ◆ F11 (SinCos®)
- ◆ F12 (linear and rotary direct drives)
- ◆ I11 T30
- ◆ I20 T30
- ◆
- ◆ I32 T30
- ◆ I21 T30
- ◆ I22 T30
- ◆ I30 T30
- ◆ I31 T30

1.2 ProfiNet Certificate



Certificate

PROFIBUS Nutzerorganisation e.V. grants to

Parker Hannifin (Electromechanical Automation)
Robert-Bosch-Str. 22, 77656 Offenburg, Germany

the Certificate No: **Z10601** for the PROFINET IO Device:

Model Name: Compax3 "C3xxxxVxFxxI32TxxMxxxxx"
Revision: 1; SW/FW: V1.51.0; HW: 24.02
Identnumber: 0x010F; 0xC332
GSD: GSDML-V2.3-Parker-Compax3-20130429.xml
DAP: IDT_DAP_C3: Compax3, 0x00000200

This certificate confirms that the product has successfully passed the certification tests with the following PROFINET scope:

<input checked="" type="checkbox"/> Hardware	Auto_Negotiation, Auto_Polarity, Auto_Crossover
<input checked="" type="checkbox"/> Conformance Class B	RT_CLASS_1, RTA, LLDP, SNMP, MIB-II, LLDP-MIB

Test Report Number: PN223-1
Authorized Test Laboratory: SIEMENS AG, Fürth, Germany


The tests were executed in accordance with the following documents:
 "Test Specifications for PROFINET IO devices, Version 2.2.4 from December 2010" and
 "Test Cases for PN-Tester for PROFINET IO devices, Version 2.2.4.16.21".

This certificate is granted according to the document:
 "Framework for testing and certification of PROFIBUS and PROFINET products".


For all products that are placed in circulation by May 06, 2016 the certificate is valid for life.


 (Official in Charge)

Board of PROFIBUS Nutzerorganisation e. V.



(Karsten Schneider)



(K.-P. Lindner)



1.3 Scope of delivery

The following items are furnished with the device:

◆ Manuals*

- ◆ Installation manual (German, English, French)
- ◆ Compax3 DVD
- ◆ Startup Guide (German / English)

*Comprehensiveness of documentation depends on device type

◆ Device accessories

Device accessories for Compax3S

- ◆ Cable clamps in different sizes for large area shielding of the motor cable, the screw for the cable clamp as well as
- ◆ the mating plug connectors for the Compax3S plug connectors X1, X2, X3, and X4
- ◆ a toroidal core ferrite for one cable of the motor holding brake
- ◆ Lacing cord

◆ Device accessories for Compax3M

- ◆ Cable clamps in different sizes for large area shielding of the motor cable, the screw for the cable clamp as well as
- ◆ the matching plug for the Compax3M connectors X14, X15, X43
- ◆ a toroidal core ferrite for a cable of the motor holding brake
- ◆ an interface cable (SSK28/23) for communication within the axis combination
- ◆ With safety option S3: Mating plugs X28 and connection cable X26 / X27

◆ Device accessories for PSUP

- ◆ Matching plug for the PSUP connectors X9, X40, X41
- ◆ 2 bus terminal connectors (BUS07/01) for mains module and the last axis controller in the combination

◆ Device accessories for Compax3H

- ◆ Mating connector for X3 and X4
- ◆ SSK32/20: RS232 adapter cable (programming port C3HxxxV4 - SSK1 - PC)
- ◆ VBK17/01: SubD jumper mounted

1.4 Type specification plate

Compax3 - Type
specification plate
(example):

The present device type is defined by the type specification plate (on the housing):



Explanation:

1	Type designation: The complete order designation of the device (2, 5, 6, 9, 8).
2	C3 : Abbreviation for Compax3 S025 : Single axis device, nominal device current in 100mA (025=2.5A) M050 : Multi-axis device, nominal device current in 100mA (050=5A) H050 : High power device, nominal device current in 1A (050=50A)
	D6 : Designation nominal supply V2 : Mains supply voltage (2=230VAC/240VAC, 4=400VAC/480VAC)
3	Unique number of the particular device
4	Nominal supply voltage Power Input: Input supply data Power Output: Output data
5	Designation of the feedback system F10 : Resolver F11 : SinCos® / Single- or Multiturn F12 : Feedback module for direct drives
6	Device interface I10 : Analog, step/direction and encoder input I11 / I12 : Digital Inputs / Outputs and RS232 / RS485 I20 : Profibus DP / I21 : CANopen / I22 : DeviceNet / I30 : Ethernet Powerlink / I31 : EtherCAT / I32 : Profinet C20 : integrated controller C3 <i>powerPLmC</i> , Linux & Web server
7	Date of factory test
8	Options Mxx : I/O extension, HEDA Sx : optional safety technology on C3M
9	Technology function T10 : Servo controller T11 : Positioning T20 : Pressure / Volume flow rate T30 : Motion control in accordance with IEC61131-3 T40 : Electronic cam
10	CE compliance
11	Certified safety technology (corresponding to the logo displayed)
12	UL certified (corresponding to the logo displayed)

1.5 Packaging, transport, storage

Packaging material and transport



Caution!

The packaging material is inflammable, if it is disposed of improperly by burning, lethal fumes may develop.

The packaging material must be kept and reused in the case of a return shipment. Improper or faulty packaging may lead to transport damages.

Make sure to transport the drive always in a safe manner and with the aid of suitable lifting equipment (**Weight** (see on page 493, see on page 504)). Do never use the electric connections for lifting. Before the transport, a clean, level surface should be prepared to place the device on. The electric connections may not be damaged when placing the device.

First device checkup

- ◆ Check the device for signs of transport damages.
- ◆ Please verify, if the indications on the **Type identification plate** (see on page 12) correspond to your requirements.
- ◆ Check if the consignment is complete.

Disposal

This product contains materials that fall under the special disposal regulation from 1996, which corresponds to the EC directory 91/689/EEC for dangerous disposal material. We recommend to dispose of the respective materials in accordance with the respectively valid environmental laws. The following table states the materials suitable for recycling and the materials which have to be disposed of separately.

Material	suitable for recycling	Disposal
Metal	yes	no
Plastic materials	yes	no
Circuit boards	no	yes

Please dispose of the circuit boards according to one of the following methods:

- ◆ Burning at high temperatures (at least 1200°C) in an incineration plant licensed in accordance with part A or B of the environmental protection act.
- ◆ Disposal via a technical waste dump which is allowed to take on electrolytic aluminum condensers. Do under no circumstances dump the circuit boards at a place near a normal waste dump.

Storage

If you do not wish to mount and install the device immediately, make sure to store it in a dry and clean **environment** (see on page 506). Make sure that the device is not stored near strong heat sources and that no metal chippings can get into the device.

Please note in the event of storage >1 year:

Forming the capacitors

Forming the capacitors only required with 400VAC axis controllers and PSUP mains module

If the device was stored longer than one year, the intermediate capacitors must be re-formed!

Forming sequence:

- ◆ Remove all electric connections
- ◆ Supply the device with 230VAC single phase for 30 minutes
 - ◆ via the L1 and L2 terminals on the device or
 - ◆ multi axis devices via L1 and L2 on the PSUP mains module

1.6 Safety instructions

In this chapter you can read about:

General hazards	14
Safety-conscious working	14
Special safety instructions	15

1.6.1. General hazards

General Hazards on Non-Compliance with the Safety Instructions

The device described in this manual is designed in accordance with the latest technology and is safe in operation. Nevertheless, the device can entail certain hazards if used improperly or for purposes other than those explicitly intended.

Electronic, moving and rotating components can

- ◆ constitute a hazard for body and life of the user, and
- ◆ cause material damage

Designated use

The device is designed for operation in electric power drive systems (VDE0160). Motion sequences can be automated with this device. Several motion sequences can be combined by interconnecting several of these devices. Mutual interlocking functions must be incorporated for this purpose.

1.6.2. Safety-conscious working

This device may be operated only by qualified personnel.

Qualified personnel in the sense of these operating instructions consists of:

- ◆ Persons who, by virtue to their training, experience and instruction, and their knowledge of pertinent norms, specifications, accident prevention regulations and operational relationships, have been authorized by the officer responsible for the safety of the system to perform the required task and in the process are capable of recognizing potential hazards and avoiding them (definition of technical personnel according to VDE105 or IEC364),
- ◆ Persons who have a knowledge of first-aid techniques and the local emergency rescue services.
- ◆ persons who have read and will observe the safety instructions.
- ◆ Those who have read and observe the manual or help (or the sections pertinent to the work to be carried out).

This applies to all work relating to setting up, commissioning, configuring, programming, modifying the conditions of utilization and operating modes, and to maintenance work.

This manual and the help information must be available close to the device during the performance of all tasks.

1.6.3. Special safety instructions



Caution!

Due to movable machine parts and high voltages, the device can pose a lethal danger. Danger of electric shock in the case of non-respect of the following instructions. The device corresponds to DIN EN 61800-3, i.e. it is subject to limited sale. The device can emit disturbances in certain local environments. In this case, the user is liable to take suitable measures.

- ◆ Check that all live terminals are secured against contact. Perilous voltage levels of up to 850V occur.
- ◆ Do not bypass power direct current

Be cautious when performing configuration downloads with master - slave couplings (electronic gear, cam) Deactivate the drive before starting the configuration download: Master and Slave axis.



Caution!

Due to movable machine parts and high voltages, the device can pose a lethal danger. Danger of electric shock in the case of non-respect of the following instructions. The device corresponds to DIN EN 61800-3, i.e. it is subject to limited sale. The device can emit disturbances in certain local environments. In this case, the user is liable to take suitable measures.

- ◆ The device must be permanently grounded due to high earth leakage currents.
- ◆ The drive motor must be grounded with a suitable protective lead.
- ◆ The devices are equipped with high voltage DC condensers. Before removing the protective cover, the discharging time must be awaited. After switching off the supply voltage, it may take up to 10 minutes (with additional capacity modules it may take up to 30 minutes) to discharge the capacitors.
Danger of electric shock in case of non respect.
- ◆ Before you can work on the device, the supply voltage must be switched off at the L1, L2 and L3 clamps. Wait at least 10 minutes so that the power direct current may sink to a secure value (<50V). Check with the aid of a voltmeter, if the voltage at the DC+ and DC- clamps has fallen to a value below 50V.
Danger of electric shock in case of non respect.
- ◆ Do never perform resistance tests with elevated voltages (over 690V) on the wiring without separating the circuit to be tested from the drive.
- ◆ Please exchange devices only in currentless state and, in an axis system, only in a defined original state.
- ◆ If the axis controller is replaced, it is absolutely necessary to transfer the configuration determining the correct operation of the drive to the device, before the device is put into operation. Depending on the operation mode, a machine zero run will be necessary.
- ◆ The device contains electrostatically sensitive components. Please heed the electrostatic protection measures while working at/with the device as well as during installation and maintenance.
- ◆ Operation of the PSUP30 only with line choke.



Attention - hot surface!

The heat dissipater can reach very high temperatures (>70°C)

Protective seals



Caution!

The user is responsible for protective covers and/or additional safety measures in order to prevent damages to persons and electric accidents.

Please note in the event of storage >1 year:

Forming the capacitors

Forming the capacitors only required with 400VAC axis controllers and PSUP mains module

If the device was stored longer than one year, the intermediate capacitors must be re-formed!

Forming sequence:

- ◆ Remove all electric connections
- ◆ Supply the device with 230VAC single phase for 30 minutes
 - ◆ via the L1 and L2 terminals on the device or
 - ◆ multi axis devices via L1 and L2 on the PSUP mains module

1.7 Warranty conditions

- ◆ The device must not be opened.
- ◆ Do not make any modifications to the device, except for those described in the manual.
- ◆ Make connections to the inputs, outputs and interfaces only in the manner described in the manual.
- ◆ Fix the devices according to the **mounting instructions**. (see on page 76, see on page 82)
We cannot provide any guarantee for other mounting methods.

Note on exchange of options

Device options must be exchanged in the factory to ensure hardware and software compatibility.

- ◆ When installing the device, make sure the heat dissipators of the device receive sufficient air and respect the recommended mounting distances of the devices with integrated ventilator fans in order to ensure free circulation of the cooling air.
- ◆ Make sure that the mounting plate is not exposed to external temperature influences.

1.8 Conditions of utilization

In this chapter you can read about:

Conditions of utilization for CE-conform operation	17
Conditions of utilization for UL certification Compax3S	20
Conditions of utilization for UL approval Compax3M	21
Conditions of utilization for UL approval PSUP	22
Conditions of utilization for UL certification Compax3H	23
Current on the mains PE (leakage current)	24
Supply networks	24

1.8.1. Conditions of utilization for CE-conform operation

- Industry and trade -

The EC guidelines for electromagnetic compatibility 2004/108/EC and for electrical operating devices for utilization within certain voltage limits 2006/95/EC are fulfilled when the following boundary conditions are observed:

Operation of devices only in the state in which they are delivered.

In order to ensure contact protection, all mating plugs must be present on the device connections even if they are not wired.

Please respect the specifications of the manual, especially the technical characteristics (mains connection, circuit breakers, output data, ambient conditions,...).

1.8.1.1 Conditions of utilization mains filter

Mains filter: A mains filter is required in the mains input line if the motor cable exceeds a certain length. Filtering can be provided centrally at the system mains input or separately for each device or with C3M for each axis system.

Use of the devices in a commercial and residential area (limit value class in accordance with EN 61800-3)

The following mains filters are available for independent utilization:

Device: Compax3S	Limit value class	Motor cable length	Mains filter Order No.:
S0xxV2	C2	< 10 m	without
	C2	> 10 m, < 100 m	NFI01/01
S1xxV2, S0xxV4, S150V4	C2	< 10 m	without
	C2	> 10 m, < 100 m	NFI01/02
S300V4	C3	< 10 m	without
	C2, C3	> 10 m, < 100 m	NFI01/03
Device: Compax3H	Limit value class	Motor cable length	Mains filter Order No.:
H050V4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/01
H090V4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/02
H1xxV4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/03

Use of the devices in the industrial area (limit values class C3 in accordance with EN 61800-3)

The following mains filters are available for independent utilization:

Device: PSU	Limit value class	Reference: Axis system with motor cable	Mains filter Order No.:
P10	C3	< 6 x 10 m	NFI03/01
P10	C3	< 6 x 50 m	NFI03/02
P20	C3	< 6 x 50 m	NFI03/03
P30	C3	< 6 x 50 m	NFI03/03

Connection length: Connection between mains filter and device:

unshielded: < 0.5 m
shielded < 5 (fully shielded on ground - e.g. ground of control cabinet)

1.8.1.2 Conditions of utilization for cables / motor filter

Motor and Feedback cable: Operation of the devices only with motor and feedback cables whose plugs contain a special full surface area screening.

Compax3S motor cable < 100 m (the cable should not be rolled up!)
A **motor output filter** (see on page 455) is required for motor cables >20 m:
◆ MDR01/04 (max. 6.3 A rated motor current)
◆ MDR01/01 (max. 16 A rated motor current)
◆ MDR01/02 (max. 30 A rated motor current)

Compax3H motor cable A motor output filter is required for motor cables >50m. Please contact us.

Compax3M motor cable <80m per axis (the cable must not be rolled up!)
The entire length of the motor cable per axis combination may not exceed 300m.
A **motor output filter** (see on page 455) is required for motor cables >20 m:
◆ MDR01/04 (max. 6.3 A rated motor current)
◆ MDR01/01 (max. 16 A rated motor current)
◆ MDR01/02 (max. 30 A rated motor current)

Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.

Feedback cable < 100 m
Compax3S,
Compax3H &
Compax3F:

Compax3M encoder cable: < 80m

Cable für Compax3S, Compax3M Corresponding to the specifications of the terminal clamp with a temperature range of up to 60°C.

Cable für Compax3H Corresponding to the specifications of the terminal clamp with a temperature range of up to 75°C.

Cable installation:

- ◆ Signal lines and power lines should be installed as far apart as possible.
- ◆ Signal lines should never pass close to excessive sources of interference (motors, transformers, contactors etc.).
- ◆ Do not place mains filter output cable parallel to the load cable.

1.8.1.3 Additional conditions of utilization

Motors: Operation with standard motors.

Control: Use only with aligned controller (to avoid control loop oscillation).

Grounding: Connect the filter housing and the device to the cabinet frame, making sure that the contact area is adequate and that the connection has low resistance and low inductance.

Never mount the filter housing and the device on paint-coated surfaces!

Compax3S300V4 For CE and UL conform operation of the Compax3S300V4, a mains filter is compulsory:

- ◆ 400 VAC / 0.740 mH certified in accordance with EN 61558-1 bzw. 61558-2-2
- ◆ We offer the mains filter as an accessory: LIR01/01

Accessories: Make sure to use only the accessories recommended by Parker

Connect all cable shields at both ends, ensuring large contact areas!

Warning:


This is a product in the restricted sales distribution class according to EN 61800-3. In a domestic area this product can cause radio frequency disturbance, in which case the user may be required to implement appropriate remedial measures.

1.8.2. Conditions of utilization for UL certification Compax3S

UL certification for Compax3S

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).



Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ The X2 terminals are not suitable for field wiring.
- ◆ Tightening torque of the field wiring terminals (green Phoenix plugs)
 - ◆ C3S0xxV2 0.57 - 0.79Nm 5 - 7Lb.in
 - ◆ C3S1xxV2, 0.57 - 0.79Nm 5 - 7Lb.in
 - C3S0xxV4, C3S150V4
 - ◆ C3S300V4 1.25 - 1.7Nm 11 - 15Lb.in
- ◆ Temperature rating of field installed conductors shall be at least 60°C. Use copper lines only
Please use the cables described in the **accessories chapter** (see on page 440, see on page 442), they feature a temperature rating of at least 60°C.
- ◆ Maximum Surrounding Air Temperature: 45°C.
- ◆ Motor over temperature monitoring is only supported, if the external temperature sensor is connected.
- ◆ Suitable for use on a circuit capable of delivering at least 5000 symmetrical amperes effectively and 480 Volts when protected with fuses.
Fuses:
In addition to the main fuse, the devices must be equipped with a S201K, S203K, S271K or S273K circuit breaker with K characteristic made by ABB.
 - ◆ C3S025V2: ABB, nom 480V 10A, 6kA
 - ◆ C3S063V2: ABB, nom 480V, 16A, 6kA
 - ◆ C3S100V2: ABB, nom 480V, 16A, 6kA
 - ◆ C3S150V2: ABB, nom 480V, 20A, 6kA
 - ◆ C3S015V4: ABB, nom 480V, 6A, 6kA
 - ◆ C3S038V4: ABB, nom 480V, 10A, 6kA
 - ◆ C3S075V4: ABB, nom 480V, 16A, 6kA
 - ◆ C3S150V4: ABB, nom 480V, 20A, 6kA
 - ◆ C3S300V4: ABB, nom 480V, 25A, 6kA



CAUTION

Risk of electric shock.

Discharge time of the bus capacitor is 10 minutes.

- ◆ The drive provides internal motor overload protection.
This must be set so that 200% of the motor nominal current are not exceeded.
- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 495, see on page 496)
 - ◆ Maximum cross-section limited by the terminals mm² / AWG
 - ◆ C3S0xxV2 2.5mm² AWG 12
 - ◆ C3S1xxV2, 4.0mm² AWG 10
 - C3S0xxV4, C3S150V4
 - ◆ C3S300V4 6.0mm² AWG 7

1.8.3. Conditions of utilization for UL approval Compax3M

UL approval for Compax3M

Conform to UL:	◆ in accordance with UL508C
Certified	◆ E-File_No.: E235342

The UL approval is documented by a "UL" logo on the device (type specification plate).



Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ Tightening torque of the field wiring terminals (green Phoenix plugs)

Device	X43: Motor connector	X15: Temperature monitoring
C3M050-150	0.5Nm (4.43Lb.in)	0.22Nm (1.95Lb.in)
C3M300	1.2Nm (10.62Lb.in)	0.22Nm (1.95Lb.in)

- ◆ Temperature rating of field installed conductors shall be at least 60°C. Use copper lines only
Please use the cables described in the **accessories chapter** (see on page 440, see on page 442), they feature a temperature rating of at least 60°C.
- ◆ Maximum Surrounding Air Temperature: 40°C.
- ◆ Control voltage supply (24VDC) only permissible with "class 2" power supply.
- ◆ Compax3M may only be operated with a mains module of the PSUP series.
- ◆ Motor Over Temperature sensing is not provided by the drive unless the external temperature sensor is connected.



Caution!

Risk of electric shock.

Discharge time of the bus capacitor is 10 minutes.

The drive provides internal motor overload protection.

This must be set so that 200% of the motor nominal current are not exceeded.

- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 495, see on page 496)
- ◆ Maximum cross-section limited by the terminals mm² / AWG

Line cross-sections of the power connections (on the device bottoms)

Compax3 device:	Cross-section: Minimum... Maximum [with conductor sleeve]
M050, M100, M150	0.25 ... 4 mm ² (AWG: 23 ... 11)
M300	0.5 ... 6 mm ² (AWG: 20 ... 10)

1.8.4. Conditions of utilization for UL approval PSUP

UL approval for mains modules PSUP

Conform to UL:	◆ in accordance with UL508C
Certified	◆ E-File_No.: E235342

The UL approval is documented by a "UL" logo on the device (type specification plate).



UL approval PSUP30 in preparation!

Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ Tightening torque of the field wiring terminals (green Phoenix plugs)

Device	X40: Ballast resistor	X41: Mains connector	X9: 24VDC
PSUP10	0.5 Nm (4.43Lb.in)	1.2 Nm (10.62Lb.in)	1.2 Nm (10.62Lb.in)
PSUP20	0.5 Nm (4.43Lb.in)	1.7 Nm (15Lb.in)	1.2 Nm (10.62Lb.in)
PSUP30	UL approval in preparation		

- ◆ Temperature rating of field installed conductors shall be at least 60°C. Use copper lines only
Please use the cables described in the **accessories chapter** (see on page 440, see on page 442), they feature a temperature rating of at least 60°C.
- ◆ Maximum Surrounding Air Temperature: 40°C.
- ◆ Control voltage supply (24VDC) only permissible with "class 2" power supply.
- ◆ Suitable for use on a circuit capable of delivering not more than 5000 rms symmetrical amperes and 480 volts maximum and protected by (see below).
- ◆ The devices need a "branch circuit protection".

PSUP10D6

Maximum fuse rating per device	Measure for line and device protection: MCB miniature circuit breaker (K characteristic) 25A in accordance with UL category DIVQ (ABB) S203UP-K25 (480VAC)
---------------------------------------	---

PSUP20D6

Maximum fuse rating per device 2 special purpose fuses in line are required	Cable protection measure: MCB (K characteristic) with a rating of 50A / 4xxVAC (depending on the input voltage). (ABB) S203U-K50 (440VAC) Device protection measure: Fuses 80A / 700VAC per supply leg in accordance with UL category JFHR2: Bussmann 170M1366 or 170M1566D
--	--



Caution!

Risk of electric shock.
Discharge time of the bus capacitor is 10 minutes.

1.8.5. Conditions of utilization for UL certification Compax3H

UL certification for Compax3H

Conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).

"UL" logo:



Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ Tightening Torque of the Field Wiring Terminals.

Terminal clamps - max. line cross sections

The line cross sections must correspond to the locally valid safety regulations. The local regulations have always priority.

	Power clamps (minimum/maximum section)	
C3H050V4	2.5 / 16mm ²	
	Massive	Multiwire
C3H090V4	16 / 50mm ²	25 / 50mm ²
C3H1xxV4	25 / 95mm ²	35 / 95mm ²

The standard connection clamps of Compax3H090V4 and Compax3H1xxV4 are not suitable for flat line bars.

Temperature rating of field installed conductors shall be at least 75°C. Do only use copper lines.

- ◆ Maximum Surrounding Air Temperature: 45°C.
- ◆ Motor overtemperature monitoring is only supported, if the external temperature sensor is connected.
- ◆ Suitable for use on a circuit capable of delivering not more than 18000A symmetrical amperes effectively when protected with fuses as follows:

Device	Protection data
C3H050V4	480 VAC 80 A
C3H090V4	480 VAC 100 A
C3H125V4	480 VAC 160 A
C3H155V4	480 VAC 200 A

Caution!

Risk of electric shock.

Upon removing power to the equipment, please wait at least 10 minutes before accessing the device to ensure internal voltage levels are less than 50VDC.

- ◆ The drive provides internal motor overload protection.
This must be set so that 200% of the motor nominal current are not exceeded.
- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 495, see on page 496)
 - ◆ This device is provided with Solid State Short Circuit (output) Protection.



1.8.6. Current on the mains PE (leakage current)



Caution!

This product can cause a direct current in the protective lead. If a residual current device (RCD) is used for protection in the event of direct or indirect contact, only a type B (all current sensitive) RCD is permitted on the current supply side of this product. Otherwise, a different protective measure must be taken, such as separation from the environment by doubled or enforced insulation or separation from the mains power supply by means of a transformer.

Please heed the connection instructions of the RCD supplier.

Mains filters do have high leakage currents due to their internal capacity. An internal mains filter is usually integrated into the servo controllers. Additional discharge currents are caused by the capacities of the motor cable and the motor winding. Due to the high clock frequency of the power output stage, the leakage currents do have high-frequency components. Please check if the FI protection switch is suitable for the individual application.

If an external mains filter is used, an additional leakage current will be produced.

The figure of the leakage current depends on the following factors:

- ◆ Length and properties of the motor cable
- ◆ Switching frequency
- ◆ Operation with or without external mains filter
- ◆ Motor cable with or without shield network
- ◆ Motor housing grounding (how and where)

Remark:

- ◆ The leakage current is important with respect to the handling and usage safety of the device.
- ◆ A pulsing leakage current occurs if the supply voltage is switched on.

Please note:


The device must be operated with effective grounding connection, which must comply with the local regulations for high leakage currents (>3.5 mA).

Due to the high leakage currents it is not advisable to operate the servo drive with an earth leakage circuit breaker.


1.8.7. Supply networks

This product is designed for fixed connection to TN networks (TN-C, TN-C-S or TN-S). Please note that the line-earth voltage may not exceed 300VAC.

- ◆ When grounding the neutral conductor, mains voltages of up to 480VAC are permitted.



- ◆ When grounding an external conductor (delta mains, two-phase mains), mains voltages (external conductor voltages) of up to 240VAC are permitted.



Devices which are to be connected to an IT network must be provided with a separating transformer. Then the devices are operated locally as in a TN network. The secondary sided center of the separating transformer must be grounded and connected to the PE connector of the device.

2. IEC 61131-3 - Positioning with function modules based on PLCopen

IEC 61131-3 Programming

Due to its high functionality, Compax3 in the version “IEC 61131-3 - Positioning with function modules based on PLCopen” forms an ideal basis for many applications in high-performance motion automation.

A standard with general applicability was created with Standard IEC 61131-3. The programming system is equipped with a series of functions in addition to the compliant editor. The Motion Control functions specified in PLCopen are also provided by Parker as a library with the device and control software.

The graphical program editor supports the following functions:

- ◆ Ladder diagram
- ◆ Function block diagram (structurally-guided)
- ◆ Function block diagram (free graphical editor)

The text-oriented editor supports programming in

- ◆ Instruction list
- ◆ Structured text

Programming of Compax3 based on IEC 61131-3 is also made considerably easier by a series of additional functions. This includes in particular Syntax Coloring, multi-level undo/redo and context-sensitive input help.

Interfaces with superordinate controllers

Independent of your motion automation you can access Compax3 externally via different interfaces (e.g. with the superordinate control):

- ◆ via RS232 / RS485
- ◆ via digital Inputs/Outputs (Interface I11)
- ◆ via Profibus (Interface I20)
- ◆ via Profinet (Interface I32)
- ◆ via CANopen (Interface I21)
- ◆ via Ethernet Powerlink (interface I30)
- ◆ via EtherCAT (interface I31)

Profibus (I20) & Profinet (I32) functions

The higher-level control system communicates with Compax3 via Profibus or Profinet.

A number of different cyclic transfer telegrams (which can be conveniently adjusted with the Compax3 ServoManager) can be used to adjust bus communication to the requirements of specific applications.

In addition to the cyclic data channel, parameter access is also possible via a DPV1 master or using the parameter channel with a DPV0 master.

- CANopen (I21 - functions)** The higher level control system communicates with Compax3 via CANopen. Via various cyclic process data objects (which can be comfortably set with the Compax3 ServoManager) the bus communication can be adapted to the application requirements. Apart from the cyclic process data objects, acyclic parameter access is possible via service data objects.
- DeviceNet (I22 functions)** The higher level control system communicates with Compax3 via DeviceNet. Cyclic I/O messages (which can be conveniently adjusted with the Compax3 ServoManager) can be used to adjust bus communication to the requirements of specific applications. Besides the cyclic data, acyclic access to objects is possible via Explicit Messages.
- Ethernet Powerlink (I30 functions) / EtherCAT (I31 functions)** The higher level control system communicates with Compax3. Via various cyclic process data objects (which can be comfortably set with the Compax3 ServoManager) the bus communication can be adapted to the application requirements. Apart from the cyclic process data objects, acyclic parameter access is possible via service data objects.
- Compax3 control technology** High-performance control technology and openness for various sender systems are fundamental requirements for a fast and high-quality automation of movement.
- Model / standards / auxiliary material** The structure and size of the device are of considerable importance. High-quality electronics are a fundamental requirement for the particularly small and compact form of the Compax3 devices. All connectors are located on the front of the Compax3S.
- Partly integrated mains filters permit connection of motor cables up to a certain length without requiring additional measures. EMC compatibility is within the limits set by EN 61800-3, Class A. The Compax3 is CE-conform.
- The intuitive user interface familiar from many applications, together with the oscilloscope function, wizards and online help, simplifies making and modifying settings via the PC.
- The optional **Operator control module (BDM01/01)** (see on page 477) for Compax3S/F makes it possible to exchange devices quickly without requiring a PC.



- Configuration** Configuration is made with a PC with the help of the Compax3 ServoManager.

3. Compax3 device description

In this chapter you can read about:

Meaning of the status LEDs - Compax3 axis controller	27
Meaning of the status LEDs - PSUP (mains module)	28
Connections of Compax3S	29
Installation instructions Compax3M	38
PSUP/Compax3M Connections	40
Connections of Compax3H	50
Communication interfaces	58
Signal interfaces	70
Mounting and dimensions	76
Safety function - STO (=safe torque off)	85

3.1 Meaning of the status LEDs - Compax3 axis controller

Device status LEDs	Right LED (red)	Left LED (green)
Voltages missing	off	off
During the booting sequence	alternately flashing	
<ul style="list-style-type: none"> ◆ No configuration present. ◆ SinCos® feedback not detected. ◆ Compax3 IEC61131-3 program not compatible with Compax3 Firmware. ◆ no Compax3 IEC61131-3 program ◆ Hall signals invalid. 	flashes slowly	off
Axis powerless	off	flashes slowly
Power supplied to axis; commutation calibration running	off	flashes quickly
Axis powered	off	on
Axis in error state / error present / axis powered (error reaction 1)	flashes quickly	on
Axis in error state / error present / axis not powered (error reaction 2)	on	off
Compax3 faulty: Please contact us	on	on

Note on Compax3H: The **internal** device status LEDs are only connected to the **external** housing LEDs, if the RS232 jumper at X10 is fitted to the control and the upper dummy cover is fitted.

3.2 Meaning of the status LEDs - PSUP (mains module)

PSUP Status LEDs	Left LED (green)	Right LED (red)
Control voltage 24 VDC is missing	off	off
Error of mains module*	off	on
Address assignment CPU active or incorrect wiring	flashes quickly	-
Address assignment CPU completed	flashes slowly	-
Device state: INIT Mains voltage is missing or built up	flashes	flashes quickly
Device state: ERROR One or multiple errors occurred	flashes	on
Device state: RUN	on	off
Device in bootloader state	flashes slowly	flashes slowly

*can be read out in each axis controller



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.

3.3 Connections of Compax3S

In this chapter you can read about:

Compax3S connectors29
 Connector and pin assignment C3S.....30
 Control voltage 24VDC / enable connector X4 C3S32
 Motor / Motor brake C3S connector X333
 Compax3Sxxx V234
 Compax3Sxxx V436

3.3.1. Compax3S connectors



X1	AC Supply	X20	HEDA in (Option M10, M11)	Option M21 inputs
X2	Ballast / DC power voltage	X21	HEDA out (Option M10, M11)	Option M21 inputs
X3	Motor / Brake	X22	Inputs Outputs (Option M10/12)	
X4	24VDC / Enable	X23/ X24	Bus (Option)	Connector type depends on the bus system!
X10	RS232/RS485	S24	Bus settings	
X11	Analog/Encoder	LED1	Device status LEDs	
X12	Inputs/Outputs	LED2	HEDA LEDs	
X13	Motor position feedback	LED3	Bus LEDs	



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
 Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.



Attention - PE connection!

PE connection with 10mm² via a grounding screw at the bottom of the device.



Attention - hot surface!


The heat dissipater can reach very high temperatures (>70°C)

Line cross sections of the line connections X1, X2, X3

Compax3 device:	Cross-section: Minimum... Maximum[mm ²]
S025V2, S063V2	0.25 ... 2.5 (AWG: 24 ... 12)
S100V2, S150V2 S015V4, S038V4, S075V4, S150V4	0.25 ... 4 (AWG: 24 ... 10)
S300V4	0.5 ... 6 (AWG: 20 ... 7)


3.3.2. Connector and pin assignment C3S

Overview:




Further information on the assignment of the plug mounted at the particular device can be found below!

In detail: The fitting of the different plugs depends on the extension level of Compax3. In part, the assignment depends on the Compax3 option implemented.



The jumper drawn in at X4 (at the left side in red) is used to enable the device for testing purposes. During operation, the enable input is in most cases switched externally.

3.3.3. Control voltage 24VDC / enable connector X4 C3S



PIN	Description
1	+24V (supply)
2	Gnd24V
3	Enable_in
4	Enable_out_a
5	Enable_out_b

Line cross sections:
 minimum: 0.25mm²
 maximum: 2.5mm²
 (AWG: 24 ... 12)

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

Hardware - enable (input X4/3 = 24VDC)

This input is used as safety interrupt for the power output stage.

Tolerance range: 18.0V - 33.6V / 720Ω

"Safe torque off (X4/3=0V)

For implementation of the "safety torque off" safety feature in accordance with the "protection against unexpected start-up" described in EN1037. Observe instructions in the corresponding **chapter** (see on page 85) with the circuitry examples!

The energy supply to the drive is reliably shut off, the motor has no torque. A relay contact is located between X4/4 and X4/5 (normally closed contact)

Enable_out_a - Enable_out_b	Power output stage is
Contact opened	activated
Contact closed	disabled

Series connection of these contacts permits certain determination of whether all drives are de-energized.


Relay contact data:

Switching voltage (AC/DC): 100mV - 60V

Switching current: 10mA - 0.3A

Switching power: 1mW...7W

3.3.4. Motor / Motor brake C3S connector X3




PIN	Designation	Motor cable lead designation*		
		U / L1 / C / L+	1	U1
1	U (motor)	U / L1 / C / L+	1	U1
2	V (motor)	V / L2	2	V2
3	W (motor)	W / L3 / D / L-	3	W3
4	PE (motor)	YE / GN	YE / GN	YE / GN
5	BR+ Motor holding brake	WH	4	Br1
6	BR- Motor holding brake	BK	5	Br2

* depending on the cable type

Requirements for motor cable

< 100m (the cable should not be rolled up!)

A **motor output filter** (see on page 455) is required for motor cables >20 m:



Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.



Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.

Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A

Motor cable

3.3.5. Compax3Sxxx V2

In this chapter you can read about:


Main voltage supply C3S connector X134
 Braking resistor / high voltage DC C3S connector X235

3.3.5.1 Main voltage supply C3S connector X1

Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which will cause a device error.

Therefore please wait at least 2 minutes after switching off before you switch the device on again!



Power supply plug X1 for 1 AC 230VAC/240VAC devices

PIN	Designation
1	L
2	N
3	PE

Mains connection Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Continuous working voltage	Single phase 230VAC/240VAC 80-253VAC / 50-60Hz	
Receiver current consumption	6Arms	13Arms
Maximum fuse rating per device	10 A (automatic circuit breaker K)	16A (automatic circuit breaker K)


* for **UL conform operation** (see on page 20), a miniature circuit breaker, K characteristic, Type S203 is to be used.



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
 Dangerous voltages are still present until 10 min. after switching off the power supply.

Power supply plug X1 for 3AC 230VAC/240VAC devices



PIN	Designation
1	L1
2	L2
3	L3
4	PE

Mains connection Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Supply voltage	Three phase 3* 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	10Arms	13Arms
Maximum fuse rating per device	16A	20A
	MCB miniature circuit breaker, K characteristic	

* for **UL conform operation** (see on page 20), a miniature circuit breaker, K characteristic, Type S203 is to be used.

Caution! The 3AC V2 devices must only be operated with three phases!




Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
 Dangerous voltages are still present until 10 min. after switching off the power supply.

3.3.5.2 Braking resistor / high voltage DC C3S connector X2

The energy generated during braking operation is absorbed by the Compax3 storage capacity.
 If this capacity is too small, the braking energy must be drained via a braking resistor.

Braking resistor / high voltage supply plug X2 for 1AC 230VAC/240VAC devices



PIN	Designation
1	factory use
2	- braking resistor (not short-circuit protected!)
3	PE
4	+ braking resistor (not short-circuit protected!)
5	factory use


Braking operation Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Capacitance / storable energy	560µF / 15Ws	1120µF / 30Ws
Minimum braking- resistance	100Ω	56Ω
Recommended nominal power rating	20 ... 60W	60 ... 180W
Maximum continuous current	8A	15A

Caution!

The power voltage DC of two Compax3 1AC V2 devices (230VAC/240VAC devices) must not be connected.

Braking resistor / high voltage supply plug X2 for 3AC 230VAC/240VAC devices



PIN	Description	
1	+ Braking resistor	no short-circuit protection!
2	- Braking resistor	
3	PE	
4	+ DC high voltage supply	
5	- DC high voltage supply	

Braking operation Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Capacitance / storable energy	780µF / 21Ws	1170µF / 31Ws
Minimum braking- resistance	22Ω	15Ω
Recommended nominal power rating	60 ... 450W	60 ... 600W
Maximum continuous current	20A	20A

Connection of a braking resistor

Minimum line cross section: 1.5mm²
 Maximum line length: 2m
 Maximum output voltage: 400VDC

3.3.6. Compax3Sxxx V4

In this chapter you can read about:


Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices36
 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices37
 Connection of the power voltage of 2 C3S 3AC devices37

3.3.6.1 Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices

Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which will cause a device error.

Therefore please wait at least 2 minutes after switching off before you switch the device on again!



PIN	Designation
1	L1
2	L2
3	L3
4	PE

Mains connection Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Continuous working voltage	Three phase 3*400VAC/480VAC 80-528VAC / 50-60Hz				
Receiver current consumption	3Aeff	6Arms	10Arms	16Arms	22Arms
Maximum fuse rating per device	6A	10A	16A	20A	25A
	MCB miniature circuit breaker, K characteristic				D*

* for UL conform operation (see on page 20), a miniature circuit breaker, K characteristic, Type S203 is to be used.

Caution!




The 3AC V4 devices must only be operated with three phases!

Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
 Dangerous voltages are still present until 10 min. after switching off the power supply.

3.3.6.2 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices



PIN	Description	
1	+ Braking resistor	no short-circuit protection!
2	- Braking resistor	
3	PE	
4	+ DC high voltage supply	
5	- DC high voltage supply	

Braking operation Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Capacity / storable energy 400V / 480V	235µF 37 / 21 Ws	235µF 37 / 21 Ws	470µF 75 / 42 Ws	690µF 110 / 61 Ws	1230µF 176 / 98 Ws
Minimum ballast - resistance	100 Ω	100 Ω	56 Ω	47 Ω	15 Ω
Recommended nominal power rating	60 ... 100W	60 ... 250W	60 ... 500 W	60 ... 1000 W	60 ... 1000 W
Maximum continuous current	10A	10A	15A	20A	30A

Connection of a braking resistor

Minimum line cross section: 1.5 mm²
 Maximum line length: 2 m
 Maximum output voltage: 800 VDC

3.3.6.3 Connection of the power voltage of 2 C3S 3AC devices

Caution!

The power voltage DC of the single phase Compax3 servo axes must not be connected!

In order to improve the conditions during brake operation, the DC power voltage of 2 servo axes may be connected.
 The capacity as well as the storable energy are increased; furthermore the braking energy of one servo axis may be utilized by a second servo axis, depending on the application.



It is not permitted to connect the power voltage in order to use one brake circuit for two servo axes, as this function cannot be ensured reliably.

Note the following:

Caution! In case of non-compliance with the following instructions, the device may be destroyed!

- ◆ You can only connect two similar servo axes (same power supply; same rated currents)
- ◆ Connected servo axes must always be fed separately via the AC power supply. If the external pre-fuse of one of the servo axes takes action, the second servo axis must also be disconnected automatically.

Please connect as follows:

Servo axis 1 X2/4 to servo axis 2 X2/4
 Servo axis 1 X2/5 to servo axis 2 X2/5

3.4 Installation instructions Compax3M

General introductory notes

- ◆ Operation of the Compax3M multi-axis combination is only possible in connection with a PSUP (mains module).
- ◆ Axis controllers are aligned at the right of the mains module.
- ◆ Arrangement within the multi-axis combination sorted by power (with the same device types according to device utilization), the axis controller with the highest power is placed directly at the right of the mains module.
e.g. first the device type with high utilization, at the right of this, the same device type with a lower utilization.
- ◆ Max. 15 Compax3M (axis controllers) per PSUP (mains module) are permitted (please respect the total capacity of max. 2400 μ F for PSUP10, max. 5000 μ F for PSUP20).
- ◆ The continuation of the current rail connection outside the axis combination is not permitted and will lead to a loss of the CE and UL approbation.
- ◆ External components **may not** be connected to the rail system.

Required tools:

- ◆ Allen key M5 for fixing the devices in the control cabinet.
- ◆ Crosstip screwdriver M4 for connection rails of the DC rail modules.
- ◆ Crosstip screwdriver M5 for grounding screw of the device.
- ◆ Flat-bladed screwdriver 0.4x2.5 / 0.6x3.5 / 1.0x4.0 for wiring and mounting of the phoenix clamps.

Order of installation

- ◆ Fixing the devices in the control cabinet.
 - ◆ Predrilling the mounting plate in the control cabinet according to the specifications. Dimensions. Fit M5 screws loosely in the bores.
 - ◆ Fit device on the upper screws and place on lower screw. Tighten screws of all devices. The tightening torque depends on the screw type (e.g. 5.9Nm for M5 screw DIN 912 8.8).
- ◆ Connection of the internal supply voltage.

The Compax3M axis controllers are connected to the supply voltages via the rail modules. **Details** (see on page 42).

 - ◆ Deblocking the yellow protective cover with a flat-bladed screwdriver on the upper surface (click mechanism). Remove the closing devices (contact protection) that are not required from between the devices.
 - ◆ Connecting the rail modules, beginning with the mains module.

For this, loosen crosshead screws (5 screws at the right in the mains module, all 10 screws in the next axis controller), push the rails one after the other against to the left and tighten screws. Proceed accordingly for all adjacent axis controllers in the combination.

Max. tightening torque: 1.5Nm.
 - ◆ Close all protective covers. The protective covers must latch audibly.

Please note:

Insufficiently fixed screw connections of the DC power voltage rails may lead to the destruction of the devices.

Protective seals



Caution - Risk of Electric Shock!

In order to secure the contact protection against the alive rails, it is absolutely necessary to respect the following:

- ◆ Insert the yellow plastic comb at the left or right of the rails.


Make sure that the yellow plastic combs are placed at the left of the first device and at the right of the last device in the system and have not been removed.
- ◆ Setup of the devices only with closed protective covers.
- ◆ Connect protective earth to mains module (M5 crosshead screw on front of device bottom).
- ◆ Connecting the internal communication. **Details** (see on page 59).
- ◆ Connecting the signal and fieldbus connectors. **Details** (see on page 70).
- ◆ Connection of mains power supply **Details** (see on page 44) ballast resistor **details** (see on page 46) and motor **details** (see on page 48).
- ◆ Connecting the configuration interface to the PC. **Details** (see on page 59).

3.5 PSUP/Compax3M Connections

In this chapter you can read about:

Front connector40
 Connections on the device bottom41
 Connections of the axis combination.....42
 Control voltage 24VDC PSUP (mains module)43
 Mains supply PSUP (mains module) X41.....44
 Braking resistor / temperature switch PSUP (mains module)46
 Motor / motor brake Compax3M (axis controller)48
 X14 Safety technology option S1 for Compax3M (axis controller)49
 Safety technology option S3 for Compax3M (axis controller)49

3.5.1. Front connector



P	
	PSUP Mains module
LED1	Status LEDs Mains module
S1	Basic address
X3	Configuration interface (USB)
X9	Supply voltage 24VDC
M	
	Axis controller
LED2	Status LEDs of the axis
S10	Function
X11	Analog/Encoder
X12	Inputs/Outputs
X13	Motor position feedback
X14	Safety technology (Option S1) (replaced by X28 with Option S3)
X15	Motor temperature monitoring
LED3	HEDA LEDs
X20	HEDA in (Option)
X21	HEDA out (Option)
X22	Inputs Outputs (Option M10/12)
X23	Bus (option) connector type depends on the bus system!
X24	Bus (option) depends on the bus system!
LED4	Bus LEDs
S24	Bus settings
1	Behind the yellow protective covers you can find the rails for the supply voltage connection. ♦ Supply voltage 24VDC ♦ DC power voltage supply

3.5.2. Connections on the device bottom



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.




Attention - PE connection!

PE connection with 10mm² via a grounding screw at the bottom of the device.



Attention - hot surface!

The heat dissipater can reach very high temperatures (>70°C)



P		Mains module PSUP
X40		Ballast resistor
X41		Mains supply VAC/PE
1		Central ground connection for the axis system, with 10mm ² to the ground screw on the housing.
4		Fan*
M		Axis controller
X43		Motor / Brake
2		Fixing for motor shield clamp
4		Fan*
3		optionally, the axis controller features a ground screw on the housing, if the grounding is not possible via the back plate.

* is internally supplied.

Line cross-sections of the power connections (on the device bottoms)

Compax3 device:	Cross-section: Minimum... Maximum [with conductor sleeve]
M050, M100, M150	0.25 ... 4 mm ² (AWG: 23 ... 11)
M300	0.5 ... 6 mm ² (AWG: 20 ... 10)
PSUP10	Mains supply: 0.5 ... 6 mm ² (AWG: 20 ... 10) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)
PSUP20 & PSUP30	Mains supply: 0.5 ... 16 mm ² (AWG: 20 ... 6) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)

3.5.3. Connections of the axis combination

The axis controllers are connected to the supply voltages via rails.

- ◆ Supply voltage 24VDC
- ◆ DC power voltage supply

The rails can be found behind the yellow protective covers. In order to connect the rails of the devices, you may have to remove the yellow plastic device inserted at the side.

CAUTION: Risk of Electric Shock



Caution - Risk of Electric Shock!

Please note before opening:

- ◆ **Warning** - Possible risk of electric shock; disconnect power before removing cover.
- ◆ **Caution!** - Dangerous electric voltage! Respect discharge time.



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.


Protective seals



Caution - Risk of Electric Shock!

In order to secure the contact protection against the alive rails, it is absolutely necessary to respect the following:

- ◆ Insert the yellow plastic comb at the left or right of the rails.
Make sure that the yellow plastic combs are placed at the left of the first device and at the right of the last device in the system and have not been removed.
- ◆ Setup of the devices only with closed protective covers.



- | | |
|---|--------|
| 1 | 24VDC |
| 2 | GND24V |
| 3 | -HV DC |
| 4 | PE |
| 5 | +HV DC |

Note: External components **may not** be connected to the rail system.

Maximum capacity in the axis system:

- ◆ PSUP10: 2400 µF
- ◆ PSUP20 & PSUP30: 5000 µF

Reference value for the required capacity in an axis system

100 µF per kW of the temporal medium value of the total power (transmissions + power dissipation) in the axis system.

Example: PSUP20 (1175 µF) with one axis controller (440 µF)

Total power 15 kW, 100 µF/kW => 1500 µF required in the axis system.
Axis system: 1615 µF are sufficient.

Protective seals




Caution!

The user is responsible for protective covers and/or additional safety measures in order to prevent damages to persons and electric accidents.

3.5.4. Control voltage 24VDC PSUP (mains module)

Connector X9



Pin	Designation
1	+24 V
2	GND24V

Line cross sections:
minimum: 0.5mm² with conductor sleeve
maximum: 6mm² with conductor sleeve
(AWG: 20 ... 10)

Control voltage 24 VDC PSUP

Device type	PSUP
Voltage range	21 - 27VDC
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes (class 2 mains module)
Current drain PSUP	PSUP10: 0.2A PSUP20 / PSUP30: 0.3A
Electric current drain Compax3M	C3M050D6: 0.85 3M100D6: 0.85A C3M150D6: 0.85A C3M300D6: 1.0 A + Total load of the digital outputs + current for the motor holding brake

3.5.5. Mains supply PSUP (mains module) X41


Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which may cause damage to the device.

Wait at least one minute between two switching on processes!

Operation of the PSUP30 only with mains filter!

Connector X41



Pin	Designation
PE	Earth conductor
L3	Phase 3
L2	Phase 2
L1	Phase 1

Mains connection PSUP10D6

Device type PSUP10	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	22Arms	22Arms	18Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	6kW	10 kW	10 kW
Pulse power (<5s)	12kW	20kW	20kW
Heat dissipation	60W	60W	60W
Maximum fuse rating per device	Measure for line and device protection: MCB miniature circuit breaker (K characteristic) 25A in accordance with UL category DIVQ Recommendation: (ABB) S203UP-K25 (480VAC)		

Mains connection PSUP20D6

Device type PSUP20	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	44Arms	44Arms	35Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	12kW	20kW	20kW
Pulse power (<5s)	24kW	40kW	40kW
Heat dissipation	120W	120W	120W
Maximum fuse rating per device 2 special purpose fuses in line are required	Cable protection measure: MCB (K characteristic) with a rating of 50A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K50 (440VAC) Device protection measure: Circuit breakers 80A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1366 or 170M1566D		

PSUP30D6 Mains connection

Device type PSUP30	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	50Arms	50Arms	42Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	17kW	30kW	30kW
Pulse power (<5s)	34kW	60kW	60kW
Heat dissipation	140W	140W	140W
Maximum fuse rating per device 2 special purpose fuses in line are required	Cable protection measure: MCB (K characteristic) with a rating of 63A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K63 (440VAC) Device protection measure: Circuit breakers 125A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1368 or 170M1568D		

Caution!

Only three-phase operation of the PSUP devices is permitted!


The PSUP30 mains module may only be operated with mains filter (see on page 457)

Required mains filter for the PSUP30: 0.45 mH / 55 A


We offer the following mains filters:

- ◆ LCG-0055-0.45 mH (WxDxH: 180 mm x 140 mm x 157 mm; 10 kg)
- ◆ LCG-0055-0.45 mH-UL (with UL approval) (WxDxH: 180 mm x 170 mm x 157 mm; 15 kg)

Dimensional drawing: LCG-0055-0.45 mH



Dimensional drawing: LCG-0055-0.45 mH-UL




Caution - Risk of Electric Shock!

Always switch devices off before wiring them!
 Dangerous voltages are still present until 10 min. after switching off the power supply.

3.5.6. Braking resistor / temperature switch PSUP (mains module)

The energy generated during braking operation must be dissipated via a braking resistor.

Connector X40



Pin	Description	
+R	+ Braking resistor	short-circuit proof!
-R	- Braking resistor	
PE	PE	
T1R	Temperature Switch	
T2R	Temperature Switch	

Braking operation PSUPxxD6 (mains module)

Device type	PSUP10	PSUP20	PSUP30
Capacitance / storable energy	550 µF/ 92 Ws at 400 V 53 Ws at 480 V	1175 µF/ 197 Ws at 400 V 114 Ws at 480 V	1175 µF/ 197 Ws at 400 V 114 Ws at 480 V
Minimum braking-resistance	27 Ω	15 Ω	10 Ω
Recommended nominal power rating	500 ... 1500 W	500 ... 3500 W	500 ... 5000 W
Pulse power rating for 1s	22 kW	40 kW	60 kW
Maximum permissible continuous current	13 A	15 A	15 A

Maximum capacity in the axis system:

- ◆ PSUP10: 2400 µF
- ◆ PSUP20 & PSUP30: 5000 µF

Reference value for the required capacity in an axis system

100 µF per kW of the temporal medium value of the total power (transmissions + power dissipation) in the axis system.

Example: PSUP20 (1175 µF) with one axis controller (440 µF)

Total power 15 kW, 100 µF/kW => 1500 µF required in the axis system.
Axis system: 1615 µF are sufficient.

Connection of a braking resistor on PSUP (mains module)

Minimum line cross section: 1.5 mm²
Maximum line length: 2 m
Maximum intermediate circuit voltage: 810 VDC
Switch-on threshold: 780 VDC
Hysteresis 20 VDC

Braking operation Compax3MxxxD6 (axis controller)

Device type Compax3	M050	M100	M150	M300
Capacity/ storable energy	110µF/ 18Ws at 400V 10Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	440µF/ 74Ws at 400V 42Ws at 480V

3.5.6.1 Temperature switch PSUP (mains module)**Connector X40 Pin T1R, T2R****Temperature monitoring:**

The temperature switch (normally closed contact) must be connected, unless an error message will be issued.

Temperature switch/relay

No galvanic separation, the temperature sensor (normally closed contact) must comply with the safe separation according to EN 60664.

If there is no temperature monitoring due to the connected braking resistor, the T1R and T2R connections must be connected by a jumper.

**Caution!**

Without temperature monitoring, the braking resistor might be destroyed.

3.5.7. Motor / motor brake Compax3M (axis controller)

Connector X43



Compax3M motor cable

PIN	Designation	Motor cable lead designation*		
BR-	Motor holding brake *	BK	5	Br2
BR+	Motor holding brake *	WH	4	Br1
PE	PE (motor)	YE / GN	YE / GN	YE / GN
W	W (motor)	W / L3 / D / L-	3	U3
V	V (motor)	V / L2	2	U2
U	U (motor)	U / L1 / C / L+	1	U1

* depending on the cable type

<80m per axis (the cable must not be rolled up!)


The entire length of the motor cable per axis combination may not exceed 300m. A **motor output filter** (see on page 455) is required for motor cables >20 m:

- ◆MDR01/04 (max. 6.3 A rated motor current)
- ◆MDR01/01 (max. 16 A rated motor current)
- ◆MDR01/02 (max. 30 A rated motor current)

Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.



Motor cables can be found in the accessories chapter of the device description.

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A



Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.

Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.

3.5.7.1 Measurement of the motor temperature of Compax3M (axis controller)

Connector X15

The acquisition of the motor temperature by the axis controller can either take place via the connection of X15 (Tmot) or via the feedback cable and the corresponding connection on X13 PIN10.



Pin	Description
1	+5V
2	Sensor

The temperature acquisition on X15 Tmot can not be connected at the same time as X13 Pin 10.

3.5.8. X14 Safety technology option S1 for Compax3M (axis controller)

Connector X14 (Not available with Safety option S3)



Pin	Description	
1	STO1/	+24VDC
2	STO-GND	GND
3	STO2/	+24VDC
4	STO-GND	GND

NOTICE

Note!

If the Compax3M axis controller features a safety option, these connections must also be wired, otherwise it is not possible to set up the axis.

3.5.9. Safety technology option S3 for Compax3M (axis controller)

For a description of the S3 safety option, please refer to the following manuals:

- ◆ 192-120210 Installation Manual Safety Option S3 for Compax3M
- ◆ 192-120211 Programming Manual Safety Option S3 for Compax3M
- ◆ 192-120212 Description of the Standard I/O Profile R0110001xx for Option S3 (Compax3M)

These manuals can be found on the Compax3 DVD in the ""Safety_Option_S3"" folder.


3.6 Connections of Compax3H

In this chapter you can read about:

Compax3H plugs/connections	50
Connection of the power voltage.....	51
Compax3H connections front plate	52
Plug and pin assignment C3H	53
Motor / Motor brake C3H	55
Control voltage 24 VDC C3H	56
Mains connection Compax3H	56
Braking resistor / supply voltage C3H	57

3.6.1. Compax3H plugs/connections

The following figure is an example for all sizes.
 The fitting of the different controller plugs depends on the extension level of Compax3.



- (1): Dummy cover with display of the external device status LEDs.
- (2): lower clamp cover, fixed by 2 screws at the device bottom.
- (3): RS232 programming interface
 Connection to the PC via adapter cable SSK32/20 (furnished with the device) and standard RS232 cable SSK1.
- (4): Control
- (5): Power connections



Always switch devices off before wiring them!

Dangerous voltages are still present until 5 minutes after switching off the power supply!



Caution!

If the control voltage is missing and if the X10-X10 jumper is not fitted (VBK17/01) on the control part, the availability of power voltage is not displayed.



PE connection
 PE connection with 10mm² via a grounding screw at the bottom of the device.




Attention hot surface!
 Metal parts can heat up to a temperature of 90°C during operation.

3.6.2. Connection of the power voltage

The terminal block of the drive can be found under the front cover. It is secured with 2 screws at the bottom of the device. Remove the bottom cover in order to access the connection clamps.
 Make sure that all live parts are covered by the housing after installation.

Illustration of the connection clamps exemplarily for all sizes:



- L1, L2, L3: 3 phase mains connection
 - M1, M2, M3: Motor connections
 - DC+, DC-: DC link voltage
 - (1) DBR+ and DBR-: Connection of external braking resistor
 - (2) AUX1, AUX2: only with C3H1xxV4 external supply (AC) for device ventilator L, N
 - ◆ All shields must be connected via a cable joint to the cable feed through plate.
 - ◆ Braking resistor and cable must be shielded if they are not installed in a control cabinet.
 - ◆ The standard connection clamps of C3H090V4 and C3H1xxV4 are **not** suitable for flat line bars.
- Attention: The MOT/TEMP connection is not supported by the Compax3H050; do therefore not wire this connection!

Terminal clamps - max. line cross sections

The line cross sections must correspond to the locally valid safety regulations. The local regulations have always priority.

	Power clamps (minimum/maximum section)	
C3H050V4	2.5 / 16mm ²	
	Massive	Multiwire
C3H090V4	16 / 50mm ²	25 / 50mm ²
C3H1xxV4	25 / 95mm ²	35 / 95mm ²

The standard connection clamps of Compax3H090V4 and Compax3H1xxV4 are not suitable for flat line bars.

Cover plate for cable feed through

The cable feed through holes have the following dimensions:


C3H050V4	28.6mm for M20, PG16 and 1/2" NPT (America). 37.3mm for M32, PG29 and 1" NPT (America).
C3H090V4	22.8mm for M20, PG16 and 1/2" NPT (America). 28.6mm for M25, PG21 and 3/4" NPT (America). 47.3mm for M40, PG36 and 1 1/4" NPT (America). 54.3mm for M50, PG42 and 1 1/2" NPT (America).
C3H1xxV4	22.8mm for M20, PG16 and 1/2" NPT (America) 28.6mm for M25, PG21 and 3/4" NPT (America)

Recommended tightening torques

	High voltage supply	Ballast resistor	Grounding
C3H050V4	4Nm / 35lb-in	4Nm / 35lb-in	4.5Nm / 40lb-in
C3H090V4	6-8Nm / 53-70lb-in	6-8Nm / 53-70lb-in	6-8Nm / 53-70lb-in
C3H1xxV4	15-20Nm / 132-177lb-in	0.7Nm / 6.1lb-in	42Nm / 375lb-in

cable glands

Use metallic cable joints permitting a 360° shielding in order to comply with the EMC directive.



- 1: Cable feed through plate
- 2: metallic joint with 360° shielding for EMC compliant design

The device must be grounded without interruption according to EN 61800-5-1. The mains supply lines must be protected with a suitable fuse or a circuit breaker (FI switches or earth fault fuses are not recommended).


For installation in accordance with EN 61800-5-1 mm Europe:

- ◆ For grounding without interruption, two separate protective leads (² cross-section) or one lead (>10mm² cross-section) are required. Each protective lead must meet the requirements according to EN 60204.

3.6.3. Compax3H connections front plate

Communication and signal interfaces

Showcase front plate of the control (number of connectors depends on the extension level of the Compax3)




X3	Motor brake	X20	HEDA in (Option)
X4	24VDC	X21	HEDA out (Option)
X10	RS232/RS485 with jumper to the programming interface	X22	Inputs Outputs (Option M10/12)
X11	Analog/Encoder	X23	Bus (Option) Connector type depends on the bus system!
X12	Inputs/Outputs	S24	Bus settings
X13	Motor position feedback	LED1	Device status LEDs
		LED2	HEDA LEDs
		LED3	Bus LEDs

Note on Compax3H: The **internal** device status LEDs are only connected to the **external** housing LEDs, if the RS232 jumper at X10 is fitted to the control and the upper dummy cover is fitted.
 The RS232 programming interface under the upper dummy cover is only available if the X10 jumper at the controller is fitted.


3.6.4. Plug and pin assignment C3H

Overview



Further information on the assignment of the plug mounted at the particular device can be found below!

In detail: The fitting of the different plugs depends on the extension level of Compax3. In part, the assignment depends on the Compax3 option implemented.



The RS232 programming interface under the upper dummy cover is only available if the X10 jumper at the controller is fitted.

Please note

C3H1xxV4 uses a ventilator fan which must be externally supplied via separate connections. The ventilator fan is available in two versions for single phase feed: 220/240VAC; 110/120VAC

3.6.5. Motor / Motor brake C3H

Compax3H motor cable

A motor output filter is required for motor cables >50m. Please contact us.

Shielding connection of the motor cable

The motor cable should be fully shielded and connected to the Compax3 housing.

The shield of the motor cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type. Motor connection clamps figure (see on page 51)

PIN	Designation	Motor cable lead designation*		
M1/U	U (motor)	U / L1 / C / L+	1	U1
M2/V	V (motor)	V / L2	2	U2
M3/W	W (motor)	W / L3 / D / L-	3	U3
PE	PE (motor)	YE / GN	YE / GN	YE / GN

* depending on the cable type

Compax3H motor cable

A motor output filter is required for motor cables >50m. Please contact us.

Shielding connection of the motor cable

The motor cable should be fully shielded and connected to the Compax3 housing. The shield of the motor cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.




Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.

Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.



Connection of motor brake X3 figure (see on page 52)

PIN	Designation	Motor cable lead designation*		
1	BR	WH	4	Br1
2	GND	BK	5	Br2

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A

3.6.6. Control voltage 24 VDC C3H



Connection of control voltage 24VDC figure (see on page 52)

Connector X4 Pin	Description	
1	NC	NC
2	GND24V	GND
3	+24 V	24 VDC (power supply)

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

3.6.7. Mains connection Compax3H

Device protection

Avoid permanent switching on and off so that the charging connection is not overloaded. Therefore wait at least 1 minute before switching on the device again.

Connection of mains voltage figure (see on page 51)

Mains connection Compax3HxxxV4 3*400VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Continuous working voltage	Three-phase 3*400VAC 350-528VAC / 50-60Hz			
Receiver current consumption	66Arms	95Arms	143Arms	164Arms
Output current	50Arms	90Arms	125Arms	155Arms
Maximum input fuse rating per device	80A	100A	160A	200A
Recommended line protection in accordance with UL	JDDZ Class K5 or H JDRX Class H			

Mains connection Compax3HxxxV4 3*480VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Continuous working voltage	Three-phase 3*480VAC 350-528VAC / 50-60Hz			
Receiver current consumption	54Arms	82Arms	118Arms	140Arms
Output current	43Arms	85Arms	110Arms	132Arms
Maximum input fuse rating per device	80A	100A	160A	200A
Recommended line protection in accordance with UL	JDDZ Class K5 or H JDRX Class H			

3.6.8. Braking resistor / supply voltage C3H

The energy generated during braking operation is absorbed by the Compax3 storage capacity.
If this capacity is too small, the braking energy must be drained via a braking resistor.

3.6.8.1 Connect braking resistor C3H

Connection of braking resistor figure (see on page 51)

PIN	Designation
DBR+	+ Braking resistor
DBR-	- Braking resistor

Braking operation of Compax3HxxxV4

Controller type	H050V4	H090V4	H125V4	H155V4
Capacitance / storable energy 400V / 480V	2600 μ F 602 / 419 Ws	3150 μ F 729 / 507 Ws	5000 μ F 1158 / 806 Ws	5000 μ F 1158 / 806 Ws
Minimum braking- resistance	24 Ω	15 Ω	8 Ω	8 Ω
Maximum continuous current	11 A	17 A	31 A	31 A

Minimum line cross section: 2.5mm²
Maximum line length: 2m
Maximum output voltage: 830VDC

3.6.8.2 Power supply voltage DC C3H

Connection of power voltage DC -figure (see on page 51)

PIN	Description
DC+	+ DC high voltage supply
DC-	- DC high voltage supply



Warning!

Do not connect any braking resistor on DC+/DC- .

3.6.8.3 Connection of the power voltage of 2 C3H 3AC devices

In order to improve the conditions during brake operation, the DC power voltage of 2 servo axes may be connected.

The capacity as well as the storable energy are increased; furthermore the braking energy of one servo axis may be utilized by a second servo axis, depending on the application.



It is not permitted to connect the power voltage in order to use one brake circuit for two servo axes, as this function cannot be ensured reliably.

Note the following:

Caution! In case of non-compliance with the following instructions, the device may be destroyed!

- ◆ You can only connect two similar servo axes (same power supply; same rated currents)
- ◆ Connected servo axes must always be fed separately via the AC power supply.
- ◆ If the external pre-fuse of one of the servo axes takes action, the second servo axis must also be disconnected automatically.

Please connect as follows:

Servo axis 1 DC+ with servo axis 2 DC+

Servo axis 1 DC- with servo axis 2 DC-


- figure (see on page 51)

3.7 Communication interfaces

In this chapter you can read about:

RS232 / RS485 interface (plug X10).....58
 Communication Compax3M.....59
 Profibus connector X23 on Interface I2061
 Profinet connector X23, X24 on Interface I32.....61
 CANopen connector X23 Interface I21.....64
 DeviceNet Stecker X23.....66
 Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X2467

3.7.1. RS232 / RS485 interface (plug X10)



Interface selectable by contact functions assignment of X10/1:

X10/1=0V RS232

X10/1=5V RS485

PIN X10	RS232 (Sub D)
1	(Enable RS232) 0V
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	+5V
PIN X10	RS485 two wire (Sub D) Pin 1 and 9 jumpered externally
1	Enable RS485 (+5V)
2	res.
3	TxD_RxD/
4	res.
5	GND
6	res.
7	TxD_RxD
8	res.
9	+5V
PIN X10	RS485 four wire (Sub D) Pin 1 and 9 externally jumpered
1	Enable RS485 (+5V)
2	RxD
3	TxD/
4	res.
5	GND
6	res.
7	TxD
8	RxD/
9	+5V

USB - RS232/RS485 converter

The following USB - RS232 converters were tested:

- ◆ ATEN UC 232A
- ◆ USB GMUS-03 (available under several company names)
- ◆ USB / RS485: **Moxa Uport 1130**
http://www.moxa.com/product/UPort_1130_1130I.htm
- ◆ Ethernet/RS232/RS485: **NetCom 113** <http://www.vscom.de/666.htm>
- ◆ Exsys Adapter USB to RS232 with FTDI processor (Windows 7)


3.7.2. Communication Compax3M

In this chapter you can read about:

PC - PSUP (Mains module)59
 Communication in the axis combination (connector X30, X31).....59
 Adjusting the basic address60
 Setting the axis function.....60

3.7.2.1 PC - PSUP (Mains module)

Connector X3



USB2.0


Connect your PC to the USB sleeve X3 of the mains module via an USB cable (SSK33/03).

3.7.2.2 Communication in the axis combination (connector X30, X31)

The communication in the axis combination is implemented via a SSK28 cable and double RJ45 sleeves on the device top.

Beginning with the PSUP (mains module) the connection is always made from X30 to X31 of the next device. On the first device (X31) and the last device (X30) in the multi-axis combination, a bus termination plug (**BUS07/01** (see on page 487)) is required.

Orientation to the back side



Orientation to the front plate

PSUP (Mains module)	
X30	out
X31	in
res.	factory use
Compax3M (axis)	
X30	out
X31	in
res.	factory use

3.7.2.3 Adjusting the basic address

On the mains module, the basic address of the device combination is set in steps of 16 with the aid of the first three dip switches.

The mains module contains the set basic address while the axes placed at the right in the combination contain the following addresses.

Switch S1



Address setting

Basic addresses

Switch	Value upon ON
1	16
2	32
3	64

Settings:

left: OFF

right: ON

Settable value range: 0, 16, 32, 48, 64, 80, 96, 112

Address of the 1st axis = basic address+1

The addresses of the axis controllers are newly assigned after PowerOn.

Example:

Basic address = 48; mains module with 6 axis controllers in the combination

1. Axis right: Address = 49


2. Axis right: Address = 50

...

6. Axis right: Address = 54

3.7.2.4 Setting the axis function

Switch S10




Function settings for T30 and T40

The value of switch S10 on the axis controller is stored in object O110.1

C3plus.Switch_DeviceFunction and can be evaluated with the aid of a program.

This helps realize a more simple function selection.

3.7.3. Profibus connector X23 on Interface I20



Pin X23	Profibus (Sub D)
1	factory use
2	factory use
3	Data line B
4	RTS
5	GND
6	+5V
7	factory use
8	Data line A
9	factory use

The assignment corresponds to Profibus standard EN 50170.
Wiring (see on page 490).

3.7.3.1 Adjusting the bus address (Profibus I20)

Address setting

Values:

1: 2⁰; 2: 2¹; 3: 2²; ... 7: 2⁶; 8: reserved

Settings:


left: OFF

right: ON

(The address is set to 0 in the illustration to the left)

Range of values: 1 ...127

Address 0 is set internally to address 126.




3.7.3.2 Function of the Bus LEDs (Profibus I20)

Function of the LEDs (under X23)

Green LED (left)	Red LED (right)	Description
alternately flashing		Field bus program missing
off	flashing	Device is not initialized
on	flashing	Bus operation mode (no DATA exchange)
on	off	Bus operation mode (DATA exchange)
on	on	Bus error

3.7.4. Profinet connector X23, X24 on Interface I32




	RJ45 (X23)	RJ45 (X24)
Pin	in	out
1	Tx +	Tx +
2	Tx -	Tx -
3	Rx +	Rx +
4	-	factory use
5	-	factory use
6	Rx -	Rx -
7	-	factory use
8	-	factory use

Wiring with Ethernet Crossover cable Cat5e (from X24 to X23 of the next device without termination); for this, we offer our **SSK28** (see on page 444, see on page 483) interface cable.

3.7.4.1 Adjusting the bus address (Profinet I32)

With Profinet, the bus nodes are identified by name. This name is assigned during setup with the aid of a configuration tool (Engineering Tool). In order to identify each device during this phase, a blinking check can be used. The Profinet node currently worked on in the configuration tool is made to identify itself optically (see LED description // C3 xxx LED flashes green). With the aid of the address switch, it is possible to allocate a non-ambiguous name to each Compax3 in a network, without using a configuration tool.



Address setting

Settings:

left: OFF
right: ON

Address switch	Device name used
0	The device name used is the name assigned with the aid of the configuration tool. (standard settings)
1	Device name - "compax3-001"
...	
255	Device name - "compax3-255"

3.7.4.2 Function of the Bus LEDs (Profinet I32)

Function of the LEDs

LED2 (left)	LED1 (right)	Description
flashing green	-	Bus operation mode (no DATA exchange)
illuminated green	-	Bus operation mode (DATA exchange)
	flashing green	The blinking check in the PROFINET-IO-Controller projecting was activated in order to locate the node optically.
	illuminated red	Communication Error (Data exchange terminated).
illuminated green	flashing red	Faulty Profinet configuration (PPO C3 <> PPO Master)
flashing red	flashing red	<ul style="list-style-type: none"> ◆ Troubleshoot if: <ul style="list-style-type: none"> ◆ Address switch S24 = 0: Set S24 to unequal to zero and switch devices off/on ◆ Set address switch S24 = 255: Object 860.3 (IpAdr) to the desired IP address, then write flash, then switch device off/on
Alternately flashing red		Fieldbus Interface in the boot loader mode (no valid Firmware available).
Alternately flashing red/green		Firmware is written into the FLASH during the firmware update (caution, do not switch off device).

3.7.5. CANopen connector X23 Interface I21




Pin X23	CANopen (Sub D)	
1	factory use	
2	CAN_L	CAN Low
3	GNDfb	Opto-isolated GND-supply
4	factory use	
5	SHIELD	Shield optional
6	factory use	
7	CAN_H	CAN High
8	factory use	
9	factory use	

The assignment corresponds to CANopen DS301.

At the beginning and end of the device chain a terminating resistor of 120Ω is required between CAN_L and CAN_H

Wiring (see on page 491).

3.7.5.1 Setting baud rate and Node-ID



Proceeding:

- ◆ Switch off 24VDC
- ◆ Switch 8 must be set to ON
- ◆ Set **Baud rate** with switches 1...7:
 - 0:= 20kbit/s
 - 1:= 50kbit/s
 - 2:= 100kbit/s
 - 3:= 125kbit/s
 - 4:= 250kbit/s
 - 5:= 500kbit/s
 - 6:= 800kbit/s
 - 7...127:= 1Mbit/s
- ◆ switch on 24VDC and wait until both LEDs above the DIP switch are blinking simultaneously
- ◆ With switch 1...7 **set Node ID**:
 - Values: **1**: 2⁰; **2**: 2¹; **3**: 2²; ... **7**: 2⁶;
 - value range: 1 ...127
- ◆ **Switch 8**: = OFF
- ◆ Compax3 is now ready to operate

Position of the switch

left: OFF
right: ON

Note:

The baud rate can also be set in the C3 ServoManager. After switching on, the last setting made is valid!

3.7.5.2 Function of the Bus LEDs

LED red


No.	Signal	Status	Description
1	off	No Error	The bus is operating
2	Single flash	Warning	At least one of the error counters of the CAN controller has reached the warning level. Cannot send Bootup Message.
3	Double flash	Error	Node Guarding Error
4	Triple flash	Error	Sync Error Buffer overflow (0x8110)
5	on	Bus not active	

If several errors occur at once, the error with the most significant number is reported.


LED green

Signal	Status	Description
Single flash	Stop	The bus is in STOPPED state
blinks (permanently)	pre-operational	The bus is ready to operate (Pre-Operational)
on	operational	The bus is operating (operational)

Single flash




Double flash



Triple flash




CANopen states



- 6: Start Remote Node
- 7: Stop Remote Node
- 8: Enter Pre-Operational State
- 10: Reset Node
- 11: Reset Communication

The "Initialization" state is no fixed state but only a transition state.

3.7.6. DeviceNet Stecker X23



Pin X23	DeviceNet (Open Plug Phoenix MSTB 2.5/5-GF5.08 ABGY AU)	
1	V-	Mass
2	CAN-	CAN Low
3	Shield	Shield
4	CAN+	CAN High
5	V+	not required, internal supply

A mating plug is included in the delivery.

If Compax3 is used as first or last device in the fieldbus network, a terminal resistance of 121 Ω is required. This is integrated between Pin 2 and Pin 4.

Additional information on the DeviceNet wiring can be found under www.odva.org <http://www.odva.org>.

Please do also heed the instructions in the DeviceNet master manual.

3.7.6.1 Adjusting the bus address

Address setting (NA: Node Address)

Values:

1: 2⁰; 2: 2¹; 3: 2²; ... 6: 2⁵reserved

Settings:

left: OFF

right: ON

(The address is set to 2 in the illustration)

Range of values: 1 ... 63


Address 0 is set internally to address 63.

Data Rate setting (DR):

Data Rate [kBit/s]	S24_7	S24_8
125	left: OFF	left: OFF
250	right: ON	left: OFF
500	left: OFF	right: ON
factory use	right: ON	right: ON

Bear in mind that the maximum cable length depends on the Data rate:

Data Rate	Maximum length
500kbit/s	100m
250kbit/s	250m
125kbit/s	500m



3.7.6.2 Function of the Bus LEDs

LED (red)


No.	Signal	Status	Description
1	off	No Error	The bus is operating
2	Single flash	Warning	at least one of the error counters of the CAN controller has reached the warning level.
3	Double flash	Error	Communication Fault
4	Triple flash	Error	Double Mac ID
5	on	Error	Bus Off

If several errors occur at once, the error with the most significant number is reported.

LED green

Signal	Status	Description
Single flash	On-line Not Connected	Online, not at the master (not allocated)
blinks (permanently)	On-line Connected	Online, at the master (allocated)
on	On-line I/O Connected	I/O Messages allocated

Single flash




Double flash



Triple flash



3.7.7. Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24




	RJ45 (X23)	RJ45 (X24)
Pin	in	out
1	Tx +	Tx +
2	Tx -	Tx -
3	Rx +	Rx +
4	-	factory use
5	-	factory use
6	Rx -	Rx -
7	-	factory use
8	-	factory use

Wiring with Ethernet Crossover cable Cat5e (from X24 to X23 of the next device without termination); for this, we offer our **SSK28** (see on page 444, see on page 483) interface cable.

Meaning of the RJ45 LEDs (only for Ethernet Powerlink, I30)

Green LED (top): connection established (RPT_LINK/RX)

Yellow LED (bottom): Traffic (exchange of data) (Transmit / Receive Data) (RPT_ERR)



3.7.7.1 Set Ethernet Powerlink (option I30) bus address

Address setting

Values:

1: 2⁰; 2: 2¹; 3: 2²; ... 7: 2⁶; 8: 2⁷

Settings:

left: OFF

right: ON

(The address is set to 0 in the illustration)

Range of values: 1 ... 239

3.7.7.2 Set EtherCAT (option I31) bus address

Automatic address assignment with EtherCAT

3.7.7.3 Meaning of the Bus LEDs (Ethernet Powerlink)

Red LED (right): Ethernet Powerlink error

LED is influenced by the transitions of the NMT - status diagram (for further details, please refer to the **Ethernet Powerlink Specification**

<http://divapps.parker.com/divapps/eme/EME/downloads/compax3/EPL/epl2.0-ds-v-1-0-0.pdf>)

Error LED	Transition
off => on	NMT_CT11, NMT_GT6, NMT_MT6
on => off	NMT_CT6, NMT_GT2, NMT_CT3, NMT_MT5

Green LED (left): Ethernet Powerlink Status

LED indicates the states of the NMT - status diagram (for further details, please refer to the **Ethernet Powerlink Specification**

<http://divapps.parker.com/divapps/eme/EME/downloads/compax3/EPL/epl2.0-ds-v-1-0-0.pdf>)

Status LED		Status
off	off	NMT_GS_OFF, NMT_GS_INITIALISATION, NMT_CS_NOT_ACTIVE / NMT_MS_NOT_ACTIVE
flickering	flickering	NMT_CS_BASIC_ETHERNET
single flash	Single flash	NMT_CS_PRE_OPERATIONAL_1 / NMT_MS_PRE_OPERATIONAL_1
double flash	Double flash	NMT_CS_PRE_OPERATIONAL_2 / NMT_MS_PRE_OPERATIONAL_2
triple flash	Triple flash	NMT_CS_READY_TO_OPERATE / NMT_MS_READY_TO_OPERATE
on	on	NMT_CS_OPERATIONAL / NMT_MS_OPERATIONAL
blinking	flashing	NMT_CS_STOPPED

3.7.7.4 Meaning of the Bus LEDs (EtherCAT)

Red LED (right): EtherCAT error

LED is influenced by the transitions of the status diagram


Error LED	Error	Description
Off	No Error	
Flickering	Boot error	Error during initialization
Blinking	Invalid configuration	
Single Flash	Unsolicited change of status	Slave changed the status independently
Double Flash	Application Watchdog Timeout	Watchdog
On	PDI Watchdog Timeout	

Green LED (left): EtherCAT Status

LED shows the states of the status diagram


Status LED	Status	Description
Off	INITIALIZATION	Initialization
Blinking	PRE-OPERATIONAL	Ready
Single Flash	SAFE-OPERATIONAL	Master reads values
On	OPERATIONAL	Operation

Status diagram



Transition	Action
1	Start mailbox communication
2	Stop mailbox communication
3	Start input update
4	Stop input update
5	Start output update
6	Stop output update
7	Stop output update, stop input update
8	Stop input update, stop mailbox communication
9	Stop output update, stop input update, stop mailbox communication

Meaning of the LED states




3.8 Signal interfaces

In this chapter you can read about:

Resolver / Feedback (connector X13).....71
 Analogue / encoder (plug X11)73
 Digital inputs/outputs (plug X12)74

3.8.1. Resolver / Feedback (connector X13)



Assignment with feedback F10 (Resolver)

PIN X13	Feedback /X13 High Density /Sub D
	Resolver (F10)
1	factory use
2	factory use
3	GND
4	REF-Resolver+
5	+5V (for temperature sensor)
6	factory use
7	SIN-
8	SIN+
9	factory use
10	Tmot*
11	COS-
12	COS+
13	factory use
14	factory use
15	REF-Resolver-

Assignment with feedback F11 (SinCos)

PIN X13	Feedback /X13 High Density /Sub D
	SinCos (F11)
1	factory use
2	factory use
3	GND
4	Vcc (+8V with Compax3S & Compax3H; +10 V with Compax3M)
5	res+5 V (for temperature sensor)
6	factory use
7	SIN-
8	SIN+
9	factory use
10	Tmot*
11	COS-
12	COS+
13	DATAfbk
14	DATAfbk/
15	GND (Vcc)

Assignment with feedback F12 (EnDat)

PIN X13	Feedback /X13 High Density /Sub D		
	EnDat 2.1 & 2.2 with incremental track (Endat01, Endat02)	EnDat 2.1 fully digital (Endat21) (cable length max. 90 m)	EnDat 2.2 fully digital (Endat02, Endat22) (cable length max. 25 m)
1	Sense -*		factory use
2	Sense +*		factory use
3	factory use		
4	Vcc (+5 V) * max. 350 mA load		
5	+5 V (for temperature sensor)		
6	CLKfbk		
7	SIN- / A- (Encoder)	factory use	
8	SIN+ / A+ (Encoder)	factory use	
9	CLKfbk/		
10	Tmot*		
11	COS- / B- (Encoder)	factory use	
12	COS+ / B+ (Encoder)	factory use	
13	DATAfbk		
14	DATAfbk/		
15	GND (Vcc)		

*X13 Pin10 Tmot may not be connected at the same time as X15 (on Compaxx3M).

Resolver cables (see on page 459) can be found in the accessories chapter of the device description.

SinCos® **cables** (see on page 460) can be found in the accessories chapter of the device description.

EnDat - cable GBK38 (EnDat2.1) and GBK56 (EnDat2.2) (see on page 443, see on page 460)

Incremental Feedback (optionally with hall sensors)

PIN X13	Feedback option F12 / X13 High Density /Sub D
1	Sense -*
2	Sense +*
3	Hall1 (digital)
4	Vcc (+5V)* max. 350 mA load
5	+5 V (for temperature sensors and Hall sensors)
6	Hall2 (digital)
7	SIN-, A- (Encoder) or analog Hall sensor
8	SIN+, A+, (Encoder) or analog Hall sensor
9	Hall3 (digital)
10	Tmot*
11	COS-, B- (Encoder) or analog Hall sensor
12	COS+, B+ (Encoder) or analog Hall sensor
13	N+
14	N-
15	GND (Vcc)

*X13 Pin10 Tmot may not be connected at the same time as X15 (on Compaxx3M).

Note on F12:


*+5V (Pin 4) is measured and controlled directly at the end of the line via Sense+ and Sense-.

Cable length max.: 100m

Caution!

- ◆ Pin 4 and Pin 5 must under no circumstances be connected!
- ◆ Plug in or pull out feedback connector only in switched off state (24VDC switched off).

3.8.2. Analogue / encoder (plug X11)



PIN X11	Reference High Density Sub D		
		Encoders	SSI (see on page 145)
1	+24V (output) max. 70mA		
2	Ain1 -: analog input - (14Bits; max. +/-10V)		
3	D/A monitor channel 1 ($\pm 10V$, 8-bit resolution)		
4	D/A monitor channel 0 ($\pm 10V$, 8-bit resolution)		
5	+5 V (output for encoder) max. 150 mA		
6	- Input: steps RS422 (5V - level)	A/ (Input / -simulation)	Clock-
7	+ Input: steps RS422 (5V - level)	A/ (Input / -simulation)	Clock+
8	+ Input: direction RS422 (5V - level)	B Input / -simulation)	
9	Ain0 +: analog input + (14Bits; max. +/-10V)		
10	Ain1 +: analog input + (14Bits; max. +/-10V)		
11	Ain0 -: analog input- (14Bits; max. +/-10V)		
12	- Input: direction RS422 (5V - level)	B/ input / -simulation)	
13	factory use	N/ input / -simulation)	DATA-
14	factory use	N input / -simulation)	DATA+
15	GND		


Technical Data X11 (see on page 501)

3.8.2.1 Wiring of analog interfaces


Output

Input

Compax3



Compax3




Perform an **offset adjustment** (see on page 229)!

Structure image of the **internal signal processing of the analog inputs**, Ain1 (X11/10 and X11/2) has the same wiring!


3.8.2.2 Connections of the encoder interface

Compax3



The input connection is available in triple (for A & /A, B & /B, N & /N)

3.8.3. Digital inputs/outputs (plug X12)



Pin X12/	Input/output	I/O /X12 High density/Sub D
1	Output	+24 V DC output (max. 400mA)
2	O0	Output 0 (max. 100 mA)
3	O1	Output 1 (max. 100 mA)
4	O2	Output 2 (max. 100 mA)
5	O3	Output 3 (max. 100 mA)
6	I0	Input 0
7	I1	Input 1
8	I2	Input 2
9	I3	Input 3
10	I4	Input 4
11	I	24V input for the digital outputs Pins 2 to 5
12	I5	Input 5 or limit or direction reversal switch
13	I6	Input 6 or limit or direction reversal switch
14	I7	Input 7 or home switch
15	Output	GND24V

All inputs and outputs have 24V level.

Maximum capacitive loading of the outputs: 30nF (max. 2 Compax3 inputs)

Note:

The inputs and outputs are freely programmable using an IEC61131-3 program. Input 7 is planned as home switch, the inputs 5 and 6 as limit switches or direction reversal switches.

If no limit switches are used and these are switched off (in the C3 ServoManager under configuration), the inputs 5 and 6 can be freely assigned.

The same applies for input 7: A machine zero mode without home switch allows to freely assign input 7.


Optimization window display

The display of the digital inputs in the optimization window of the C3 ServoManager does not correspond to the physical status (24Volt=on, 0Volt=off) but to the logic status: if the function of an input or output is inverted (e.g. limit switch, negatively switching), the corresponding display (LED symbol in the optimization window) is OFF with 24Volts at the input and ON with 0 Volts at the input.

3.8.3.1 Connection of the digital Outputs/Inputs

Wiring of digital outputs

Compax3




The circuit example is valid for all digital outputs!
The outputs are short circuit proof; a short circuit generates an error.

Status of digital inputs

SPS/PLC

Compax3



The circuit example is valid for all digital inputs!
Signal level:
◆ > 9.15V = "1" (38.2% of the control voltage applied)
◆ < 8.05V = "0" (33.5% of the control voltage applied)

F1: Delayed action fuse

F2: Quick action electronic fuse; can be reset by switching the 24 VDC supply off and on again.

3.8.3.2 Logic proximity switch types

Type	1	2	3	4
Transistor switch	PNP	PNP	NPN	NPN
Logic	(N.O.) "active high"	(N.C) "active low"	(N.O.) "active low"	(N.C) "active high"
Description of logic	Compax3 sees a logical "1" upon activation	Compax3 sees a logical "0" upon activation	Compax3 sees a logical "0" upon activation	Compax3 sees a logical "1" upon activation
Fail safe logic	no	yes	Only conditional ¹⁾	no
Instruction for pull up resistor in the initiator	-	-	R _{min} =3k3 R _{max} =10k ²⁾	R _{min} =3k3 R _{max} =10k ²⁾
Connections				

¹⁾ When the connection between transistor emitter of the initiator and X12/15 (GND24V of the Compax3) is lost, it can not be guaranteed, that the Compax3 detects a logical „0“.

²⁾ The INSOR NPN types INHE5212 and INHE5213 manufactured by Schönbuch Electronic do correspond to this specification.

3.9 Mounting and dimensions

In this chapter you can read about:


Mounting and dimensions Compax3S.....	76
Mounting and dimensions PSUP/C3M.....	80
Mounting and dimensions C3H.....	82

3.9.1. Mounting and dimensions Compax3S

3.9.1.1 Mounting and dimensions Compax3S0xxV2

Mounting:

3 socket head screws M5



Stated in mm


Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

3.9.1.2 Mounting and dimensions Compax3S100V2 and S0xxV4

Mounting:

3 socket head screws M5



Stated in mm


Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

3.9.1.3 Mounting and dimensions Compax3S150V2 and S150V4

Mounting:

4 socket head screws M5



Stated in mm

- Please respect an appropriate mounting gap in order to ensure sufficient convection:
- ◆ At the side: 15mm
 - ◆ At the top and below: at least 100mm

3.9.2. Mounting and dimensions PSUP/C3M

Ventilation: During operation, the device radiates heat (power loss). Please provide for a sufficient mounting distance below and above the device in order to ensure free circulation of the cooling air. Please do also respect the recommended distances of other devices. Make sure that the mounting plate is not exhibited to other temperature influences than that of the devices mounted on this very plate. The devices must be mounted vertically on a level surface. Make sure that all devices are sufficiently fixed.


3.9.2.1 Mounting and dimensions PSUP10/C3M050D6, C3M100D6, C3M150D6

The devices are force-ventilated via a ventilator fan fixed to the lower part of the heat dissipator!

Mounting spacing: At the top and below: at least 100mm

Information on PSUP10D6/C3M050D6, C3M100D6, C3M150D6


Mounting:
2 socket head screws M5



3.9.2.2 Mounting and dimensions PSUP20/PSUP30/C3M300D6

Information on PSUP20/PSUP30/C3M300D6


Mounting:
4 socket head screws M5



Tolerances: DIN ISO 2768-f

3.9.2.3 With upper mounting, the housing design may be different


Mounting:
3 socket head screws M5



3.9.3. Mounting and dimensions C3H

The devices must be mounted vertically on a level surface in the control cabinet.

Dimensions:




(1): Electronics
(2): Head dissipator

	H	H1	D	W	W1
C3H050V4	453mm	440mm	245mm	252mm	150mm
C3H090V4	668.6mm	630mm	312mm	257mm	150mm
C3H1xxV4	720mm	700mm	355mm	257mm	150mm

Mounting: 4 screws M6

Ventilation: During operation, the device radiates heat (power loss). Please provide for a sufficient mounting distance below and above the device in order to ensure free circulation of the cooling air. Please do also respect the recommended distances of other devices. Make sure that the mounting plate is not exhibited to other temperature influences than that of the devices mounted on this very plate. If two or more devices are combined, the mounting distances are added.


3.9.3.1 Mounting distances, air currents Compax3H050V4



in mm

	I	J	K	L	M
C3H050V4	15	5	25	70	70


3.9.3.2 Mounting distances, air currents Compax3H090V4



in mm

	I	J	K	L	M
C3H090V4	0	0	25	70	70

3.9.3.3 Mounting distances, air currents Compax3H1xxV4



in mm

	I	J	K	L	M
C3H1xxV4	0	0	25	70	70

3.10 Safety function - STO (=safe torque off)

In this chapter you can read about:

General Description.....85
 STO (= safe torque off) with Compax3S88
 STO (= safe torque off) with Compax3m (Option S1).....98

3.10.1. General Description

In this chapter you can read about:

Important terms and explanations.....85
 Intended use.....86
 Advantages of using the "safe torque off" safety function.....86
 Devices with the STO (=safe torque off) safety function.....87

The present documentation assumes a basic knowledge of our drive controllers as well as an understanding of safety-oriented machine design. References to standards and other regulations are only rudimentarily expressed. For complementary information, we recommend the respective technical literature.

3.10.1.1 Important terms and explanations

Term	Explanation
Safety category 3 in accordance with EN ISO 13849-1	Definition according to standard: Circuit with safety function against individual errors. Some, but not all errors are detected. An accumulation of errors may lead to a loss of the safety function. The remaining risk is accepted. The determination of the safety category required for an application (risk analysis) lies within the responsibility of the machine manufacturer. It can take place according to the method described in EN ISO 13849-1, appendix A.
"Safe torque off" or abbreviated: STO=Safe torque off	With the "safe torque off", the energy supply of the drive is safely interrupted according to EN 1037, paragraph 4.1. The drive is not to be able to produce a torque and thus dangerous movements (see EN 1037, paragraph 5.3.1.3). The standstill position must not be monitored. If an external force effect, e.g. a drop of hanging loads, is possible with the "safe torque off", additional measures to safely prevent those must be provided (e.g. additional mechanical brakes). The following measures are appropriate for a "safe torque off": Contactor between mains and drive system (mains contactor) Contactor between power section and motor (motor contactor) Safe blocking of the power semiconductor control (start inhibitor)
Start inhibitor	Safe blocking of the power semiconductor control. With the aid of this function, you can obtain a "safe torque off".

Stop categories according to EN60204-1 (9.2.2)

Stop category	Safety function	Requirement	System behavior	Remark
0	Safe torque off (STO)	Stopping by immediately switching off the energy supply of the machine drive elements	Uncontrolled stop	Uncontrolled stop is the stopping of a machine movement by switching off the energy of the machine drive elements. Available brakes and/or other mechanical stopping components are applied.
1	Safe stop 1 (SS1)	Stop where the energy of the machine drive elements is maintained in order to reach a stop. The energy supply is only interrupted, if the standstill is attained.	Controlled stop	Controlled stop is the stopping of a machine movement by for instance resetting the electrical command signal to zero, as soon as the stop signal has been detected by the controller, the electrical energy for the machine drive elements remains however during the stopping procedure.
2	Safe stop 2 (SS2)	Stop where the energy to the machine drive elements is maintained.	Controlled stop	This category is not covered.

3.10.1.2 Intended use

The Compax3 drive controller supports the "safe torque off" (STO) safety function, with protection against unexpected startup according to the requirements of EN ISO 13849-1, category 3 to PLe and EN 1037.

Together with the external safety control device, the "safe stop 1" (SS1) safety function according to the requirements of EN ISO 13849-1 category 3 can be used. As the function is however realized with the aid of an individually settable time delay on the safety switching device, you must take into account that, due to an error in the drive system during the active braking phase, the axis trundles to a stop unguided or may even accelerate actively in the worst case until the expiry of the preset switch-off time.

According to a risk evaluation which must be carried out according to the machine standard 98/37/EG and 2006/42/EG or EN ISO 12100, EN ISO 13849-1 and EN ISO 14121-1, the machine manufacturer must project the safety system for the entire machine including all integrated components. This does also include the electrical drives.

Qualified personnel

Projecting, installation and setup require a detailed understanding of this description. Standards and accident prevention regulation associated with the application must be known and respected as well as risks, protective and emergency measures.

3.10.1.3 Advantages of using the "safe torque off" safety function.

Safety category 3 in accordance with EN ISO 13849-1

Requirements performance feature	Use of the safe torque off function	Conventional solution: Use of external switching elements
Reduced switching overhead	Simple wiring, certified application examples Grouping of drive controllers on a mains contactor is possible.	Two safety-oriented power contactors in series connection are required.
Use in the production process High operating cycles, high reliability, low wear	Extremely high operating cycles thanks to almost wear-free technology (low-voltage relay and electronic switch). The "safe torque off" status is attained due to the use of wear-free electronic switches (IGBTs).	This performance feature cannot be reached with conventional technology.
Use in the production process High reaction speed, fast restart	Drive controller remains performance- and control-oriented in connected state. No significant waiting times due to restart.	When using power contactors in the supply, a long waiting time for the energy discharge of the DC link circuit is required. When using two power contactors on the motor side, the reaction times may increase, you must however take into consideration other disadvantages: a) Securing that switching takes only place in powerless state (Direct current! Constant electric arcs must be prevented). b) Increased overhead for EMC conform wiring.
Emergency-stop function	According to the German version of the standard: Permitted without control of mechanical power switching elements 1)	Switch-off via mechanical switching elements is required

1) According to the preface of the German version of the EN 60204-1/11.98, electronic equipment for emergency-stop devices are also permitted, if they comply with the safety categories as described in EN ISO 13849-1.

3.10.1.4 Devices with the STO (=safe torque off) safety function

The STO (Safe torque off) safety function is implemented in the following devices:

Compax3 technology function

- ◆ I10T10, I11T11, I12T11,
- ◆ I10T20, I20T20, I32T20
- ◆ I11T30, I20T30, I21T30, I22T30, I30T30, I31T30, I32T30,
I11T40, I20T40, I21T40, I22T40, I30T40, I31T40, I32T40
I11T70, I20T70, I32T70
- ◆ I20T11, I21T11, I22T11, I30T11, I31T11, I32T11
- ◆ C10T11, C10T30, C10T40,
C13T11, C13T30, C13T40,
C20T11, C20T30, C20T40

with the device power / series

S025V2, S063V2, S100V2, S150V2, S015V4, S038V4, S075V4, S150V4, S300V4
M050D6, M100D6, M150D6, M300D6,
and is only valid with the stated conditions of utilization.

3.10.2. STO (= safe torque off) with Compax3S

In this chapter you can read about:

STO Principle (= Safe Torque Off) with Compax3S	88
Conditions of utilization STO (=safe torque off) Safety function.....	90
Notes on the STO function.....	90
STO application example (= safe torque off).....	91
Technical Characteristics STO Compax3S	97

3.10.2.1 STO Principle (= Safe Torque Off) with Compax3S

To ensure safe protection against a motor starting up unexpectedly, the flow of current to the motor and thus to the power output stage must be prevented. This is accomplished for Compax3S with two measures independent of each other (Channel 1 and 2), without disconnecting the drive from the power supply:

Channel 1:

Activation of the power output stage can be disabled in the Compax3 controller by means of a digital input or with a fieldbus interface (depending on the Compax3 device type) (deactivation of the energize input).


Channel 2:

The power supply for optocouplers and drivers of power output stage signals is disconnected by a safety relay activated by the enable input "ENAIN"(X4/3) and equipped with force-directed contacts. This prevents control signals from being transferred to the power output stage.



**The STO (= Safe Torque Off) safety function in accordance with EN ISO 13849-1: 2008 PLd or PLe, Kat.3 is only possible when using both channels via an external safety switching device
Please note the application examples!**


Circuit diagram illustrating working principle:



Notes

- ◆ In normal operation of Compax3, 24VDC of power is supplied to the "Enable" input (X4/3). The control of the drive takes then place via the digital inputs/outputs or via the fieldbus.

STO delay times



The deceleration time $t_{deceleration}$ depends on the configuration of the Compax3. It must be configured so that oscillation free bringing to standstill is possible, depending on the mechanical load. The delay time t_{delay_time} must be set in the safety control device UE410 so that $t_{delay_time} > t_{deceleration}$. Only after the elapsing of the relay delay $t_{delay_relay_ch2}$, the STO function is completely activated. The relay delay time $t_{deay_relay_ch2}$ is 15 ms.


3.10.2.2 Conditions of utilization STO (=safe torque off) Safety function

- ◆ STO can only be implemented in Compax3 with a corresponding safety switching device considering the application examples.
- ◆ Safety functions must be tested 100%.
- ◆ The Compax3S and the safety switching device used must be mounted in a protected way (IP54 mounting cabinet).
- ◆ Only qualified staff members are permitted to install the STO (=safe torque off) function and place it in service.
- ◆ For all applications in which the first channel of the "Safe torque off" is implemented by means of a PLC, care must be taken that the part of the program that is responsible for current flowing to or not flowing to the drive is programmed with the greatest possible care. The Safe Torque off application example of Compax3 with fieldbus should be considered.
The designer and operator responsible for the system and machine must refer programmers who are involved to these safety-related points.
- ◆ Terminal X4/2 (GND 24 V and at the same time the reference point for the safety relay bobbin) must be connected with the PE protective lead. This is the only way to ensure protection against incorrect operation through earth faults (EN60204-1 Section 9.4.3)!
- ◆ All conditions necessary for CE-conform operation must be observed.
- ◆ When using an external safety switching device with adjustable delay time, (as illustrated in the STO application example), it must be ensured that the delay time cannot be adjusted by persons not authorized to do so (for example by applying a lead seal). With the UE410-MU3T5 safety switching device, this is not necessary, if the anti manipulation measures are respected.
- ◆ The adjustable delay time on the safety switching device must be set to a value greater than the duration of the braking ramp controlled by the Compax3 with maximum load and maximum speed.
If the setting range for the specified Emergency power-off module is not sufficient, the Emergency power-off module must be replaced by another equivalent module.
- ◆ All safety-related external leads (for example the control lead for the safety relay and feedback contact) must absolutely be laid so they are protected, for example in a cable duct. Short circuits and crossed wires must be reliably excluded!
- ◆ If there are external forces operating on the drive axes, additional measures are required (for example additional brakes). Please note in particular the effects of gravity on suspended loads!

3.10.2.3 Notes on the STO function

- ◆ It should be noted in connection with the STO (= safe torque off) application example illustrated here that after the Emergency stop switch has been activated, no galvanic isolation in accordance with EN 60204-1 Section 5.5 is guaranteed. This means that the entire system must be disconnected from the mains power supply with an additional main switch or mains power contactor for repair jobs. Please note in this regard that even after the power is disconnected, dangerous electrical voltages may still be present in the Compax3 drive for about 10 minutes.
- ◆ During the active braking phase of Stop category 1 (controlled bringing to a stop with safely monitored delay time according to EN60204-1) or safe stop 1, faulty function must be expected. If an error in the drive system or mains failure occurs during the active braking phase, the axis may trundle to a stop unguided or might even actively accelerate until the expiry of the defined switch-off time.
- ◆ Please note that the control of the drive via Energize (Energize input or fieldbus interface) is not executed in all operating conditions. The following restrictions apply when the set-up window of the C3 ServoManager is used:
 - ◆ If the setup mode is switched on, the fieldbus interface and the energize input are blocked.
 - ◆ the energize input can be ignored if the input simulator is activated (depending on the settings).

Note on error switch-off

	<p><u>If the "safe torque off" function of Compax3 is required or used for a machine or system, the two errors:</u></p> <ul style="list-style-type: none"> ◆ "Motor_Stalled" (Motor stalled) and ◆ "Tracking" (following error) <p><u>are not to be switched off (see on page 139, see on page 315, see on page 314, see on page 141).</u></p>
---	--

3.10.2.4 STO application example (= safe torque off)

The application example described here corresponds to Stop Category 1 as defined by EN60204-1.

Together with the external safety switching device, the "Safe Stop 1"(SS1) safety function can also be implemented.

A Stop Category 0 in accordance with EN 60204-1 can be implemented, for example by setting the delay time on the Emergency power-off module as well as on the Compax3 (delay time for "switch to currentless") to 0. The Compax3M will then be turned off immediately in 2 channels and will therefore not be able to generate any more torque. Please take into consideration that the motor will not brake and a coasting down of the motor may result in hazards. If this is the case, the STO function in stop category 0 is not permitted.


Safe torque off without bus option**In this chapter you can read about:**

Circuit layout overview.....	91
Circuit:	92
Safe torque off description	93

Circuit layout overview

- ◆ 2 Compax3 devices (the circuit example is also valid for one or multiple devices, if it is adapted accordingly)
- ◆ 1 Emergency Power-off module (UE410-MU3T5 manufactured by Sick)
With adjustable delayed deactivation of the Compax3 enable input ENAi.
The time must be set so that all axes are at a standstill before the Compax3 controllers are deactivated.
- ◆ The operating instructions of the UE410-MU3T5 safety switching device must be observed.
- ◆ 1 emergency power-off switch
- ◆ Hazardous area accessible via a safety door with safety door switch S6.
- ◆ 1 pushbutton per Compax3
- ◆ For the Energize input on Compax3, a debouncing time > 3 ms must be configured
- ◆ 1 relay per Compax3
The relay must be dimensioned so that it has a lifetime of at least 20 years, taking the cycle time into consideration. If this is not the case, the relays must be exchanged for new relays after expiration of the lifetime.

Circuit:



*Energize = I0 (X12/6) (debounced digital input)

Instead of the safety switching device manufactured by Sick mentioned above, you may use other safety switching devices.

The safety switching device must however provide the following features:

- ◆ 1 normally open contact is required for switching off channel 1 (as an alternative, a safe semiconductor output is possible)
- ◆ 1 off-delayed normally open safety contact is required for switching off channel 2 (as an alternative, a safe semiconductor output with adjustable delay time for the high_to_low_edge is possible).
- ◆ 1 one-channel monitoring circuit where the feedback contacts of channels 1 and 2 can be integrated for simultaneous monitoring, is required.
At the same time it must be possible to integrate a one-channel start button for activation of the safety switching device into the circuit.
A new start may only be successful, if it is ensured, that channels 1 and 2 are switched off.
- ◆ 1 two-channel connection for emergency power off and/or safety door contacts with cross fault monitoring is required.
- ◆ The safety switching device must feature performance PL e. The I/Os must at least correspond to category 3.

Switches and buttons:

1 N/C (S4, S5) per device:	Guide Device to a currentless state
S6:	closed when the safety door is closed
S2:	Activate safety switching device

Caution! Module UET410-MU3T5 modulates regularly test switching signals (OSSD) on outputs Q3 and Q4.
We recommend to use a filter > 3 ms for signal Q3 in the PLC.
If different safety switching devices are used, please make sure that the pulse width of the test pulses is not wider than 700µs. The safety switching device used can only send test pulses (active low) with high level.

Safe torque off description

In this chapter you can read about:

Basic functions:	96
Access to the hazardous area	97

In this chapter you can read about:

Safe torque off basic function	93
Access to the hazardous area	94

Safe torque off basic function

Compax3 devices disabled by:

Channel 1: Energize input to "0" by safety switching device output Q3
Channel 2: Enable input ENAI to "0" by safety switching device output Q4

Activate safety switching device

Before the Compax3 can be placed into operation, the safety switching device must be activated by a pulse to Input S2.

Prerequisite:

- ◆ S2 closed
- ◆ Safety door closed
- ◆ K1 and K2 energized
 - ◆ K1: receives current if Compax3 Device 1 is currentless (output = "1" in currentless state) = Channel 1 feedback
 - ◆ K2: receives current if Compax3 device 2 is currentless (output = "1" in the currentless state) = channel 1 feedback
- ◆ The feedback contact of all Compax3 devices must be closed (channel 2).

Energize Compax3 (Motor and power output stage)

- ◆ With the safety switching device, the Compax3 devices are enabled via the energize input and the Enable input ENAI. (If an error is still present in the Compax3, it must be acknowledged - the ackn function depends on the Compax3 device type)
- ◆ The motors are energized with current.

Summary: Compax3 is only energized if the feedback functions are capable of functioning via two channels.

Access to the hazardous area

Actuate emergency power-off switch

Due to the interruption on two channels at the emergency power-off switch, the safety switching device is deactivated - output Q3 is immediately "0".

Channel 1: Via the Energize input, the Compax3 devices receive the command to guide the drive to a currentless state (using the ramp configured in the C3 ServoManager for "drive disable").

Channel 1 feedback 1: The "Controller Feedback" Compax3 outputs supply current to Relays K1 and K2.

Channel 2: After the delay time set in the safety switching device, (this time must be set so that all drives are stopped after it has elapsed) the output Q4 = "0", which in turn deactivates the Enable inputs ENAi of the Compax3 devices.

Channel 2 feedback: Via the series circuit of all feedback contacts, the "Safe Torque-off" status (all Compax3 devices without current) is reported.

Only if the drives are all at a standstill, the safety door may be opened and the hazardous area may be accessed.

If the safety door is opened during operation and the emergency-power-off switch was not triggered before, the Compax3 drives will also trigger the stop ramp.



Caution! The drives may still move.

If danger to life and limb of a person entering cannot be excluded, the machine must be protected by additional measures (e.g. a safety door locking).

Safe torque off with bus option

In this chapter you can read about:


Safe torque off layout with bus.....	94
Circuit:	95
Safe torque off description	96

Safe torque off layout with bus

- ◆ 2 Compax3 devices (the circuit example is also valid for one or multiple devices, if it is adapted accordingly)
- ◆ 1 Emergency Power-off module (UE410-MU3T5 manufactured by Sick)
With adjustable delayed deactivation of the Compax3 enable input ENAi.
The time must be set so that all axes are at a standstill before the Compax3 controllers are deactivated.
- ◆ The operating instructions of the UE410-MU3T5 safety switching device must be observed.
- ◆ 1 emergency power-off switch
- ◆ Hazardous area accessible via a safety door with safety door switch S6.
- ◆ 1 pushbutton per Compax3

Circuit:

Designation	Bus device I20	additional bus devices
control:	Control word CW	Controlword
status:	Status word SW	Status word



* Energize: free selection in the "control"
 Controller Feedback Option: free choice in "status"

Instead of the safety switching device manufactured by Sick mentioned above, you may use other safety switching devices.

The safety switching device must however provide the following features:

- ◆ 1 normally open contact is required for switching off channel 1 (as an alternative, a safe semiconductor output is possible)
- ◆ 1 off-delayed normally open safety contact is required for switching off channel 2 (as an alternative, a safe semiconductor output with adjustable delay time for the high_to_low_edge is possible).
- ◆ 1 one-channel monitoring circuit where the feedback contacts of channels 1 and 2 can be integrated for simultaneous monitoring, is required.
At the same time it must be possible to integrate a one-channel start button for activation of the safety switching device into the circuit.
A new start may only be successful, if it is ensured, that channels 1 and 2 are switched off.
- ◆ 1 two-channel connection for emergency power off and/or safety door contacts with cross fault monitoring is required.
- ◆ The safety switching device must feature performance PL e. The I/Os must at least correspond to category 3.

Switches and buttons:

1 N/C (S4, S5) per device:	Guide Device to a currentless state
S6:	closed when the safety door is closed
S2:	Activate safety switching device

Caution! Module UET410-MU3T5 modulates regularly test switching signals (OSSD) on outputs Q3 and Q4.
We recommend to use a filter > 3 ms for signal Q3 in the PLC.
If different safety switching devices are used, please make sure that the pulse width of the test pulses is not wider than 700µs. The safety switching device used can only send test pulses (active low) with high level.

Safe torque off description

Basic functions:

Compax3 devices disabled by:

Channel 1: Energize deactivated by PLC and safety switching device output Q3.
Channel 2: Enable input to “0” by safety switching device output Q4.

Activate safety switching device

Before the Compax3 can be placed into operation, the safety switching device must be activated by a pulse to Input S2.

Prerequisite:

- ◆ S2 closed
- ◆ Safety door closed: only then the safety door monitor will enable the safety switching device on two channels
- ◆ Feedback activated via PLC (Controller feedback channel 1: motor not energized)
- ◆ The feedback contact of all Compax3 devices must be closed (channel 2).

Energize Compax3 (Motor and power output stage)

- ◆ The PLC enables the Compax3 devices by means of the control word and the safety switching device enables the Compax3 devices by means of the Enable input. (If an error is still present on the Compax3, it must be acknowledged before)
- ◆ The motors are energized with current.

Summary: Compax3 is only energized if the feedback functions are capable of functioning via two channels.

Access to the hazardous area

Actuate emergency power-off switch

Due to the interruption on two channels at the emergency stop switch, the safety switching device is deactivated - output Q is immediately "0".

The PLC evaluates this and responds as follows:

Channel 1: The Compax3 devices receive via the control word the command to guide the drive to currentless state (vi the ramp for "deenergizing" configured in the C3 ServoManager).

Channel 1 feedback: The Compax3 feedback via the status word is evaluated by the PLC and passed on to the safety switching device via the Compax3 Feedback (X4.4 and X4.5).

Channel 2: After the delay time set in the safety switching device, (this time must be set so that all drives are stopped after it has elapsed) the output Q4 = "0", which in turn deactivates the Enable inputs ENAi of the Compax3 devices.

Channel 2 feedback: Via the series circuit of all feedback contacts, the "Safe Torque-off" status (all Compax3 devices without current) is reported.

Only if the drives are all at a standstill, the safety door may be opened and the hazardous area may be accessed.

If the safety door is opened during operation and the emergency-power-off switch was not triggered before, the Compax3 drives will also trigger the stop ramp.



Caution! The drives may still move.

If danger to life and limb of a person entering cannot be excluded, the machine must be protected by additional measures (e.g. a safety door locking).

3.10.2.5 Technical Characteristics STO Compax3S

Safety technology Compax3S

<p>Safe torque-off in accordance with EN ISO 13849: 2008, Category 3, PL d/e Certified. Test mark IFA 1003004</p>	<ul style="list-style-type: none"> ◆ For implementation of the "protection against unexpected start-up" function described in EN1037. ◆ Please note the circuitry examples (see on page 85).
--	---

Compax3S STO (=safe torque off)

Nominal voltage of the inputs	24 V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1 A
Grouping of safety level	<p><500 000 STO cycles per year are assumed.</p> <ul style="list-style-type: none"> ◆ STO switch-off via internal safety relay & digital input: PL e, PFHd=2.98E-8 ◆ STO switch-off via internal safety relay & fieldbus: PL d, PFHd=1.51E-7 (is applicable for a MTTFd=15 years of the external PLC) ◆ Lifetime: 20 Years



3.10.3. STO (= safe torque off) with Compax3m (Option S1)

In this chapter you can read about:


Safety switching circuits.....	98
Safety notes for the STO function in the Compax3M.....	99
Conditions of utilization for the STO function with Compax3M	99
STO delay times.....	100
Compax3M STO application description	101
STO function test.....	104
Technical details of the Compax3M S1 option	106

3.10.3.1 Safety switching circuits

The current flow in the motor windings is controlled by a power semiconductor bridge (6-fold IGBT). A processor circuit and PWM circuit will switch the IGBT with rotary field orientation. Between control logic and power module, optocouplers are used for potential separation.

On the Compax3M drive controller with S1 option, the X14 (STO) connector can be found on the front plate. 2 optocouplers are controlled on two channels via the STO1/ and STO2/ terminals of this connector. When requesting the STO via an external safety switching device, the two auxiliary voltage supply channels of the power stage control circuits are switched off on two channels. Therefore the power transistors (IGBTs) for the motor current can not longer be switched on.

The hardware monitor detects the failure of the optocoupler circuit of a channel by always checking both channels for similarity. If the hardware monitor detects a discrepancy for a defined time (ax. 20s), the error will be stored in the hardware memory. The processor signals this error externally via the 0x5493 error code. An activation of the coupler supply can then only take place via a hardware reset (switching off and on again) of the device.



* Potential separation with optocoupler.

3.10.3.2 Safety notes for the STO function in the Compax3M

- ◆ It should be noted in connection with the STO application examples illustrated here that after the Emergency stop switch has been activated, no galvanic isolation in accordance with EN 60204-1 Section 5.5 is guaranteed. This means that the entire system must be disconnected from the mains power supply with an additional main switch or mains power contactor for repair jobs. Please note in this regard that even after the power is disconnected, dangerous electrical voltages may still be present in the Compax3 drive for about 10 minutes.
- ◆ During the active braking phase of Stop category 1 (controlled bringing to a stop with safely monitored delay time according to EN60204-1) or safe stop 1, faulty function must be expected. If an error in the drive system occurs during the active braking phase, the axis may trundle to an unguided stop or might even actively accelerate until the expiry of the defined switch-off time.
- ◆ For synchronous motors operated in the field weakening range, the operation of the STO function may lead to over speed and destructive, life-threatening over voltages as well as explosions in the servo drive. Therefore, NEVER use the STO function with synchronous drives in the field-weakening range.
- ◆ It is important to note that if the drive is being activated (Energize) by the USB / RS485 interface, it may not be possible to execute switch-off by a controlled braking ramp. For example, this is true when the set-up window of the C3 ServoManager is used. If set-up mode is turned on or with the input simulator, the digital I/O interface and fieldbus interface are automatically disabled.


Maintenance

When using the S1 option, a protocol describing the orderly working of the safety function must be made upon the setup and in defined maintenance intervals (see protocol proposal).

3.10.3.3 Conditions of utilization for the STO function with Compax3M

- ◆ The STO safety function must be tested and protocolled **as described** (see on page 104). The safety function must be requested at least once a week. In safety door applications, the weekly testing interval must not be observed, as you can assume that the safety doors will be opened several times during the operation of the machine.
- ◆ The Compax3M with integrated STO safety function as well as the utilized safety switching devices must be mounted protected (IP54 control cabinet).
- ◆ Only qualified staff members are permitted to install the STO function and place it in service.
- ◆ The X9/2 (GND24V) terminal on the PSUPxx mains module must be connected to the PE protective lead. This is the only way to ensure protection against incorrect operation through earth faults (EN60204-1 Section 9.4.3)!
- ◆ When using an external safety switching device with adjustable delay time, (as illustrated in the STO application example), it must be ensured that the delay time cannot be adjusted by persons not authorized to do so (for example by applying a lead seal). With the UE410-MU3T5 safety switching device, this is not necessary, if the anti manipulation measures are respected.
- ◆ The adjustable delay time on the safety switching device must be set to a value greater than the duration of the braking ramp controlled by the Compax3 with maximum load and maximum speed.
- ◆ All conditions necessary for CE-conform operation must be observed.
- ◆ If there are external forces operating on the drive axes, additional measures are required (for example additional brakes). Please note in particular the effects of gravity on suspended loads! This must be respected above all for vertical axes without self-locking mechanical devices or weight balance.
- ◆ When using synchronous motors, a short movement over a small angle is possible, if two errors occur simultaneously in the power section. This depends on the number of pole pairs of the motor (rotary types: 2 poles = 180°, 4 poles = 90°, 6 poles = 60°, 8 poles = 45°, Linear motors: 180° electrically).

3.10.3.4 STO delay times




3.10.3.5 Compax3M STO application description

In this chapter you can read about:

STO function with safety switching device via Compax3M inputs..... 101
 STO function description102
 Emergency stop and protective door monitoring without external safety switching device.103

STO function with safety switching device via Compax3M inputs



Recommendation Energize = I0 (X12/6) (debounceable digital input)
 The acknowledgement S2 via the safety control UE410-MU3T5 is only necessary, if after the disabling of the STO function, a danger to any person or to the machine could arise by automatic starting. During the **Configuration des Compax3M** (see on page 137) you must see to a debouncing time >3ms being configured for the Energize input.
 The operating instructions of the UE410-MU3T5 safety control must be observed. The Compax3M devices and the UE410-MU3T5 safety control must be mounted in the same control cabinet.

1 N.C. (S3, S4) per device	Guide Device to a currentless state
S1	closed when the safety door is closed
S2	Activate safety switching device

STO function description

When opening the protective door or after actuating the emergency stop switch, the signal of the "energize" input of the Compax3M drive modules is interrupted via the Q3 output on the UE410-MU3T5 safety control. This triggers an immediate braking ramp on the drives. Then after the delay time set on the UE410-MU4T5 safety control, the STO function in the drives is triggered via the Q4 output. The servo drives are then in safe torqueless state. The delay time must be set on the safety control so that the braking ramp in the drives has run off and the drives are at standstill when the delay time has elapsed.

The described application example corresponds to the stop category 1 according to EN 60204-1. Together with the external safety switching device, the "Safe Stop 1" safety function can also be implemented.

A Stop Category 0 in accordance with EN 60204-1 can be implemented, for example by setting the delay time on the safety switching device to 0. The Compax3M will then be turned off immediately in 2 channels and will not be able to generate any more torque. Please take into consideration that the motor will not brake and a coasting down of the motor may result in hazards. If this is the case, the STO function in stop category 0 is not permitted.

Depending on the interface Ixx or technology function Txx of the Compax3M, the "energize" input can be a digital input or for instance a defined bit of a fieldbus control word (see the overview table below).

In the I10T10, I11T11, I12T11, I2xT11 and I3xT11 devices, the ackn input is assigned fixed.

Interface/Technology	"Energize"	Ackn
I10T10	Digital input I0 (X12/6)	I2 (X12/8)
I11T11	Digital input I2 (X12/8) (Energize & Ackn identical)	
I12T11	Digital input I0 (X12/6) (Energize & Ackn identical)	
I2xT11, I3xT11		
I2xT11, I3xT11	Applications with fieldbusses	
I11T30 and I11T40	Debounced digital input defined in the IEC program, which leads to the enable input of the MCpower function module	
I2xT30, I2xT40, I3xT30 and I3xT40	Bit defined in the IEC program (debounced digital input or via fieldbus) which is linked to the enable input of the MCpower function module	
C1xT30 and C1xT40 C20T30 and C20T40	Debounced digital input defined in the IEC program, which leads to the enable inputs of several MCpower function modules for different axes. The information is passed on to the individual axes via the CANbus.	


The acknowledgement via the safety control UE410-MU3T5 is only necessary, if after the disabling of the STO function, a danger to any person or to the machine could arise due to automatic startup..

Emergency stop and protective door monitoring without external safety switching device.

With Compax3M, a 2-channel protective door monitoring switch or a 2 channel emergency power-off switch can be directly connected. The figure below visualizes an application with 2 channel protective door monitoring switch.

The Compax3M drive modules with PSUPxx mains rectifier must be located in a protected area (IP54 control cabinet). Outside this protected area, the line guiding to the external switches must be separated channelwise or must be especially protected (blinded).

It is also permitted to use one acknowledgement switch for both servo drives at a time. In both cases the acknowledgement does only correspond to category B, therefore this acknowledgement should not be used if there is any possibility of stepping in the dangerous area. In this case, an external acknowledgement device must be used.



3.10.3.6 STO function test

The STO function must be checked in the event of:

- ◆ Commissioning
- ◆ After each exchange of any equipment within the system
- ◆ After each intervention into the system wiring
- ◆ In defined maintenance intervals (at least once per week) and after a longer standstill of the machine

If the STO function was triggered by opening a protective door and if this door is opened several times a week, the weekly testing interval is not required.

The check must be made by qualified personnel adhering to all necessary safety precautions.

The following testing steps must be performed:

STO Test	Action, activity	Expected reaction and effect
1	24V DC voltage on terminal X14.1 and X14.3	
2	Switch on power and 24V supply voltage	No error must be present
3	Configuring the device	No error must be present
4	Testing active STO on terminal X14.1 and X14.3: Remove 24V DC on terminal X14.1 and X14.3 at the same time	Error message 0x5492 must be present 1)
5	Re-apply 24V DC voltage on terminals X14.1 and X14.3 and then acknowledge error	No error must be present
6	Then switch off and on again 24V voltage supply	No error must be present

1) In order to automate the test, it is sufficient here to monitor the general error output with an external logic.

A manual check of the torqueless drive is here also sufficient.

The triggering of the STO can also be made by actuating the emergency stop switch. During the automated test, the STO can also be triggered via the contacts of an external relay

Following the test steps

The performance of the individual test steps of the STO function must be logged. A protocol specimen can be found in the following section.

Depending on the machine version, additional or other test steps may be required.

STO test protocol specimen (Safety Option S1)

General information:

Project/machine: _____

Servo axis: _____

Name of the tester: _____

STO function test:

Test specification according to the
Compax3 release: _____

STO function test steps 1-6: successfully tested

Acknowledgement safety switching device: successfully tested
 is not used

Safe stop 1: successfully tested
 is not used

Initial acceptance on:

Repeat check on:

Signature of the tester

Signature of the tester

3.10.3.7 Technical details of the Compax3M S1 option

Safety technology Compax3M

Safe torque-off in accordance with EN ISO 13849-1: 2007, Category 3, PL=e Certified. Test mark MFS 09029	◆ Please respect the stated safety technology on the type designation plate (see on page 12) and the circuitry examples (see on page 98)
---	--

Compax3M S1 Option: Signal inputs for connector X14

Nominal voltage of the inputs	24V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1A
Number of inputs Signal inputs via optocoupler	2 Low = 0...7V DC or open High = 15...30V DC I_{in} at 24V DC: 8mA
STO1/	Low = STO activated High = STO deactivated Reaction time max. 3ms
STO2/	Low = STO activated High = STO deactivated Reaction time max. 3ms
Switch-off time with unequal input statuses	20 s (max. error reaction time)
Grouping of safety level	◆ Category 3 ◆ PL=e (according to table 4 in EN ISO 13849-1 this corresponds to SIL 3) ◆ PFHd=4.29E-8 ◆ Lifetime: 20 years

◆

4. Setting up Compax3

In this chapter you can read about:

Configuration	107
Configuring the signal source	143
Load control.....	149
Optimization	152

4.1 Configuration

In this chapter you can read about:

Selection of the supply voltage used.....	108
Motor selection	109
Optimize motor reference point and switching frequency of the motor current.....	109
Ballast resistor.....	112
General drive.....	113
Defining the reference system	113
Defining jerk / ramps.....	138
Limit and monitoring settings	138
Encoder simulation	140
Recipe table	141
Error response.....	141
Configuration name / comments	142

The general proceeding in order to operate an empty-running motor is described [here](#) (see on page 108).

Configurations sequence:

Installation of the C3 ServoManager

The Compax3 ServoManager can be installed directly from the Compax3 DVD. Click on the corresponding hyperlink resp. start the installation program "C3Mgr_Setup_V.....exe" and follow the instructions.

PC requirements

Recommendation:

Operating system:	MS Windows XP SP3 / MS Vista (32 Bit) / Windows 7 (32 Bit / 64 Bit)
Browser:	MS Internet Explorer 8.x or higher
Processor:	Intel / AMD Multi core processor >=2GHz
RAM memory:	>= 1024MB
Hard disk:	>= 20GB available memory
Drive:	DVD drive (for installation)
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB 2.0

Minimum requirements:

Operating system:	MS Windows XP SP2 / MS Windows 2000 as from SP4
Browser:	MS Internet Explorer 6.x
Processor:	>=1.5GHz
RAM memory:	512MB
Hard disk:	10GB available memory
Drive:	DVD drive
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB

Note:

- ◆ For the installation of the software you need administrator authorization on the target computer.
- ◆ Several applications running in parallel, reduce the performance and operability.
- ◆ Especially customer applications, exchanging standard system components (drivers) in order to improve their own performance, may have a strong influence on the communication performance or even render normal use impossible.
- ◆ Operation under virtual machines such as Vware Workstation 6/ MS Virtual PC is not possible.
- ◆ Onboard graphics card solutions reduce the system performance by up to 20% and cannot be recommended.
- ◆ Operation with notebooks in current-saving mode may lead, in individual cases, to communication problems.

Connection between PC and Compax3

Your PC is connected with Compax3 via a RS232 cable (**SSK1** (see on page 480)). Start the Compax3 ServoManager and make the setting for the selected interface in the "**Options Communication settings RS232/RS485...**" menu.

Device Selection

In the menu tree under device selection you can read the device type of the connected device (Online Device Identification) or select a device type (Device Selection Wizard).

Configuration

Then you can double click on "Configuration" to start the configuration wizard. The wizard will lead you through all input windows of the configuration.

Input quantities will be described in the following chapters, in the same order in which you are queried about them by the configuration wizard.

In the device online help, we show you at this place an animation of a test setup with the aim to move an unloaded motor.

- ◆ Simple and independent of the Compax3 device variant*
- ◆ Without overhead for configuration
- ◆ Without special knowledge in programming

* for device specific functions, please refer to the corresponding device description.

Due to continuous optimization, individual monitor displays may have changed. This does however hardly influence the general proceeding.

4.1.1. Selection of the supply voltage used

Please select the mains voltage for the operation of Compax3. This influences the choice of motors available.

4.1.2. Motor selection

The selection of motors can be broken down into:

- ◆ Motors that were purchased in Europe and
- ◆ Motors that were purchased in the USA.
- ◆ You will find non-standard motors under "Additional motors" and
- ◆ under "User-defined motors" you can select motors set up with the C3 MotorManager.

For motors with holding brake SMHA or MHA brake delay times can be entered. For this see **Brake delay times** (see on page 267).

Please note the following equivalence that applies regarding terms concerning linear motors:

- ◆ **Rotary motors / linear motors**
- ◆ **Revolutions \equiv Pitch**
- ◆ **Rotation speed (velocity) \equiv Speed**
- ◆ **Torque \equiv Power**
- ◆ **Moment of inertia \equiv Load**

Notes on direct drives (see on page 447) (Linear and Torque - Motors)

4.1.3. Optimize motor reference point and switching frequency of the motor current

Optimization of the motor reference point

The motor reference point is defined by the reference current and the reference (rotational) speed.

Standard settings are:

- ◆ Reference current = nominal current
- ◆ Reference (rotational) speed = nominal (rotational) speed

These settings are suitable for most cases.

The motors can, however, be operated with different reference points for special applications.

- ◆ By reducing the reference (rotational) speed, the reference current can be increased. This results in more torque with a reduced speed.
- ◆ For applications where the reference current is only required cyclically with long enough breaks in between, you may use a reference current higher than I_0 . The limit value is however reference current = max. $1.33 \cdot I_0$. The reference velocity must also be reduced.

The peak current is not changed from Release R09-20, it remains fixed to the value taken from the motor library.

With exception of R09-20, the peak current was also adapted with the changing of the reference current.

The possible settings or limits result from the respective motor characteristics.

Caution!

Wrong reference values (too high) can cause the motor to switch off during operation (because of too high temperature) or even cause damage to the motor.



Optimization of the switching frequency

The switching frequency of the power output stage is preset to optimize the operation of most motors.

It may, however, be useful to increase the switching frequency especially with direct drives in order to reduce the noise of the motors. Please note that the power output stage must be operated with reduced nominal currents in the case of increased switching frequencies.

The switching frequency may only be increased.

Caution!

By increasing the motor current switching frequency, the nominal current and the peak current are reduced.

This must already be observed in the planning stage of the plant!



The preset motor current switching frequency depends on the performance variant of the Compax3 device.

The respective Compax3 devices can be set as follows:

Resulting nominal and peak currents depending on the switching frequency**Compax3S0xxV2 at 1*230VAC/240VAC**

Switching frequency*		S025V2	S063V2
16kHz	I_{nom}	2.5A _{rms}	6.3A _{rms}
	$I_{peak} (<5s)$	5.5A _{rms}	12.6A _{rms}
32kHz	I_{nom}	2.5A _{rms}	5.5A _{rms}
	$I_{peak} (<5s)$	5.5A _{rms}	12.6A _{rms}

Compax3S1xxV2 at 3*230VAC/240VAC

Switching frequency*		S100V2	S150V2
8kHz	I_{nom}	-	15A _{rms}
	$I_{peak} (<5s)$	-	30A _{rms}
16kHz	I_{nom}	10A _{rms}	12.5A _{rms}
	$I_{peak} (<5s)$	20A _{rms}	25A _{rms}
32kHz	I_{nom}	8A _{rms}	10A _{rms}
	$I_{peak} (<5s)$	16A _{rms}	20A _{rms}

Compax3S0xxV4 at 3*400VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I_{nom}	-	-	-	15A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	-	-	-	30A _{rms}	60A _{rms}
16kHz	I_{nom}	1.5A _{rms}	3.8A _{rms}	7.5A _{rms}	10.0A _{rms}	26A _{rms}
	$I_{peak} (<5s)$	4.5A _{rms}	9.0A _{rms}	15.0A _{rms}	20.0A _{rms}	52A _{rms}
32kHz	I_{nom}	1.5A _{rms}	2.5A _{rms}	3.7A _{rms}	5.0A _{rms}	14A _{rms}
	$I_{peak} (<5s)$	3.0A _{rms}	5.0A _{rms}	10.0A _{rms}	10.0A _{rms}	28A _{rms}

Compax3S0xxV4 at 3*480VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I_{nom}	-	-	-	13.9A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	-	-	-	30A _{rms}	60A _{rms}
16kHz	I_{nom}	1.5A _{rms}	3.8A _{rms}	6.5A _{rms}	8.0A _{rms}	21.5A _{rms}
	$I_{peak} (<5s)$	4.5A _{rms}	7.5A _{rms}	15.0A _{rms}	16.0A _{rms}	43A _{rms}
32kHz	I_{nom}	1.0A _{rms}	2.0A _{rms}	2.7A _{rms}	3.5A _{rms}	10A _{rms}
	$I_{peak} (<5s)$	2.0A _{rms}	4.0A _{rms}	8.0A _{rms}	7.0A _{rms}	20A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency**Compax3HxxxV4 at 3*400VAC**

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	50A _{rms}	90A _{rms}	125A _{rms}	155A _{rms}
	$I_{peak} (<5s)$	75A _{rms}	135A _{rms}	187.5A _{rms}	232.5A _{rms}
16kHz	I_{nom}	33A _{rms}	75A _{rms}	82A _{rms}	100A _{rms}
	$I_{peak} (<5s)$	49.5A _{rms}	112.5A _{rms}	123A _{rms}	150A _{rms}
32kHz	I_{nom}	19A _{rms}	45A _{rms}	49A _{rms}	59A _{rms}
	$I_{peak} (<5s)$	28.5A _{rms}	67.5A _{rms}	73.5A _{rms}	88.5A _{rms}

Compax3HxxxV4 at 3*480VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	43A _{rms}	85A _{rms}	110A _{rms}	132A _{rms}
	$I_{peak} (<5s)$	64.5A _{rms}	127.5A _{rms}	165A _{rms}	198A _{rms}
16kHz	I_{nom}	27A _{rms}	70A _{rms}	70A _{rms}	84A _{rms}
	$I_{peak} (<5s)$	40.5A _{rms}	105A _{rms}	105A _{rms}	126A _{rms}
32kHz	I_{nom}	16A _{rms}	40A _{rms}	40A _{rms}	48A _{rms}
	$I_{peak} (<5s)$	24A _{rms}	60A _{rms}	60A _{rms}	72A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3MxxxD6 at 3*400VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	5A _{rms}	10A _{rms}	15A _{rms}	30A _{rms}
	I_{peak} (<5s)	10A _{rms}	20A _{rms}	30A _{rms}	60A _{rms}
16kHz	I_{nom}	3.8A _{rms}	7.5A _{rms}	10A _{rms}	20A _{rms}
	I_{peak} (<5s)	7.5A _{rms}	15A _{rms}	20A _{rms}	40A _{rms}
32kHz	I_{nom}	2.5A _{rms}	3.8A _{rms}	5A _{rms}	11A _{rms}
	I_{peak} (<5s)	5A _{rms}	7.5A _{rms}	10A _{rms}	22A _{rms}

Compax3MxxxD6 at 3*480VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	4A _{rms}	8A _{rms}	12.5A _{rms}	25A _{rms}
	I_{peak} (<5s)	8A _{rms}	16A _{rms}	25A _{rms}	50A _{rms}
16kHz	I_{nom}	3A _{rms}	5.5A _{rms}	8A _{rms}	15A _{rms}
	I_{peak} (<5s)	6A _{rms}	11A _{rms}	16A _{rms}	30A _{rms}
32kHz	I_{nom}	2A _{rms}	2.5A _{rms}	4A _{rms}	8.5A _{rms}
	I_{peak} (<5s)	4A _{rms}	5A _{rms}	8A _{rms}	17A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

4.1.4. Ballast resistor

If the regenerative brake output exceeds the **amount of energy that can be stored by the servo controller** (see on page 501), then an error will be generated. To ensure safe operation, it is then necessary to either

- ◆ reduce the accelerations resp. the decelerations,
- ◆ or to use an **external ballast resistor** (see on page 463).

Please select the connected ballast resistor or enter the characteristic values of your ballast resistor directly.

Please note that with resistance values greater than specified, the power output from the servo drive can no longer be dissipated in the braking resistor.

4.1.5. General drive


External moment of inertia / load

The external moment of inertia is required for adjusting the servo controller. The more accurately the moment of inertia of the system is known, the better is the stability and the shorter is the settle-down time of the control loop.


It is important to specify the minimum and maximum moment of inertia for best possible behavior under varying load.

If you do not know the moment of inertia, click on "Unknown: using default values". You have then the possibility to determine the moment of inertia by means of automatic **load identification** (see on page 227).

Minimum moment of inertia / minimum load



Maximum moment of inertia / maximum load



Enter minimum = maximum moment of inertia when the load does not vary.

4.1.6. Defining the reference system

The reference system for positioning is defined by:

- ◆ a unit,
- ◆ the travel distance per motor revolution,
- ◆ a machine zero point with true zero,
- ◆ positive and negative end limits.

4.1.6.1 Measure reference

In this chapter you can read about:

You can select from among the following for the unit:

Unit

- ◆ mm,
- ◆ increments *
- ◆ angle degrees or
- ◆ Inch.

The unit of measure is always [mm] for linear motors.


*

The unit "increments" is valid only for position values!

Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

Travel distance per motor revolution / pitch

The measure reference to the motor is created with the value: "travel distance per motor revolution / pitch" in the selected unit.




Input as numerator and denominator

You can enter the "travel distance per motor revolution" as a fraction (numerator divided by denominator). This is useful in the case of continuous operation mode or in reset mode if the value cannot be specified as a rational number. Long term drifts can be avoided by integer numerators and denominators.

Example 1:


Rotary table control



Unit: Grade
 Gear transmission ratio 70:4 => 4 load revolutions = 70 motor revolutions
 Travel distance per motor revolution = $4/70 * 360^\circ = 20.571\ 428\ 5 \dots^\circ$ (number cannot be represented exactly)
 Instead of this number, you have the option of entering it exactly as a numerator and denominator:
 Travel distance per motor revolution = 144/7
 This will not result in any drift in continuous operation mode or in reset mode, even with relatively long motion in one direction.

Example 2:

Conveyor belt



Unit: mm
 Gear transmission ratio 7:4 => 4 load revolutions = 7 motor revolutions
 Number of pinions: 12
 Tooth separation: 10mm
 Travel path per motor revolution = $4/7 * 12 * 10\text{mm} = 68.571\ 428\ 5 \dots \text{mm}$ (this number cannot be expressed exactly)
 Instead of this number, you have the option of entering it exactly as a numerator and denominator:
 Travel distance per motor revolution = 480/7 mm
 For "travel distance per motor revolution" that can be represented exactly, enter 1 as the denominator.

Travel distance per motor revolution /-pitch

Numerator

Unit: Unit	Range: depends on the unit selected	Standard value: depends on the unit selected
Resolution: 0.000 000 1 (7 decimal places)		
Unit	Division	Standard value
Increments*	10 ... 1 000 000	1024
mm	0.010 000 0 ... 2000.000 000 0	1.000 000 0
Grade	0.010 000 0 ... 720.000 000 0	360.000 000 0
Inch	0.010 000 .. 2000.000 000	1.000 000

Denominator

Unit: -	Range: 1 ... 1 000 000	Standard value: 1
Integer value		

*

The unit "increments" is valid only for position values!

Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).


Invert Motor Rotation/Direction Polarity

Unit: -	Range: no / yes	Standard value: no
Reverse direction inverts the sense of rotation, i.e. the direction of movement of the motor is reversed in the case of equal setpoint.		

Reset mode Reset mode is available for applications in which the positioning range repeats; some examples are: Rotary table applications, belt conveyor. ... After the reset travel distance (exactly specifiable as **numerator and denominator** (see on page 114)) the position values in Compax3 are reset to 0.

Example:

Conveyor belt (from the "Conveyor belt" example) with reset path



A reset path of 300 mm can be entered directly with numerator = 300 mm and denominator = 1.

Reset mode is not possible for linear motors.

Reset distance

Numerator

Unit: Unit	Range: depends on the unit selected	Standard value: depends on the unit selected
Unit	Division	Standard value
Increments	10 ... 1 000 000	0
mm	1 ... 2000	0
Grade	1 ... 720	0

Denominator

Unit: -	Range: 1 ... 1 000 000	Standard value: 0
Integer value		

Turn off reset mode

Reset mode is turned off for numerator = 0 and denominator = 0.

4.1.6.2 Machine Zero

The Compax3 machine zero modes are adapted to the CANopen profile for Motion Control CiADS402.

Position reference point

Essentially, you can select between operation with or without machine reference. The reference point for positioning is determined by using the machine reference and the machine reference offset.

Machine reference run

In a homing run the drive **normally** (see on page 117) moves to the position value 0 immediately after finding the home switch. The position value 0 is defined via the **homing offset** (see on page 304).

A machine reference run is required each time after turning on the system for operation with machine reference.



Please note:

During homing run the software end limits are not monitored.

In this chapter you can read about:


Positioning after homing run	117
Absolute encoder.....	118
Operation with MultiTurn emulation	119
Store absolute position in the feedback	119
Machine zero modes overview.....	120
Homing modes with home switch (on X12/14)	122
Machine zero modes without home switch.....	128
Adjusting the machine zero proximity switch.....	132
Machine zero speed and acceleration.....	132

Positioning after homing run


The positioning made after the home switch has been found can be switched off. For this enter in the “machine zero” window in the configuration wizard “no” under “approach MN point after MN run”.

Example Homing (MN) mode 20 (Home on homing (MN) switch) with T40 by homing offset 0

With positioning after homing run The motor stands then on 0:



Without positioning after homing run The position reached is not exactly on 0, as the drive brakes when detecting the home and stops:



Absolute encoder

Using a SinCos® or EnDat Multiturn absolute value sensor as feedback system, the absolute position can be read in over the entire travel range when switching on the Compax3. This means that a machine zero run is not necessary after the switching on (feedback may not be shifted by the absolute range while switched off).

In this case the reference only needs to be established once

- ◆ at initial commissioning time
- ◆ after an exchange of motor / feedback system
- ◆ after a mechanical modification and
- ◆ after an exchange of device (Compax3); does not apply for the "Store absolute position in feedback" function.
- ◆ after a configuration download

by carrying out a machine zero run.

The homing mode 35 "**MN at the current position**" (see on page 128)" is appropriate for this, because it is therewith possible to operate without proximity switch, but any other homing mode is possible too - if the hardware prerequisites are fulfilled.

When you have once re-established the reference, reset the machine zero run mode to "without machine zero run".

Operation with MultiTurn emulation

You can simulate the function of a Multiturn over the entire travel distance by the aid of a Multiturn emulation. A resolver or a SinCos® / EnDat Singleturn feedback is sufficient as a feedback signal from the motor.

It differs from the physical Multiturn in the way that the motor may not be moved by more than half a turn if Compax3 (24VDC) is switched off - unless the absolute position is lost.

Besides that, the Multiturn emulation offers the same function as the physical Multiturn feedback.

You can switch on the Multiturn emulation directly in the wizard.

You can assign the maximum permissible motor angle via the Multiturn validity window

If Compax3 states after switching on that this value is not exceeded, then das "Referenziert" gesetzt (Zustandswort Bit 12 oder Ausgang M.A8) is applied.

Compax3 restores nevertheless the absolute position, the motor angle is correct, the absolute position may however not be correct, if the motor was moved by more than the validity window while currentless.

Attention: In this case, the drive is considered "not referenced" and the software end limit monitoring is inactive!

Machine reference run For a unique machine zero run the same conditions apply as for the use of an absolute encoder (Multiturn).

Store absolute position in the feedback

With SinCos® or EnDat feedback systems, the absolute position can be memorized in the feedback; therefore the Compax3 device can be exchanged without loss of position.

The function is possible with Multiturn absolute value feedback systems and in combination with the "Multiturn emulation" function and is activated by selecting "Store absolute position: in the position feedback" (Configuration wizard: Reference system).

The standard setting valid up to now is "Store absolute position: in the device".

Read / write position value

The writing process into the position feedback takes place upon a successful machine zero run.

After PowerOn of Compax3, the position value of the position feedback is read out.

Please note:

- ◆ Other data stored in the feedback are overwritten!
- ◆ The motor may not move away from the homing position by more than +/-2048 revolutions (motor position upon completed homing mode), otherwise, the motor position will be lost after PowerOff/On (->endless instructions with only one travel direction or with one stroke bigger than 2048 motor revolutions are not permitted in this operating mode)!

Machine zero modes overview


Selection of the machine zero modes (MN-M)

Machine home switch on X12/14: MN-M 3 ... 14, 19 ... 30	Without motor reference point MN-M 19 ...30	without direction reversal switches: MN-M 19, 20 (see on page 122), MN-M 21, 22 (see on page 123) with reversal switches: MN-M 23, 24, 25, 26 (see on page 124), MN-M 27, 28, 29, 30 (see on page 124)
	With motor reference point MN-M 3 ... 14 (possibly an initiator adjustment (see on page 132) is required)	without direction reversal switches: MN-M 3, 4 (see on page 125), MN-M 5, 6 (see on page 126) with reversal switches: MN-M 7, 8, 9, 10 (see on page 127), MN-M 11,12,13, 14 (see on page 127)
Without machine zero initiator on X12/14: MN-M 1, 2, 17, 18, 33 .. 35, 128, 129, 130 ... 133	Without motor reference point MN-M 17, 18, 35, 128, 129	MN-M 35: on the actual position (see on page 128) MN-M 128, 129: by moving to block (see on page 128)
		With limit switch as machine zero: MN-M 17, 18 (see on page 129)
		Only motor reference: MN-M 33, 34 (see on page 130), MN-M 130, 131 (see on page 130)
		With limit switch as machine zero: MN-M 1, 2 (see on page 131), MN-M 132, 133 (see on page 132)

Definition of terms / explanations:

Motor zero point	Zero pulse of the feedback Motor feedback systems such as resolvers or SinCos® / EnDat give one pulse per revolution. Some motor feedback systems of direct drives do also have a zero pulse, which is generated once or in defined intervals. By interpreting the motor zero point (generally in connection with the machine zero initiator) the machine zero can be defined more exactly.
Machine zero initiator:	For creating the mechanical reference Has a defined position within or on the edge of the travel range.
Direction reversal switches:	Initiators on the edge of the travel range, which are used only with a machine zero run in order to detect the end of the travel range. In some cases, the function "direction reversal via Stromschwelle" is also possible, then you will need no initiator, Compax3 detects the end of the travel range via the threshold. Please observe the respective notes. During operation, the direction reversal switches are often used as limit switches.

Example axis with the initiator signals



- 1: Direction reversal / end switch on the negative end of the travel range (the **assignment of the reversal / end switch inputs** (see on page 137) to travel range side can be changed).
- 2: Machine zero initiator (can, in this example, be released to 2 sides)
- 3: Direction reversal / end switch on the positive end of the travel range (the **assignment of the reversal / end switch inputs** (see on page 137) to travel range side can be changed).
- 4: Positive direction of movement
- 5: Signals of the motor zero point (zero pulse of the motor feedback)
- 6: Signal of the machine zero initiator (**without inversion of the initiator logic** (see on page 137)).
- 7: Signal of the direction reversal resp. end switch on the positive end of the travel range (without inversion of the initiator logic).
- 8: Signal of the direction reversal / resp. end switch on the negative end of the travel range (without inversion of the initiator logic).
- 9: Signal of the machine zero initiator (**with inversion of the initiator logic** (see on page 137)).
- 10: Signal of the direction reversal resp. end switch on the positive end of the travel range (with inversion of the initiator logic).
- 11: Signal of the direction reversal / end switch on the negative end of the travel range (with inversion of the initiator logic).
- 12: Logic state of the home switch (independent of the inversion)
- 13: Logic state of the direction reversal resp. end switch on the positive end of the travel range (independent of the inversion)
- 14: Logic state of the direction reversal resp. end switch on the negative end of the travel range (independent of the inversion)

The following principle images of the individual machine zero modes always refer to the logic state (12, 13, 14) of the switches.

Homing modes with home switch (on X12/14)

In this chapter you can read about:

Without motor reference point..... 122
 With motor reference point..... 125

Without motor reference point

In this chapter you can read about:

Without direction reversal switches..... 122
 With direction reversal switches..... 123

Without direction reversal switches

MN-M 19,20: MN-Initiator = 1 on the positive side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

Without motor zero point, without direction reversal switches

MN-M 19: The negative edge of the MN proximity switch is taken directly as MN (the motor zero point remains without consideration).

MN-M 20: The positive edge of the MN proximity switch is used directly as MN (the motor zero point remains without consideration).



MN-M 21,22: MN Initiator = 1 on the negative side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

Without motor zero point, without direction reversal switches

MN-M 21: The negative edge of the MN proximity switch is taken directly as MN (the motor zero point remains without consideration).

MN-M 22: The positive edge of the MN proximity switch is used directly as MN (the motor zero point remains without consideration).



1: logic state

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see on page 137) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function “direction reversal via Stromschwelle”.

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

**Caution!**

Wrong settings can cause hazard for man and machine.


It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.

In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 23...26: Direction reversal switches on the positive side


Without motor zero point, with direction reversal switches



- 1: Logic state of the home switch
- 2: Logic state of the direction reversal switch

MN-M 27...30: Direction reversal switches on the negative side

Without motor zero point, with direction reversal switches



- 1: Logic state of the home switch
- 2: Logic state of the direction reversal switch

With motor reference point

In this chapter you can read about:

Without direction reversal switches 125
 With direction reversal switches 126

Without direction reversal switches

MN-M 3,4: MN-Initiator = 1 on the positive side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

With motor zero point, without direction reversal switches

MN-M 3: The 1st motor zero point at MN initiator = "0" is used as MN.

MN-M 4: The 1st motor reference point with MN initiator = "1" is used as the MN.



- 1: Motor zero point
- 2: Logic state of the home switch

MN-M 5,6: MN Initiator = 1 on the negative side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 continuous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

With motor zero point, without direction reversal switches

MN-M 5: The 1st motor reference point with MN initiator = "0" is used as the MN.

MN-M 6: The 1st motor reference point with MN initiator = "1" is used as the MN.



1: Motor zero point
2: Logic state of the home switch

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see on page 137) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Stromschwelle".

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

**Caution!**

Wrong settings can cause hazard for man and machine.


It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 7...10: Direction reversal switches on the positive side

With motor zero point, with direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.




- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

MN-M 11...14: With direction reversal switches on the negative side

With motor zero point, with direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.



- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

Machine zero modes without home switch


In this chapter you can read about:

Without motor reference point..... 128
 With motor reference point..... 130

Without motor reference point

MN-M 35: MN (machine zero) at the current position

The current position when the MN run is activated is used as an MN.



Please note: Due to encoder noise it is possible that a value $\neq 0$ is set when teaching to 0. If end limits = 0, an end limit error may occur during homing run.

MN-M 128/129: Stromschwelle while moving to block

Without a MN (machine zero) initiator, an end of travel region (block) is used as MN (machine zero).

For this the Stromschwelle is evaluated if the drive pushes against the end of the travel region. When the adjusted current is exceeded, the Homing is set. During the homing run (MN), the error reaction "following error" is deactivated.

Please observe:

The machine zero offset must be set so that the zero point (reference point) for positioning lies within the travel range.

MN-M 128: Travel in the positive direction to the end of the travel region




MN-M 129: Travel in the negative direction to the end of the travel region



	<p>Caution! Wrong settings can cause hazard for man and machine.</p>
--	--

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
 In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 17,18: Limit switch as machine zero

1: Logic state of the direction reversal switch

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Stromschwelle".

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

**Caution!**

Wrong settings can cause hazard for man and machine.

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

With motor reference point

In this chapter you can read about:

Machine zero only from motor reference..... 130
 With direction reversal switches..... 131

Machine zero only from motor reference


MN-M 33,34: MN at motor zero point

The motor reference point is now evaluated (no MN initiator):

Without home switch

MN-M 33: For a MN run, starting from the current position, the next motor zero point in the negative travel direction is taken as the MN.

MN-M 34: For a MN run, starting from the current position, the next motor zero point in the positive travel direction is taken as the MN.




1: Motor zero point

MN-M 130, 131: Acquire absolute position via distance coding

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).




1: Signals of the distance coding

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides. The **assignment of the direction reversal switches** (see on page 137) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function “direction reversal via Stromschwelle”. The drive drives against the mechanical end stop. When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.


	<p>Caution! Wrong settings can cause hazard for man and machine.</p>
---	---

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).


MN-M 1,2: Limit switch as machine zero

End switch on the negative side



1: Motor zero point
2: Logic state of the direction reversal switch

End switch on the positive side:




1: Motor zero point
2: Logic state of the direction reversal switch

MN-M 132, 133: Determine absolute position via distance coding with direction reversal switches

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).




1: Signals of the distance coding
2: Logic state of the direction reversal switches

Adjusting the machine zero proximity switch

This is helpful in some cases with homing modes that work with the home switch and motor reference point.

If the motor reference point happens to coincide with the position of the MN initiator, there is a possibility that small movements in the motor position will cause the machine reference point to shift by one motor revolution (to the next motor reference point).

Via status value "Distance MN sensor - motor zero", (O1130.13) you can check if the distance between machine home sensor and motor zero point is too short.



1: Motor zero point
2: Logic state of the home switch

A solution to this problem is to move the MN initiator by means of software. This is done using the value initiator adjustment.

Initiator adjustment

Unit: Motor angle in degrees	Range: -180 ... 180	Standard value: 0
Move the machine reference initiator using software As an aid you can use the status value "distance MN sensor - motor zero" in the "Positions" chapter under "status values"		

Machine zero speed and acceleration


With these values you can define the motion profile of the machine zero run.

4.1.6.3 Positioning after homing run


The positioning made after the home switch has been found can be switched off. For this enter in the “machine zero” window in the configuration wizard “no” under “approach MN point after MN run”.

Example Homing (MN) mode 20 (Home on homing (MN) switch) with T40 by homing offset 0

With positioning after homing run The motor stands then on 0:



Without positioning after homing run The position reached is not exactly on 0, as the drive brakes when detecting the home and stops:



4.1.6.4 Travel Limit Settings

Software end limits


The error reaction when reaching the software end limits can be set:
Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

If "no reaction" was set, no software limits must be entered.

Software end limits:


The travel range is defined via the negative and positive end limits.



- 1: negative end limit
2: positive end limit

Software end limit in absolute operating mode

The positioning is restricted to the range between the travel limits.
A positioning order aiming at a target outside the travel range is not executed.



- 1: negative end limit
2: positive end limit

The reference is the position reference point that was defined with the machine reference and the machine reference offset.

Software end limits in reset mode

The reset mode does not support software end limits

Software end limit in continuous mode

Each individual positioning is confined within the travel limits.
 A positioning order aiming at a target outside the software end limits is not executed.
 The reference is the respective current position.

Error when disregarding the software end limits

A software end limit error is triggered, if the position value exceeds an end limit.
 For this, the position setpoint value is evaluated in energized state; in currentless state, the actual position value is evaluated.

Hysteresis in disabled state:

If the axis stands currentless at an end limit, another error may be reported due to position jitter after acknowledging the end limit error. To avoid this, a hysteresis surrounding the end limits was integrated (size corresponds to the size of the positioning window).
 Only if the distance between axis and the end limits was larger than the positioning window, another end limit error will be detected

Error codes (see on page 439) of the end limit errors:

- 0x7323 Error when disregarding the positive software end limit.
- 0x7324 Error when disregarding the negative software end limit.

Activating / deactivating the end limit error:

In the C3 ServoManager under configuration: End limits, the error can be (de)activated.
 For IEC-programmable devices with the "C3_ErrorMask" module.

Behavior after the system is turned on


The end limits are not active after switching on. The end limits do not refer to the position reference point until after a machine reference run.
 During homing run the end limits are not monitored.
 With a Multiturn encoder or with active Multiturn emulation, the limit is valid immediately after switching on.

Behavior outside the travel range

1. If the software end limit errors are deactivated, all movements are possible.

2. If the software end limit errors are activated:

After disregarding the software end limits, an error is triggered. First of all, this error must be acknowledged.
 Then a direction block is activated: only motion commands in the direction of the travel range are executed. These will not trigger another error.
 Motion commands inciting a movement in the opposite direction of the travel range are blocked and will trigger another error.



- 1: negative end limit
- 2: positive end limit

Notes on special feedback systems (Feedback F12)

During automatic commutation, the end limit monitoring is deactivated!

Behavior with software end limits of a referenced axis

	Position within target outside	Position outside target outside and aiming in the opposite direction of the travel range	Position outside target within and aiming in the direction of the travel range
--	---------------------------------------	---	---

JOG +/-	<ul style="list-style-type: none"> ◆ Positioning up to the end limits ◆ No Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ No Error 	<ul style="list-style-type: none"> ◆ Positioning
MC_MoveAbsolute, MC_MoveRelative, MC_MoveAdditive, C3_MoveSuperImposed	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ Positioning
MC_GearIn, MC_Cam... C3_Cam...	<ul style="list-style-type: none"> ◆ Positioning up to the end limits, from these on braking with the error ramp. The end limit is exceeded ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error
MC_MoveVelocity	<ul style="list-style-type: none"> ◆ Positioning up to the end limits ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ Positioning
MC_Home	<ul style="list-style-type: none"> ◆ No monitoring of the software end limits 		

The software end limit error can be deactivated in general via the configuration or separately for each end limit via the **C3_Error_Mask** (see on page 315) module.

Hardware end limits

The error reaction when reaching the hardware end limits can be set:

Possible settings for the error reaction are:


- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

Hardware end limits are realized with the aid of end switches.

These are connected to X12/12 (input 5) and X12/13 (input 6) and can be (de)activated separately in the C3 ServoManager under Configuration: End limits.

After a limit switch has been detected, the drive decelerates with the ramp values set for errors (error code 0x54A0 at X12/12 active, 0x54A1 at X12/13 active) and the motor is switched to currentless.

Please make sure that after the detection of the end switch there is enough travel path left up to the limit stop.



- 1: Limit switch E5 (X12/12)
- 2: Limit switch E6 (X12/13)
- 3: Limit switch position E5 (X12/12)
- 4: Limit switch position E6 (X12/13)

The **assignment of the limit switches** (see on page 137) can be changed!

Please note: The limit switches must be positioned so that they cannot be released towards the side to be limited.

Limit switch / direction reversal switch
Behavior in the case of an active limit switch

Limit switches functioning as direction reversal switches during homing run, will not trigger a limit switch error.

The error can be acknowledged with activated limit switch.
 The drive can then be moved out of the end switch range with a normal positioning.
 Both directions of movement are possible.
 A direction block can be programmed in the IEC program with the aid of the limit switch bits or the error message.

(De)activate limit switch errors

The limit switch error can be deactivated in general via the configuration or separately for each limit switch via the **C3_Error_Mask module** (see on page 315).

Debouncing: Limit switch, machine zero and input 0

A majority gate is used for debouncing.
 The signal is sampled every 0.5ms
 The debounce time determines the number of scans the majority gate will perform.
 If the level of more than half of the signals was changed, the internal status will change.
 The debounce time can be set in the configuration wizard within the range of 0 ... 20ms.
 The value 0 deactivates the debouncing.

If the debouncing time is stated, the input I0 can be debounced as well (checkbox below).

4.1.6.5 Change assignment direction reversal / limit switches

If this function is not activated, the direction reversal / end switches are assigned as follows:

Direction reversal / limit switch on I5 (X12/12): negative side of the travel range
 Direction reversal / limit switch on I6 (X12/13): positive side of the travel range

Change assignment of direction reversal / limit switch is activated

If this function is activated, the direction reversal / limit switches are assigned as follows:

Direction reversal / limit switch on **I5** (X12/12): **positive side** of the travel range
 Direction reversal / limit switch on **I6** (X12/13): **negative side** of the travel range

4.1.6.6 Change initiator logic

The initiator logic of the limit switches (this does also apply for the direction reversal switches) and the machine zero initiator can be changed separately.

- ◆ Limit switch E5 low active
- ◆ Limit switch E6 low active
- ◆ Home switch E7 low active

In the basic settings the inversion is deactivated, so that the signals are "high active".

With this setting the inputs I5 to I7 can even be switched within their logic, if they are not used as direction reversal/limit switches or machine zero.

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)


4.1.7. Defining jerk / ramps

In this chapter you can read about:

Ramp upon error and stromlos schalten 138

4.1.7.1 Ramp upon error and stromlos schalten

Ramp (delay) upon error and "stromlos schalten"



3: Deceleration upon error and upon deactivation of **MC_Power** (see on page 280)

Please observe:

The configured error ramp is limited. The error ramp will not be smaller than the deceleration set in the last motion set.

4.1.8. Limit and monitoring settings

In this chapter you can read about:

Current (Torque) Limit 138

Positioning window - Position reached 138

Following error limit 139

Maximum operating speed 139

4.1.8.1 Current (Torque) Limit

The current required by the speed controller is limited to the current limit.

4.1.8.2 Positioning window - Position reached


Position reached indicates that the target position is located within the position window.

In addition to the position window, a position window time is supported. If the actual position goes inside the position window, the position window time is started. If the actual position is still inside the position window after the position window time, "Position reached" is set.

If the actual position leaves the position window within the position window time, the position window time is started again.

When the actual position leaves the position window with Position reached = "1", Position reached is immediately reset to "0".

Position monitoring is active even if the position leaves the position window because of measures taken externally.



1: Position Window

2: In Position Window Time

3: Setpoint position reached (== object 420.6
C3.PositioningAccuracy_PositionReached)

4.1.8.3 Following error limit

The error reaction upon a following error can be set:

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

The following error is a dynamic error.

The dynamic difference between the setpoint position and the actual position during a positioning is called the following error. Do not confuse this with the static difference which is always 0; the target position is always reached exactly.

The change of position over time can be specified exactly using the parameters jerk, acceleration and speed. The integrated Setpoint value generator calculates the course of the target position. Because of the delay in the feedback loop, the actual position does not follow the target position exactly. This difference is referred to as the following error.

Disadvantages caused by a following error

When working with a number of servo drives (for example Master controller and slave controller), following errors lead to problems due to the dynamic position differences, and a large following error can lead to positioning overshoot.


Error message

If the following error exceeds the specified following error limit, the “following error time” then expires. If the following error is even greater than the following error limit at the end of the following error time, an error is reported.

If the following error falls short of the following error limit, a new following error time is then started.

Minimizing the following error

The following error can be minimized with the help of the extended (advanced) control parameters, in particular with the feed forward parameters.



1: Following error limit [parameterized unit]

2: Following Error Time

ERROR: Error output of positioning modules

ACKN: Ackn with MC_Reset module

4.1.8.4 Maximum operating speed

The speed limitation is deduced from the maximum operating speed. In order to ensure control margins, the speed is limited to a higher value.

The speed setpoint value is actively limited to 1.1 times the given value.

If the speed actual value exceeds the preset maximum speed by 21% (=“switching off limit speed”), error 0x7310 is triggered.

4.1.9. Encoder simulation

You can make use of a permanently integrated encoder simulation feature to make the actual position value available to additional servo drives or other automation components.

Position of zero pulse:

Before R09-40 the zero pulse is coupled fixedly to the motor zero point (zero crossing of the feedback position without absolute reference). This resulted in a unequivocal and repeatable zero pulse position at all feedback devices (Resolver, SinCos(R), EnDat, analogue Hallsensors, at C3Fluid: SSI-feedback system, analogue feedback).

With R09-40 the zero pulse is adjustable in the range of -180...180 (object 0620.6) - furthermore teaching of the zero pulse for the actual motor position is possible by writing 0620.7 with -1 or by entering ":TEACH_ENC_SIM_ZERO" in the entry field of the optimization window.

Zero pulse with multiple pole feedback sensor:

With these feedback systems the simulation does not refer to the mechanical motor position but to the feedback position, this means the correct quantity of A/B pulses is put out to a motor revolution respectively to a motor pitch, however the zero pulse output multiply occurs within one motor revolution respectively within one motor pitch. (Quantity=figure pair of feedback pole=feedback pole figure/2).

At linear feedback systems 50mm correspond to a virtual motor revolution.

Caution!

- ◆ The encoder simulation (A/B) is not possible at the same time as the encoder input, der SSI-Schnittstelle resp. the step/direction input.
The same interface is used here.
- ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.

Simulated Encoder Output Resolution

Unit: Increments per revolution / pitch	Range: 4 - 16384	Standard value: 1024
Any resolution can be set Limit frequency: 620kHz (track A or B) i.e. , with:		
Increments per revolution	max. Velocity	
1024	36000 rpm	
4096	9000 rpm	
16384	2250 rpm	

4.1.9.1 Encoder bypass with Feedback module F12 (for direct drives)

If the feedback module F12 is used, the encoder signals can be placed directly (Bypass) to the encoder interface (X11: same assignment as encoder simulation) for further use. Sine/Cosine signals are directly converted into encoder signals, however no additional zero pulse is generated; an available zero pulse will be transmitted.

The advantage is, that the limit frequency** is 5MHz instead of 620kHz (track A or B). The direction of rotation is only defined via the encoder wiring; a direction inversion configured in the C3 ServoManager does not have any consequence.

** Limit frequency = 1MHz for Compax3M (higher bandwidths on request)

4.1.10. Recipe table

If you would like to work with the **Recipe table** (see on page 273), (e.g. for memorizing variable machine data) you can make preassignments in it with Compax3 ServoManager.

Note:

The recipe array can also be loaded separately into the device (>button on the right side).

Row	Column 1 REAL	Column 2 REAL	Column 3 INT	Column 4 INT	Column 5 INT	Column 6 DINT	Column 7 DINT	Column 8 DINT	Column 9 DINT
1	0.000000	0.000000	0	0	0	0	0	0	0
2	0.000000	0.000000	0	0	0	0	0	0	0
3	0.000000	0.000000	0	0	0	0	0	0	0
4	0.000000	0.000000	0	0	0	0	0	0	0
5	0.000000	0.000000	0	0	0	0	0	0	0
6	0.000000	0.000000	0	0	0	0	0	0	0
7	0.000000	0.000000	0	0	0	0	0	0	0
8	0.000000	0.000000	0	0	0	0	0	0	0
9	0.000000	0.000000	0	0	0	0	0	0	0
10	0.000000	0.000000	0	0	0	0	0	0	0
11	0.000000	0.000000	0	0	0	0	0	0	0
12	0.000000	0.000000	0	0	0	0	0	0	0
13	0.000000	0.000000	0	0	0	0	0	0	0
14	0.000000	0.000000	0	0	0	0	0	0	0
15	0.000000	0.000000	0	0	0	0	0	0	0
16	0.000000	0.000000	0	0	0	0	0	0	0
17	0.000000	0.000000	0	0	0	0	0	0	0
18	0.000000	0.000000	0	0	0	0	0	0	0
19	0.000000	0.000000	0	0	0	0	0	0	0
20	0.000000	0.000000	0	0	0	0	0	0	0
21	0.000000	0.000000	0	0	0	0	0	0	0

4.1.11. Error response

Under "configuring: Error reaction" you can change the error reaction for individual **errors** (see on page 439) (the error no. which can be influenced is displayed).

Possible settings for the error reaction are:


- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)


Note on Compax3H:

The error reaction upon the "low voltage DC" error (0x3222) is fixed to "downramp/deenergize" for Compax3H.

4.1.12. Configuration name / comments

Here you can name the current configuration as well as write a comment. Then you can download the configuration settings or, in T30 or T40 devices, perform a complete Download (with IEC program and curve).

	<p>Caution! Deactivate the drive before downloading the configuration software!</p> <p>Please note! Incorrect configuration settings entail danger when activating the drive. Therefore take special safety precautions to protect the travel range of the system.</p>
---	--

	<p>Mechanical limit values! Observe the limit values of the mechanical components! Ignoring the limit values can lead to destruction of the mechanical components.</p>
---	---

4.2 Configuring the signal source

Possible master signal sources

Under the tree entry "Configuring the signal source" of the C3 ServoManager you can configure the signal sources for Master - Slave applications.

The master signal source can then be selected in the IEC program with the aid of the C3_MasterControl module via the input "Master".

The following signal sources are available:

- ◆ Physical source
 - analog value above +/-10V
 - Encoder signal A/B (5V)
 - Step/Direction signal (5V)
 - SSI - Geber
- ◆ Internal virtual master (IEC program) (only T40)
- ◆ HEDA

Note on Compax3 firmware versions < 2.05

The "use as current signal source" CheckBox can be found in the signal source configuration wizards.

This CheckBox is only relevant for the Compax3 firmware versions <V2.05; it is used to define the signal source for the CoDeSys program.

Otherwise, the signal source is directly selected at the IEC module.

In this chapter you can read about:

Signal source of the load feedback system	143
Physical Source	143
Internal virtual master	147
Fieldbus master	147
HEDA Master signal source	147

4.2.1. Signal source of the load feedback system

Configuration of the **load control** (see on page 149) (Dual Loop Option)

4.2.2. Physical Source

In this chapter you can read about:

Encoder A/B 5V, step/direction or SSI feedback as signal source	144
+/-10V Master speed	146

4.2.2.1 Encoder A/B 5V, step/direction or SSI feedback as signal source

- Caution!**
- ◆ The encoder simulation (A/B) is not possible at the same time as the encoder input, der SSI-Schnittstelle resp. the step/direction input.
The same interface is used here.
 - ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.
- The dimensional reference to the master is established via the following settings:
- ◆ Travel path per motor revolution (or pitch for linear motors) master axis numerator
With denominator = 1 the value can be entered directly.
Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.
 - ◆ Travel per motor revolution (or pitch of linear motors) master axis denominator
 - ◆ Increments per revolution of the master axis
- If required the direction of rotation of the master axis read in can be changed.

Example: Electronic gearbox with position detection via encoder

Reference to master axis The reference to the master axis is established via the increments per revolution and the travel path per revolution of the master axis (corresponds to the circumference of the measuring wheel).

That is:

$$\text{MasterPos} = \frac{\text{Master_I}}{\text{I_M}} * \frac{\text{Travel Distance per Master Axis revolution}}{\text{Travel Distance per Master Axis revolution - Denominator}} \quad (1)$$

MasterPos: Master Position

Master_I: master increments read in

I_M: Increments per revolution of the master axis

External signal source Encoder with 1024 increments per master revolution and a circumference of the measuring wheel of 40mm.

Settings: Travel path per revolution of the master axis numerator = 40
Travel path per revolution of the master axis denominator = 1
Increments per revolution of the master axis = 1024

Configuration wizard: Reference system of Slave axis: Unit of measure [mm]
Travel path per revolution numerator = 1
Travel path per revolution denominator = 1

Gearing: Gearing numerator = 2
Gearing denominator = 1

This results in the following interrelations:

If the measuring wheel moves by 40mm (1 master revolution), the slave axis will move by 80mm.


$$\text{Slave unit} = \text{MasterPos} * \frac{\text{Gearing numerator}}{\text{Gearing denominator}} \quad (2)$$

(1) set into (2) and with numerical values results with 1024 increments read in (=1 Master revolution):

$$\text{Slave unit} = 1024 * \frac{1}{1024} * \frac{40\text{mm}}{1} * \frac{2}{1} = 80\text{mm}$$

Master - Position = +40mm => Slave - Position = +80mm

Structure:



Detailed structure image (see on page 220, see on page 221, see on page 222) with:

$$MD = \frac{Z1}{N1} * \frac{\text{Travel Distance per Master Axis revolution}}{\text{Travel Distance per Master Axis revolution - Denominator}}$$

Entry in the "configuration of the signal source" wizard

$$SD = \frac{Z2}{N2} * \frac{\text{Travel path per revolution slave axis numerator}}{\text{Travel path per revolution slave axis denominator}}$$

Entry in the "configuration of the signal source" wizard

MD: Feed of the master axis
SD: Feed of the slave axis

SSI configuration

Notes on the SSI sensor (see on page 145)


- ◆ With Multiturn: Number of sensor rotations with absolute reference
- ◆ Word length: Gives the telegram length of the sensor.
- ◆ Baud rate/step: Max. Transmission rate of the path measurement system.
- ◆ Gray code: Sensor gray code coded yes/no (if no binary coded).

Note:

The absolute position is not evaluated!
 It is available in the objects 680.24 (load position) and 680.25 (master position) (C3T30, C3T40).

General requirements for supported SSI feedbacks

- ◆ Baud rate: 350k ... 5MBaud
- ◆ Word length: 8 ... 32 Bit
- ◆ Binary or gray code (start value = 0)
- ◆ Initialization time after PowerOn: < 1,1s
- ◆ Signal layout:



The most significant bit must be transmitted the first!

Caution! Feedback systems, transmitting data containing error or status bits are not supported!


◆ Examples of supported SSI feedback systems:

- ◆ IVO / GA241 SSI;
- ◆ Thalheim / ATD 6S A 4 Y1;
- ◆ Hübner Berlin / AMG75;
- ◆ Stegmann / ATM60 & ATM90;
- ◆ Inducoder / SingleTurn: EAS57 & Multiturn: EAMS57

4.2.2.2 +/-10V Master speed

Via Analogkanal 0 (X11/9 und X11/11) the speed of the master is read in. From this value a position is internally derived.

Signal processing of the analog input 0



B: Continuative structure image (see on page 220)

The reference to the master is established with the velocity at 10V.


If required the direction of rotation of the master axis read in can be changed.

Time frame signal source master

Averaging and a following filter (interpolation) can help to avoid steps caused by discrete signals.

If the external signal is analog, there is no need to enter a value here (Value = 0).

For discrete signals e.g. from a PLC, the scanning time (or cycle time) of the signal source is entered.



This function is only available if the analog interface +/-10V is used!

4.2.3. Internal virtual master

In this chapter you can read about:

Only Compax3 T40!

The reset distance of the virtual master is only used for resetting the displayed value (Object680.2).

The travel per motor revolution of the master axis (numerator/denominator) is set to 1 for a virtual master.

If required the direction of rotation of the master axis read in can be changed.

4.2.4. Fieldbus master

Only for Compax3 with the following fieldbusses:


- ◆ CanOpen
- ◆ Ethernet Powerlink
- ◆ EtherCAT

If required the direction of rotation of the master axis read in can be changed.

4.2.5. HEDA Master signal source

Please choose if the virtual master of the HEDA master is transmitted via the HEDA. If yes, the input “travel per revolution” is not necessary, as a positioning signal is already present.

Here the dimensional reference to the master position is established.



The position value are transferred via channel 1.

1) Select the position value to be transferred on the Compax3 HEDA-Master (Target position value, actual position value, external position value or position value of the virtual Master)).

2)By specifying the source under "Configuration: Configuration of the signal source:HEDA", most of the reference values are pre-set.

◆ Standard source

Position value of the rotative drives

Travel path per motor revolution master axis numerator

With denominator = 1 the value can be entered directly.

Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.

◆ Position value of virtual master of Compax3 T40

◆ Position value of linear motor (mm)

Please enter pitch length in mm

◆ Position value of linear motor (inch)

Please enter pitch length in inch

◆ Position value of hydraulic cylinder - linear feedback (metric) of Compax3F

◆ Position value of hydraulic cylinder - linear feedback (imperial) of Compax3F

◆ Position value of hydraulic cylinder - rotary feedback of Compax3F

1) Select the position value to be transferred on the Compax3 HEDA-Master (Target position value, actual position value, external position value or position value of the virtual Master)).

If required the direction of rotation of the master axis read in can be changed.

4.3 Load control

In this chapter you can read about:

Configuration of load control	150
Error: Position difference between load mounted and motor feedback too high	151
Load control signal image	151

The load control can be activated via an additional feedback system for the acquisition of the actual position of the load.

This helps for example compensate the slip between material and roller or non-linearities of the mechanic parts.

The load position is set to the demand position.

Please note:

- ◆ This function is not available in the C3I10T10 and C3I11T11 devices.
- ◆ As a sensor signal, **Encoder** (see on page 508) with A/B track, Step/Direction signal or SSI - sensor is supported.
- ◆ This controller structure improves the stationary precision at the load after the decay of all control movements.
An increase of the dynamic precision (faster transient response) can in general not be reached with the "load control" structure variant.

Notes on the SSI sensor (see on page 145)

- ◆ With Multiturn: Number of sensor rotations with absolute reference
- ◆ Word length: Gives the telegram length of the sensor.
- ◆ Baud rate/step: Max. Transmission rate of the path measurement system.
- ◆ Gray code: Sensor gray code coded yes/no (if no binary coded).


Note:

The absolute position is not evaluated!

It is available in the objects 680.24 (load position) and 680.25 (master position) (C3T30, C3T40).

General requirements for supported SSI feedbacks

- ◆ Baud rate: 350k ... 5MBaud
- ◆ Word length: 8 ... 32 Bit
- ◆ Binary or gray code (start value = 0)
- ◆ Initialization time after PowerOn: < 1,1s
- ◆ Signal layout:



The most significant bit must be transmitted the first!

Caution! Feedback systems, transmitting data containing error or status bits are not supported!

- ◆ Examples of supported SSI feedback systems:
 - ◆ IVO / GA241 SSI;
 - ◆ Thalheim / ATD 6S A 4 Y1;
 - ◆ Hübner Berlin / AMG75;
 - ◆ Stegmann / ATM60 & ATM90;
 - ◆ Inducoder / SingleTurn: EAS57 & Multiturn: EAMS57

4.3.1. Configuration of load control

Configuration in the "configure signal source" wizard under "load feedback system":

- ◆ The selection of the feedback signal activates the acquisition and the signals are available as **status values** (see on page 151).
- ◆ Rotatory or linear feedback systems are supported.
- ◆ Input values for rotatory feedback systems:
 - ◆ Increments per feedback revolution (physical, without quadruplication)
 - ◆ Direction reversal

Attention!With wrong sense of direction and active load control, you will get a positive feedback; the motor will accelerate in an uncontrolled way
Solution: Before the load control is activated, the signals must be checked with the aid of the **status values** (see on page 151) and secured against wrong sense of direction by configuring a "maximum difference to motor position" (O410.6).
 - ◆ Load travel per feedback revolution: Is used for establishing the measure reference between load- and motor position.
The value can be configured very precisely by entering numerator and denominator.
- ◆ Input values for linear feedback system
 - ◆ Feedback resolution (physical, without quadruplication)
Position difference, which corresponds to a cycle duration of the feedback signal.
 - ◆ Direction reversal

Attention!With wrong sense of direction and active load control, you will get a positive feedback; the motor will accelerate in an uncontrolled way
Solution: Before the load control is activated, the signals must be checked with the aid of the **status values** (see on page 151) and secured against wrong sense of direction by configuring a "maximum difference to motor position" (O410.6).
 - ◆ Scaling factor for an additional adaptation of the feedback signal (is normally not required = 1)
- ◆ Maximum difference to the motor position
Upon exceeding this value, Compax3 will report **error 7385hex** (see on page 151) (29573dec)
- ◆ Intervention limitation (O2201.13 in % of the reference velocity or reference speed);
only active with position controller I component switched off (O2200.25=0)
You can use this specification in order to limit position correction intervention, i.e. to limit the velocity correction factor resulting from the position difference. This can be especially sensible during the acceleration phase, if the material slips because of too high corrective velocities.
- ◆ Activate / Deactivate load control

Attention!

**The load control is immediately active after the configuration download!
Please do only activate after checking the load position signal (scaling,
direction, value).**

Alignment of the load control:

There is an **Alignment of the position values** of motor and load under the following operating conditions (Load position = Motor position):

- ◆ During a **Machine zero run** the load control is deactivated until the position value 0 (defined via the machine zero offset) was approached. Then an alignment of the position values is performed and the load control is activated.
- ◆ After switching on Compax3.
- ◆ When writing "1" into object 2201.2
- ◆ When activating the load control.

Continuous mode

In continuous operation (object 1111.8 <> 0) an alignment of the position values of motor and load (load position = motor position) takes place upon each new positioning command.

Application: e.g. roller feed

4.3.2. Error: Position difference between load mounted and motor feedback too high

The (unfiltered) position difference between motor feedback and load feedback has exceeded the "maximum difference to motor position" value (O410.6)

The load position in the position controller is deactivated.


In order to re-activate the function (after eliminating the cause of the error), you have the following possibilities:

- ◆ Activate function in configuration and perform configuration download or enter True (-1) into O2201.1
- ◆ Perform Ackn and/or Homing (function becomes effective after homing run).

Caution!

The position difference is aligned to zero when switched on again, i.e. the original position reference is lost. Therefore it is advisable to approach the reference point again in this case (Machine zero run or Homing).

4.3.3. Load control signal image



Description of the objects (see on page 415)

4.4 Optimization

- ◆ Select the entry "**Optimization**" in the tree.
- ◆ Open the optimization window by clicking on the "**Optimization Tool**" button.


In this chapter you can read about:

Optimization window.....	152
Scope.....	153
Controller optimization.....	160
Signal filtering with external command value.....	220
Input simulation.....	223
Setup mode.....	224
Load identification.....	227
Alignment of the analog inputs.....	229
C3 ServoSignalAnalyzer.....	231
ProfileViewer for the optimization of the motion profile.....	265
Turning the motor holding brake on and off.....	267

4.4.1. Optimization window

Layout and functions of the optimization window

- | | |
|---------------------|--|
| Segmentation | Functions (TABs) |
| Window 1: | ◆ Oscilloscope (see on page 153) |
| Window 2: | ◆ Optimization: Controller optimization |
| | ◆ D/A Monitor (see on page 438): Output of status values via 2 analog outputs |
| | ◆ Scope Settings |
| Window 3: | ◆ Status Display |
| | ◆ Compax3 Error History |
| Window 4: | ◆ Status values |
| | ◆ Commissioning: Setup mode (see on page 224) with load identification (see on page 227) |
| | ◆ Parameters for commissioning, test movements (relative & absolute) and for load identification. |



4.4.2. Scope

The integrated oscilloscope function features a 4-channel oscilloscope for the display and measurement of signal images (digital and analog) consisting of a graphic display and a user interface.


Special feature:

In the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement into the ServoManager later.

In this chapter you can read about:

Monitor information.....	153
User interface.....	154
Example: Setting the Oscilloscope.....	158

4.4.2.1 Monitor information








- 1: Display of the trigger information
- 2: Display of the operating mode and the zoom setting
- ◆ 2a: Green indicates, that a measurement is active (a measurement can be started or stopped by clicking here).
- ◆ 2b: Active channel: The active channel can be changed sequentially by clicking here (only with valid signal source).
- 3: Trigger point for Single and Normal operating mode
- 4: Channel information: Type of display and trigger setting; choice of the active channel
- 5: X-DIV: X deviation set
- 6: Single channel sources

Cursor modes -functions

Depending on the operating mode, different cursor functions are available within the osci monitor.

The functions can be changed sequentially by pressing on the right mouse button.


Cursor Symbol	Function
	Set Marker 1 the measurement values of the active channel as well as the Y difference to marker 2 are displayed
	Set Marker 2
	Delete and hide marker
	Move offset of the active channel. The yellow symbol indicates that the scrolling is active.
	Set trigger level and pretrigger

In the ROLL operating mode, marker functions and set trigger level positions are not available.

4.4.2.2 User interface

In this chapter you can read about:

Oscilloscope operating mode switch:.....	155
Setting the time basis XDIV.....	155
Settings for channels 1..4.....	156
Trigger settings.....	157
Special functions.....	157



- 1: **Operating mode switch** (see on page 155) (Single / Normal / Auto / Roll)
- 2: **Setting the time basis** (see on page 155)
- 3: Starting / Stopping the measurement (prerequisites are valid channel sources and if necessary valid trigger settings.)
- 4: **Setting channel** (see on page 156) (Channels 1 ..4)
- 5: **Special functions** (see on page 157) (Color settings; memorizing settings and measurement values)
- 6: Loading a measurement from Compax3: in the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement later.
- 7: **Setting triggering** (see on page 157)
- 8: Copy osci display to clipboard
- 9: Zoom of the osci display (1, 2, 4, 8, 16 fold) with the possibility to shift the zoom window (<,>)

Oscilloscope operating mode switch:

Oscilloscope operating mode switch:



Selection of the desired operating mode: SINGLE, NORMAL; AUTO and ROLL by clicking on this button.

Changing the operating mode is also permitted during a measurement. The current measurement is interrupted and started again with the changed settings.

The following operating modes are possible:


Operating mode	Short description
SINGLE	Single measurements of 1-4 channels with trigger on a freely selectable channel
NORMAL	Like Single, but after each trigger event, the measurement is started again.
AUTO	No Trigger. Continuous measuring value recording with the selected scanning time or XDIV setting
ROLL	Continuous measuring value recording of 1 .. 4 channels with selectable scanning time and a memory depth of 2000 measuring values per channel.

With SINGLE / NORMAL / AUTO, the measurement is made in Compax3 and is then loaded into the PC and displayed.

With ROLL, the measuring values are loaded into the PC and displayed continuously.

Setting the time basis XDIV

Setting the time basis XDIV



Depending on the selected operating mode, the time basis can be changed via the arrow keys.

For the operating modes **SINGLE**, **NORMAL** and **AUTO**, the following **XDIV** time settings are possible:


XDIV	Scanning time	Samples DIV/TOTAL	Measuring time
0.5 ms	125 us	4/40	5 ms
1.0 ms	125 µs	8/80	10 ms
2.0 ms	125 µs	16/160	20 ms
5.0 ms	125 µs	40/400	50 ms
10.0 ms	125 µs	80/800	100 ms
20.0 ms	1 ms	20/200	200 ms
50.0 ms	1 ms	50/500	500 ms
100.0 ms	2 ms	50/500	1 s
200.0 ms	2.5 ms	80/800	2 s
500.0 ms	10 ms	50/500	5 s
1s	12.50 ms	80/800	10 s
2s	25.00 ms	80/800	20 s
5s	62.50 ms	80/800	50s
10s	125.00 ms	80/800	100 s

For the operating mode **ROLL**, the following **XDIV** time settings are possible:

XDIV	Scanning time	Samples DIV/TOTAL
400 ms	2 ms	200/2000
1 s	5 ms	200/2000
2 s	10 ms	200/2000
4 s	20 ms	200/2000
10 s	50 ms	200/2000
20 s	100 ms	200/2000
40 s	200 ms	200/2000
100 s	500 ms	200/2000
200 s	1 s	200/2000

Changing the time basis is also permitted during an OSCI measuring sequence. This means, however, that the current measurement is interrupted and started again with the changed settings.

Settings for channels 1..4



1: Select channel color

2: Open menu for channel-specific settings

- ◆ **Resetting channel CH 1..4:** All channel settings are deleted.
Please note: Channels can only be filled with sources one after the other. It is, for example, not possible to start a measurement which has only a signal source for channel 2!
- ◆ **Select channel color:** Here you can change the color of the channel.
- ◆ **Show/hide channel:** Hide/show display of the channel.
- ◆ **Change logic display mask:** Mask bits in logic display.
- ◆ **Autoscale:** Calculating YDIV and offset: The program calculates the best settings for YDIV and channel offset in order to display the complete signal values optimally.

3: Set signal source with object name, number and if necessary unit


- ◆ Define source: Draw the desired status object with the mouse (drag & drop) from the "Status value" window (right at the bottom) into this area.
Multiple oscilloscope in Compax3M: select device in addition to the object.

4: Set Channel offset to 0**5: Select channel display (GND, DC, AC, DIG)**

- ◆ **DC**: Display of the measurement values with constant component
- ◆ **AC**: Display of the measurement values without constant component
- ◆ **DIG**: Display of the individual bits of an INT signal source.
The displayed bits can be defined via the logic display mask.
- ◆ **GND**: A straight line is drawn on the zero line.

6: Set Y-amplification (YDIV)

Change of the Y amplification YDIV in the stages 1, 2, 5 over all decades.
Arrow upwards increases YDIV, arrow downwards diminishes YDIV.
The standard value is 1 per DIV.
The measurement value of the channel at the cursor cross is displayed.

Trigger settings

Select trigger channel: Buttons C1, C2, C3, C4

Select trigger mode: DC, AC, DG

Selecting the trigger edge: Rising / or falling \.

The pretrigger as well as the trigger level are set by clicking on the trigger cursor (



) directly in the OSCI display.

Special functions

Menu with special oscilloscope functions such as memorizing or loading settings.

Functions:

- ◆ **Select background color**: Adapt background color to personal requirements.
- ◆ **Select grid color**: Adapt grid color to personal requirements.
- ◆ **Memorize OSCI settings in file**: The settings can be memorized in a file on any drive. The file ending is *.OSC.
- ◆ The format corresponds to an INI file and is presented in the appendix.
- ◆ **Open OSCI settings from file**: Loading a memorized set of settings. The file ending is *.OSC.
- ◆ **Memorizing OSCI settings in the project**: Up to four sets of OSCI settings can be memorized in the current C3 ServoManager project. .
- ◆ **Open OSCI settings from project**: If settings were memorized in the project, they can be read in again.
- ◆ **Memorize OSCI measurement in file**: Corresponds to memorizing the setting; the measurement values of the measurement are stored in addition. Thus it is possible to memorize and read measurements completely with settings. The file ending is *.OSM.
- ◆ **Export measure samples to csv file**: e.g. for reading into Excel.

4.4.2.3 Example: Setting the Oscilloscope

SINGLE measurement with 2 channels and logic trigger on digital inputs

The order of the steps is not mandatory, but provides a help for better understanding. As a rule, all settings can be changed during a measurement. This will lead to an automatic interruption of the current measurement and to a re-start of the measurement with the new settings:

Assumption: A test movement in the commissioning mode is active.

1.) Select OSCI operating mode 

2.) Select Time basis XDIV 

3.) Select channel 1 signal source digital inputs 120.2 from status tree with the aid of Drag & Drop

4.) Select channel 2 (filtered actual speed) via "Drag and drop" from the status tree

5.) Set trigger to channel 1 and DG.

Input of the mask in HEX
 Triggering a rising edge to input I1.
 BIT 0 (value 1) = I0
 BIT 1 (value 2) = I1
 BIT 2 (value 4) = I2 etc.

Trigger to input	I0	I1	I2	I3	I4	I5	I6	I7
Trigger mask in hex	1	2	4	8	10	20	40	80

The masks can also be combined so that the trigger is only active, if several inputs are active. Example: Triggering to I2 and I5 and I6 -> 4h + 20h + 40h = 64h

The mask for input I1 is in this case 2.

Select rising edge.

NOTE: If the trigger mask DG (digital) is selected for a channel, the display mode of the trigger channel is automatically set to DIG display.

6.) Start measurement

7.) Set pretrigger in the OSCI window


Note: There is no level for the DIG trigger. The the event limit determines the mask. If a trigger event occurs, the measurement values are captured until the measurement is completed.

Afterwards, the measurement values are read from the Compax3 and displayed. The display mask of trigger channel 1 was not yet limited, therefore it shows all 16 bit tracks (b0...b15). In order to limit it to 8 bit tracks, you must call up the menu for channel 1 via [CH1] and select "change logic of display mask [H].

Limit the display mask to 8 bit tracks with Mask FFh.

In the display the bit tracks b0 to b7 are now shown:

Example: Only b0 and b1 are to be displayed: Set display mask to 03



4.4.3. Controller optimization

In this chapter you can read about:

Introduction..... 160
 Configuration 162
 Automatic controller design..... 178
 Setup and optimization of the control 190

4.4.3.1 Introduction


In this chapter you can read about:

Basic structure of the control with Compax3 160
 Proceeding during configuration, setup and optimization 160
 Software for supporting the configuration, setup and optimization..... 161

Basic structure of the control with Compax3

Compax3 is an intelligent servo drive for different applications and dynamic motion sequences.


Basic structure of a control with the Compax3e servo drive



As shown in the above figure, the programmed motion sequences are generated by the internal Compax3 setpoint generator. The setpoint position as well as the other status values of the feedforward control are made available to the position controller in order to keep the following error as small as possible.

For the control, Compax3 requires on the one hand the actual position and on the other hand the commutation position, which represents the reference between the mechanic feedback position and the motor magnet.

Proceeding during configuration, setup and optimization



Overview of the processes during configuration and setup of the Compax3 drive system


The controller presettings are calculated from the configured motor and application parameters with the aid of the automatic controller design which runs in the background.

These controller presettings provide normally for a stable and robust control. Due to continually rising application requirements, this presetting is often not sufficient, so that further optimization of the control behavior is necessary.

This manual describes the setup and optimization procedure for Compax3.

In order to better understand the correlations and interactions, we will describe in the first step the individual correlations and physical values, that are required for the configuration and the prespecification of the control loops. In the following, the manual will then describe the function blocks for the optimization implemented in the servo drive as well as the setup tool.

Software for supporting the configuration, setup and optimization



The entry of the motor and application parameters is made with the C3 ServoManager2 (C3Mgr2.exe):


The configuration requires:

Application parameters

The wizard guided entry of the application parameters takes place directly in the ServoManager.

Carefully verify the entries and default values in order to detect entry errors in the run-up.

After the configuration download, the drive can be set up and be optimized if needs be. For this, please open the optimization window of the ServoManager:




4.4.3.2 Configuration

In this chapter you can read about:

Control path 162
 Motor parameters relevant for the control 163
 Mass inertia 163
 Nominal point data 163
 Saturation values 165
 Quality of different feedback systems 165
 Typical problems of a non optimized control 166
 Feedback error compensation 167
 Commutation settings 168
 I²t - monitoring of the motor 168
 Relevant application parameters 171
 Asynchronous Motors 174

Control path

For the motors, the knowledge of the mathematical model is a prerequisite. Mathematically idealized model of the control path:



U:	Control voltage
U _{EMK} :	electromagnetically generated voltage in the motor
T:	electric time constant of the motor winding
L:	Winding Inductance
R:	Winding Resistance
M _A :	Drive torque of the motor
M _L :	Load torque
M _B :	Acceleration torque
I:	Actual current r.m.s. (torque-producing)
K _T :	Torque constant
J _{mot} :	Motor mass moment of inertia
J _{ext} :	external mass moment of inertia
J _{total} :	Total mass moment of inertia
a:	Acceleration
n:	Velocity

Explanation:

The motor is controlled by the servo drive with control voltage U . During motion of the motor, an internal back e.m.f. U_{EMC} is induced. This antagonizes the control voltage and is therefore deduced in the motor model. The difference is available for the acceleration of the motor.

The first order delay component represents the delaying property of the motor winding with the time constant $T=L/R$. According to Ohm's Law, a current $I=U/R$ results.

The drive torque of the motor is calculated by multiplying the current with the motor torque constant K_T . This is antagonized by the load torque of the machine.

The remaining acceleration torque accelerates the motor.

The resulting acceleration depends on the total mass moment of inertia (= motor + load moment of inertia).

The integration of the acceleration (sum of the acceleration over time) results in the velocity of the motor, which influences the amplitude of the induced EMC voltage.

Motor parameters relevant for the control

All motor parameters relevant for the control quality will be explained below. Wizard guided entry of the motor parameters in the MotorManager.

Electromotoric countercheck EMC

A non-energized synchronous motor induces an induction voltage, the so-called EMC voltage during an armature movement.

The EMC constant (motor EMC) states the value of the induced voltage subject to velocity.

The EMC constant corresponds to the motor torque constant K_T , which represents the correlation between the torque-producing current and the drive torque, however in a different unit.

The EMC voltage antagonizes the control voltage of the servo drive.

As the control voltage of the drive is not unlimited, it must be taken into consideration that the drive may approach the voltage limit at high velocities and therefore high EMC voltages.

The EMC constant is important with respect to the velocity control design.

The motor EMC is entered in the "motor characteristics" wizard window of the MotorManager. You may choose between different units. Please note the information on the motor type specification plate.

Mass inertia

The mass moment of inertia (moment of inertia) is also an important motor parameter for the design of the velocity control loop. For the velocity control design, this parameter is effective in correlation with the external mass moment of inertia of the load. The external load is entered in the C3 ServoManager. With the "load identification" function of the C3 ServoManager, the mass inertia can be determined, if it is not yet known.

Nominal point data**In this chapter you can read about:**

Motor characteristic line of a synchronous servo motor (torque via velocity) 164


Calculation of the reference current from the characteristic line. 164

The nominal point data can be found in the velocity characteristic line of the motor.

The prespecified nominal point can be changed in the 2nd wizard page of the C3 ServoManager configuration with the aid of "activate change of reference point" via the reference velocity and the reference current.

Motor characteristic line of a synchronous servo motor (torque via velocity)

SMH 60 30 1.4 ...2ID...4: 3000rpm at 400VAC



1: Nominal point

2: Forbidden range

Calculation of the reference current from the characteristic line.

$$I = \frac{M[\text{Nm}]}{EMK} \cdot 85,5 = \frac{M[\text{Nm}]}{K_T}$$

or for linear motors

$$I = \frac{M[\text{Nm}]}{EMK_V} \cdot \frac{\sqrt{2}}{\sqrt{3}} = \frac{M[\text{Nm}]}{K_f}$$

In the MotorManager, a motor can be defined for different operating modes (230V, 400V and 480V) without having to create several entities.

Additional parameters of a motor are:

◆ Standstill current [mA_{rms}]


◆ Pulse current [in % of the nominal current]

The pulse current can be provided by the Compax3 for the duration of the pulse current time (as far as the device current permits). The thermal pulse load of the motor rises due to the pulse current. This pulse load is monitored by the i²t monitoring in the Compax3.

Saturation values

A motor may show a saturation behavior at higher currents due to iron saturation. This results in the reduction of the winding inductance at higher currents. As the inductance value of the winding enters directly into the P term of the current controller, the saturation at higher currents will result in too fast current control. This behavior can be counter steered with saturation values (entered in the "motor characteristics" wizard window of the MotorManager).

Consideration of the saturation values with the aid of a linear characteristic line



- L 100% Entered value of the nominal inductance
- Lmin Minimum winding inductance [% of the nominal inductance].
- Ibeg Value to which the inductance of the winding sinks at Ifinal.
- Ifinal End of the saturation [% of the nominal inductance].

For the determination of the saturation values please see chapter 0 (see on page 220, see on page 221, see on page 222).

Quality of different feedback systems

In this chapter you can read about:

Interface	165
Resolution	165
Noise	166

The controller quality depends to a great extent on the signal quality of the position feedback and its signal acquisition. It is therefore important to select a suitable measurement system for the individual application.

In the rotary range, a resolver is mostly used for reasons of economics. The single pole resolver provides one sine/cosine period per revolution. In very demanding applications, the performance of the resolver is often not satisfactory, so that a SinCos feedback with a higher resolution must be used. The typical resolution of a SinCos feedback is 1024 periods/revolution.

Other position feedbacks which are often used in the linear range, differ with respect to the reading principle. High-quality optical position measuring systems offer the highest resolution and accuracy.

Interface

An additional distinctive feature is the electric interface between servo drive and feedback. Analog sine/cosine signals or digital encoder signals (RS422 standard) are used to transmit the incremental position information. Due to the high interpolation rate (approx. 14 bits) of the Compax3 servo controller, an analog sine/cosine signal is in most cases preferable to digital encoder signals.


Resolution

The less precise the resolution, the higher the quantization noise on the velocity signal.


Noise

The feedbacks have different levels of analog noise, which have a negative effect on the control. The noise can be dampened with the aid of filters in the actual value acquisition, however at the cost of the controller bandwidth.

For comparison, the noise of the actual velocity value at standstill of two different feedbacks is displayed.



Resolver: 1 period/revolution



SinCos: 1024 periods/revolution


Typical problems of a non optimized control

In this chapter you can read about:

Too high overshoot on velocity 166
 Increased following error 166
 Instable behavior 167

Upon first setup of a control, the controller is normally not able to meet all application requirements at once. Typical problems may be:


Too high overshoot on velocity



- 1) Actual velocity
- 2) Setpoint velocity


Increased following error

Increased following error when approaching the target position or the reduction of the following error takes too long



- 1) Following error
- 2) Setpoint velocity
- 3) Actual velocity

Instable behavior




- 1) Setpoint velocity
- 2) Actual velocity
- 3) Following error

Feedback error compensation

Feedbacks with sine/cosine tracks may have different errors. The feedback error compensation supported by Compax3 eliminates offset and gain errors on both tracks online.


The feedback error compensation is activated in the MotorManager: "Feedback system" wizard under "feedback error compensation".

Without compensation



top: Actual current value
bottom: Actual speed value

With compensation



Scale:
Current = 50mA/Div
Speed = 0.2mm/s/Div
Time = 3.8ms/Div

Type of motor: Parker LMDT 1200-1 ironless linear motor
Linear encoder: Renishaw RGH 24B with 20µm resolution
Servo drive: Compax3

In order to accept the changes in the MotorManager in the project, the individual configuration pages must be clicked through. In order to make the changes made in the MotorManager effective in the device, the configuration download in the C3Manager must be executed.

In the event of formal errors, the feedback error compensation may however be disadvantageous; therefore it is switched off as a default.

Commutation settings

Another prerequisite for a good control quality is the correct motor commutation of the motor. This comprises several settings.

- ◆ The commutation angle describes the relation of the feedback position with respect to the motor pole pair position.
- ◆ Commutation direction reversal describes the correlation between the position of the feedback and the commutation position.
- ◆ Feedback direction reversal describes the direction correlation between the defined positive direction of the drive and the feedback position.
- ◆ If the commutation direction does not match the defined direction of rotation, this will result in a subsequent error with the error message "following error" or "motor stalled".
- ◆ A faulty commutation angle value results in increased current and following error. Therefore the voltage limit is reached faster. If the value of the commutation error exceeds 90°, the motor will spin due to the positive feedback effect.

These 3 settings can be automatically acquired with the MotorManager.

With the aid of the automatic commutation acquisition, the commutation settings can be determined and plausibility checks can be made. You will be guided through the individual wizard pages and the MotorManager will issue a prompt to define the positive direction of the drive. The wizard pages supporting the user depend on the feedback system as well as on the motor type (linear or rotary).

This function is activated in the MotorManager:

"Feedback system" wizard under "automatic commutation settings".

Note The motor should be operated without load (=> no load torque e.g. weight force of a z-axis).

Additional setting of the commutation for incremental feedback:

This function is activated in the MotorManager:

"Feedback system" wizard under "feedback resolution".

In the event of an incremental feedback (Sine/cosine or RS424 encoder) the commutation must be defined in addition, in order to find the position reference to the winding.

- ◆ Automatic commutation with movement
- ◆ Commutation with digital hall sensors

I²t - monitoring of the motor

In this chapter you can read about:

Motor continuous usage:	168
Motor pulse usage	170
Reference point 2: Increased torque thanks to additional cooling.....	170

With the I²t - monitoring, the motor is protected against overload or thermal destruction. For this, knowledge on the load bearing capacity of the motor is required. This information can be taken from the manufacturer documentation (motor parameters). Compax3 monitored:


- ◆ Continuous usage of the motor (motor usage)
- ◆ Pulse usage of the motor (motor pulse usage)

Motor continuous usage:

This kind of monitoring watches over the continually deliverable torque (continuous current). This continuous current depends on the velocity and is acquired online from the linearization of the motor characteristic line.

Linearized motor characteristic lien for different operating points


Nominal point



- I_0 : Standstill current
- 1: Nominal point
- I_N : Nominal current (defined in the MotorManager)
- n_N : Nominal Speed
- 2: Forbidden range

For monitoring the continuous utilization, the linearized characteristic line between I_0 and I_N / n_N is used as a threshold.

Reference point 1: higher velocity at reduced torque




- I_0 : Standstill current
- rp1: Reference point 1 (defined in the C3 ServoManager)
- I_1 : Reference current to reference point 1
- n_1 : Reference velocity to reference point 1
- 2: Forbidden range

For monitoring the continuous usage, the linearized characteristic line between I_0 and I_1 / n_1 is used as a threshold.


Motor pulse usage

This monitoring watches over the duration of the defined pulse current. The permitted duration for the pulse current is defined by the pulse current time constant. If the acceleration current exceeds the nominal current for a defined time t_1 , a sufficient break time t_2 is required. If the current remains in average above the nominal current, the "monitoring motor pulse usage" [0x7180] error is triggered. Upon a high pulse usage, the error will occur almost without delay.

Current cycle:



Reference point 2: Increased torque thanks to additional cooling



- I_0 : Standstill current
- 1: Nominal point
- rp2: Reference point 2 (defined in the C3 ServoManager)
- I_2 : Reference current to reference point 2
- n_2 : Reference velocity to reference point 2
- 2: Forbidden range

In order to monitor the continuous usage, the velocity-idenpendent current limit I_2 is used.

If a r.m.s. current over the valid straight flows continually in the motor, the I^2t monitoring will issue the "effective motor current monitoring" error message [0x5F48]. The period of time until the error occurs depends on the thermal time constant of the motor defined in the motor parameters. The electronic temperature monitoring simulates approximately the temperature behavior of the motor. By defining a reference point different from the motor nominal data, the I^2t monitoring of the motor can be adapted to changed thermal ambient conditions (e.g. air stream caused by a ventilator fan).

Relevant application parameters

In this chapter you can read about:

Switching frequency of the motor current / motor reference point.....	171
External Moment of Inertia.....	173
Limit and monitoring settings	174

Application parameters relevant for the control (C3 ServoManager)

Compax3 is configured with the aid of the C3 ServoManager. Here you can make application dependant settings. Among these are also parameters, that are relevant for the control. They will be explained below.

Switching frequency of the motor current / motor reference point


In this chapter you can read about:

Following Error (Position Error).....	171
Reduction of the current ripple.....	172
Motor parameters	172
Changing the switching frequency and the reference point	173

The higher the switching frequency, the better the quality of the current control. The higher switching frequency reduces the dead time of the current control path as well as the current control noise. Furthermore, thermal losses caused by current ripple are reduced at higher switching frequencies.

Following Error (Position Error)


Too high following error (position error) during a movement



- 1) Setpoint Position
- 2) Position deviation = following error
- 3) Effective position

Reduction of the current ripple

Reduction of the current ripple of the phase current due to the higher switching frequency



- 1: Current ripple
- 2: Phase current
- 3: PWM control

Hint Please note that a high switching frequency means also high switching losses in the power output stage of the controller. For this reason, you must consider derated data of the servo controller for the drive design with higher switching frequencies.


Motor parameters

In this chapter you can read about:

Parker Motor.....	172
Other motor	172
Motor types supported.....	173

Parker Motor

If a Parker motor is used for the application, the parameters are already contained in the installed software. You can just select one of the available motors from the first configuration page.



Other motor

When using a motor from a different manufacturer, you will have to enter the relevant data. This process is supported by the MotorManager software tool, which can be called up from the ServoManager:



After double clicking on "new", the individual motor parameters are queried by the MotorManager.

Be careful to respect the units of the individual parameters when making your entries!

Furthermore you can use the MotorManager to edit motors already available. In addition, the import and export of motor data entities in XML format is supported.

Motor types supported

Compax3 supports the following motor types:

- ◆ Permanently excited synchronous rotary motors
- ◆ Permanently excited synchronous linear motors
- ◆ Asynchronous rotary motors

In general, rotary and linear motors do have the same signal flow chart. The difference consists solely in the basic physical values, which refer to circular movement resp. the linear motion laws of physics. For this, the following analogies can be established:

Rotary drive [unit]		Linear drive [unit]	
Travel x	[rev]	Path x	[m]
Mass moment of inertia J	[kgm ²]	Mass m	[kg]
Velocity n	[rps]	Velocity v	[m/s]
Angular velocity ω	[1/s]		
Torque constant Kt	[Nm/Arms]	Force constant KF	[N/Arms]
Torque M	[Nm]	Force F	[N]

For reasons of clarity, we will in the following refer to the rotary motor, which will represent both drive types.

An asynchronous motor is set up in the same way as a synchronous motor. The only differences are varying motor parameters.

Changing the switching frequency and the reference point

The switching frequency and the reference point are activated in the ServoManager: "Motor reference point" wizard

A reference point differing from the nominal data may also be entered on the wizard page displayed above.

Please activate "activate changing the reference point", then you may enter the new reference velocity as well as the new reference current.

Motor reference point

A reference point differing from the nominal data may also be entered on the wizard page displayed above.

Please activate "activate changing the reference point", then you may enter the new reference velocity as well as the new reference current.

External Moment of Inertia

The external mass moment of inertia is set against the moment of inertia of the rotor to form the total moment of inertia. The total moment of inertia is used for the controller design.

If you do not know or have only a vague knowledge of the external mass moment of inertia, the mass inertia can be determined via the load identification.

Configuration of an unknown external mass inertia:

The load identification is activated in the ServoManager:


Wizard "External moment of inertia" "unknown: Using default values".

The correct values can be determined later via the load identification!

Limit and monitoring settings

On the "limit and monitoring settings" wizard page, you can set among others the current and velocity limits in % of the nominal values. The nominal values are motor parameters resulting from the motor library or from shifting the reference point on the "motor reference point" wizard page.

Limit and Monitoring Settings wizard page:



- 1: Current (Torque) Limit
- 2: Velocity limit

Asynchronous Motors

In this chapter you can read about:


Type specification plate data	174
Replacement switching diagram - data for a phase.....	174
Slip Frequency	175
Saturation behavior	175
Cut-off frequency for the field weakening range	176
Rotor time constant	176
Determination of the commutation settings	176
Asynchronous motors: Extension of the controller structure.....	177

Type specification plate data

On the 2nd. wizard page of the Compax3 MotorManager, the type specification plate data must be entered.

Replacement switching diagram - data for a phase

This data can be obtained from the manufacturer or be determined by measurement.



U1:	Nominal phase voltage
R1:	Stator leg resistance
$X_{1\sigma} = 2\pi f L_{1\sigma}$:	Leak reactance (for f=50Hz mains frequency)
$L_{1\sigma}$:	Stator leakage inductance
$X_h = 2\pi f L_h$:	Main reactance (for f=50Hz mains frequency)
L_h :	Main field inductance
$X_{2\sigma}' = 2\pi f L_{2\sigma}'$:	Referenced leak reactance (for f=50Hz mains frequency)
$L_{2\sigma}'$:	Rotor leak inductance
$R_{2\sigma}'$:	Referenced carriage resistance
I_{mR} :	Magnetizing current

Slip Frequency

The slip frequency is stated in [Hz electrical] or in [%] and can be determined as follows

$$f_2[mHz \text{ (electrical)}] = (f_s \cdot 60 - N_{Nenn} \cdot \frac{P}{2}) / N$$

$$f_2[mHz(el.)] = \frac{f_s \cdot 60 - N_{Nenn} \cdot \frac{P}{2}}{f_s \cdot 60} \cdot f_s \cdot 1000 = \left(f_s - N_{Nenn} \cdot \frac{P}{120} \right) \cdot 1000$$

$$f_2[Pr omille] = \frac{f_s \cdot 60 - N_{Nenn} \cdot \frac{P}{2}}{f_s \cdot 60} \cdot 1000$$

$$\frac{f_s \cdot 60 \cdot 2}{N_{Nenn}}$$


Whereas P = value before the point of the term è

- f_s: Synchronous nominal frequency (dimensioning base)
- N_{Nom}: Nominal speed in rpm
- f₂: Slip frequency in mHz (electrical)

Saturation behavior

The saturation of the main field inductance can be considered with the help of the following characteristic.


Activate the "consider saturation values" checkbox.



- 1) Nominal point in the basic speed range
- Lhmax: max. main field inductance
- Sbeg: Beginning of Saturation
- Send: End of Saturation

Cut-off frequency for the field weakening range

The statement of the cut-off speed defines the beginning of the field weakening operation. From the cut-off speed on, the magnetization current and thus the force constant of the motor are reduced inversely proportional to the speed; the motor is operated in the field weakening range. In the field weakening range, the shaft power produced remains constant.



- 1: Basic speed range
2: Field weakening range

Rotor time constant


If the value of the rotor time constant is not known, it can be approximated automatically.

Determination of the commutation settings

On the last wizard page of the Compax3 MotorManager, the commutation settings (feedback direction reversal and commutation direction reversal) can be determined automatically.

Asynchronous motors: Extension of the controller structure

Structure of the magnetization current controller and determination of the slip frequency:



4.4.3.3 Automatic controller design

In this chapter you can read about:

Dynamics of a control	178
Cascade control.....	184
Rigidity	185
Automated controller design	187
Controller coefficients	188


Dynamics of a control

In this chapter you can read about:

Structure of a control	178
Oscillating plant	178
Stability, attenuation	178
Velocity, bandwidth.....	179
Setpoint and disturbance behavior of a control loop.....	182
Response	184
Limitation behavior	184

A change in the input value of a dynamic transmission element causes a change of its output value. The change of the output value is however not immediately effective, but takes a certain time, the transient response. The course of the transient response is characteristic for certain kinds of transmission behavior. For this reason, a complete description of the transmission properties of a control comprises the stationary behavior (all setpoint, actual and disturbance values in settled state), as well as the dynamic behavior.

Structure of a control



The basic task of a control is the generation and maintaining of a desired state or sequence in spite of interfering disturbances. It is essential that the effects of the disturbances are balanced with the correct force and at the correct time. In the above figure, the setpoint value W represents the desired state and the disturbance value Z represents the interfering disturbance. The actual value X represents the generated and maintained state.

Oscillating plant

Oscillating control paths are control paths that respond with attenuated or unattenuated oscillation to an abrupt change in the setpoint value. Part of this class are for instance:

- ◆ Linear actuators with toothed belts, as a toothed belt represents an elasticity.
- ◆ A mechanic shaft with an external mass moment of inertia, as the shaft represents an elasticity due to its torsional properties.

In general this kind of elasticity is due to a high ratio between J_{Load}/J_{Motor} , as the shaft is normally not designed for this high external load and which may lead to a considerable distortion.

Stability, attenuation

In this chapter you can read about:


Stability problem in the high-frequency range:	179
Stability problem in the low-frequency range:.....	179

In general, two stability problems may occur in a servo drive control:


Stability problem in the high-frequency range:

The "control structure" figure shows that the reverse effect in the control loop (negative feedback) is a prerequisite for the functioning of a control system. Due to the delay in signal transmission, the effect of the negative feedback is diminished or even compensated. The reason is that the corrective measures of the controller are also delayed in the event of delayed signal transmission. This results in a typical oscillating course of the control variable. In the worst case, the deviation of the control variable and the effect of the corrective measures get in phase, if the delays reach a defined value. The negative feedback passes into positive feedback. If the product of the gain factors of all control loop components is higher than 1, the oscillation amplitude will continually rise. In this case the control loop is unstable. In the total gain of 1 the oscillation keeps its amplitude and the control loop is within the limits of stability. The transient response can be characterized by the attenuation and the transient time (velocity).


Step response of a stable controller and of a controller approaching the stability limit



Rugged
Well attenuated



Rugged
Poorly attenuated




Stability limit
not attenuated

W: Setpoint value
x: Actual value

Stability problem in the low-frequency range:

In this case the controller was set for a very inert control path, while the actual control path is much more dynamic. The controller reacts to a disturbance variable with a much too strong corrective measure so that the disturbance variable is overcompensated and even an increasing oscillation may be the result. In this case the mechanic system of the control path may be destroyed.

Velocity jerk response (low-frequency stability limit)



1: Setpoint speed value
2: Actual speed value


Velocity, bandwidth

In this chapter you can read about:

P-TE - Symbol 180
 Step response of a delay component..... 180
 Approximation of a well-attenuated control loop..... 180
 Frequency response of the P-TE component (value and phase)..... 181


A well attenuated control loop can, under certain conditions, be approximated in order to simplify the controller design with a first order delay component (P-TE component) with the replacement time constant TE and the total gain Kp. A P-TE component represents a first order delay component and is a simple dynamic basic component.

P-TE - Symbol



Step response of a delay component

Step response of a first order delay component with $K_p=1$ and $T_E=2.0s$



T: Tangent

S: Input jerk

P-TE: Output value of the P-TE component

TE: Time constant of the P-TE component


The definition of the delay time constant is displayed in the above figure. The time of intersection of the tangent and the jerk function itself is by definition the delay time constant (called filter time constant for filters) of a P-TE component. At this point in time the value of the step response is approx. 63% of the final value. In practice the step response corresponds, for instance, to the voltage charge curve of a capacitor.

Approximation of a well-attenuated control loop

The approximation of a well-attenuated control loop is based on the sameness of the control surface of the ideal first order delay component (P-T1 component) and the approximated system (P-TE component).

The control surface is a measure for the velocity of a system and is defined in the following figure. If the surface of the approximated system corresponds to the surface of the ideal system, the approximated system can be described, up to a certain frequency, with the transmission function of the P-T1 component.

Determination of the control surface from the transmission behavior of a P-TE component.




1: Control surface of the approximated system

2: Control surface of the ideal P-T1 component


The velocity of a dynamic system can also be described in the frequency range. In the frequency range, the system behavior is analyzed to sinusoidal inputs signals of different frequencies (frequency response).

Input and output signals of a dynamic transmission component at a defined frequency $f=f_1$



The bode diagram represents the behavior of a dynamic system (in our case of the P-TE component) against the input signal frequency with respect to amplitude and phase.

Frequency response of the P-TE component (value and phase)



Cut-off frequency

$$f_0 = \frac{1}{2\pi \cdot T_E} = 0,0795 Hz$$

is the frequency where the input signal is attenuated by 3dB (-3dB attenuation). The phase shift between the output and the input is -45° at this frequency. Precisely this cut-off frequency is called the bandwidth of a control loop.

Setpoint and disturbance behavior of a control loop


In this chapter you can read about:

Demand behavior 182
 Disturbance behavior 182
 Test functions 183
 Characteristics of a control loop setpoint response 183

The setpoint behavior is the behavior of the control loop for the setpoint variable W . We assume that the disturbance variable $Z=0$.


The disturbance behavior describes the behavior of the control loop for disturbance variable Z . In this case, we assume, in analogy to the setpoint behavior, that the setpoint variable $W=0$.

Demand behavior



W: Setpoint value
 X: Actual value
 Z: Disturbance variable

Disturbance behavior




W: Setpoint value
 X: Actual value
 Z: Disturbance variable

In order to examine the disturbance and setpoint behavior, the Compax3 setup software offers 4 jerk functions.

Test functions


Test functions for the analysis of disturbance and setpoint behavior of the control loops



1: 4 jerk functions

The properties of the setpoint behavior of the velocity controller can be acquired from the velocity jerk response.

Characteristics of a control loop setpoint response




T_{sr} :	Response time. (Time elapsing until the control variable reaches one of the $\pm 5\%$ tolerance limits for the first time)
T_s :	Settling time. (Time elapsing until the control variable ultimately enters the $\pm 5\%$ range)
V_m :	maximum overshoot width
1	Tolerance range $\pm 5\%$
2	Setpoint value

Response

The response of the controller is the behavior of the actual value with respect to the calculated profile of the setpoint generator. The kinematic status variables, speed, acceleration and jerk are fed into the cascade as feedforward signals. The feedforward signals work with calculated factors and contribute to an improved contour constancy due to the minimization of the following error.

Compax3 servo controller structure



- x: Position actual value
- x_w: Setpoint position value
- a_w: Acceleration setpoint value
- n: Actual (rotational) speed
- n_w: Velocity setpoint value
- i: Actual current value
- j_w: Jerk setpoint value

Limitation behavior

Each control variable is limited by the control (actuating) element. If the control variable demanded by the controller is within the linear range (without limitation), the control loop shows the behavior defined by the design. If the controller demands however a higher control variable than permitted by the limitation, the control variable is limited and the controller slows down.

Hint You should therefore make sure that the control variable (output) of the controller does not remain within the limitation or only for a very short time.


Cascade control

In this chapter you can read about:

Structure of a cascade control 184
 Cascade structure of Compax3..... 185

In drive technology, a cascading structure with several controllers (normally 3) is often used. This improves the control behavior. For this, additional sensors must be fixed within the control path. You will get the structure of a cascade control.

Structure of a cascade control




- W1 Setpoint value (setpoint) for the superposed controller 2
- W2 Setpoint value (setpoint) for the subordinate controller 1
- X2: Actual variable (actual value) for controller 2
- X1: Actual variable (actual value) for controller 1

The cascade control offers the following advantages:

- ◆ Disturbances occurring within the control path, can be compensated in the subordinate control loop. Therefore they must not pass through the entire control path and are thus compensated earlier.
- ◆ The delay times within the path can be reduced for the superposed controller.
- ◆ The limitation of the intermediate variables can be made by the control variable limitation of the superposed controller rather easily.
- ◆ The effects of the non-linearity for the superposed controllers can be reduced by the subordinate control loops.

In the Compax3 servo drive, a triple cascade control is implemented with the following controllers - position controller, velocity controller and current controller.

Cascade structure of Compax3



Rigidity

In this chapter you can read about:

Static stiffness	185
Dynamic stiffness	185
Correlation between the terms introduced.....	187

The stiffness of a drive represents an important characteristic. The faster the disturbance variable can be compensated in the velocity control path and the smaller the oscillation caused, the higher the stiffness of the drive. With regard to stiffness, we distinguish static and dynamic stiffness.

Static stiffness

The static stiffness of a direct drive is comparable with the spring rate D of a mechanical spring, and indicates the excursion of the spring in the event of a constant interference force. It is the ratio between the constant force FDmax of the motor and a position difference. Due to the I term in the velocity controller, the static stiffness is therefore infinitely high in theory, as the I term is integrated until the control difference vanishes. In a digital control the static stiffness is above all limited by the finite resolution of the position signal (the error must be at least one quantization step, so that it can be detected by the reading system) and by numerical resolution. Additional effects are for instance mechanical stiffness of the mechanic components in the control path (e.g. load connection, guiding system) as well as measurement errors of the measurement system.

Dynamic stiffness

In this chapter you can read about:


Traditional generation of a disturbance torque/force jerk.....	186
Electronic simulation of a disturbance torque jerk with the disturbance current jerk.....	186
Disturbance jerk response	186

The dynamic stiffness is described by the ratio between the change in load torque or in load force and the resulting position deviation (following error):

$$\frac{-\Delta M_L}{\Delta x}$$

The higher this ratio (=dynamic stiffness), the higher the necessary change is load torque in order to generate a defined following error.
 The dynamic stiffness can be acquired from the disturbance jerk response.


Traditional generation of a disturbance torque/force jerk



In settled state of the control, the motor force F_M corresponds exactly to the load force $F_G = m \times g$.
 If the cord is cut through, the load force is eliminated abruptly and the controller must first of all settle to the new situation.


In order to simulate this load jerk electronically, a disturbance current jerk is fed to the Compax3 as a variable proportional to the disturbance torque at the velocity controller output.

Electronic simulation of a disturbance torque jerk with the disturbance current jerk



Feeding in of a disturbance current jerk, which corresponds to a disturbance torque jerk.
 The maximum amplitude and the settling time of the following error decline with rising dynamic stiffness. The settling behavior of the following error is furthermore a measure for the attenuation and the bandwidth of the control.

Disturbance jerk response



- 1: Compensation torque of the controller
- 2: Simulated disturbance torque
- 3: Actual speed
- 4: Following error
- 5: Settling Time

Correlation between the terms introduced

The introduced terms:

- ◆ Stability
- ◆ Damping
- ◆ Velocity
- ◆ Bandwidth
- ◆ Setpoint and disturbance behavior
- ◆ Control variable limitation
- ◆ Replacement time constant
- ◆ Rigidity

are related as follows:

- ◆ A well-attenuated control features a stable control behavior.
- ◆ The velocity of a control loop is a measure for the reaction rate of the controller to the disturbance variable (disturbance behavior) as well as to the setpoint variable (setpoint behavior).
- ◆ The faster the control, the higher its bandwidth.
- ◆ The term replacement time constant is an approximation and is only valid in a defined scope¹. In this scope, the control is always stable and well-attenuated.
- ◆ If the controller does not work in the linear range, but the control variable of the controller is within the limitation, the control slows down and the control difference rises.
- ◆ The stiffness represents the bandwidth of the velocity control. The higher the stiffness value of the velocity control, the higher the bandwidth of the velocity controller and the stiffer the drive.

Automated controller design

In this chapter you can read about:

Step response of the velocity loop depending on the optimization parameter "attenuation" and "stiffness"..... 188

The controller design takes place after the configuration immediately before the configuration download into the device. The controller coefficients are preassigned according to the design method of cross-ratios so that a stable control is achieved. The automatic, robust controller design calculates the P and I terms of the individual controllers (current, velocity, position) on the basis of the configured motor and application parameters.

Please observe: Faulty motor and application parameters may lead under certain circumstances to instable controllers.

The controller parameters are not directly available for the optimization. Instead, they can be changed with the aid of the following optimization parameters:


- | | |
|--|--------------------------------------|
| Optimization of the current controller dynamics: | ◆ Current loop bandwidth in % |
| Optimization of the velocity loop dynamics: | ◆ "Attenuation of current loop" in % |
| | ◆ "Stiffness" in % |
| | ◆ "Attenuation" in % |
| | ◆ Velocity loop - "D" term in % |

The bandwidth parameter states the actually effective % of the calculated default velocity. The default bandwidth of the current controller is fixed to approx. fGR=531Hz. In reverse this signifies that each motor delivers the same step response. The prerequisite is, of course, that you keep out of the control signal limitation (voltage limitation). The attenuation characterizes the controller's tendency to oscillate with respect to an excitation signal (see below). The stiffness (of the velocity loop, corresponds to the bandwidth of the current loop) describes the velocity of the velocity loop (see below).

Step response of the velocity loop depending on the optimization parameter "attenuation" and "stiffness"

Attenuation = 100%

Stiffness = 100%



- 1: Setpoint value
- 2: Actual value (stiffness = 200%)
- 3: Actual value (stiffness = 100%)
- 4: Actual value (stiffness = 50%)
- 5: Actual value (attenuation = 500%)
- 6: Actual value (attenuation = 100%)
- 7: Actual value (attenuation = 50%)

The D-term parameter (of the velocity loop) activates existing control oscillations of drives with elastic coupling (e.g. toothed belt drives). The D-term is not automatically designed and must therefore be set manually.

The position controller is automatically adapted depending on the stiffness of the velocity loop.

Controller coefficients

In this chapter you can read about:

Velocity Loop P Term 188
 D-term of the KD velocity controller 189
 P-term KV position loop 189

Dependence of the controller coefficients from the optimization objects

The controller coefficients are influenced by the optimization objects such as "stiffness" and/or "attenuation". The dependency is displayed below.

I-term KI in the velocity loop

$$K_I = \frac{St[\%]}{100 \cdot T_{EGD}}$$

$$\Rightarrow K_I \sim St$$

- T_{EGD}: The replacement time constant of the closed velocity loop.
- St Rigidity

Velocity Loop P Term

$$K_{PV} = \frac{St[\%]}{100 \cdot T_{EGD}} \cdot \frac{Tm[\%]}{100} \cdot T_N \cdot \frac{100}{EMK[\%]} \cdot \frac{30 + 0,14 \cdot Dp[\%]}{20}$$

$$\Rightarrow K_{PV} \sim St \wedge K_{PV} \sim Tm / EMK \wedge K_{PV} = f_{LIN}(Dp)$$

- T_{EGD}: The replacement time constant of the closed velocity loop.
- T_N: The mechanical integration time constant of the motor.
- f_{LIN}(): Linear function (straight) between attenuation and KPV
- Tm Moment of Inertia
- St Rigidity
- Dp Damping

D-term of the KD velocity controller

$$K_D = \frac{Dterm[\%]}{100} \cdot K_{D_100\%}$$

$$\Rightarrow K_D \sim Dterm$$

KD_100 The defined 100% coefficient
%:

Dterm D term

P-term KV position loop

$$K_V = \frac{St[\%]}{100 \cdot T_{EGD}} \cdot \frac{20}{30 + 0,14 \cdot Dp[\%]} \cdot T_X$$

$$\Rightarrow K_V \sim St[\%] \wedge K_V = f_{LIN}(1/Dp[\%])$$

T_{EGD}: The replacement time constant of the closed velocity loop.

T_X: The position integration time constant of the motor.

St Rigidity

Dp Damping


f_{LIN}(): Linear function (straight) between 1/attenuation and KV

4.4.3.4 Setup and optimization of the control

For the setup and optimization of the control loops, the optimization window is available.

The Compax3 control functionality is divided into 2 sections, standard and advanced; the advanced functionality does however incorporate the entire standard functionality. The switching can be made in the optimization window.

Switching between standard and advanced



Note: The listed objects are not up to date!


In this chapter you can read about:

Standard.....	190
Advanced	196
Commissioning window	211
Proceeding during controller optimization	213

Standard

In this chapter you can read about:

Standard cascade structure	191
Standard optimization parameters	192
Control signal limitations	192
Feedforward channels	194
Control signal filter / filter of actual acceleration value.....	196



Description of the objects (see on page 415)

The framed objects are coupling objects for Compax3 - Compax3 coupling via HEDA.

Please note that the corresponding controller components must be deactivated for the coupling:

When coupling the velocity (O2219.14): O100.1 or O100.2=1063 (see object description)

When coupling via current (O2220.2): O100.1 or O100.2=1031 (see object description)

O100.1 is only copied into O100.2 upon activation of the controller, the controller can be influenced in active state with the aid of O100.2.










WARNING Changing objects O100.1 and O100.2 may cause the control to be deactivated! Protect dangerous areas!

External command value

During external setpoint specification, please respect the structure images for electronic cams or gearboxes for **signal filtering with external setpoint specification** (see on page 220) !

Complementary structure for **load control** (see on page 151).

Compax3 **controller structures** (see on page 191, see on page 196, see on page 198).

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Standard optimization parameters

Overview optimization objects		
Optimization object	Value	Unit
Reference reaction (Feed-Forward)		
Velocity feed-forward [2010.1]	100	%
Acceleration feed-forward [2010.2]	100	%
Current feed-forward [2010.4]	100	%
Jerk feed-forward [2010.5]	100	%
Setpoint-Disturbance reaction (Dynamics)		
Stiffness [2100.2]	100	%
Damping [2100.3]	100	%
Velocity loop - "D" term [2100.7]	0	%
Analog Input		
Gain 0 [170.2]	1	
Offset 0 [170.4]	0	

The above figure shows the parameters for the standard group. With the aid of these parameters, you can optimize the standard cascade structure.

Control signal limitations

In this chapter you can read about:

Limitation of the setpoint velocity 193
 Limitation of the setpoint current 193
 Limitation of the control voltage 194

The cascade structure shows that a limitation block is available in the control signal sector of each controller. The limitations of the position and velocity loops are calculated from the set limitations in the configuration and the motor parameters of the selected motor.

Limitation of the setpoint velocity

Limitation of the setpoint velocity in the control signal sector of the position loop:
This limitation value is calculated from the maximum mechanical velocity of the motor and the set value in the configuration in % of the nominal velocity. The smaller of the two values is used for the limitation.

Example

MotorManager

maximum mechanical velocity of the motor:	$n_{\max}=3100\text{rpm}$
Rated speed of the motor:	$n_N=2500\text{rpm}$

C3 ServoManager

Max. Operating velocity:	$n_{b\max}=200\%$ of n_N $\Rightarrow 5000\text{rpm}$
--------------------------	--

Velocity limitation value = $MIN(n_{\max}, n_{b\max} * n_N / 100) =$	3100rpm
--	------------------------------------

Limitation of the setpoint current

Limitation of the setpoint current in the control signal sector of the velocity loop:
This limitation value is calculated from the device peak current, the pulse current of the motor and the set value in the configuration in % of the nominal current. The smaller of the three values is used for the current limitation.

Example

Device

C3 S063 V2 F10 T30 M00 device peak current:	$I_{G\max}=12.6A_{\text{rms}}$
---	--------------------------------

MotorManager

Rated current of the motor:	$I_N=5.5A_{\text{rms}}$
Peak Current:	$I_{\text{imp}}=300\%$ I_N $\Rightarrow 16.5A_{\text{rms}}$

C3 ServoManager

Current (Torque) Limit:	$I_{b\max}=200\%$ of I_N $\Rightarrow 11A_{\text{rms}}$
-------------------------	--

Current limitation value = $MIN(I_{G\max}, I_{\text{imp}} * I_N / 100, I_{b\max} * I_N / 100) =$	$11A_{\text{rms}}$
--	--------------------------------------

Limitation of the control voltage

Limitation of the control voltage in the control signal sector of the current loop:
This limitation is fixed and cannot be influenced by the user. The limitation value depends on the DC voltage of the device.

Please note! In the event of highly dynamic motion cycles it is necessary to make sure not to enter the control signal limitation (or, if so only for a very short time) as the drive is then not in the position to follow the set dynamics due to the slow drive physics and the limited control signal range.

Feedforward channels

In this chapter you can read about:

Influence of the feedforward measures	194
Motion cycle without feedforward control	195
Motion cycle with feedforward measures	195

The feedforward channels are used for the specific influence of the guiding behavior of a control. The calculated and evaluated status variables are coupled into the corresponding places within the controller cascade. In practice, the feedforward control offers the following advantages:

- ◆ Minimal following error
- ◆ Improves the transient response
- ◆ Gives greater dynamic range with lower maximum current

The Compax3 servo drive disposes of four feedforward measures (see in the standard cascade structure):


- ◆ Velocity Feed Forward
- ◆ Acceleration feed-forward
- ◆ Current feed-forward
- ◆ Jerk feed-forward

The above order represents at the same time the effectiveness of the individual feedforward measures. The influence of the jerk feedforward may be, depending on the profile and the motor, negligibly small.

Please note! But the principle of feedforward control fails in limiting the motor current or the motor speed during the acceleration phase!


Influence of the feedforward measures

Following error minimization by feedforward control / course of the setpoint generator signals




- xws: Position setpoint value of the setpoint generator
- nws: Velocity setpoint - setpoint generator
- aws: Acceleration setpoint value setpoint generator
- rws: Jerk setpoint value setpoint generator

Motion cycle without feedforward control




Motion cycle with feedforward measures


Velocity feedforward




Velocity and acceleration feedforward



Velocity, acceleration and current feedforward



Velocity, acceleration, current and jerk feedforward



Control signal filter / filter of actual acceleration value

The filters in the Compax3 firmware are implemented as P-T1 filters (first order deceleration component see chapter 0 (see on page 220, see on page 221, see on page 222).)

The two "control signal filter (velocity loop)" (Object 2100.20) and "acceleration value filter" (Object 2100.21) are set in μs . The value range for these filters is 63... 8 300 000 μs . Depending on the replacement time constant of the closed velocity loop, we can make recommendations for the setting.

Setting recommendation for "control signal filter (velocity loop)":

$$O2100.20 \leq O2210.17[\mu\text{s}] / 5$$

$$\text{for } O2210.17 \geq 10\,000\mu\text{s}$$

$$O2100.20 \leq O2210.17[\mu\text{s}] / 3 - 1333\mu\text{s}$$

$$\text{for } 4000\mu\text{s} \leq O2210.17 < 10\,000\mu\text{s}$$

$$O2210.20 = 0$$

$$\text{for } O2210.17 < 4000\mu\text{s}$$

O2210.17: Object replacement time constant of the velocity loop in μs .

O2100.20: Object control signal filter (velocity loop) in μs .

Please note!


It cannot be excluded that the filter may have a destabilizing effect even though set according to the above recommendation. In this case the filter time constant must be reduced.

Advanced

In this chapter you can read about:

- Extended cascade (structure variant 1)..... 196
- Extended cascade structure (structure variant 2 with disturbance variable observer)..... 198
- Optimization parameter Advanced..... 199
- EMC feedforward..... 200
- Motor parameters 200
- Filter "External Command Interface"..... 200
- Voltage decoupling 200
- Load control..... 200
- Luenberg observer 200
- Commutation settings of the automatic commutation 203
- Notch filter 207
- Saturation behavior 209
- Control measures for drives involving friction 210

Extended cascade (structure variant 1)



Description of the objects (see on page 415)

The framed objects are coupling objects for Compax3 - Compax3 coupling via HEDA.

Please note that the corresponding controller components must be deactivated for the coupling:

When coupling the velocity (O2219.14): O100.1 or O100.2=1063 (see object description)

When coupling via current (O2220.2): O100.1 or O100.2=1031 (see object description)

O100.1 is only copied into O100.2 upon activation of the controller, the controller can be influenced in active state with the aid of O100.2.



WARNING

Changing objects O100.1 and O100.2 may cause the control to be deactivated! Protect dangerous areas!








External command value

During external setpoint specification, please respect the structure images for electronic cams or gearboxes for **signal filtering with external setpoint specification** (see on page 220) !

Complementary structure for **load control** (see on page 151).

Compax3 **controller structures** (see on page 191, see on page 196, see on page 198).

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
○	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Optimization parameter Advanced

Overview optimization objects		
Optimization object	Value	Unit
Reference reaction (Feed-Forward)		
Velocity feed-forward [2010.1]	100	%
Acceleration feed-forward [2010.2]	100	%
Current feed-forward [2010.4]	100	%
Jerk feed-forward [2010.5]	100	%
Setpoint-/Disturbance reaction (Dynamics)		
Stiffness [2100.2]	100	%
Damping [2100.3]	100	%
Moment of Inertia [2100.4]	100	%
Velocity loop - "D" term [2100.7]	0	%
Filter - Actual velocity [2100.5]	100	%
Filter 2 - actuating signal (velocity controller) [2100.10]	0	us
Filter - Actual acceleration [2100.6]	0	%
Filter 2 - Actual acceleration [2100.11]	0	us
Current loop - Bandwidth [2100.8]	50	%
Current loop - Damping [2100.9]	100	%
Observer		
Time Constant [2120.1]	0	us
Filter - Observed disturbance [2120.5]	1000	us
Enable Disturbance Compensation [2120.7]	0	
Position Control		
Position Loop - KV factor [2200.3]	100	%
Filter external input setpoints		
Filter - Ext. velocity feed-forward [2011.1]	500	%
Filter - Ext. accel. feed-forward [2011.2]	500	%
Filter - Ext. jerk feed-forward [2011.3]	500	%
Filter external signal source		
Filter - Ext. velocity feed-forward [2011.1]	500	%
Filter - Ext. accel. feed-forward [2011.2]	500	%
Trackingfilter HEDA [2109.1]	0	500us
Filter setpoints		
Trackingfilter [2110.1]	1	500us
Filter velocity [2110.3]	0	%
Filter acceleration [2110.4]	0	%
Analog Input		
Gain 0 [170.2]	1	
Offset 0 [170.4]	0	
Gain 1 [171.2]	1	
Offset 1 [171.4]	0	

Current controller

The current controller works with a P component in the feedback; this results in very low overshoot.

With the aid of object 2220.27 (Bit 0 = "1"), it is possible to switch to P component in the forward path.

EMC feedforward

The EMC feedforward compensates the electromagnetically generated back e.m.f. of the motor U_{EMC} . This signal is proportional to velocity and is deduced from the setpoint velocity of the setpoint generator.

Motor parameters

Furthermore you can re-optimize the motor parameters inductance, resistance and EMC (or K_t) in the advanced mode. The $LdLqRatio$ parameter is the ratio of the smallest and the highest inductance value of the winding, measured during one motor revolution.

Filter "External Command Interface"

Signal filtering with external command value (see on page 220, see on page 221, see on page 222)

Voltage decoupling

In the current control path there is a velocity and current proportional voltage disturbance variable, which must be compensated by the current loop. Due to limited controller dynamics, this disturbance variable can not always be entirely compensated by the current loop. The influence of this disturbance variable may however be minimized by activating the voltage decoupling.

Load control

If a second position feedback is available for the acquisition of the load position, the load control can be activated.

For more detailed information on the load control see device help for T30/T40 devices in the setup chapter Compax3\\load control.

Luenberg observer

In this chapter you can read about:

Introduction observer	200
Signal flow chart Luenberg observer	201

Introduction observer

A high signal quality of the actual signal value is of high significance in the control of the motor velocity n or the motor speed v . By means of oversampling and transmitter error compensation, a high-quality position signal can be produced for speed determination. As a rule the motor speed is determined by numeric differentiation of the motor position. In this case the quantization noise Q_{vD} of the digital speed signal depends on the quantisation Q_x of the position signal and the sampling time T_{AR} of the digital control loop:

Quantization speed signal Q_{vD}

$$Q_{vD} = \frac{Q_x}{T_{AR}}$$


The quantisation of the speed signal is inversely proportional to the sampling time TAR. Hence the demands for the lowest possible sampling time and the minimum quantization noise oppose each other in the determination of speed by numeric differentiation. The noise superimposed by the digital speed signal may be reduced by the low-pass filter, however this is always at the cost of the stability margin of the digital control loop. An alternative method is to determine the speed by integration of the acceleration. The dependence of the quantisation noise QvD of the digital speed signal on the quantisation Qx of the position signal and the sampling time TAR of the digital control loop is shown by the following correlation.

Quantization speed signal QvI

$$Q_{vI} = Q_a \cdot T_{AR}$$

The observer technology offers the advantage that the velocity can be calculated with the aid of integration. The idea of the observer principle is to connect a mathematical model of the control path parallel to the section observed and with the same transfer behavior. In this case, the controller also has the intermediate variables (state variables) of the control path available. However in the presence of model deviations (in structure or parameters), different signal values occur between the model and the control path. For this reason, the technique cannot be employed in this way in practice. However, the model contains the measurable output signal of the control section as a redundant quantity. By comparing the two variables, a tracking control can be used to adapt the model state variables to the state variables of the control path. As the model deviations have become minor in this case due to the simple mechanical drive train, the observer now has an efficient aid available to increase the signal quality. Increase in signal quality in the observer means that the noise components decrease, and the dynamics improve as the observed speed is feedforward-controlled undelayed by the current and is not just calculated delayed from the position signal using simple differentiation.

Signal flow chart Luenberg observer



$I(t)$:	Torque-forming motor current
K_t :	Torque constant
$M_L(t)$:	External disturbance torque
J_{total} :	Total mass moment of inertia (motor + load)
$a(t)$:	Acceleration
$n(t)$:	Velocity
$x(t)$:	Position
Index b:	Observed signal quantities
$h_0 \dots h_2$:	Controller coefficients of the tracking controller

The figure shows that an additional I element is connected for interference compensation to correct external disturbance forces in the observer. Therefore the speed and the acceleration observed are statically precise. The same applies to the output of the integrator in the tracking controller which is a statically precise determination of an external interference torque M_L . For this reason, the I component is not required in the speed controller for some applications, and the entire control can be set up as a state cascade control. This increases the bandwidth of the speed and position controlled member by factor 2. For this reason this increases the interference stiffness of the drive and the following error behavior improve.

Note The use of the speed monitor with interference compensation (\Rightarrow no I-term in the speed control) needs an active position control. Without this superimposed control the axis drifts, even with a speed setpoint value of 0!

Here the quantization of the speed signal is proportional to the sampling time TAR , hence there is no longer any conflict between the requirements for minimum sampling time and minimum quantization noise. For the integral velocity acquisition, the motor current variable, which is proportional to the acceleration, can be used. This approach is particularly advantageous in direct drive engineering; due to the absence of a mechanical drive train, there is a very good match between the mathematical model of the observer and the real physical control section in the fundamental frequency range of the control. This applies in particular to direct drive systems with fixed moving masses, as otherwise the mismatch between model and the physical drive system has a destabilizing influence on the transfer behavior of the speed control. A remedy is to increase the observer dynamics, however this increases the noise of the observed signals. Therefore in the case of variable moving masses a compromise has to be found between the dynamics of the observer and the maximum stiffness of the drive.

Commutation settings of the automatic commutation

In this chapter you can read about:

Display of the commutation error in incremental feedback systems203
 Prerequisites for the automatic commutation204
 Course of the automatic commutation function204
 Other207


Permanently excited synchronous motors can only be operated with an absolute feedback system (at least for electric motor rotation). The reason is the necessary commutation information (position assignment of the magnet field generated by the motor to the motor magnets). Without the commutation information, there is inevitably the possibility of a positive feedback between position and velocity loop ("running away" of the motor) or of bad motor efficiency (reduced force constant). Digital hall sensors are the most common aid to prevent this. Due to the mechanical design it is however impossible or very hard to integrate these sensors in some motors. The Compax3 automatic commutation function (in the F12 direct drive device) described below allows however to use incremental feedback systems without hall sensors.

The functionality implemented in the servo drive establishes the necessary reference between motor stator field and permanent magnetic field without additional aids.


The incremental feedback devices are, in contrast to absolute feedback devices, able to acquire relative distances. It is true that any position can be approached from a starting point, there would be however no consistency between these position values and a fixed virtual absolute system. Other than with an absolute feedback, the correlation between rotor and stator is lost if the position acquisition is switched off ("the position acquisition zero is lost"). When switching on, the actual position is randomly taken as zero. A commutation angle error can therefore absolutely not be excluded. Even a system adjusted before, would show an angular error, for example after a current failure. Therefore the angular error occurring randomly upon each new switching on must always be compensated in an incremental system.

Display of the commutation error in incremental feedback systems

$\Delta\epsilon = 0$ (adjusted)



$\Delta\epsilon \neq 0$ (not adjusted)



Rotor was turned in switched-off state.

blue ideal position
 :
 red: unfavorable position
 PM: magnetic flux of the permanent magnets
 i_s: Current pointer
 Δε Commutation error
 l': ideal position
 i_q: Quadrature current (torque forming)

The automatic commutation function (AK) in Compax3 uses the position dependent sinusoidal torque course of permanently excited AC synchronous motors. If the motor windings are energized with DC voltage for instance, the motor develops a sinusoidal torque depending on the rotor position, which can be used for example by evaluating the resulting movement in order to determine the correct motor commutation.

The automatic commutation with movement in the Compax3 has the following properties:

- ◆ The motor movement occurring during the commutation is, with correctly parameterized function, very small. It is typically in the range smaller than 10° electrical revolution (=10°/motor poles physically or 10°/360°*motor pitch for a linear motor).
- ◆ The precision of the acquired commutation angle depends on the external conditions, however lies normally in the range better than 5° electrical revolution.
- ◆ The time until the termination of the commutation acquisition is typically below 10s.

Prerequisites for the automatic commutation

- ◆ A movement of the motor must be permitted. The movement actually occurring depends greatly on the motor (friction conditions) itself, as well as on the load moved (inertia).
- ◆ Applications requiring a motor brake, i.e. applications where active load torques are applied at the motor (e.g. vertical actuator, slope) are not permitted.
- ◆ Due to the function principle, high static friction or load torques will deteriorate the result of automatic commutation.
- ◆ When performing automatic commutation, a motion of at least ±180° must be electrically possible (no mechanic limitation)! The implemented automatic commutation function with motion cannot be used for applications with limit or reversal switches.
- ◆ With the exception of missing commutation information, the controller/motor combination is configured and ready for operation (parameters correctly assigned for the drive/linear motor). Feedback direction and effective direction of the field of rotation must be identical (automatic commutation performed in the MotorManager).


Course of the automatic commutation function

If "automatic commutation with movement" is selected as source of commutation, the automatic commutation sequence runs once if the power stage is enabled. If the power stage is enabled or disabled afterwards, the automatic commutation will be left out. If an error occurs during the execution, the automatic commutation is aborted. A new "attempt to enable" the power stage will trigger a new automatic commutation.

Function principle of the automatic commutation with movement

The implemented method with movement is based on the sinusoidal dependence of the provided motor currents and the resulting movement on the effective commutation error. The acceleration performed by the motor (-> movement) in the event of constantly maintained current is a measure for the actual change in the commutation angle in the way that it disappears upon a change of exactly 0° and is, for other angles, the acceleration and its direction in dependence of the sign and value of the angular error (-180° .. 180°).

Acceleration torque depending on the commutation error.




$\Delta\epsilon:$	Commutation error
$M/M_{\mu\alpha\xi}$	normalized acceleration torque

Searching for the torque maxima (phase 1)

If the sum of the actual and the estimated error angle is $\pm 90^\circ$ electrically, the motor torque is maximal for the provided current. If you gradually increase the provided motor current, the motor will, from a defined value on, surpass its friction torque and exceed a motion threshold defined by O2190.3:

Illustration of the first phase




- 1): Motion threshold O2190.3
- 2): Waiting for standstill
- O2190.2: Starting current

Latching of the motor (phase 2)

Here, the drive is brought to the position with the provided motor torque=0, where the angular error is either $\pm 180^\circ$ or 0° .

Current rise in the second phase.



- O2190.1: Rising time of latching current
- 1) Maximum current from controller or motor
- 2) Monitoring on 5° electrical movement
- 3) Monitoring on 60° electrical movement

Motion reduction:

It is possible, to considerably reduce the motor movement occurring during the fine angle search with the aid of the "motion reduction" parameter (O2190.4). Please respect also that the acquired commutation result may be slightly worse than without this measure.


Hint As a current well above the nominal motor current is provided here, there may be saturation effects on iron core motors, which might lead to an instable current loop (-> highly frequent "creaking noises" during the automatic commutation). This can be avoided by activating the saturation characteristic line in the motor data.

Test for positive feedback (phase 3)

Here it is verified, if the motor performs a motion in the expected positive direction in the event of positive current in the torque maximum. The same motion threshold (defined via O2190.3) as in phase 1 is valid. The test is repeated several times.

A current course in ramp form is specified (target: minimum motion). The break between the tests varies with the current rise time O2191.1.

Illustration of the third phase



- 1): Waiting for standstill
- tp: Waiting for standstill

Other

- ◆ During the sequence (time according to parameterization >> 1s) the automatic commutation is externally visualized by a LED blinking code (green permanent and red blinking).
- ◆ Device errors will lead to an abort of the automatic commutation.
- ◆ During automatic commutation, no motion commands are accepted.
- ◆ The controller cascade entirely deactivated during automatic commutation, with the exception of the current loop.
- ◆ In multi-axis applications, the axes to be automatically commutated must be awaited (output of the MC_Power block must deliver "True")!
- ◆ The automatic commutation is only started if the drive is at standstill.
- ◆ After the occurring and acknowledgement of a feedback error or a configuration change of the feedback system, the automatic commutation must be performed again, as it might be that the position entrainment in the servo controller is interrupted (commutation information is lost).


Notch filter

In this chapter you can read about:

Effect of the notch filter 207
 Wrongly set notch filter 207
 Frequency response of the notch filter 208
 Parameterization by 3 objects 208

Notch filters are small-band band elimination filters which slope in a wedge form towards the center frequency. The attenuation of this center frequency is extremely high in most cases. With the aid of the notch filters it is possible to purposefully eliminate the effects of mechanical resonance frequencies. With this, the mechanical resonance point is not activated itself, but the excitation of this point of resonance is avoided by the control.


Effect of the notch filter



Resonance


As can be seen in the figure, the notch filter is only useful in cases where the set frequency of the notch filter is exactly the same as the disturbing frequency. The notch filter as well as the resonance point are very narrowband. If the resonance point does only minimally change (e.g. by changing the masses involved), it is not sufficiently activated by the notch filter.

Wrongly set notch filter



In the Compax3, two notch filters which are independent of each other are implemented.

Frequency response of the notch filter.



Center frequency = 500Hz

Bandwidth = 50Hz

Depth = 0.99 (-40dB)

Parameterization by 3 objects.

[In this chapter you can read about:](#)

This defines the frequency at which the notch filter attenuation is highest. In practice it shows that notch filters can only sensibly be used if the distance between the controller bandwidth (velocity loop) and the center frequency is long enough (at least factor 5). This permits to deduce the following recommendation:

$$O2150.x \geq \frac{5000000}{2\pi \cdot O2210.17[\mu s]}$$

$$x = 1 \text{ or } x = 4$$

Obj2210.17: Replacement time constant of the velocity loop in μs

Note: If this distance is too small, the stability of the control can be very negatively influenced!

This defines the width of the notch filter.

The value refers to the entire frequency band, where the attenuation of the filter is higher than (-)3dB.

In practice it shows that even if there is enough distance towards the control, it can be negatively influenced by too high bandwidths (higher than 1/4 of the center frequency).

$$O2150.x \leq \frac{O2150.1/4}{4}$$

$$x = 2 \text{ or } x = 5$$

With this the size of the attenuation of the filter must be at the position of the center frequency. One stands here for complete attenuation ($-\infty$ dB) and zero for no attenuation.

$$O2150.x = 1 - 10^{-\left(\frac{D[dB]}{20}\right)}$$

$$x = 3 \text{ or } x = 6$$

D [dB]: The desired attenuation at the center frequency in dB


Saturation behavior

In this chapter you can read about:

Current jerk response209
Current jerk response with the activated saturation characteristic line.....209
Saturation can be stated with the aid of current jerk responses at different current height.

Current jerk response

Current jerk response of a motor to 2 different currents (1Arms / 2Arms)




- 1) Actual current
- 2) Setpoint current

In the above figure we can see from the settling response that the drive shows a distinctive tendency to oscillate at doubled current. The saturation characteristic line, which is used to linearly reduce the P-term of the current loop depending on the current, helps against such a saturation behavior.

If you respect the saturation for the above example with the aid of the saturation characteristic line, the tendency to oscillate of the current loop can again be activated.

Current jerk response with the activated saturation characteristic line



The parameterization of the characteristic line is made in the MotorManager.

- Note:**
- ◆ In order to accept the changes in the MotorManager in the project, the entire configuration must be confirmed.
 - ◆ In order to make the changes from the MotorManager effective in the device, the configuration download must be executed.

Control measures for drives involving friction

In this chapter you can read about:


Deadband following error.....210
 Friction compensation.....211

Some drives, which involve much friction due to their guiding system, may show permanent oscillation at standstill. The transition between static friction (standstill) and kinetic friction (very low speed) is very steep. The controller can not longer follow the friction characteristic line at this position. The I-term integrates until the control variable pulls free the drive and the drive moves too far. This procedure is repeated in the opposite direction and a control oscillation occurs (so-called limit cycle). In order to eliminate this control oscillation, the following control functions were implemented:

- ◆ Deadband following error (Obj. 2200.20)
- ◆ Filter following error (Obj. 2200.24)
- ◆ Friction compensation (Obj. 2200.21)

Deadband following error


Deadband/filter following error in the position loop



The deadband does no longer supply a velocity setpoint value (zero) for the subordinate velocity loop at small following error. The integrator of the velocity loop stops integrating and the system comes to a standstill. In order to prevent that the velocity loop is excited by the noise on the following error, the following error should be filtered before the deadband, which will lead, however, to delays in the position loop. The deadband to be set depends on the friction behavior (amplitude of the limit cycle) and on the noise on the following error (the noise must remain within the deadband).

Friction compensation

The activation of the friction compensation (end of the velocity loop)



The friction compensation helps the control to surmount static friction at low setpoint speeds. The non linear characteristic line is partly compensated by this and a smaller deadband can be chosen, which will increase the position accuracy. The amplitude of the friction compensation depends on the application and must be calculated if needed. If the value is set too high, corrective movements may result and the tendency to oscillate is increased.

Commissioning window

In this chapter you can read about:

Load identification.....	211
Setpoint generation	211

With the aid of the setup window, the drive can be set up in a simple way.

Load identification

If you do not know the mass moment of inertia, it can be determined. For this, you click on the corresponding button (see setup window no. 13). After the following parameter entry, the identification can be started via the same button.

- ◆ For more detailed information on the load identification, see the device help, chapter "load identification".
- ◆ This measurement requires the correct EMC or torque constant value K_t .

Setpoint generation

In this chapter you can read about:


Internal setpoint generation	211
External setpoint generation	213

The setpoints for the control loops are provided in two different ways - internally or externally. The setpoint generation depends on the technology option of the device.

Internal setpoint generation

The internal setpoint generation can be used for the technology options >T10. In this case, the internal setpoint generator generates the entire motion profile with position, velocity, acceleration and jerk.

Motion profile at jerk-controlled setpoint generation



x_w Position
 n_w Velocity
 a_w Acceleration
 j_w Jerk

The drive cannot move randomly through hard profiles, as certain physical limits exist for the acceleration ability due to the motor physics and the limitation of the control variable. You must therefore make sure that the set movement corresponds to the real physics of the motor and of the servo drive.

As a support you can take the following physical correlation.

The calculation of the physically possible acceleration

rotary drives

$$a[rps^2] = \frac{M_A[Nm] - M_L[Nm]}{2\pi \cdot J_{ges}[kgm^2]}$$

M_A: Drive torque of the motor
 M_L: Load torque of the motor
 J_{total}: entire mass moment of inertia
 a: possible acceleration

Linear drives

$$a[m/s^2] = \frac{F_A[N] - F_L[N]}{m_{ges}[kg]}$$

F_A: Drive force of a linear motor
 F_L: Load force of a linear motor
 m_{total}: Total mass of a linear motor

The generation of the setpoint profile is jerk-controlled and jerk-limited by the specification of the jerk.


In practice, jerk-limited setpoint generation is important if the items to be moved must be handled gently. In addition, the service life of the mechanical guiding system will be extended. A separate setting of jerk and slope of the deceleration phase also permits overshoot-free positioning in the target position. For this reason, it is common practice to use higher values for acceleration and jerk in the acceleration phase than in the deceleration phase. In consequence a higher cycle rate can be achieved.

An additional important reason for the jerk limitation is the excitation of higher frequencies due to the too high jerk in the power density spectrum of the velocity function.


Jerk=1000°/s³

Jerk=1000000°/s³

Time function:



Time function and power density spectrum of Compax3 setpoint generator with different jerk settings



Power density over the frequency

The profile can be simply calculated and displayed for control purposes.

External setpoint generation

During external setpoint generation, the necessary feedforward signals are calculated from the external setpoint with the aid of numerical differentiation and final filtering.

Hint For more detailed information on the external setpoint generation see device help for T11/T30/T40 devices in the "setup" chapter Compax3\\optimization\\controller dynamics\\signal filtering at external setpoint specification"

Test Move

In order to evaluate the behavior of the drive, test movements can be defined. For this you jump into the parameter entry either with the aid of the "enter setup/test movement parameters" or by selecting the parameter tab. Via the "setup settings" menu you access the settings for the desired test movement. The desired motion profile can be set via the parameters in the following window.

Proceeding during controller optimization

In this chapter you can read about:


Main flow chart of the controller optimization	214
Controller optimization disturbance and setpoint behavior (standard)	215
Controller optimization disturbance and setpoint behavior (advanced).....	217

If the control behavior is not sufficient for the present application, an optimization is required. We recommend the following approach:

Overview on the approach to setup + optimization

- ◆ At first, the disturbance and setpoint behavior of the velocity loop at standstill and at different displacement velocities is optimized (stiffness, attenuation, filter).
- ◆ After that, the necessary motion profiles are set via the setup tool and the desired guiding behavior in the entire velocity range is set via the feedforward control (motion profiles, feedforward).

Main flow chart of the controller optimization




Controller optimization disturbance and setpoint behavior (standard)


In this chapter you can read about:

Controller optimization standard 215
 Controller optimization of toothed belt drive 216

Controller optimization standard




Controller optimization of toothed belt drive




Controller optimization disturbance and setpoint behavior (advanced)**In this chapter you can read about:**

Controller optimization Advanced	218
Flow chart controller optimization of a direct drive.....	219
Controller optimization guiding transmission behavior.....	220


Controller optimization Advanced



Flow chart controller optimization of a direct drive



Controller optimization guiding transmission behavior




4.4.4. Signal filtering with external command value

The command signal read in from an external source (via HEDA or physical input) can be optimized via different filters. For this the following filter structure is available:

4.4.4.1 Signal filtering for external setpoint specification and electronic gearbox

Does not apply for Compax3111T11!



"virtual Master" and Busmaster only with T30 & T40.

* Speed v and acceleration a are only present in the event of linear interpolation (method of interpolation: O3925.1 - 0x60C0) if they are provided by an external source.


In quadratic or cubic interpolation, v and a are emulated.

B: **Structure image of the signal processing**,

D/E: **Structure of Gearing** (see on page 307)

Control structure (see on page 191, see on page 196, see on page 198)


Symbols



Tracking filter

The displayed filter influences all outputs of the tracking filter.


Number: Object number of the filter characteristic



Differentiator


Output signal = $d(\text{input signal})/dt$

The output signal is the derivation (gradient) of the input signal



Filter

Number: Object number of the filter characteristic



Interpolation

Linear Interpolation.

Values in the 500µs grid are converted into the more exact time grid of 125µs.

Note:

- ◆ A jerk setpoint generator is not required for external setpoint specification.
- ◆ The description of the objects can be found in the **object list** (see on page 415).

4.4.5. Input simulation

Function: The input simulation is used for the performance of tests without the complete input/output hardware being necessary. The digital inputs (standard and inputs of M10/M12 option) as well as the analog inputs are supported. The following operating modes are available for digital inputs:

- ◆ The physical inputs are deactivated, the digital inputs are only influenced via the input simulation.
- ◆ The digital inputs and the physical inputs are logically or-linked. This necessitates very careful action, as the required function is, above all with low-active signals, no longer available.

The pre-setting of an analog input value is always made in addition to the physical analog input.

The function of the inputs depends on the Compax3 device type; please refer to the respective online help or the manual.

The input simulation is only possible if the connection with Compax3 is active and if the commissioning mode is deactivated!

In this chapter you can read about:

Calling up the input simulation	223
Operating Principle	223

4.4.5.1 Calling up the input simulation

Open the optimization window (double click in the C3 ServoManager tree entry: Optimization).
 Activate the Tab "Setup" in the right lower window.
 Clicking on the following button will open a menu; please select the input simulation.



4.4.5.2 Operating Principle

Window Compax3 InputSimulator:

1. Row: Standard Inputs E7 ... E0 = "0" button not pressed; = "1" switch pressed

2. Row: Optional digital inputs (M10 / M12)

Green field: port 4 is defined as input

Red field: port 4 is defined as output

the least significant input is always on the right side

3. Row: If the button "deactivating physical inputs" is pressed, all physical, digital inputs are deactivated; only the input simulation is active.

If both sources (physical and simulated inputs) are active, they are or-linked!



Caution!

Please consider the effects of the or-linking; above all on low-active functions.

4. Row: Simulation of the analog inputs 0 and 1 in steps of 100mV.
 The set value is added to the value on the physical input.

After the input simulation has been called up, all simulated inputs are on "0".

When the input simulation is left, the physical inputs become valid.

4.4.6. Setup mode

The setup mode is used for moving an axis independent of the system control
The following functions are possible:

- ◆ Homing run
- ◆ Manual+ / Manual-
- ◆ Activation / deactivation of the motor holding brake.
- ◆ Acknowledging errors
- ◆ Defining and activating a test movement
- ◆ Activating the digital outputs.
- ◆ **Automatic determination of the load characteristic value** (see on page 227)
- ◆ **Setup** (see on page 226) of the **load control** (see on page 149)

Activating the commissioning mode



By activating the setup mode, the control program (IEC program) is deactivated; the system function of the device is no longer available.

Access via an interface (RS232/RS485, Profibus, CANopen,...) and via digital inputs is deactivated. (if necessary, acyclic communication ways are nevertheless possible (e.g. Profibus PKW channel))

Caution!

The safety functions are not always guaranteed during the setup mode!

This will for instance lead to the fact that the axis may trundle to a stop if the Emergency stop button is pressed (interruption of the 24 V on C3S X4.3), which requires special caution with z axes!

- ◆ In the Commissioning window (left at the bottom) the commissioning mode is activated.
- ◆ Then parameterize the desired test movement in the Parameter window.
You can accept changed configuration settings into the current project.
- ◆ Now energize drive in the commissioning window and start the test movement.



Caution! Safeguard the travel range before energizing!

Deactivating the commissioning mode



If the setup mode is left, the drive is deactivated and the the control program (IEC program) is re-activated.

- Note:**
- ◆ The parameters of the commissioning window are saved with the project and are loaded into Compax3 if the commissioning mode is activated (see explanation below).

4.4.6.1 Motion objects in Compax3

The motion objects in Compax3 describe the active motion set.

The motion objects can be influenced via different interfaces.

The following table describes the correlations:

Source	active motion objects		Compax3 device
	==>	describe	
Commissioning (working with the commissioning window)	<==	read	Active motion objects: ♦ Position [O1111.1] ♦ Speed [O1111.2] ♦ Acceleration [O1111.3] ♦ Deceleration [O1111.4] ♦ jerk* [O1111.5] (Acceleration) ♦ Jerk* [O1111.6] (Deceleration) * for IxxT11 - devices, both jerk values are identical
	==>	♦ With the "accept entry" button. ♦ The current project gets a motion set. Download by activating the motion	
Compax3 ServoManager project	==>	♦ C3lxxT11: via an activated motion set ♦ C3l2xT11: via a configuration download	
	<==	For Compax3 I2xT11: ♦ via a configuration upload ♦ in the commissioning window via "accept configuration"	
Fieldbus (Compax3 I2xTxx)	==>	♦ Changing the motion objects directly	
	<==	♦ Reading the motion objects	
IEC61131-3 program (Compax3 lxxT30, lxxT40)	==>	♦ via positioning modules	

4.4.6.2 Commissioning the load control

If a load control was configured, the following buttons are displayed in the Commissioning window :



- 1 Status of the load control - yellow => off; green => on
- 2 Activate / Deactivate load control
- 3 **Alignment of the position values** of motor and load
(Load position = Motor position)
Only if the load control is deactivated!

Please note the explanations for the Load control (see on page 149)!

4.4.7. Load identification

Automatic determination of the load characteristic value:

- ◆ of the mass moment of inertia with rotary systems
- ◆ of the mass with linear systems.

In this chapter you can read about:

Principle	227
Boundary conditions	227
Process of the automatic determination of the load characteristic value (load identification).....	228
Tips	229

4.4.7.1 Principle

The load characteristic value is automatically determined.

For this it is necessary to excite the system additionally with a signal (excitation signal = noise).

The excitation signal is fed into the control loop. The control loop dampens the excitation signal. Therefore, the superimposed control loop is set so slowly by reducing the stiffness, that the measurement is not influenced.

A superimposed test movement is additionally possible. This helps to eliminate possible mechanical effects such as rubbing caused by friction.

4.4.7.2 Boundary conditions

If the control is instable before the beginning of the measurement, please reduce the stiffness (in the optimization window at the left bottom)

The following factors can disturb a measurement:

- ◆ Systems with high friction (e.g. linear actuators with sliding guide)
 - Here, the systems where the static friction is considerably higher than the kinetic friction (slip-stick effect) are especially problematic.
- ◆ Systems with significant slack points (play)
- ◆ Systems with "too light" or susceptible to oscillation bearing of the total drive (rack).
 - Formation of rack resonances. (e.g. with gantries,...)
- ◆ Non constant disturbance forces which influence the speed development. (e.g. extremely strong slot moments)

The effects of the factors one to three on the measurement can be reduced by using a test movement.

Caveat emptor (exclusion of warranty)

Due to multiple possibilities for disturbing influences of a real control path, we cannot accept any liability for secondary damages caused by faultily determined values.

Therefore it is essential to verify all values automatically determined before loading them into the control loop.

4.4.7.3 Process of the automatic determination of the load characteristic value (load identification)

- ◆ Please click on "unknown: default values are used" in the configuration wizard in the "External moment of inertia" window.
- ◆ After the configuration download, you can enter directly, that the optimization window is to be opened.
- ◆ In the Commissioning window (left at the bottom) change to commissioning mode.
- ◆ Finally enter the values of the excitation signal and of the test movement in the parameter window.
Parameters of the excitation signal:
 - ◆ Amplitude of the excitation signal in % of the motor reference current
Only an amplitude value causing a distinct disturbance can give a usable result.
 - ◆ permissible following error
In order to avoid a following error caused by the excitation signal, the permissible following error must be increased for the measurement if necessary.
 - ◆ Selection of the test movement: inactive, reverse, continuous
 - ◆ Parameterizing of the test movement if necessary
- ◆ Now energize drive and open load identification window in the commissioning window.



Caution! Safeguard the travel range before energizing!

- ◆ Starting the load identification.



Caution! The drive will perform a jerky movement during load identification!

- ◆ After the measurement, the values can be accepted. Depending on the application, 2 measurements for minimum external load and maximum external load are recommended.

4.4.7.4 Tips

Tip	Problem	Measures
1	Speed too low (with reverse operation)	Increase maximum speed and adapt travel range*
2	Speed too low (with continuous operation)	Increase maximum speed
3	Test movement missing	A test movement is important for drives with high friction or with mechanical slack points (play).
4	No error detected	Please note the boundary conditions (see on page 227).
5	Speed too low and amplitude of the excitation signal too small (with reverse operation)	Increase amplitude of the excitation signal; increase maximum speed and adapt travel range*
6	◆ Speed too low and ◆ amplitude of the excitation signal too small (with continuous operation)	Increase amplitude of the excitation signal; increase maximum speed.
7	◆ Test movement missing ◆ amplitude of the excitation signal too small	◆ Increase amplitude of the excitation signal or / and ◆ activate an appropriate test movement
8	amplitude of the excitation signal too small	Increase the amplitude of the excitation signal.
9	Following error occurred	Increase the parameter "permissible following error" or decrease the amplitude of the excitation signal.

*if the travel range is too short, the speed is not increased, as the drive does not reach the maximum speed.

4.4.8. Alignment of the analog inputs

In this chapter you can read about:

Signal processing of the analog inputs..... 230
 Offset alignment 230
 Gain alignment 230

There are two possibilities to align the analog inputs in the optimization window:

- ◆ Wizard-guided under commissioning: Commissioning functions (click on the yellow triangle with the left mouse button:

Attention”


This wizard guided automatic alignment does not work if you bridge Ain+ with Ground for the alignment!

In this case, please make a manual alignment as described below.

or

- ◆ by directly entering under optimization: Analog Input

4.4.8.1 Signal processing of the analog inputs



B: **Continuative structure image** (see on page 220)

4.4.8.2 Offset alignment

Performing an offset alignment when working with the $\pm 10\text{V}$ analog interface in the optimization window under optimization: Analog input Offset [170.4].

Enter the offset value for 0V input voltage.

The currently entered value is shown in the status value "analog input" (optimizing window at the top right) (unit: 1 \equiv 10V). Enter this value directly with the same sign as offset value.

The status value "analogue input" shows the corrected value.

4.4.8.3 Gain alignment

Performing an offset alignment when working with the $\pm 10\text{V}$ analog interface in the optimization window under optimization: Analog input: Gain [170.2].

A gain factor of 1 has been entered as default value.

The currently entered value is shown in the status value "analog input" (optimizing window at the top right).

The status value "analogue input" shows the corrected value.

4.4.9. C3 ServoSignalAnalyzer

In this chapter you can read about:

ServoSignalAnalyzer - function range	231
Signal analysis overview	232
Installation and activation of the ServoSignalAnalyzer	233
Analyses in the time range	235
Measurement of frequency spectra	238
Measurement of frequency responses	241
Overview of the user interface	247
Basics of frequency response measurement	260

4.4.9.1 ServoSignalAnalyzer - function range

The function range of the ServoSignalAnalyzer is divided into 2 units:

Analysis in the time range

This part of the function is freely available within the Compax3 ServoManager. The Compax3 ServoManager is part of the Compax3 servo drive delivery range.

Analysis in the frequency range

This part of the function requires a license key which you **can buy** (see on page 233).

The license is a company license and must only be bought once per company. For each PC you need however an individual key, which you can request individually.

4.4.9.2 Signal analysis overview


The ServoSignalAnalyzer offers three basic methods of analyzing systems:

- ◆ Analysis in the time range by measuring the step response
- ◆ Spectral analysis of individual signals
- ◆ Measurement of frequency response (Bode diagram) of the position control or of individual parts of the control as well as of the control path

These functions are available in the Compax3 ServoManager after the **activation** (see on page 233) with the aid of a system-dependent key.

You do not require expensive and complex measurement equipment -> a Compax3 device and a PC will do!

Basic structure of the signal analysis



Systems / signals

Depending on the kind of measurement, the SignalAnalyzer can help analyze the most different signals and systems.

Signal generator

This allows to inject different excitation signals (step, sine and noise signals) into the control loop.

Superposed system

For different analyses, superposed systems must be manipulated in order to allow a measurement. After the measurement, the changes made for this purpose are reset

C3 software oscilloscope

With the aid of the software oscilloscope, the contents of different objects can be registered and be loaded into the PC for further analysis.

Control and signal processing

The control of the entire measurement as well as the processing of the uploaded sample data are made in the PC.

4.4.9.3 Installation and activation of the ServoSignalAnalyzer

- ◆ Compax3 with up-to-date controller board (CTP 17)
- ◆ Firmware version R06-0 installed
- ◆ Execution of the C3 ServoManager Setup (on CD)
- ◆ If the firmware is too old => update with the aid of the firmware from the CD

Activation

In order to being able to use the analysis functions in the frequency range (for example frequency response measurement), a software activation is required.


Please observe:

The activation is only valid for the PC on which it was performed!


Caution! If the PC disposes of network adapters which are removed at times (e.g. PCMCIA cards or notebook docking stations), these adapters should be removed before generating the key!

In order to activate the ServoSignalAnalyzer, please follow these steps:

- ◆ Start the Compax3 ServoManager.




- ◆ Select the Select the C3 ServoSignalAnalyzer in the function tree under optimization.
In the right part of the window you can see the note that no key file was found.
- ◆ A double click on the preselected C3 ServoSignalAnalyzer will generate a system-dependent key.




- ◆ Acknowledge with OK and enter the key, which is on your clipboard, into an e-mail, which you please send to **eme.ssalicence@parker.com** (**mailto:eme.ssalicence@parker.com**).
- ◆ After receipt of the reply, copy the attached file "C3_SSA.KEY" into the C3 ServoManager directory (C:\Programs\Parker Hannifin\C3Mgr2\).
- ◆ => the software is activated.

4.4.9.4 Analyses in the time range

Selection and parameterization of the desired analysis function



Exemplary step function



step Value = Step Size

The following functions are available:

Position demand value step: For analysis of the demand value behavior of the position control**Step value < (admissible motion range / 2)**

=> even a 100% overshoot does not incite an error message

Speed demand value step: For analysis of the demand value behavior of the speed control

The position control is switched off during the measurement, this might lead in exceptional cases to a slow drift of the position.

Furthermore you should make sure that the selected speed step value corresponds to the parameterized admissible motion range.

Step value < (admissible motion range / time of measurement)

with time of measurement > 2s

Current demand value step: For analysis of the demand value behavior of the current control

The current setpoint jerk is set at the end of the oscilloscope recording time, but is reset to 0 after max. 50mS.

**Caution!**

- ◆ Many systems are not stable without control!
- ◆ Position as well as speed control are switched off during measurement =>
no measurement on z-axes!

Disturbance torque / force step response: For analysis of the disturbance value behavior of the control

The step of an external disturbance force is simulated and the reaction of the controller is registered.

Shaker function

For this, a sine signal is injected to the current which is used to excite the mechanic system. This allows to analyze the oscillation behavior - what oscillates at which frequency.

Basic settings of the analysis functions:**Maximum torque / maximum current / maximum speed (display):**

This is used as a lead for the selection of a suitable step value and indicates which maximum step value is possible.

Step value:

Gives the value of a step.

Permissible motion range (+/-):

- ◆ Indication, in which position window the axis may move during the analysis.
- ◆ This range is not left even in the event of an error.
- ◆ If the drive approaches the limits of the motion range, the controller will decelerate so that the drive will come to a standstill within the permitted motion range. The maximum permitted velocity is used to calculate the deceleration ramp, therefore the drive stops even before reaching the range limits and reports an error.
- ◆ Please make sure that a sufficiently large movement is set for the measurement and that it will be reduced by a high maximum permitted velocity.
- ◆ The motion range monitoring is especially important during current step responses, as position as well as speed control are deactivated during the measurement.

Max permitted speed

When exceeding this value, an error is triggered, the controller decelerates and reports an error.


When measuring the velocity setpoint jerk, the maximum permitted velocity is set to twice the step height.

Setting and automatic start of the oscilloscope:

After pressing "accept entries", the parameters of the oscilloscope (such as scanning time and the assignment of the individual channels) are automatically set to default values according to the respective step value.

When starting the step function, the oscilloscope is automatically started.

Start of the measurement



The start of the step function is made with the aid of the highlighted button.

4.4.9.5 Measurement of frequency spectra


Please note that you require a license key (see on page 233, see on page 231) for this application!

In this chapter you can read about:

- Functionality of the measurement.....238
- Leak effect and windowing.....239


Functionality of the measurement

Measurement of the spectral analysis



During the spectral analysis of scanned signals with the aid of the discrete Fourier transformation, a so-called frequency resolution (Δf) results, Δf being $=fA/N$, independently of the scanning frequency (fA) and of the number of measurement values used (N).
 The spectra of scanned signals are only defined for frequencies, which are an integer multiple of this frequency resolution.

Interpretation of the frequency spectrum




Leak effect and windowing

If frequencies not corresponding to the frequency resolution are present in the analyzed spectrum, the so-called leak effect can be caused.


Display of the leak effect with the aid of a 16 point discrete Fourier transformation

Complete oscillation period in the scanning period



Envelope without leak effect

Non complete oscillation period in the scanning period




Envelope with leak effect

Sine at 200Hz without windowing

Consequence of the leak effect shown at the example of a sine signal.


($f_A=4000\text{Hz}$; $N=500$; $\Rightarrow \Delta f=8\text{Hz}$)

$f_0=200\text{Hz} = 25 \cdot \Delta f$ frequency corresponds to the frequency-resolution



The sine frequency is exactly on a multiple of the frequency resolution (200Hz / 8Hz=25). The spectrum is clearly separated and there are no leak effects visible.

Sine at 204Hz



$\Delta f=8\text{Hz} / f_0=204\text{Hz} = 25.5 \cdot \Delta f / \text{frequency}$ does not correspond to the frequency resolution!

The sine frequency has only minimally changed, due to which it does, however, no longer match the frequency resolution ($204\text{Hz}/8\text{Hz}=25.5$) => leak effect

Two consequences are visible:

The spectrum is faded in the ranges at the right and at the left of the sine frequency. In this range, an amplitude is displayed, even though these frequencies are not contained in the real signal.


- ◆ The height of the peak of the sine frequency is reduced, => it seems as if the signal energy is leaking out and distributing over the spectrum. This explains the term leak effect.

Windowing

With the aid of the windowing, leak effects can be avoided. There are many different kinds of windowing, who do all have the same restrictions.

- ◆ windowing reduces the total energy of the analyzed signal, which results in a reduced amplitude of all measured frequencies.
- ◆ Individual frequency peaks do not appear so sharp and narrow as with measurements without windowing.

Sine at 200Hz and 204Hz with Hanning windowing



4.4.9.6 Measurement of frequency responses

Please note that you require a license key (see on page 233, see on page 231) for this application!

In this chapter you can read about:

Safety instructions concerning the frequency response measurement.....	241
Functionality of the measurement.....	241
Open/Closed Loop frequency response measurement	243
Excitation Signal.....	244
Non-linearities and their effects.....	244


Safety instructions concerning the frequency response measurement

During the measurement of the frequency response, the control is changed and influenced in multiple ways. You should therefore respect the following notes:

- ◆ During the measurement, the entire system is excited via a broad frequency spectrum. This might damage especially sensitive components (such as lenses) The risk increases with the extent of the excitation. In addition, natural mechanical frequencies may cause an increased excitation of individual components.
- ◆ The measurement of the frequency response can only be made in the setup mode with energized controller.
- ◆ During the current measurement (between start and stop of the measurement), no write flash may be executed.
- ◆ In the event of a break in communication during the measurement, the controller must be switched off and then on again in order to reestablish the original status.
- ◆ Changes of the controller parameters during the measurement are not permitted. Those may be overwritten by standard values when the measurement is terminated.

Functionality of the measurement

Basic structure of a frequency response measurement



In general, the analysis of the dynamic behavior of a system is made by analyzing the input and output signals.

If you transform the input signal as well as the output signal of a system into the range (Fourier transformation) and then divide the output signal by the input signal, you get the complex frequency response of the system.

$$G(s) = \frac{Y(s)}{U(s)}$$

$$y(t) \xrightarrow{F} Y(s)$$

with $u(t) \xrightarrow{F} U(s)$

A problem are, however, superimposed systems (the control)

Course of the measurement

- ◆ Superimposed controls are switched of (open Loop) or attenuated
- ◆ The excitation signal is injected in front of the system to be measured with the aid of the signal generator. Wait, until the system settled.
- ◆ Execution of the measurement: Registration of input and output signal with the aid of the oscilloscope.
- ◆ Upload of the measurement values from the controller into the PC.
- ◆ Processing of the measurement values into a frequency response
- ◆ If a cumulated measurement is configured: Averaging over several frequency responses.

During cumulated measurement, an average is taken over all measurements in the result memory and the result is then put out.

Open/Closed Loop frequency response measurement

In order to be able to analyze the transmission behavior of subordinate systems (such as for example speed control, current control or mechanical system), the influence of the superposed controls on the measurement must be avoided.

Influence of a superposed system on the frequency response measured

In the simplest case, the superposed controls are switched off completely (Open Loop) This provides the best measurement results due to the elimination of any influence caused by the superposed controls.

This is, however, rarely possible for reasons of safety or feasibility.




Caution!

- ◆ Many systems are not stable without control!
- ◆ Position as well as speed control are switched off during measurement => **no measurement on z-axes!**

If you want to analyze for example the mechanic system of a z-axis, the position control as well as the speed control must remain active.

In systems subject to friction it may be necessary in order to improve the quality of the measurement, to **move the system with a superimposed speed** (see on page 245), which is however only possible with a closed loop measurement.

Influence of an active superposed control on the result of the measurement



At the left without, at the right with the influence of the superposed control

In order to attenuate the influence of the superposed controls, the controller bandwidth is reduced to such an extent, that their influence on the measurement is negligible.


Excitation Signal

In order to be able to analyze the behavior of the system at individual frequencies, it is necessary that these frequencies can be measured in the input signal as well as in the output signal. For this, a signal generator excites all frequencies to be measured. For this applies, that the signal noise distance of the measurement is the larger, the larger the excitation of the system.
 High noise distance => low influence of disturbances on the measurement.

For this, an excitation signal is injected in front of the system to be measured.

The power (amplitude) of the excitation signal can be set. Start with a small amplitude and increase the amplitude slowly during the current measurement until the result of the measurement shows the desired quality.

Influence of the excitation amplitude on the quality of the measurement results



Left: Too small amplitude of the excitation signal (7.3mA)
 Right: Suitable amplitude of the excitation signal (73mA)

In the case of non-linearities in the system, an increase in the excitation may however lead to a **decline of the quality of the measurement** (see on page 244).


Non-linearities and their effects

In this chapter you can read about:

- Attenuation of the excitation amplitude 245
- Shifting the working point into a linear range..... 245

Non-linearities in mechanical systems are for example due to friction, backlash or position-dependent transmissions (cams and crankshaft drives). In general, the frequency response is only defined for linear systems (see 7.2 (see on page 261)). What happens in the frequency range in the event of a non-linear system, is shown below.


Signal amplitude too high => non-linearity in the signal range



Due to the non-linear transmission behavior of the system, many "new" frequencies were generated in the output signal. In the frequency response, only one change of the frequency present in the input signal can be displayed meaningfully.
 => The frequencies generated in the spectrum of the output signal lead to a deterioration of the measured frequency response.
 There are however two possibilities to make successful measurements of frequency responses in spite of non-linearities present:

Attenuation of the excitation amplitude

Signal amplitude too small => no non-linearity in the signal range



The signal range is reduced so that approximately linear conditions are valid. The results of the measurement will then display the dynamic behavior at the working point.

Example cam drive:

If the drive moves considerably (e.g. 180°) during the measurement, the behavior of the system will change greatly over this range => caused by non-linearities in the signal range.


An inexact measurement is the result.

If the excitation is reduced so that the drive will move only by a few degrees, the behavior of the system at this working point will be approximately constant.

An exact measurement is the result.

Shifting the working point into a linear range

Signal amplitude large with offset => no non-linearity in the signal range




For this, the signal range is shifted so that approximately linear conditions are valid => the results of the measurement show the dynamic behavior at the working point.

Example rubbing caused by friction:

In systems subject to a distinct transition between rubbing caused by friction and sliding friction, the rubbing force will reduce abruptly as soon as the drive is moved ($v > 0$). With a motor at standstill, the excitation signal will cause a multiple passing through the range of rubbing friction during measurement. Due to the non-linearity in the signal range, the resulting measurement will be inexact.

If the drive moves, however, fast enough during the measurement, so that the speed will not become zero during the measurement, the system remains in sliding friction and a precise measurement can be obtained.

Optimal measurement with rubbing friction

$V_{\text{test move}}$: Speed of the test movement

$V_{\text{stimulation}}$: Speed of the excitation signal


static friction: Static friction

Example backlash: (for example in gearboxes)

Here, non-linearities are caused, if the tooth edges will turn from one side to the other during measurement. The reason for this is a change of the sign of the force transmitted by the gearbox.

In order to avoid this, you can try to transmit a constant torque by keeping a constant speed and to avoid a change of the sign during the measurement by choosing a relatively small excitation amplitude.

4.4.9.7 Overview of the user interface



- (1) Selection of the signal or system to be measured (see on page 247)
- (2) Frequency settings (see on page 251)
- (3) Other settings (see on page 253)
- (4) Operating and status field (see on page 256)
- (5) Display of the measurement result (see on page 258)
- (6) Display of the measurement point at the cursor position (see on page 259)

In this chapter you can read about:

Selection of the signal or system to be measured.....	247
Frequency settings	251
Speed control	252
Other settings	253
Operating and status field.....	256
Display of the measurement result.....	258
Display of the measurement point at the cursor position	259

Selection of the signal or system to be measured.

In this chapter you can read about:

Current control.....	247
Mechanical system	248
Position control	249

With the aid of the tree structure, you may select what you want to measure. Here, the selection is made, if a frequency spectrum or a frequency response is to be measured.


The shown structures are simplified in such as all feedbacks are displayed without special transmission behavior. This is surely not the case in reality, serves however a better overview.

Current control

Closed current control

Shows the dynamic behavior of the closed current control.

=> How a signal on the current demand value is transmitted to the current actual value.
(response)



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:


During the optimization of the current control for verification

◆ for the design of superposed controllers.

Mechanical system

Current to velocity

Shows the dynamic behavior between the measured current actual value and the velocity actual value



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung


Reflects the transmission behavior between the acceleration at the motor and the acceleration at the load to be moved.

Application:

◆ for the analysis of the dynamic behavior of the mechanic system

Current to position

Shows the dynamic behavior between current actual value and position actual value.



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |

Application:


- ◆ for the analysis of the dynamic behavior of the mechanic system

Position control

Closed position control

Shows the dynamic behavior of the closed position control.

=> How a signal on the position demand value is transmitted to the position actual value.



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |


Application:

For the design of superposed controllers or systems.

- ◆ For the verification of the obtained controller speed during optimization
- ◆ for the revision of the controller design of the position control

open position control

Shows the dynamic behavior of all components in the position control loop, but without closing it.




Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:

- ◆ For the graphic design of the position control.

Compliance of Position control

Shows the dynamic disturbance value behavior of the position control.
 => which dynamic influence does a disturbance torque have on the following error.
 The disturbance torque is injected as disturbance current => this corresponds to the effect of a disturbance torque f




Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:

- ◆ Verification of the dynamic disturbance value behavior of the position control.
- ◆ Which following error generates a sinusoidal disturbance torque / disturbance current with the frequency f_Z ?
- ◆ The frequency response of the compliance corresponds to the disturbance step response in the time range

Frequency settings



(1) start frequency

- ◆ This is the smallest frequency at which is still measured. During the measurement of frequency spectrum and noise frequency response this results automatically from the bandwidth and is only displayed as an information.

(2) End (bandwidth)

- ◆ This corresponds to the highest frequency which is measured. Start frequency as well as the frequency resolution can be varied with the aid of the bandwidth for frequency spectrum and noise frequency response.

(3) Frequency resolution (see on page 238)


- ◆ During the measurement of frequency spectrum and noise frequency response this results automatically from the bandwidth and is only displayed as an information.

Speed control

Closed velocity control

Shows the dynamic behavior of the closed velocity control.

=> How a signal on the velocity demand value is transmitted to the velocity actual value.




- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |

Application:

- ◆ During the optimization of the velocity control for verification
- ◆ For the design of superposed controllers.

Open velocity control

Shows the dynamic behavior of all components in the velocity control loop, but without closing it.



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |

Application:


For the graphic design of the velocity control.

Compliance of velocity control

Shows the dynamic disturbance value behavior of the velocity control.

=> which dynamic influence does a disturbance torque have on the control deviation of the velocity control.

The disturbance torque is injected as disturbance current => this corresponds to the effect of a disturbance torque f




Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:

- ◆ Verification of the disturbance value behavior of the velocity control
- ◆ Which velocity deviation generates a sinusoidal disturbance torque / disturbance current with the frequency fZ ?
- ◆ The frequency response of the compliance corresponds to the disturbance step response in the time range

Other settings



(1) Excitation

Serves to set the excitation signal of the frequency response measurement.

(2) Permissible following error (only for frequency response measurement)

The resulting following error is increased by the injection of the excitation signal during the frequency response measurement. In order to allow for this, the permissible following error window can be enlarged so that the measurement can be made. After the end of the measurement, this is reset to the original value.

(3) Selection of the kind of analysis of the measurement results

Depending on the fact whether frequency spectra or frequency responses are measured, the following types of analyses are available:

For frequency spectra:

- ◆ (a) Spectrum
- ◆ (b) Spectrum cumulated
- ◆ (c) cascade diagram

For frequency responses:


- ◆ (d) noise frequency response
- ◆ (e) noise frequency response cumulated


Non cumulated measurement (a & d)

The measured data are displayed directly. This is especially suitable if you wish to analyze the effects of changes on the measurement results directly and promptly. The disadvantage is however a smaller noise distance (quality) and an increased sensitiveness of the measurement towards unique disturbances.

Cumulated measurement (b & e)

An average is taken from all measurements in the result memory. This reduces the influence of random signals and disturbances extremely (improvement of the quality). The number of measurements from which the average is taken, is set with the **Size of the result memory** (see on page 256).


Comparison of two frequency spectra without and with cumulation



Cascade diagram (c)


Frequency spectra are displayed subject to time. The information on the value of the signal is color-coded.

Cascade diagrams of the velocity signal during an acceleration process



This kind of display is suitable for the analysis of temporal changes in the measured spectrum.

Operating and status field



(1) Start and Stop of the measurement


(2) Status display

Current status of the measurement or of the controller (if no measurement is taking place).

(3) Progress of the registration of the signals in the controller

The time of registration of the signals in the controller itself can, depending on the bandwidth and the kind of measurement, take up to one minute.

(4) status of the activity of the different partitions of the measurement



a: Registration of the measurement in the controller

b: Upload of the measurement from the controller to the PC

c: Processing the measurement in the PC

(5) Different settings and options

Functions available in a pull-down menu:

Open superimposed control loops (see on page 243)**accept load force**

This serves, when opening the velocity controller, to accept the load which the controller has provided at the time of switching off => a z-axis does not drop down abruptly.

Measurement synchronous to the test movement

If this option is selected, it is ensured during the measurement, that the sampling does not take place in the turning point during a movement. Unless frequencies are generated due to the deceleration/acceleration of the drive, which influence the measurement.

Result memory

In the result memory, the results of the N last measurements are kept. This is important for the display of the cumulated measurement and for the cascade diagram. The larger the memory, the "older" the results still used. When the contents is deleted, all old measurements are discarded and do no longer influence the new results.

Windowing (see on page 239)

Here you can select different windowing modes for the measurement of frequency spectra. As default, no window is used.

Save measure to file

The currently displayed measurement result is stored and can be uploaded later into the ServoSignalAnalyzer. This does, however, not apply to the cascade diagram display.

Open measure from file


Here you can reload the measurements memorized before. You have the possibility to load up to four measurements subsequently and display them together in a graphic display.

Copy measurement to clipboard as graphic display.


The currently displayed measurement result is copied as pixel graphic (e.g. BMP) to the clipboard.

Display of the measurement result

Frequency spectra




Bode diagrams: Value and phase



By clicking with the left mouse button on the legend, this can be shifted by 90°. By clicking on the color bar, the color of the respective graph can be modified.

Cascade diagrams



By clicking with the left mouse button on the color scale, you can change between autoscale mode and fixscale mode.

AutoScaleMode:


In this mode, the scaling of the color scale is adapted automatically so that all values can be displayed.

FixScaleMode:

Here, the scaling is fixed.

=> If, for instance, a considerably higher value than before is to be displayed, it is simply displayed like the former maximum (red).

Display of the measurement point at the cursor position



The cursor is set by clicking on the left mouse button. All measurement data of the selected cursor position (frequency) are displayed in the "cursor" operating field.

4.4.9.8 Basics of frequency response measurement

In the drive and control technology, the display of signals and systems in the frequency range is often the best possibility to solve different tasks.

In this chapter you can read about:

Distinction between signals and systems	260
Linear Systems (LTI System).....	261
Mechanical system	262
Resonance points and their causes	263


Distinction between signals and systems

Defined objects and their interactions that can be combined to a whole by a plausible distinction from their environment (i.e. the complex reality) are called a system.

Example electric motor

This consists of a multitude of different components, but the function and the behavior of a motor can be described as a whole without describing each individual component and their interactions separately.

If the motor is energized, it will generate a torque at the motor shaft.



Current is therefore a signal, which causes at the input of the system motor a change of its torque output signal.

In order to register and process such signals in the controller, they are digitized and read in with the so-called scanning frequency (f_A). Thus the physical signal was converted into a finite sequence of numbers, which can be processed in the controller.

Linear Systems (LTI System)


Further explanations are based on the concept of so-called linear systems. This means that doubling the input value means that the portion of the output value influenced by it is also doubled. This, for instance, is not the case in the event of influence due to limitations, friction and backlash.

=> those are called non-linear systems, which can not be analyzed with the methods described here (or only with difficulties).

One of the most important properties of linear systems is that a sine signal, which is put through a linear system, is still a sine signal at the output, which differs from the input signal only in value and phase.

When a signal passes a LTI system, no new frequencies are generated.

Input and output signals of a linear system




If you know the value ($V(f_0)$) as well as the phase position ($u(f_0)$) for all frequencies, the LTI system is completely defined.

Such a graph of value and phase position in dependence of the frequency, is called frequency response or bode diagram.

=> only LTI systems can be analyzed with the aid of frequency responses.

Frequency response / bode diagram




The frequency response shows the amplification (value) and the phase shift (phase), which a signal is submitted to when passing through a system.

The displayed bode diagram allows the following conclusions:

If a sine with 60Hz and an amplitude of 1A is present at the input, a sine delayed by 94° and an amplitude of 0.01m/s will result at the output.

Mechanical system

Frequency response of a mechanic system: Current - velocity of a motor



The outlined course at the end of the measurement range does not permit statements on the system measured due to disturbances. Due to the attenuation of the signals increasing with the frequency, the sensitiveness of the measurement to disturbances (signal to noise ratio) increases with a rising frequency. The value as well as the phase response of the displayed frequency response are "disturbed" at the same intensity, this shows, that disturbances are the reason.


The value response consists basically of a straight, which declines with a slope of -20dB/decade (-20dB/decade => per tenfold increase of the frequency, the value decreases also by factor ten).

The phase response remains however almost constantly at -90° over a relatively large range.

In control technology, this is called integrating behavior (I-behavior).

the I-behavior can be explained as follows.

The measured current is proportional to the motor force and thus also to the acceleration of the driven mass. As the velocity is calculated from the integrated acceleration, the measured system looks as follows:




Input value is the current actual value, output value is the velocity actual value

Resonance points and their causes

In this chapter you can read about:

Rotary two mass system.....263
 Linear two mass system264
 Toothed belt drive as two mass system264

Mechanical system with a resonance point




fARes: Anti resonance frequency
 fRes: Resonance frequency

The displayed change of the frequency response (resonance point), has its cause in a so-called two mass system (caused by the elastic coupling of two masses).

Hint As, upon closer examination, each mechanic coupling shows a certain elasticity, it is no the question if there is a resonance point, but at which frequency it is and how well it is attenuated.

Rotary two mass system



The shown system corresponds for instance to a motor with a flywheel coupled via a shaft. Hereby J1 corresponds to the motor moment of inertia and J2 to the moment of inertia of the flywheel.


Calculation of the resonance frequencies in the rotary system with a hollow shaft as elastic coupling element

$$D = \int_{r_i}^{r_A} \frac{2 \cdot \pi \cdot G}{l} \cdot r^3 \cdot dr = \frac{G \cdot \pi \cdot (r_A^4 - r_i^4)}{2 \cdot l}$$

$$f_{ARes} = \frac{1}{2 \cdot \pi} \cdot \sqrt{\frac{D}{J_2}} \qquad f_{Res} = \frac{1}{2 \cdot \pi} \cdot \sqrt{D \cdot \left(\frac{1}{J_1} + \frac{1}{J_2} \right)}$$

G	Shear modulus of the material used [N/m ²] (e.g. approx. 80750N/mm ² for steel)
D	Torsional rigidity in [m/rad]
rA	Outer radius of the hollow shaft
rl	Inner radius of the hollow shaft
l	Length of the hollow shaft

Linear two mass system




Resonance frequencies in the linear system

$$f_{ARes} = \frac{1}{2 \cdot \pi} \cdot \sqrt{\frac{D}{m_2}}$$

$$f_{Res} = \frac{1}{2 \cdot \pi} \cdot \sqrt{D \cdot \left(\frac{1}{m_1} + \frac{1}{m_2} \right)}$$

D	Rigidity in [N/m]
m1	e.g. motor mass
m2	e.g. load mass

Toothed belt drive as two mass system



In toothed belt drives, the toothed belt is the elastic coupling element. Its rigidity depends directly on the lengths l_1 and l_2 and changes in dependence of the position of the moved mass.

$$D_{spez} = \frac{F_{max}}{0,004}; \quad l_2 = 2 \cdot l_{Achse} - l_1$$

$$D_1 = \frac{D_{spez}}{l_1}; \quad D_2 = \frac{D_{spez}}{l_2}; \quad D = D_1 + D_2 = \frac{2 \cdot D_{spez}}{l_1 \cdot \left(2 - \frac{l_1}{l_{Achse}}\right)}$$

$$f_{ARes} = \frac{1}{2\pi} \cdot \sqrt{\frac{D}{m_2}} \quad f_{Res} = \frac{1}{2\pi} \cdot \sqrt{D \cdot \left(\frac{1}{m_2} + \frac{(r_{Zahnrad})^2}{J_1 \cdot (i_{Getriebe})^2} \right)}$$

D	Total spring constant of the toothed belt drive
Dspez	Specific spring constant of the toothed belt used
D1	Spring rate of the belt length l_1
D2	Spring rate of the belt length l_2
iGearbox	Transmission ratio of the gearbox
lAxis	Length of the axis
J1	Moment of inertia of motor and gearbox
m2	translatory moved mass
rToothed wheel	Radius of the drive pinion


Here you can find examples as a movie in the help file.

4.4.10. ProfileViewer for the optimization of the motion profile

In this chapter you can read about:

- Mode 1: Time and maximum values are deduced from Compax3 input values265
- Mode 2: Compax3 input values are deduced from times and maximum values.....266

You will find the ProfilViewer in the Compax3 ServoManager under the "Tools" Menu:



4.4.10.1 Mode 1: Time and maximum values are deduced from Compax3 input values

- ◆ The motion profile is calculated from Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
 - ◆ Times for the acceleration, deceleration and constant phase
 - ◆ Maximum values for acceleration, deceleration and speed

4.4.10.2 Mode 2: Compax3 input values are deduced from times and maximum values

- ◆ A jerk-limited motion profile is calculated from the positioning time and the maximum speed / acceleration
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
 - ◆ the parameters Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
 - ◆ Times for the acceleration, deceleration and constant phase
 - ◆ Maximum values for acceleration, deceleration and speed


Set deceleration and acceleration phase

The profile can be defined more exactly by entering the segmentation into deceleration and acceleration phase.

When setting 50% and 50%, a symmetrical design will result, the values for triangular operation are calculated, which is limited by the maximum speed.

The total of the percentage values may not exceed 100.

Example:



4.4.11. Turning the motor holding brake on and off

Compax3 controls the holding brake of the motor and the power output stage. The time behavior can be set.


Application:

With an axis that is subject to momentum when it is halted (e. g. for a z-axis) the drive can be switched on and off such that no movement of the load takes place. The drive thereby remains energized during the holding brake response time. This is adjustable.

The power output stage current is de-energized by:

- ◆ Error or
- ◆ by deactivating the MC_Power module
- ◆ the ServoManager

Thereafter the motor is braked to zero rotation speed on the set ramp. When zero speed is reached, the motor is de-energized with the delay "brake closing delay time".




- 1: Motor powered
- 2: Motor de-energized
- 3: Open brake
- 4: Engage the brake
- 5: Brake closing delay time

The power output stage is enabled by:

- ◆ Quit (acknowledge) (after error) with the MC_Reset module
- ◆ by activating the MC_Power module
- ◆ the ServoManager

The motor is energized with the delay "delay time for brake release":
 brake closing delay time > 0 brake closing delay time < 0



- 1: Motor powered
 - 2: Motor de-energized
 - 3: Open brake
 - 4: Engage the brake
 - 5: Delay time for brake release (positive value)
 - 6: Delay time for brake release (negative value)
- A negative value (6) can be used to energize the motor and then to release the brake after the given time.

5. Motion control

In this chapter you can read about:

Programming based on IEC61131-3.....	268
Status diagram based on PLCopen	278
Control functions.....	279
Reading values.....	285
Positioning functions (standard).....	289
Error handling.....	312
Process image.....	316
Interface to C3 powerPLmC.....	327
IEC examples	332
Profibus: Simulate Profidrive profile (C3_ProfiDrive_Statemachine).....	339
Emulate CanOpen DS402 (C3_DS402_Statemachine)	341

5.1 Programming based on IEC61131-3

In this chapter you can read about:

Compax3 ServoManager: IEC61131-3 programming.....	269
Prerequisites	269
CoDeSys / Compax3 target system (Target Package).....	269
Languages supported.....	270
Function range supported.....	270
Data types supported.....	273
Retain Variables	273
Recipe table with 9 columns and 32 (120) lines	273
Maximum program size	274
Cycle time.....	274
Access to the Compax3 object directory	274
Compilation, debugging and down/upload of IEC61131 programs	275
General rules / timing.....	275
Library constants	277

5.1.1. Compax3 ServoManager: IEC61131-3 programming

In the function directory of the Compax3 ServoManager, you can find the "IEC61131-3 programming category with IEC61131-3 functions:

- ◆ IEC61131-3 settings
 - Input of the setpoint cycle time and specification of the error reaction upon cycle timeout
- ◆ IEC61131-3 CoDeSys development environment
 - Starting CoDeSys
- ◆ IEC61131-3 Debugger
 - Starting the Debugger
- ◆ Link IEC61131-3 Project.
 - Link external IEC project to the active Compax3 project. When editing the IEC project, the external project is also edited. This makes it possible to use the same IEC project with several Compax3 projects.
- ◆ Import IEC61131-3 Project.
 - Integrate external IEC project into the active Compax3 project.
- ◆ Export IEC61131-3 Project.
 - Export IEC project from the active Compax3 project.

5.1.2. Prerequisites

- ◆ Installation of the CoDeSys programming tool.
- ◆ Installation of necessary Target Packages (target systems):
 - ◆ Bring up the "InstallTarget" program (program group "3S Software": "CoDeSys V2.3")
 - ◆ Select the target file; file name from "Open"; file name: "Compax3.tnf".
 - ◆ The selected target can be installed with "Install".

5.1.3. CoDeSys / Compax3 target system (Target Package)

Targets for Compax3 servo axes

Beginning with Compax3 software version V2.0, two Compax3 targets are included with delivery (containing module and object descriptions).

- ◆ **CoDeSys for C3 T30:** for Compax3 T30 (as per Compax3 Software version V2.0)
- ◆ **CoDeSys for C3 T40:** for Compax3 T40 (as per Compax3 Software version V2.0)

The old target is still available for programs that were created earlier (created with Compax3 software version < V2.0).

- ◆ **CoDeSys for Compax3:** for Compax3 T30
- This programs are thus still capable of running.

When migrating to a new target, you must be certain that the module and object names have been changed.

Edit the appropriate parts of the IEC program accordingly.

Targets for Compax3F hydraulic axes

- ◆ **CoDeSys for C3F T30:** for Compax3 T30
- ◆ **CoDeSys for C3F T40:** for Compax3 T40

5.1.3.1 Program development and test

Program development

CoDeSys is the development environment for control systems which will help you develop Compax3 IEC61131 programs. CoDeSys is called up from the Compax3 ServoManager (under "programming: IEC61131-3 CoDeSys development environment")

The IEC program can be integrated into the C3 ServoManager project or exported again from the project as required.

When CoDeSys is brought up, the IEC program stored in the project is opened. If the project does not contain an IEC program, a selection dialog appears.

Download to Compax3

After the IEC61131 program has been developed and compiled with CoDeSys, it is downloaded to Compax3 by means of the ServoManager (in "Download: PC -> Compax3").

Program test

For testing your program directly with Compax3, you may use the Compax3 IEC61131-3 debugger (the debug functions of CoDeSys are not supported in conjunction with Compax3). The debugger is called up from the ServoManager (under Programming: IEC61131-3 debugger). It automatically accesses the last IEC61131-3 program in the ServoManager to be loaded into Compax3 with "Download: IEC61131-3" and makes its modules and variables available in the project tree.

The data from Compax3 are read via the instruction "log in". Please note in this regard that the interface to Compax3 can only be assigned once: Online functions in the ServoManager such as Upload, Download, Status display in the Optimization window or oscilloscope functions are not possible simultaneously. These functions interrupt the connection between debugger and Compax3 automatically.

5.1.3.2 Recipe management

The recipe management function in CoDeSys is not supported in conjunction with Compax3. Please use the recipe table available in Compax3 (also see in the configuration wizard).

5.1.4. Languages supported

- ◆ IL (Instruction List)
- ◆ ST (Structured Text)
- ◆ FBD (Function block diagram)
- ◆ CFC (continuous function chart editor)
- ◆ LD (Ladder diagram)

5.1.5. Function range supported

In this chapter you can read about:

Operators supported.....	271
Standard functions supported	272
Standard function modules supported.....	272

5.1.5.1 Operators supported

IL	FBP / CFC / SFC	ST
LD(N)		
ST(N)		
R		
S		
AND(N)	AND	AND(N)
OR(N)	OR	OR(N)
XOR(N)	XOR	XOR(N)
NOT	NOT	NOT
ADD	ADD	+
SUB	SUB	-
MUL	MUL	*
DIV	DIV	/
GT	GT	>
GE	GE	>=
EQ	EQ	=
NE	NE	<>
LE	LE	<=
LT	LT	<
RET	RET	RETURN
	MOVE	
		:=
CAL(C/N)		
JMP(C/N)		
		CASE
		DO
		ELSE
		ELSIF
		END_CASE
		END_FOR
		END_IF
		END_REPEAT
		END_WHILE
		EXIT
		FOR
		IF
		REPEAT
		THEN
		TO
		UNTIL
		WHILE

5.1.5.2 Standard functions supported

Bit manipulation functions

SHL, SHR, ROL, ROR

Numeric functions

ABS, SQRT, SIN, COS

Functions for type conversion

Type conversions x_TO_y	X=Source data type, Y=Target data type
TRUNC	

Functions for selection

MIN	Not for BOOL /WORD / DWORD
MAX	Not for BOOL /WORD / DWORD
LIMIT	Not for BOOL /WORD / DWORD
SEL	Not for BOOL /WORD / DWORD

5.1.5.3 Standard function modules supported

FlipFlops

RS, SR,

Trigger

R_TRIG, F_TRIG,

Numerator

CTU, CTD, CTUD,

Timer

TON, TOF, TP,

maximum 8 pieces, time resolution 0.5ms

(the number of timers required is displayed in the CoDeSys output window during compilation)

PID Controller function block

5.1.6. Data types supported

The following data types are available for IEC61131-3 programming:

Name	Division	Format
BOOL	Status values: TRUE or FALSE	Logical variable.
INT	-32768...32767	16-bit integer: Fixed point number without places after the decimal
DINT	-2147483648...2147483647	32 bit integer: Fixed point number without places after the decimal
REAL		32-bit floating point: 16 bits before the decimal and 16 bits after the decimal
WORD	0...65535	16-bit bit sequence (no range of values)
DWORD	0...4294967295	32-bit bit sequence (no range of values)
TIME	0...4194.3035s	32 Bit - Format (resolution: 0.5 ms)
ENUM	User-defined type of enumeration (local enumerations are not supported)	

Altogether 500 16-bit variables are available. These include BOOL, INT, and WORD. Altogether 150 32-bit variables are available. These include DINT, DWORD, TIME, REAL.

The number of the required variables is displayed in the CoDeSys output window during compilation.

5.1.7. Retain Variables

6 retain variables (variables that are safe from power failure) are available

- ◆ 3x16-bit retain-variables
- ◆ 3x32-bit retain-variables

5.1.8. Recipe table with 9 columns and 32 (120) lines

An array, i.e. a table with 9 columns and 32 rows for direct access and additional 88 rows for indirect access, is available to store values.

This table is freely assignable and can be used for example to store position sets or for recipe management.

In addition, this table can be used to exchange data with an external control system or a POP, for example.

The layout of the table is as follows:

Column 1 Type: REAL objects O1901	Column 2 Type: REAL objects O1902	Column 3 Type: INT objects O1903	Column 4 Type: INT objects O1904	Column 5 Type: INT objects O1905	Column 6 Type: DINT objects O1906	Column 7 Type: DINT objects O1907	Column 8 Type: DINT objects O1908	Column 9 Type: DINT objects O1909
Row 1 "C3Array.Col01_Row01" (1901.1)	Row 1 "C3Array.Col02_Row01" (1902.1)	Row 1 "C3Array.Col03_Row01" (1903.1)	Row 1 "C3Array.Col04_Row01" (1904.1)	Row 1 "C3Array.Col05_Row01" (1905.1)	Row 1 "C3Array.Col06_Row01" (1906.1)	Row 1 "C3Array.Col07_Row01" (1907.1)	Row 1 "C3Array.Col08_Row01" (1908.1)	Row 1 "C3Array.Col09_Row01" (1909.1)
...
...
...
Row 32 "C3Array.Col01_Row32" (1901.32)	Row 32 "C3Array.Col02_Row32" (1902.32)	Row 32 "C3Array.Col03_Row32" (1903.32)	Row 32 "C3Array.Col04_Row32" (1904.32)	Row 32 "C3Array.Col05_Row32" (1905.32)	Row 32 "C3Array.Col06_Row32" (1906.32)	Row 32 "C3Array.Col07_Row32" (1907.32)	Row 32 "C3Array.Col08_Row32" (1908.32)	Row 32 "C3Array.Col09_Row32" (1909.32)

In addition to direct access to the first 32 table rows, indirect access to the 120 rows of the complete table is possible via pointer addressing.

To do this, the table pointer "C3ArrayPointer_Row" (Object 1900.1) must be set to the desired row.

This offers access to Columns 1 through 9 of the referenced rows through "C3Array_Indirect_Col1" to "C3Array_Indirect_Col9" (objects 1910.1 to 1910.9).

5.1.9. Maximum program size

Up to 6000 (IL) instructions are possible

Note! Please note, that integrated function modules do also require program memory. The required program memory can therefore increase due to a Targets update, even without any program changes.

The number of instructions generated is displayed in the CoDeSys output window by the Compax3 compiler during interpretation.

5.1.10. Cycle time

Minimal cycle time: 1ms.


The cycle time can be adjusted with the Compax3 ServoManager when downloading IEC61131-3 programs.

It is possible to optimize later in the optimization display of the Compax3 ServoManager. The cycle time is displayed there in increments of 500 μ s (2 = 1 ms; 3 = 1.5 ms; etc.).

The IEC61131-3 program is stopped cycle time of 0.

5.1.11. Access to the Compax3 object directory

All Compax3 objects are encapsulated in the "C3" program module. Access to **Compax3 objects** (see on page 415) in CoDeSys:



Compax3 objects are divided into groups:

C3.	Compax3 - Objects
C3Array.	Variable (Recipe) List
C3Pop.	Objects for the Parker Operator Panel Pop.
C3Cam.	Objects for the T40 cam control. Do only use the objects described in this help; the additional objects are for internal use only!
C3Plus.	Additional objects that are generally not required.
C3Scope.	Objects for programming the oscilloscope function. For internal use only!

The object name reveals the group assignment.

In general, it applies:

Objects that are not described here are reserved objects!

5.1.12. Compilation, debugging and down/upload of IEC61131 programs

- ◆ Compiling IEC61131-3 programs in CoDeSys
- ◆ Downloading or uploading of IEC61131-3 programs with the Compax3 ServoManager.
- ◆ The debugger is called up from the C3 ServoManager under "Programming: IEC61131-3 debugger" called up.

Note:

Before compiling you have to enter for which Compax3 versions the compilation is to be executed.

Please note that when selecting "all versions" not all functions are available, only the minimal range of functions is supported.

Only if the latest firmware version was selected (and the corresponding firmware is loaded in the target Compax3) all functions described here are supported.

5.1.13. General rules / timing

General rules

Positioning

Within an IEC cycle, only one positioning module may be activated!

If 2 positioning modules are activated within one IEC cycle, it is not defined which one is executed.

Status of the outputs

- ◆ The outputs "Done", "InVelocity", "Error", "ErrorID" and "CommandAborted" reset with the falling edge of the "Execute" input.
- ◆ If the "Execute" input goes back to FALSE again before the module action (for example positioning) has been completed ("pulse to Execute"), the corresponding outputs (for example "Done") is set upon termination for precisely ONE cycle.
- ◆ The outputs "Done" and "Error" are never simultaneously TRUE.
- ◆ If the instance of a function module receives a new "Execute" signal before the function ends, the module will not show any response (no "Done" and no "Command Aborted") in reference to the previous action.

Input parameters	<ul style="list-style-type: none"> ◆ Parameters are accepted with the rising edge of the "Execute" signal. ◆ To be able to accept modified parameters, the module must be triggered again with an "Execute" signal.
Missing input parameters	<ul style="list-style-type: none"> ◆ If an input parameter is missing, the previous value of this instance will be used in accordance with IEC61131-3. ◆ On the 1st. callup, the standard value is used.
Position and distance	<ul style="list-style-type: none"> ◆ "Position" is a value that is defined for a reference system, i.e. a specific position value is a fixed location in the reference system. ◆ "Distance" is the difference between 2 positions.
Sign	<ul style="list-style-type: none"> ◆ "Velocity", "Acceleration", "Deceleration" and "Jerk" are always positive variables. ◆ "Position" and "Distance" may be positive or negative.
Error handling	<ul style="list-style-type: none"> ◆ All function modules have an "Error" output that can be activated by a module during a module sequence. ◆ The ErrorID (error number) can be read by an axis error with the "MC_ReadAxisError" module.
Behavior of the "Done" - output	<p>The "Done" output is set if the function module has been successfully executed. If one positioning process is interrupted by a second If one positioning process is interrupted by a second before it is complete, the first function block no "Done"</p>
Behavior of the "CommandAborted" output	<p>"CommandAborted" is set if a positioning process is interrupted by a second positioning process is interrupted by "MC_Stop" or MC_Power. The reset behavior of "CommandAborted" is the same as "Done". If "CommandAborted" occurs, the other outputs will be reset.</p>
Value range of the movement parameters	<p>Please note that the limits are specified in revolutions. To convert to the configured unit, multiply the min/max values by the "travel distance per motor revolution".</p>
Linear motors	<p>With a configured linear motor, all revolution data must be replaced by pitch. To convert to the configured unit, the min/max values must be multiplied by the pitch length (see the technical data for the motor).</p>


5.1.14. Library constants

The following global constants are declared in the PLCopen function module library:

For the selection of the master signal source:		
AXIS_REF_Physical	C3_AXIS_Ref	for +/-10V analog input, step / direction input 5V or Encoder A/B input 5V (depending on the configuration of the physical source under signal source)
Axis_REF_HEDA	C3_AXIS_Ref	HEDA
General constants		
MC_Direction_Positive	INT	For supply of the Direction input of the MC_MoveVelocity module (for positive rotational direction)
MC_Direction_Negative	INT	For supply of the Direction input of the MC_MoveVelocity module (for negative rotational direction)
MC_Direction_Current	INT	For supply of the Direction input of the MC_MoveVelocity module (retaining the last rotational direction to be selected)
Direction_Memory	INT (Variable)	The MC_MoveVelocity modules instances store the last direction parameter in this variable. This variable can only be used by Motion Control modules and must not be overwritten!
Reset positioning mode		
All directions	INT	C3_all_direction
Positive direction	INT	MC_positive_direction
Shortest path	INT	MC_shortest_way
Negative direction	INT	MC_negative_direction
Actual direction	INT	MC_current_direction

For power supply of the axis inputs/outputs of modules:		
Axis_Ref_LocalAxis	INT	Local axis (physically present axis)
Reset positioning mode		
All directions	INT	C3_all_direction
Positive direction	INT	MC_positive_direction
Shortest path	INT	MC_shortest_way
Negative direction	INT	MC_negative_direction
Actual direction	INT	MC_current_direction

5.2 Status diagram based on PLCopen




5.3 Control functions

In this chapter you can read about:

Activation of the drive (MC_Power).....	280
Stop (MC_Stop).....	282
Opening the brake (C3_OpenBrake).....	284

5.3.1. Activation of the drive (MC_Power)


FB name	MC_Power	
Transition into the "Standstill: disable" state or "Standstill: powered"		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Enable	BOOL	Activates the module; A rising edge on the input activates the drive, a falling edge deactivates the drive with the ramp defined for errors (see on page 138). Please observe: The configured error ramp is limited. The error ramp will not be smaller than the deceleration set in the last motion set.
VAR_OUTPUT		
Status	BOOL	State of the power output stage (TRUE=drive activated, FALSE=drive deactivated)
Error	BOOL	Error when activating or deactivating the drive
<p>Notes:</p> <ul style="list-style-type: none"> ◆ If the input parameter "Enable" is set to "TRUE", all enables of the drive are set. The command is only accepted if the axis is not yet or still active (Output "State" = FALSE). Furthermore, the device may not be in error state. ◆ All enables will be reset if the input parameter "Enable" = FALSE, the axis decelerates with the configured error ramp to speed = 0 - the "state" output remains on "TRUE" during downramping. ◆ Compax3 Servo: During automatic commutation, the output "State" is not set to TRUE for activation, but rather not until after automatic commutation has been successfully completed. ◆ Compax3 Servo: With Asynchronous motors, the output "State" is not set to TRUE for activation, but rather not until after the magnetization current has been successfully built up. ◆ An enable is denied until the intermediate circuit is loaded, this may take up to 2s when switching on Compax3H for the first time. ◆ In the Compax3M, an enable is denied if the mains module is in the initialization phase (e.g. the intermediate circuit is not yet completely loaded) or the communication between axis and axis combination is not active. ◆ If the drive is in error state (error reaction 1: controller active) and the enable of the MC_Power is deactivated, the drive is deactivated (error reaction 2). ◆ C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group. ◆ The "Error" output is generated, if activation is not possible. Possible cause: Device in error state, activation of a different IEC module after execution of the MC_Power. ◆ The "Error" output is generated, if deactivation is not possible. Possible cause: Activation of a different IEC module after execution of MC_Power. ◆ Compax3 Servo: On motors with brake, the configured braking delay for opening the brake leads to a temporal delay of the "state" output with reference to control of the "enable" input. <p>Note on sequencer programming (see on page 282)</p> <ul style="list-style-type: none"> ◆ Input False on the enable input interrupts a stop sequence triggered by a rising edge on the Execute input of the MC_Stop. ◆ The axis is also in "Standstill" state after PowerOff (however deactivated), but the Done output of MC_Stop is not set. ◆ In sequencers, a sole query of the MC_Stop.Done output is not sufficient for standstill acquisition, in addition, the MC-ReadStatus.Standstill or MC_Power.Status signals must be linked. See also description of module MC_Stop. 		



5.3.2. Stop (MC_Stop)

FB name	MC_Stop	
Stops the current movement Please note: Only one instance of MC_Stop is permitted per axis!		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Stops the movement
Deceleration	DINT	Value of deceleration (always positive) [Units/s ²] Range of values: 0.24 rev/s ² ... 1000000 rev/s ² Please observe: The configured STOP ramp is limited. The STOP ramp will not be smaller than the deceleration set in the last motion set.
Jerk	DINT	Value of the deceleration jerk [Units/s ³] (always positive) value range: 30 rev/s ³ ... 125000000 rev/s ³ Please note: The STOP deceleration is limited. It is limited to the deceleration of the latest motion set.
VAR_OUTPUT		
Done	BOOL	Movement stopped
Error	BOOL	Error while stopping positioning
<p>Note:</p> <ul style="list-style-type: none"> ◆ As long as the "Execute" input is set, the axis remains in the "Stopping" status (as long as the axis is activated) and is unable to execute any additional movement commands! ◆ If the axis is deactivated by setting the Enable signal of the "MC_Power" module to FALSE, the Stopping state will then be exited. ◆ If the enable signal of the "MC_Power" module is set to TRUE again, the axis goes back to the "Stopping" state again if the Execute input of the "MC_Stop" module is still TRUE. ◆ Compax3 T40 note: Curve operation upon STOP: The master position and the curve are not influenced by a STOP of the axis. The acquisition and cam generation continue; this means that the curve output is available in the event of an average. If the curve is to be restarted after the STOP without consideration of the previous history, the "C3_CamReset" module must be executed after stop. ◆ C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group. <p>Note on sequencer programming</p> <ul style="list-style-type: none"> ◆ In sequencers, a sole query of the done output is not sufficient for standstill acquisition, as it can be reported with a considerable delay. In addition, the MC-ReadStatus.Standstill or MC_Power.Status signals must be linked. <p>Example 1: PowerOff during a stop sequence:</p> <ul style="list-style-type: none"> ◆ Input False on the enable input of MC_Power interrupts a stop sequence triggered by a rising edge on the Execute input. ◆ The Stop module goes on in the background "without function" in the "Standstill (not powered)" states and is only continued by reactivating the axis with the MC_Power module when the "Standstill (powered)" state is reached. ◆ The Done output message is delayed until the "Standstill (powered)" state is reached. <p>Example 2: Device error during a stop sequence:</p>		

- ◆ A device error interrupts a stop sequence triggered by a rising edge on the Execute input.
- ◆ The axis is temporarily in "Errorstop" state and will only pass into "Standstill" state after acknowledging the error with MC_Reset (upon error reaction 2 not powered at first).
- ◆ The Stop module goes on in the background "without function" in the "Errorstop" and "Standstill (not powered)" states and is only continued by acknowledging the error (error reaction 1) (upon error reaction 2 followed by reactivation of the axis with MC_Power) when the "Standstill (powered)" state is reached.
- ◆ The Done output message is delayed until the "Standstill (powered)" state is reached.




In this chapter you can read about:

MC_Stop: Example 1283
 MC_Stop: Example 2284


5.3.2.1 MC_Stop: Example 1

The following illustration shows an example of how the MC_Stop module interrupts and stops a movement that is in progress. If a positioning module is interrupted by the MC_Stop module, it reports "Command Aborted" and can no longer be executed as long as the MC_Stop module is active. If the MC_Stop module is inactive (no "Execute" signal), the function module can be executed again.


Timing Diagram:



Note: If a positioning is to follow immediately after the stop, this can take place with the falling edge of the done output at the earliest:




5.3.2.2 MC_Stop: Example 2



5.3.3. Opening the brake (C3_OpenBrake)

FB name	C3_OpenBrake	
Opening the motor holding brake - works only with no current (standstill - not powered)		
VAR_INPUT		
OpenBrake	BOOL	"TRUE" opens the motor holding brake
When current is being supplied to the drive, the input has no function.		




5.4 Reading values

In this chapter you can read about:


Reading the current position (MC_ReadActualPosition).....	285
Read access to the (C3_ReadArray) array	287
Reading the device status (MC_ReadStatus)	288

5.4.1. Reading the current position (MC_ReadActualPosition)

FB name	MC_ReadActualPosition	
Reading the current axis position		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Enable	BOOL	Activates the module, continuous reading of the axis position as long as Enable=TRUE
VAR_OUTPUT		
Done	BOOL	Position value available
Error	BOOL	Error while reading the position
Position	REAL	Axis position
Note: -		




You can read the current position of the axis with this module.
 As long as the input parameter "Enable" = TRUE, the current parameter value will be supplied **cyclically** (see on page 328) to the output parameter "Position".
 The status of the input parameter must be present for at least one module call.
 The following illustration shows the behavior of parameters in the MC_ReadActualPosition function module.




5.4.2. Read access to the (C3_ReadArray) array

FB name		C3_ReadArray
This module is used for simplified read access to the array (recipe table).		
VAR_INPUT		
Enable	BOOL	The desired rows can be read with the Enable input (after selecting "Row").
Row	INT	Desired table row (1 ...120). This input works with object 1900.1, please respect this, if you access object 1900.1 directly in addition.
VAR_OUTPUT		
Error	BOOL	The output Error signalizes that there was an error during reading out the array (non existing row selected on the Row Input).
Col1 – Col9	REAL INT DINT	The individual columns of the array can be accessed through outputs Col1 through Col9.
Notes: - Rows will be read cyclically as long as Enable = TRUE.		



5.4.3. Reading the device status (MC_ReadStatus)

FB name		MC_ReadStatus
Specifies the current status according to the PLCopen status machine		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Enable	BOOL	Activates the module; continuous outputs of output parameters as long as Enable=TRUE
VAR_OUTPUT		
Done	BOOL	Status values available
Error	BOOL	Error while executing module
Errorstop	BOOL	Error stop function. The motor brakes as specified by the stop ramp and is de-energized;
Stopping	BOOL	The motor is stopped;
Standstill	BOOL	The motor is stopped;
DiscreteMotion	BOOL	Individual movement;
ContinuousMotion	BOOL	Continuous positioning;
Homing	BOOL	Machine reference is approached;
SynchronizedMotion	BOOL	Synchronous motion
Note: See also in the status diagram.		



5.5 Positioning functions (standard)

In this chapter you can read about:

Dynamic positioning	289
Value range for positioning parameters	289
Absolute positioning (MC_MoveAbsolute).....	290
Relative positioning (MC_MoveRelative)	295
Additive positioning (MC_MoveAdditive).....	298
Endless positioning (MC_MoveVelocity)	300
Manual operation (C3_Jog)	302
Machine zero (MC_Home).....	304
Electronic gearbox (MC_GearIn)	306
Current setting operation (C3_Current).....	309
Torque / force control (C3_TorqueControl)	310

5.5.1. Dynamic positioning

Dynamic positioning processes can be performed with the modules MC_MoveAbsolute, MC_MoveRelative and MC_MoveAdditive. The speed can be altered dynamically with MC_MoveVelocity.

In the state: "Discrete Motion"

If another, second positioning process is activated in the "Discrete Motion" state, Positioning activated, then the 1st. Positioning is aborted. The transition to the new destination occurs dynamically, i.e. without any intervening stop.

In "Continuous Motion" state

If a positioning process (MC_MoveAbsolute, MC_MoveRelative or MC_MoveAdditive) or a MC_MoveVelocity is activated in the "Continuous Motion" state, the active function module will then be interrupted. All input variables of the new positioning process will then be taken over.

5.5.2. Value range for positioning parameters

The unit "increments" is valid only for position values!

Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

With virtual Master other limit values apply

Speed	[Rev/s], [pitch/s]	0.00001157	... 16 000
Acceleration / deceleration	Rev/s ² , [pitch/s ²]	1.91	... 8 000 000
Acceleration / deceleration jerk:	Rev/s ³ , [pitch/s ³]	239	... 1 000 000 000

5.5.3. Absolute positioning (MC_MoveAbsolute)

FB name	MC_MoveAbsolute	
Absolute positioning to a specified position.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Position	REAL	Absolute target position of the movement to be executed (configured unit [units]) (positive and negative direction) -Value range ¹
Velocity	REAL	Value of maximum speed (always positive) (not necessarily reached) -value range ² - [Units/s ³] ³
Acceleration	DINT	Value of acceleration (always positive) [Units/s ²⁴] -value range ⁵
Deceleration	DINT	Value of deceleration (always positive) [Units/s ²⁶] -value range ⁷
Jerk	DINT	Value of the acceleration jerk (see on page 294) [Units/s ³⁸] (always positive) -value range ⁹
JerkDecel	DINT	Value of the deceleration jerk [Units/s ³¹⁰] (always positive) -value range ¹¹
VAR_OUTPUT		
Done	BOOL	Specified setpoint position on the setpoint generator output is reached
CommandAborted	BOOL	Positioning aborted
Error	BOOL	Error while executing module
<p>Notes:</p> <ul style="list-style-type: none"> ◆ Continuous operation can be selected via object 1111.8 "C3Plus.Position_restposition_mode" <> 0; setpoint value and actual value are then set to 0 before each positioning. ◆ You can optimize the motion profile data with the "ProfilViewer" (see on page 265) software tool! <p>Notes on T40 (Cam):</p> <ul style="list-style-type: none"> ◆ If a SuperImposed movement is started during an absolute movement, the absolute position is not accessed, but the absolute position plus the position entered in the SuperImposed. 		

¹ Target position: [Rev], [Pitch]-4 000 000...4 000 000

² Speed for positioning: [Rev/s], [pitch/s]0.00001157 ...2000

³ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁴ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁵ Acceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000

⁶ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁷ Deceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000


⁸ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁹ Acceleration jerk for positioning:Rev/s3], [pitch/s3]30...125 000 000

¹⁰ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).


¹¹ Deceleration jerk for positioning:Rev/s3], [pitch/s3]30...125 000 000

- ◆ The same applies if a SuperImposed movement is already being executed and an absolute movement is started, then the absolute position is not accessed but the sum of both values.
- ◆ After the SuperImposed movement has been finished, the absolute position is accessed with the next absolute movement.



The following illustration shows two examples for the combination of two MC_MoveAbsolute modules.

- ◆ The left part (a) of the time diagram shows a case in which the second Function block after the first function block is executed. If the 1st. function block has reached position 60, the “Done” output will issue the execution command to the second function module, which then moves to Position 100.
- ◆ The right part (b) of the diagram shows a case in which the second function block is executed during execution of the 1st. function block. The 1st The first function module is automatically interrupted. The 2nd. function module moves directly to position 100 whether or not position 60 of the first Function block was already reached.



5.5.3.1 Position mode in reset operation

In this chapter you can read about:

Setting the positioning mode in reset mode293

In reset operation (activated by the configured reset distance), additional positioning functions are possible for absolute positionings (can be set under configuration in the “Positioning options / positioning profiles” window only in bus mode “Positioning” or “Profile selection”):

All directions	Standard positioning mode
Positive direction	Positioning only in positive direction
Shortest path	Positioning on the shortest path
Negative direction	Positioning only in negative direction
Actual direction	Positioning by keeping the actual direction of travel

Dynamic positioning

In dynamic positioning, a decision concerning the positioning travel is not taken on the basis of the actual position, but on the basis of the braking position resulting from the motion parameters.

Please observe:

- ◆ **In the event of positioning specifications below zero and higher than or equal to the reset distance, this function is deactivated.**
The positioning target must for instance be in the range between 0..359.999999° for a reset distance of 360°.
- ◆ The positioning functions are neither effective in test movements nor in an automatic positioning after homing travel (if this was not deactivated in the configuration).
- ◆ In the event of “shortest path”, the motion is not defined for a positioning by a travel of half the reset distance.

Setting the positioning mode in reset mode

The positioning modes in reset operation are configured via object 1111.13 (C3Plus.POSITION_direction):

Mode	Value	IEC constant
All directions	0	C3_all_direction
Positive direction	1	MC_positive_direction
Shortest path	2	MC_shortest_way
Negative direction	3	MC_negative_direction
Actual direction	4	MC_current_direction

Setting the desired value must take place in the IEC initialization routine, as a configuration download by the C3 ServoManager would reset the value to 0 (due to downwards compatibility).

Example:

```
C3Plus.POSITION_direction:=MC_Direction_Positive;
```

In the help file you can find examples for the functioning of the individual positioning modes.

5.5.3.2 Description of jerk

Jerk

The jerk (marked with “4” in the drawing below) describes the change in acceleration (derivation of the acceleration)

The maximum change in acceleration is limited via the jerk limitation.

A motion process generally starts from a standstill, accelerates constantly at the specified acceleration to then move at the selected speed to the target position. The drive is brought to a stop before the target position with the delay that has been set in such a manner as to come to a complete stop at the target position. To reach the set acceleration and deceleration, the drive must change the acceleration (from 0 to the set value or from the set value to 0).


This change in speed is limited by the maximum jerk.

**Without jerk
according to
VDI2143**

According to VDI2143 the jerk is defined (other than here) as the jump in acceleration (infinite value of the jerk function).

This means that positionings with Compax3 are without jerk according to VDI2143, as the value of the jerk function is limited.

Motion sequence



- 1: Position
- 2: Speed
- 3: Acceleration
- 4: Jerk

High changes in acceleration (high jerks) often have negative effects on the mechanical systems involved. There is a danger that mechanical resonance points will be excited or that impacts will be caused by existing mechanical slack points. You can reduce these problems to a minimum by specifying the maximum jerk.

5.5.4. Relative positioning (MC_MoveRelative)

FB name	MC_MoveRelative	
Relative positioning by a specified distance.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Distance	REAL	Relative distance of the movement to be executed (configured unit [units]) -value range ¹²
Velocity	REAL	Value of the maximum speed (always positive) (not necessarily reached) [units/s ¹³] -value range ¹⁴
Acceleration	DINT	Value of acceleration (always positive) [Units/s ² ¹⁵] -value range ¹⁶
Deceleration	DINT	Value of deceleration (always positive) [Units/s ² ¹⁷] -value range ¹⁸
Jerk	DINT	Value of the acceleration jerk (see on page 294) [Units/s ³ ¹⁹] (always positive) -value range ²⁰
JerkDecel	DINT	Value of the deceleration jerk [Units/s ³ ²¹] (always positive) -value range ²²
VAR_OUTPUT		
Done	BOOL	Specified setpoint distance on the setpoint generator output is reached
CommandAborted	BOOL	Positioning aborted
Error	BOOL	Error while executing module
Note: ♦ In the case of dynamic positioning (module is called during a positioning process) the specified position is added to the current actual position. ♦ Continuous operation can be selected via object 1111.8 "C3Plus.Position_restposition_mode" <> 0; setpoint value and actual value are then set to 0 before each positioning. ♦ You can optimize the motion profile data with the " ProfilViewer " (see on page 265) software tool!		

¹² Target position: [Rev], [Pitch]-4 000 000...4 000 000

¹³ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

¹⁴ Speed for positioning: [Rev/s], [pitch/s]0.00001157 ...2000

¹⁵ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

¹⁶ Acceleration for positioning: Rev/s², [pitch/s²]0.24...1 000 000

¹⁷ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).


¹⁸ Deceleration for positioning: Rev/s², [pitch/s²]0.24...1 000 000

¹⁹ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

²⁰ Acceleration jerk for positioning: Rev/s³, [pitch/s³]30...125 000 000


²¹ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

²² Deceleration jerk for positioning: Rev/s³, [pitch/s³]30...125 000 000




The following illustration shows two examples of the combination of two MC_MoveRelative modules.

- ◆ The left part (a) of the time diagram shows a case in which the second function module is executed after the first function module. If the first function module has reached 60 units, the "Done" output gives the execution command to the second function module, which then moves an addition 40 units.
- ◆ The right part (b) of the diagram shows a case in which the second function module is activated while the first function module is being executed. Because the second module is started during the execution of the first function module, the first function module is automatically interrupted. The second function module immediately moves an additional 40 units whether or not the 60 units of the first function were already reached.



5.5.5. Additive positioning (MC_MoveAdditive)

FB name		MC_MoveAdditive
Adds a relative distance to the target position of a positioning process in progress.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Distance	REAL	Relative distance -value range ²³
Velocity	REAL	Value of the maximum speed (always positive) (not necessarily reached) [units/s ²⁴] -value range ²⁵
Acceleration	DINT	Value of acceleration (always positive) [Units/s ²⁶] -value range ²⁷
Deceleration	DINT	Value of deceleration (always positive) [Units/s ²⁸] -value range ²⁹
Jerk	DINT	Value of the acceleration jerk (see on page 294) [Units/s ³⁰] (always positive) -value range ³¹
JerkDecel	DINT	Value of the deceleration jerk [Units/s ³²] (always positive) -value range ³³
VAR_OUTPUT		
Done	BOOL	Specified distance has been reached
CommandAborted	BOOL	Positioning aborted
Error	BOOL	Error during positioning
Note: In the case of dynamic positioning (module is called during a positioning process) the specified position is added to the current target position.		



²³ Target position: [Rev], [Pitch]-4 000 000...4 000 000

²⁴ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

²⁵ Speed for positioning: [Rev/s], [pitch/s]0.00001157 ...2000

²⁶ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

²⁷ Acceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000

²⁸ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

²⁹ Deceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000

³⁰ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).


³¹ Acceleration jerk for positioning:Rev/s3], [pitch/s3]30...125 000 000

³² The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

³³ Deceleration jerk for positioning:Rev/s3], [pitch/s3]30...125 000 000


The following illustration shows two examples of the combination of a MC_MoveAbsolute and an MC_MoveAdditive module.

- ◆ The left part (a) of the time diagram shows a case in which the second function module is executed after the first function module. After the first function module has traveled to Position 60, the "Done" output gives the execution command to the second FB, which then moves on another 40 units.
- ◆ The right part (b) of the diagram shows a case in which the second function module is activated while the first FB is being executed. Because the second module is started during the execution of the first FB, the first FB is automatically interrupted. The second function module adds the missing units that are still lacking for the first module and the moves an additional 40 units with the new predefined settings.



5.5.6. Endless positioning (MC_MoveVelocity)

FB name	MC_MoveVelocity	
Endless controlled positioning with adjustable speed		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Velocity	REAL	Value of the maximum speed (always positive) [Units/s ³⁴] Range of values: 0 rev/s ... 2000 rev/s
Acceleration	DINT	Value of the acceleration and deceleration (always positive) [Units/s ³⁵] Range of values: 0.24 rev/s ² ... 1000000 rev/s ²
Direction	INT	Selection: positive direction, negative direction, current direction; library constants (see on page 277)
VAR_OUTPUT		
InVelocity	BOOL	Specified target speed on the setpoint output is reached
CommandAborted	BOOL	Execution interrupted
Error	BOOL	Error during positioning
Note:		
<ul style="list-style-type: none"> ◆ To be able to stop the drive, the function module must be interrupted by another positioning function module or positioning must be stopped by calling the MC_Stop function module. ◆ A positioning to the end limit follows. 		




³⁴ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

³⁵ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

Example


The following illustration shows two examples of the combination of two MC_MoveVelocity modules.

- ◆ The left part (a) of the time diagram shows a case in which the second function module (block) is executed after the first function module. After the first function module has accelerated to a speed of 3000, the "InVelocity" output, AND-linked with the "Next" signal issues the execution command to the second FB, which then slows to a speed of 2000.
- ◆ The right part (b) of the diagram shows a case in which the second FB is activated while the first function module is being executed. Because the second module (block) is started during the execution of the first FB, the first FB is automatically interrupted. During the acceleration of the first module (block), the second module slows again similarly to a speed of 2000 without the speed of the first module having been reached.



5.5.7. Manual operation (C3_Jog)

FB name		C3_Jog
Traveling along the axis in manual mode (in the "standstill" state)		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
JogForward	BOOL	JogForward = TRUE makes the axis move in positive direction.
JogBackward	BOOL	JogBackward = TRUE makes the axis move in negative direction. -value range- ³⁶
Velocity	REAL	Speed value [Units/s ³⁷]- value range- ³⁸
Acceleration	DINT	Value of the acceleration [Units/s ² ³⁹]- value range- ⁴⁰
Deceleration	DINT	Value of deceleration with stop [Units/s ² ⁴¹]- value range- ⁴²
Jerk	DINT	Value of the acceleration and deceleration jerk (see on page 294) [Units/s ³ ⁴³]- value range- ⁴⁴
VAR_OUTPUT		
Busy	BOOL	Module is active (manual operation in progress)
Error	BOOL	Error during manual operation or faulty parameter when starting manual operation
Note:		
<ul style="list-style-type: none"> ◆ The axis must be in the "standstill" state in order to start manual operation (Jogging Mode). ◆ Start: When starting manual operation, the output Busy is set to TRUE. ◆ Stop: The axis is brought to a standstill if the respective input (JogForward or JogBackward) is set to FALSE again ◆ As soon as manual operation is stopped, the output Busy is set to FALSE. Further commands can only be executed after this feedback. 		



³⁶ Target position: [Rev], [Pitch]-4 000 000...4 000 000

³⁷ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

³⁸ Speed for positioning: [Rev/s], [pitch/s]0.00001157 ...2000

³⁹ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁴⁰ Acceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000


⁴¹ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).

⁴² Deceleration for positioning: Rev/s2], [pitch/s2]0.24...1 000 000

⁴³ The unit "increments" is valid only for position values!Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s2 and revolutions/s3 (resp. pitch/s, pitch/s2, pitch/s3 for linear motors).


⁴⁴ Acceleration jerk for positioning:Rev/s3], [pitch/s3]30...125 000 000

Example: Manual movement via digital inputs.



5.5.8. Machine zero (MC_Home)

FB name	MC_Home	
Predefined search for the machine reference point		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Position	REAL	Position on the machine zero point (configured unit [units]) = Machine zero Offset
VAR_OUTPUT		
Done	BOOL	Referencing process completed
CommandAborted	BOOL	Referencing process aborted
Error	BOOL	Error while searching for machine reference point
<p>Note:</p> <p>This module gives the command to search for the machine reference point; not for "zero" position. The type of search function (machine reference mode) can be adjusted with the configuration or with the object "HOMING_mode" (Object 1130.4).</p> <p>Objects that are connected with the machine reference point:</p> <ul style="list-style-type: none"> ◆ C3Plus.HOMING_speed (Object 1130.3) ◆ C3Plus.HOMING_accel (Object 1130.1) C3Plus.HOMING_mode (Object 1130.4) ◆ C3Plus.HOMING_edge_sensor_distance (Object 1130.7) 		



The Compax3 machine zero modes are adapted to the CANopen profile for Motion Control CiADS402.

Position reference point Essentially, you can select between operation with or without machine reference. The reference point for positioning is determined by using the machine reference and the machine reference offset.

Machine reference run

In a homing run the drive normally moves to the position value 0 immediately after finding the home switch. The position value 0 is defined via the homing offset.


A machine reference run is required each time after turning on the system for operation with machine reference.



Please note:

During homing run the software end limits are not monitored.

Machine reference offset



1: Machine Zero point

The machine reference offset is used to determine the actual reference point for positioning.

That is: Machine zero point = - Machine zero Offset


A change in the machine reference offset does not take effect until the next machine reference run.

5.5.9. Electronic gearbox (MC_GearIn)


FB name	MC_GearIn	
Controlled speed and position synchronicity with adjustable transmission ratio		
VAR_IN_OUT		
Master	INT	Constant for the master signal source (see on page 277) Configuration (see on page 143) of the signal sources
Slave	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
RatioNumerator	REAL	Transmission ratio of numerator Please use integer values in order to avoid drift!
RatioDenominator	INT	Transmission ratio of denominator Please use integer values in order to avoid drift!
Acceleration	DINT	Value of acceleration / deceleration (always positive) until the synchronism is reached [Units/s ²] -value range ⁴⁵
VAR_OUTPUT		
InGear	BOOL	Synchronicity achieved
CommandAborted	BOOL	Command aborted <ul style="list-style-type: none"> ◆ The device is not ready to operate when the Execute is issued ◆ Another module of the MC_GearIn has interrupted (in gear operation or quasi parallelly in the same IEC cycle) ◆ The gear command was not accepted by the setpoint generator because <ul style="list-style-type: none"> ◆ The selected master source was not configured (signal source) ◆ The command cannot be accepted in the current device status (not "standstill powered", "Discrete Motion", "Continuous Motion" or "Synchronized Motion") ◆ The nominator of the gear factor (O1141.1) equals zero
Error	BOOL	Error while executing module: <ul style="list-style-type: none"> ◆ Input Slave unequal AXIS_REF_LocalAxis ◆ Input Acceleration smaller than or equal to zero ◆ Input RatioDenominator equals zero ◆ Input Master unequal to AXIS_REF_Physical, AXIS_REF_HEDA or AXIS_REF_Virtual (only T40) ◆ The device changes to "Error Stop" error status while gearing is running
<p>Note:</p> <ul style="list-style-type: none"> ◆ Behavior: The drive accelerates (with Acceleration) until the master speed is reached - the module will report synchronicity with "InGear". Position losses during acceleration to master speed are not made up. ◆ The transmission ratio can be changed at any time with a positive edge on Execute. InGear is reset until synchronicity is achieved again. ◆ For example, if speed synchronicity is not achieved because of limiting effects, the position difference that arises will be made up (by the active position controller). ◆ Acceleration / deceleration to the set transmission ratio takes place without a jerk 		

⁴⁵ Acceleration for positioning: Rev/s², [pitch/s²]0.24...1 000 000

limit.
 ♦ Please use integer values for the numerator and denominator of the transmission ratio in order to avoid drift.
 ♦ If the master and slave units do not correspond, this fact must be considered for the transmission ratio.
 ♦ **Example** (see on page 144)




Structure of the "electronic gearing" function



D: / E: **additional structure** (see on page 220)

- Note:**
- ♦ Direction -1 / +1 with direction reversal (under signal source configuration) factor -1 is applied.
 - ♦ The "virtual master" source is not available with Compax3 T30.


Example:



If Execute shows "0" InGear as well shows "0".
 If Execute goes to "0" before InGear goes to "1" then InGear for one cycle is set to "1" after synchronicity is reached

5.5.10. Current setting operation (C3_Current)

FB name	C3_Current	
Current control. Speed and position controllers are switched off. The system controls to the specified current. The current setting can be made with the module input or with an analog input.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Current	INT	Current to be set in [mA]
Mode	INT	0 = The current read during Execute on the Current input is set. 3 = After Execute, the Current input is read again in each cycle and the corresponding current is set (Execute must be permanently present for this mode).
VAR_OUTPUT		
InCurrent	BOOL	Specified current set
CommandAborted	BOOL	Command aborted
Error	BOOL	Error
Note:		
<ul style="list-style-type: none"> ◆ The current feedforward (optimization parameter) is set to 100% to operate C3_Current. ◆ The status "current control" must be aborted with MC_Stop before new positionings are possible. 		



5.5.11. Torque / force control (C3_TorqueControl)

FB name	C3_TorqueControl	
Torque / force control with speed limitation. The module can be started from the "Discrete Motion" and "Continuous Motion" states. The position control is deactivated during this operating mode.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Starts the sequences of the module with positive edge
Torque	DINT	Command torque [mNm] or command force [mN] (limit value, not necessarily reached) If the configured velocity setpoint value is reached, the drive will move at this speed. The torque or force setpoint value is not reached.
TorqueRamp	DINT	Value of the torque-force ramp (always positive) [mNm/s] [mN/s]
Velocity	REAL	Value of the maximum speed (always positive)(not necessarily reached) [units/s ⁴⁶] -value range ⁴⁷ If the command torque or the command force is not reached, the drive will move with this speed.
Acceleration	DINT	Value of maximum acceleration (always positive) [Units/s ² ⁴⁸] -value range ⁴⁹
Deceleration	DINT	Value of maximum deceleration (always positive) [Units/s ² ⁵⁰] -value range ⁵¹
Direction	INT	Selection of the permitted direction (positive direction "MC_Direction_Positive" or negative direction "MC_Direction_Negative") (library constant) The movement into the other direction is blocked, a speed of 0 is commanded!
VAR_OUTPUT		
InTorque	BOOL	Specified torque or specified force (setpoint or limitation value) reached
CommandAborted	BOOL	Module sequence is interrupted
Error	BOOL	Error while executing module
<p>Note:</p> <ul style="list-style-type: none"> ◆ The movement is limited by the set maximum speed or by the command torque/command force. ◆ The setpoint values for velocity, acceleration and deceleration are always positive. The direction of movement depends on the "Direction" Input. ◆ The torque ramp "TorqueRamp" must always be entered as a positive value. The force direction results from the sign of the "Torque" torque/force setpoint value. ◆ There is no torque/force acquisition. Actual torque or actual force is acquired from the quadrature current and the motor parameters. ◆ Due to suspension of the motion in the direction not yet approved (input "Direction") by changing to speed control it should be observed that, for "clean" resp. "proper" torque or force setpoint value (=Current Setpoint value) with force demand at 		

⁴⁶ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

⁴⁷ Speed for positioning: [Rev/s], [pitch/s] 0.00001157 ... 2000

⁴⁸ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

⁴⁹ Acceleration for positioning: Rev/s², [pitch/s²] 0.24... 1 000 000

⁵⁰ The unit "increments" is valid only for position values! Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

⁵¹ Deceleration for positioning: Rev/s², [pitch/s²] 0.24... 1 000 000

standstill or with small speeds, it might be necessary to smooth the speed control output by activating or increasing the control signal filter of velocity control (O2100.20). If the filter is used a reduction of the stiffness might be necessary (bandwidth of the speed controller) (see chapter controller optimization in help).

- ◆ Behavior on
 - ◆ Stop: (MC_Stop) => immediate switching to position control; this means entire torque (or entire force)!
 - ◆ C3 Error => depending on the error reaction (1) switching to position control, this means entire torque (or entire force)!
 - ◆ Change from positioning to velocity control (MC_MoveVelocity) in torque/force control => Torque/force limitation value is equal to the torque/force setpoint value, output "InTorque" is immediately set.
- ◆ The module can also be used for defined braking, e.g. for unwinders.
 - ◆ The command torque or the command force has then the opposite sign than the direction (direction)
 - ◆ If there is no counter torque or no counter force, so that braking is not possible, the drive will decelerate to 0 in a torque/force controlled manner.
- ◆ The module is not suitable for ballscrew actuators and for gearings with high ration. Please contact us.

Force control via ETH and Force sensor

- ◆ On the Compax3 - DVD under "\Examples\ForceControl Template_T44" directory you find an application example (T44) for force control via ETH and force sensor.
- ◆ Please observe the installation instruction for installing a Template.
- ◆ You need Option M21 with analog inputs.
Wiring of the Force Sensors:

X20: Current inputs (0 ... 20 mA)

Pin	Name	Function	Internal input channel
1	+24Vout	Sensor supply 0 (output) ¹⁾	AI0
2	in0+	Current input 0 + (0 ... 20 mA)	
3	GND	Sensor supply 0 (output) ¹⁾	AI0
4	in0-	Current input 0 - (0 ... 20 mA)	
5	+24Vout	Sensor supply 1 (output) 24 VDC out ¹⁾	AI1
6	in1+	Current input 1 + (0 ... 20 mA)	
7	GND	Sensor supply 1 (output) ¹⁾	AI1
8	in1-	Current input 1 - (0 ... 20 mA)	
9	+24Vout	Sensor supply 2 (output) ¹⁾	AI2
10	in2+	Current input 2 + (0 ... 20 mA)	
11	GND	Sensor supply 2 (output) ¹⁾	AI2
12	in2-	Current input 2 - (0 ... 20 mA)	
13	+24Vin	Sensor supply input 24 VDC in	Supply for pin 1/3, 5/7 and 9/11. ²⁾
14	GND in	Sensor supply input	
15	Shield	Shield connection	
16	Shield	Shield connection	




5.6 Error handling

In this chapter you can read about:

Acknowledging errors (MC_Reset)	312
Reading axis errors (MC_ReadAxisError).....	313
Set error reaction (C3_SetErrorReaction).....	314
Switching off error messages (C3_ErrorMask).....	315


5.6.1. Acknowledging errors (MC_Reset)

FB name	MC_Reset	
Acknowledges errors (transition from "Errorstop" status to "Standstill" status).		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Execute	BOOL	Activates the module if there is a positive edge
VAR_OUTPUT		
Done	BOOL	Error successfully acknowledged, axis is in the "Standstill" state again
Error	BOOL	Acknowledge failed /not possible
ErrorID	WORD	Error description, according to error history
<p>Note:</p> <ul style="list-style-type: none"> ◆ After the error is successfully acknowledged, the power must be supplied to the power output stage again by a rising edge on the enable input of the MC_Power power module. ◆ The execution of the module may influence the MC_Stop (see on page 282) module outputs. ◆ C3 powerPLmC Note: This module is also available as group function block. You can then trigger this function for the entire Compax3 group. 		




5.6.2. Reading axis errors (MC_ReadAxisError)

FB name	MC_ReadAxisError	
This function module displays axis errors.		
VAR_IN_OUT		
Axis	INT	Achs-ID (Bibliothekskonstanten)
VAR_INPUT		
Enable	BOOL	Activates the module
VAR_OUTPUT		
Done	BOOL	Output values available
Error	BOOL	Compax3 in error state
ErrorID	WORD	Current error description
Note: -		



5.6.3. Set error reaction (C3_SetErrorReaction)

FB name	C3_SetErrorReaction	
This module is used to define the error reaction. Note: The error reaction (see on page 439) cannot be changed for errors with standard reaction 5 (switch immediately to currentless (without ramp), close brake).		
VAR_INPUT		
Execute	BOOL	The defined error reaction is set for the selected error
ErrorID	WORD	Error number [hexadecimal] for which the error reaction should be set, e.g. 0x6281 for cycle time exceeded
Reaction	INT	Error response: 0: no reaction, error is deactivated. 1: Downramp actual speed; remain in position control state 2: Downramp the actual speed; then switch off controller
VAR_OUTPUT		
Done	BOOL	The defined error reaction was set
Error	BOOL	Error while executing module
<p>Note: Error list (see on page 439)</p> <ul style="list-style-type: none"> ◆ The error reaction settings from the configuration wizard are overwritten. ◆ The setting of the error mask is made internally via a C3 object. If the objects are saved permanently, the setting is memorized after Power off. <p>Please note:</p> <ul style="list-style-type: none"> ◆ The C3_ErrorMask overwrites (depending on the calling-up order) the settings. ◆ The corresponding error reaction is valid for both axes (of Compax3F) as the case may be. ◆ The module will overwrite the settings made via the C3 ServoManager. ◆ If the ErrorID has an invalid error number, no change is effected. 		



5.6.3.1 Error reaction of IEC61131-3 modules with Release < R5-0

A changed **error reaction** (see on page 314, see on page 141) of the errors with reaction 2 (to reaction 1 or 0) is only considered at the "ERROR" output of the IEC61131-3 modules from targets of the Compax3 - Release R5-0. Install the new targets and recompile your IEC program.

5.6.4. Switching off error messages (C3_ErrorMask)

FB name	C3_ErrorMask	
This module is used to switch off error messages. Selection between error reactions 2 and 0		
VAR_INPUT		
Execute	BOOL	The selected error mask is activated
Disable_PLC	BOOL	TRUE is used to switch off error 0x6281.
Disable_HEDA	BOOL	TRUE is used to switch off HEDA errors.
Disable_Fieldbus	BOOL	TRUE is used to switch off the errors 0x8120 and 0x8121.
Disable_MotorStalled	BOOL	TRUE is used to switch off error 0x7121.
Disable_Tracking	BOOL	TRUE is used to switch off error 0x7320.
Disable_IOShortCircuit	BOOL	TRUE is used to switch off error 0x5380.
Disable_IOAddSupply	BOOL	TRUE is used to switch off error 0x5117.
Disable_BusVoltageLow	BOOL	Error 0x3222 is switched off with TRUE. Switch off only for commissioning! Note on Compax3H: always on FALSE, as operation <420VDC is not possible.
Disable_E5LimitSwitch	BOOL	TRUE is used to switch off error 0x54A0.
Disable_E6LimitSwitch	BOOL	TRUE is used to switch off error 0x54A1.
Disable_SoftwareLimit_Pos	BOOL	TRUE is used to switch off error 0x7323.*
Disable_SoftwareLimit_Neg	BOOL	TRUE is used to switch off error 0x7324.*
Error list (see on page 439) Notes: <ul style="list-style-type: none"> ◆ The setting of the error mask is made internally with a C3 object. If the objects are saved permanently, the setting is memorized after Power off. Please note: <ul style="list-style-type: none"> ◆ In the active module, the given errors can no longer be changed to error reaction 1. ◆ With open inputs, the respective error is active, therefore you should assign the error messages you wish to eliminate with TRUE. ◆ The module will overwrite the settings made via the C3 ServoManager. ◆ * During operation with reset distance, these errors are active with a limit of 8 000 000; you should therefore switch off the errors in this operating mode by assignment to TRUE (with open input, a corresponding error is active). 		


5.7 Process image

In this chapter you can read about:

Reading digital inputs (C3_Input).....	316
Write digital outputs (C3_Output).....	316
Reading/writing optional inputs/outputs.....	316
Memorizing the signals with the trigger event (C3_TouchProbe).....	319
Integration of Parker I/Os (PIOs).....	322


5.7.1. Reading digital inputs (C3_Input)

FB name	C3_Input	
Used to generate a process image of the digital inputs.		
VAR_INPUT		
I0 ... I7	BOOL	Displays the logic status of the respective input (with low active inputs, the physical statuses are negated).
Notes: the module should always be brought up at the beginning of the processing cycle.		



5.7.2. Write digital outputs (C3_Output)

FB name	C3_Output	
Used to generate a process image of the digital outputs.		
VAR_OUTPUT		
O0 ... O3	BOOL	Displays the status of the respective output.
Notes: the module should always be brought up at the end of the processing cycle.		




5.7.3. Reading/writing optional inputs/outputs

In this chapter you can read about:

C3_IOAddition_0.....	317
C3_IOAddition_1.....	317
C3_IOAddition_2.....	318


5.7.3.1 C3_IOAddition_0

FB name	C3_IOAddition_0	
Is used to create a process image of the optional digital inputs/outputs.		
VAR_INPUT		
I0 ... I3	BOOL	Displays the status of the respective input.
O0 ... O3	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned as inputs or outputs (see on page 485). You may only use either inputs or outputs exclusively. Notes: The module should always be brought up at the beginning (inputs) or end (outputs) of the processing cycle.		




5.7.3.2 C3_IOAddition_1

FB name	C3_IOAddition_1	
Is used to create a process image of the optional digital inputs/outputs.		
VAR_INPUT		
I4 ... I7	BOOL	Displays the status of the respective input.
O4 ... O7	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned as inputs or outputs (see on page 485). You may only use either inputs or outputs exclusively. Notes: the module should always be brought up at the beginning of the processing cycle.		




5.7.3.3 C3_IOAddition_2

FB name	C3_IOAddition_2	
Is used to create a process image of the optional digital inputs/outputs.		
VAR_INPUT		
I8 ... I11	BOOL	Displays the status of the respective input.
O8 ... O11	BOOL	Displays the status of the respective output.
Please note that the group of 4 may be assigned as inputs or outputs (see on page 485). You may only use either inputs or outputs exclusively. Notes: the module should always be brought up at the beginning of the processing cycle.		




5.7.4. Memorizing the signals with the trigger event (C3_TouchProbe)

FB name	C3_TouchProbe	
Memorizing signals / objects with the trigger event - replaces the MC_TouchProbe module -		
VAR_IN_OUT		
Axis	INT	Axis ID (Library constants)
VAR_INPUT		
Execute	BOOL	Activates the module if there is a rising edge
SignalSource	Pointer	Selects the signal to be scanned. The ADR () Operator must be used imperatively. The signal scanned must be in the REAL or the INT format.
FallingEdge	BOOL	If TRUE, it is triggered in the falling edge. The logical status after a possible input inversion is respected.
TriggerInput	INT	Selects the trigger input. Constant TouchProbeInputx (see note)
ExpectedValue	REAL	Value at which the trigger event is expected.
Tolerance	REAL	Tolerance interval around ExpectedValue, where the trigger event is accepted (always positive) (with reference to the signal source).
StartIgnore	REAL	The beginning of the range in which the trigger event will not be acknowledged with Done or Error (with reference to the signal source).
StopIgnore	REAL	The end of the range in which the trigger event will not be acknowledged with Done or Error (with reference to the signal source).
EnableIgnoreZone	BOOL	Activate IgnoreZone.
Abort	BOOL	Deactivate module.
VAR_OUTPUT		
Done	BOOL	Trigger event occurred within the tolerance interval and the signal was detected.
RecordedSignal_ Real	REAL	Value scanned at the time of the trigger event, if the source is available in the coDeSys "REAL" format. Please respect the format information of the signal source (SignalSource)
RecordedSignal_ INT	INT	Value scanned at the time of the trigger event, if the source is available in the coDeSys "INT" format. Please respect the format information of the signal source (SignalSource)
Busy	BOOL	Module active and no scanning signal occurred outside the IgnoreZone.
Error	BOOL	Error while executing module.
<p>Note:</p> <ul style="list-style-type: none"> ◆ Temporal precision of signal recording: <math><1\mu\text{s}</math> ◆ TriggerInput: Trigger-input: via the constants "TouchProbeInput0" ... "TouchProbeInput7" (X12/6 - X12/14) the trigger signal input is selected. ◆ Attention! Only max. one entity of the module can be active as the hardware resources are only available once! Several entities being activated one after the other are permitted. 		



Example: Scanning the actual position, triggered via Input I0



- 1: Area where a **module error** is generated.
- 2: Ignore Zone: Area where **no module error** and **no Done** is generated.
The ranges 2 and 3 may not overlap. If they do, the ignore zone in range 3 is not effective.
- 3: ExpectedValueZone: Trigger signal in the permissible value range; this is confirmed with Done=TRUE.
- 4: RecordedSignal; is updated with every active edge of the TriggerInput signal upon Execute = TRUE.

- ◆ If the value of the signal (SignalSource) during the Trigger event is in the permissible value range between (ExpectedValue - Tolerance) and (ExpectedValue + Tolerance), this is confirmed with Done = TRUE; the RecordedSignal is updated.
- ◆ If the value of the signal (SignalSource) during the Trigger Event is between StartIgnore and StopIgnore (Ignore zone), the module will report neither error nor Done, the RecordedSignal is however updated.
- ◆ If the value of the signal (SignalSource) during the Trigger Event is outside the permissible value range and outside the zone between StartIgnore and StopIgnore (Ignore zone), the module will report an error, the RecordedSignal is updated.
- ◆ Within this range, the signals are read in with a temporal exactitude of <math><1\mu\text{s}</math> (determined by linear interpolation).
- ◆ If a Trigger Signal occurs at Execute = False, the RecordedSignal is not updated.
- ◆ If **no** Trigger Signal comes up, Busy remains active until the module is reset to the original state with Abort.
- ◆ More examples with C3_Touchprobe (example 7 and example 8).

5.7.5. Integration of Parker I/Os (PIOs)


In order to integrate PIOs via CANopen, the CANopen operating mode "**Master for PIOs** (see on page 371, see on page 372)" must be configured.

In this chapter you can read about:

Initializing the PIOs (PIO_Init).....	322
Reading the PIO inputs 0-15 (PIO_Inputx..y).....	323
Writing the PIO outputs 0-15 (PIO_Outputx..y).....	324
Example: Compax3 as CANopen Master with PIOs.....	324


5.7.5.1 Initializing the PIOs (PIO_Init)

FB name	PIO_Init	
Initialization of the PIOs		
VAR_IN_OUT		
Device	INT	PIO - ID (Address)
VAR_INPUT		
Execute	BOOL	Activates the module if there is a positive edge
VAR_OUTPUT		
Done	BOOL	Initialization executed
Error	BOOL	An error occurred during initialization
ErrorCode	WORD	1 = no Parker device Additional errors can be found in the error list (see on page 439).
AbortCode	DWORD	SDO abort code (see on page 385)
Note: Please execute this module at the beginning of the IEC program.		




5.7.5.2 Reading the PIO inputs 0-15 (PIO_Inputx...y)

FB name	PIO_Input0_15	
Is used for reading the respective inputs		
VAR_INPUT		
I0 ... I15	BOOL	Displays the status of the respective input.
Note: For the additional inputs, the following modules are available PIO_Input16_31 PIO_Input32_47 and PIO_Input48_63. Please execute this module at the beginning of the IEC program (After PIO_INIT).		



5.7.5.3 Writing the PIO outputs 0-15 (PIO_Outputx...y)

FB name	PIO_Output0_15	
Is used for writing on the respective outputs		
VAR_INPUT		
O0 ... O15	BOOL	Displays the status of the respective output.
Note: For the additional outputs, the following modules are available PIO_Output16_31 PIO_Output32_47and PIO_Output48_63. Please execute this module at the end of the IEC program.		



5.7.5.4 Example: Compax3 as CANopen Master with PIOs

- ◆ Compax3 control via PIOs.
- ◆ Configuration of the PIO connection with the C3 ServoManager.
- ◆ Initializing the PIO connection with the PIO_Init module
- ◆ Control of Compax3 via the digital PIOs and
- ◆ setpoint assignment via the analog PIOs

Related programs:

- ◆ ..\Examples\C3_with_PIOs\T30_MasterPIO_ID2.C3P
- ◆ ..\Examples\C3_with_PIOs\C3_PIO_CONNECTION_TEST.pro

Test setup:

A PIO-347 for CANopen with:

- ◆ 1 PIO-602 (24V DC feed)
- ◆ 2 PIO-402 (8 digital inputs) for operation wired to a switch box
- ◆ 6 PIO-504 (24 digital outputs)
- ◆ 1 PIO-468 (4 analog inputs)
- ◆ 1 PIO-550 (2 analog outputs) analog output 0 is wired with analog input 0 for setpoint definition
- ◆ 1 PIO-600 (Bus terminal)
- ◆ a 24V power supply unit
- ◆ a C3 S025 F10 I21 T30 M11 with power- and 24V-cable
- ◆ a motor SMH 60 60 1.4...4 with motor- and resolver cable
- ◆ a CAN-bus cable for the connection of the Compax3 with the PIO coupler.
- ◆ a serial cable for the connection of the Compax3 with the PC
- ◆ a switch box for the operation of the 8 digital inputs of the PIOs.

- Settings:**
- ◆ Baud rate = 1Mbit
 - ◆ Node address of the PIO = 5 (setting via the address switch on the device)
 - ◆ Node address of the C3 = 2 (setting via the address switch on the device)

Control interface:


Digital input	Function	Digital output	Function
0	Energize axis	0	Axis is energized
1	Travel to MN (home)	1	MN (home) is accessed
2	Start MoveVelocity	2	Setpoint speed reached
3	Stop	3	Stop is present
4	JOG +	4	Manual function active
5	JOG -	5	MoveVelocity aborted
6	Free	6	Global module error display
7	Error reset	7	Error is present
Analog input		Analog output	
0	Setpoint speed		Setpoint speed specification

Additional Compax3 settings:

- ◆ Array_Col03_Row01=1; activates the PIO_Init module
- ◆ Array_Col03_Row02=5; address of the PIO
- ◆ Array_Col03_Row03=10; Default for the analog output0 ==> setpoint speed specification

If these values are stored in the Compax3, the PIO will be automatically initialized after Power On and started for PDO data exchange with Compax3.

Solution:



5.8 Interface to C3 powerPLmC

In this chapter you can read about:

Interface module "PLmC_Interface".....	327
Cyclic data channel for C3T30 and C3T40.....	328
Example: C3 powerPLmC Program & Compax3 Program	330

5.8.1. Interface module "PLmC_Interface"

The interface between a central IEC61131-3 user program on C3 powerPLmC and a local IEC61131-3 user program on a Compax3 servo axis T30 or T40 is created with the program module "PLmC_interface".

The " PLmC_Interface" module must be called up in each Compax3 T30 which is operated as a slave on a C3 powerPLmC.

With Compax3 T40 this is only necessary, if the slave axis is programmed directly (not with operating mode: "Slave on C3 powerPLmC) (Cam programming on C3 powerPLmC)"


The call-up must take place cyclically!

The module can be found in the "C3_PLmC_interface.lib" library, which must be integrated manually via the library manager, if required.

FB name	PLmC_Interface	
	Interface module for the control of C3 powerPLmC	
VAR_OUTPUT		
O0	BOOL	Status of the digital output O0 on the C3 powerPLmC side
O1	BOOL	Status of the digital output O1 on the C3 powerPLmC side
O2	BOOL	Status of the digital output O2 on the C3 powerPLmC side
O3	BOOL	Status of the digital output O3 on the C3 powerPLmC side
LocalEnable	BOOL	Enable for the local IEC61131-3 program LocalEnable switches to FALSE for one cycle, if a command for this axis is activated on the C3 powerPLmC. This helps to avoid that the axis will receive different commands at a time.
Event1 ... Event8		factory use
EventParameter		factory use
Note:		
<ul style="list-style-type: none"> ◆ The execution of all local motion functions should be coupled with the LocalEnable output. ◆ Via the outputs O0...O3, the outputs set by C3 powerPLmC can be set out via the physical outputs with the aid of C3_Output. 		

**Recipe array line
17... 32 assigned**

Please note that the last 16 lines of the recipe array (C3Array.ColXX_Row17 to C3Array.ColXX_Row32) are reserved for the communication with C3 powerPLmC.



5.8.2. Cyclic data channel for C3T30 and C3T40

An additional communication channel (besides the one established by the Drive Interface which is not freely assignable) can be established between the programs of the C3 powerPLmC and a Compax3 axis via a freely usable cyclic data channel. To do this, the assignment of the channel is defined on the side of the C3 powerPLmC in the controller configuration for the respective axis. The assignment is always bidirectional.

The following options are available for the communication between the two programs.

2x INT:**Assignment of the cyclic channel with 2 INT variables****Mapping to Compax3 objects**

C3.PLmCToC3_INT1 / C3.PLmCToC3_INT2	from PLmC to Compax3
C3.C3ToPLmC_INT1 / C3.C3ToPLmC_INT2	from Compax3 to PLmC

Mapping to power PLmC variables

"Axis name".PLmCToC3_INT1	from PLmC to Compax3
"Axis name".PLmCToC3_INT2	from PLmC to Compax3
"Axis name".C3ToPLmC_INT1	from Compax3 to PLmC
"Axis name".C3ToPLmC_INT2	from Compax3 to PLmC

1x DINT:**Assignment of the cyclic channel with one DINT variable****Mapping to Compax3 objects**

C3.PLmCToC3_DINT	from PLmC to Compax3
C3.C3ToPLmC_DINT	from Compax3 to PLmC

Mapping to power PLmC variables

Axis name".PLmCToC3_DINT	from PLmC to Compax3
"Axis name".C3ToPLmC_DINT	from Compax3 to PLmC

1x REAL: **Assignment of the cyclic channel with one REAL variable**

Mapping to Compax3 objects


C3.PLmCToC3_REAL	from PLmC to Compax3
C3.C3ToPLmC_REAL	from Compax3 to PLmC

Mapping to power PLmC variables

"Axis name".PLmCToC3_REAL	from PLmC to Compax3
"Axis name".C3ToPLmC_REAL	from Compax3 to PLmC

Note: The use of INT or DINT variables is especially suitable for implementing a user-defined control word / status word between C3 powerPLmC IEC61131-3 program and Compax3 IEC61131-3 program.

Configuration of the data channel



Note: If the cyclic data channel is not required, it can also be assigned to the actual position of the axis. This is then provided by the "**MC_ReadActualPosition** (see on page 285)" module. Therefore the value must not be continually read via the acyclic channel if the module is used; this reduces the bus load and the IEC cycle time.


5.8.3. Example: C3 powerPLmC Program & Compax3 Program

- Task:**
- ◆ Implementation of a mark synchronization in a Compaxa3 servo axis.
 - ◆ Control of the program via the C3 powerPLmC via a user-defined control word / status word.

Main program on Compax3 (module PLC_PRG)

Cyclic call-up of the interface to powerPLmC in the PLC_PRG module

In CFC:



In ST:

```

10001 PROGRAM PLC_PRG
10002 VAR
10003   Outputs: C3_Output;
10004 END_VAR
10005
10006
10007
10008
10009
10010
10011 PmC_Interface(O0=>Outputs.O0,O1=>Outputs.O1,O2=>Outputs.O2,O3=>Outputs.O3);
10012 Outputs();
10013 IF PmC_Interface.LocalEnable THEN
10014   LocalProgram();
10015 END_IF
10016
10017
10018
10019
10020
10021
10022
10023
10024
10025
10026
10027
10028
10029
10030
10031
10032
10033
10034
10035
10036
10037
10038
10039
10040
10041
10042
10043
10044
10045
10046
10047
10048
10049
10050
10051
10052
10053
10054
10055
10056
10057
10058
10059
10060
10061
10062
10063
10064
10065
10066
10067
10068
10069
10070
10071
10072
10073
10074
10075
10076
10077
10078
10079
10080
10081
10082
10083
10084
10085
10086
10087
10088
10089
10090
10091
10092
10093
10094
10095
10096
10097
10098
10099
10100
10101
10102
10103
10104
10105
10106
10107
10108
10109
10110
10111
10112
10113
10114
10115
10116
10117
10118
10119
10120
10121
10122
10123
10124
10125
10126
10127
10128
10129
10130
10131
10132
10133
10134
10135
10136
10137
10138
10139
10140
10141
10142
10143
10144
10145
10146
10147
10148
10149
10150
10151
10152
10153
10154
10155
10156
10157
10158
10159
10160
10161
10162
10163
10164
10165
10166
10167
10168
10169
10170
10171
10172
10173
10174
10175
10176
10177
10178
10179
10180
10181
10182
10183
10184
10185
10186
10187
10188
10189
10190
10191
10192
10193
10194
10195
10196
10197
10198
10199
10200
10201
10202
10203
10204
10205
10206
10207
10208
10209
10210
10211
10212
10213
10214
10215
10216
10217
10218
10219
10220
10221
10222
10223
10224
10225
10226
10227
10228
10229
10230
10231
10232
10233
10234
10235
10236
10237
10238
10239
10240
10241
10242
10243
10244
10245
10246
10247
10248
10249
10250
10251
10252
10253
10254
10255
10256
10257
10258
10259
10260
10261
10262
10263
10264
10265
10266
10267
10268
10269
10270
10271
10272
10273
10274
10275
10276
10277
10278
10279
10280
10281
10282
10283
10284
10285
10286
10287
10288
10289
10290
10291
10292
10293
10294
10295
10296
10297
10298
10299
10300
10301
10302
10303
10304
10305
10306
10307
10308
10309
10310
10311
10312
10313
10314
10315
10316
10317
10318
10319
10320
10321
10322
10323
10324
10325
10326
10327
10328
10329
10330
10331
10332
10333
10334
10335
10336
10337
10338
10339
10340
10341
10342
10343
10344
10345
10346
10347
10348
10349
10350
10351
10352
10353
10354
10355
10356
10357
10358
10359
10360
10361
10362
10363
10364
10365
10366
10367
10368
10369
10370
10371
10372
10373
10374
10375
10376
10377
10378
10379
10380
10381
10382
10383
10384
10385
10386
10387
10388
10389
10390
10391
10392
10393
10394
10395
10396
10397
10398
10399
10400
10401
10402
10403
10404
10405
10406
10407
10408
10409
10410
10411
10412
10413
10414
10415
10416
10417
10418
10419
10420
10421
10422
10423
10424
10425
10426
10427
10428
10429
10430
10431
10432
10433
10434
10435
10436
10437
10438
10439
10440
10441
10442
10443
10444
10445
10446
10447
10448
10449
10450
10451
10452
10453
10454
10455
10456
10457
10458
10459
10460
10461
10462
10463
10464
10465
10466
10467
10468
10469
10470
10471
10472
10473
10474
10475
10476
10477
10478
10479
10480
10481
10482
10483
10484
10485
10486
10487
10488
10489
10490
10491
10492
10493
10494
10495
10496
10497
10498
10499
10500
10501
10502
10503
10504
10505
10506
10507
10508
10509
10510
10511
10512
10513
10514
10515
10516
10517
10518
10519
10520
10521
10522
10523
10524
10525
10526
10527
10528
10529
10530
10531
10532
10533
10534
10535
10536
10537
10538
10539
10540
10541
10542
10543
10544
10545
10546
10547
10548
10549
10550
10551
10552
10553
10554
10555
10556
10557
10558
10559
10560
10561
10562
10563
10564
10565
10566
10567
10568
10569
10570
10571
10572
10573
10574
10575
10576
10577
10578
10579
10580
10581
10582
10583
10584
10585
10586
10587
10588
10589
10590
10591
10592
10593
10594
10595
10596
10597
10598
10599
10600
10601
10602
10603
10604
10605
10606
10607
10608
10609
10610
10611
10612
10613
10614
10615
10616
10617
10618
10619
10620
10621
10622
10623
10624
10625
10626
10627
10628
10629
10630
10631
10632
10633
10634
10635
10636
10637
10638
10639
10640
10641
10642
10643
10644
10645
10646
10647
10648
10649
10650
10651
10652
10653
10654
10655
10656
10657
10658
10659
10660
10661
10662
10663
10664
10665
10666
10667
10668
10669
10670
10671
10672
10673
10674
10675
10676
10677
10678
10679
10680
10681
10682
10683
10684
10685
10686
10687
10688
10689
10690
10691
10692
10693
10694
10695
10696
10697
10698
10699
10700
10701
10702
10703
10704
10705
10706
10707
10708
10709
10710
10711
10712
10713
10714
10715
10716
10717
10718
10719
10720
10721
10722
10723
10724
10725
10726
10727
10728
10729
10730
10731
10732
10733
10734
10735
10736
10737
10738
10739
10740
10741
10742
10743
10744
10745
10746
10747
10748
10749
10750
10751
10752
10753
10754
10755
10756
10757
10758
10759
10760
10761
10762
10763
10764
10765
10766
10767
10768
10769
10770
10771
10772
10773
10774
10775
10776
10777
10778
10779
10780
10781
10782
10783
10784
10785
10786
10787
10788
10789
10790
10791
10792
10793
10794
10795
10796
10797
10798
10799
10800
10801
10802
10803
10804
10805
10806
10807
10808
10809
10810
10811
10812
10813
10814
10815
10816
10817
10818
10819
10820
10821
10822
10823
10824
10825
10826
10827
10828
10829
10830
10831
10832
10833
10834
10835
10836
10837
10838
10839
10840
10841
10842
10843
10844
10845
10846
10847
10848
10849
10850
10851
10852
10853
10854
10855
10856
10857
10858
10859
10860
10861
10862
10863
10864
10865
10866
10867
10868
10869
10870
10871
10872
10873
10874
10875
10876
10877
10878
10879
10880
10881
10882
10883
10884
10885
10886
10887
10888
10889
10890
10891
10892
10893
10894
10895
10896
10897
10898
10899
10900
10901
10902
10903
10904
10905
10906
10907
10908
10909
10910
10911
10912
10913
10914
10915
10916
10917
10918
10919
10920
10921
10922
10923
10924
10925
10926
10927
10928
10929
10930
10931
10932
10933
10934
10935
10936
10937
10938
10939
10940
10941
10942
10943
10944
10945
10946
10947
10948
10949
10950
10951
10952
10953
10954
10955
10956
10957
10958
10959
10960
10961
10962
10963
10964
10965
10966
10967
10968
10969
10970
10971
10972
10973
10974
10975
10976
10977
10978
10979
10980
10981
10982
10983
10984
10985
10986
10987
10988
10989
10990
10991
10992
10993
10994
10995
10996
10997
10998
10999
11000
11001
11002
11003
11004
11005
11006
11007
11008
11009
11010
11011
11012
11013
11014
11015
11016
11017
11018
11019
11020
11021
11022
11023
11024
11025
11026
11027
11028
11029
11030
11031
11032
11033
11034
11035
11036
11037
11038
11039
11040
11041
11042
11043
11044
11045
11046
11047
11048
11049
11050
11051
11052
11053
11054
11055
11056
11057
11058
11059
11060
11061
11062
11063
11064
11065
11066
11067
11068
11069
11070
11071
11072
11073
11074
11075
11076
11077
11078
11079
11080
11081
11082
11083
11084
11085
11086
11087
11088
11089
11090
11091
11092
11093
11094
11095
11096
11097
11098
11099
11100
11101
11102
11103
11104
11105
11106
11107
11108
11109
11110
11111
11112
11113
11114
11115
11116
11117
11118
11119
11120
11121
11122
11123
11124
11125
11126
11127
11128
11129
11130
11131
11132
11133
11134
11135
11136
11137
11138
11139
11140
11141
11142
11143
11144
11145
11146
11147
11148
11149
11150
11151
11152
11153
11154
11155
11156
11157
11158
11159
11160
11161
11162
11163
11164
11165
11166
11167
11168
11169
11170
11171
11172
11173
11174
11175
11176
11177
11178
11179
11180
11181
11182
11183
11184
11185
11186
11187
11188
11189
11190
11191
11192
11193
11194
11195
11196
11197
11198
11199
11200
11201
11202
11203
11204
11205
11206
11207
11208
11209
11210
11211
11212
11213
11214
11215
11216
11217
11218
11219
11220
11221
11222
11223
11224
11225
11226
11227
11228
11229
11230
11231
11232
11233
11234
11235
11236
11237
11238
11239
11240
11241
11242
11243
11244
11245
11246
11247
11248
11249
11250
11251
11252
11253
11254
11255
11256
11257
11258
11259
11260
11261
11262
11263
11264
11265
11266
11267
11268
11269
11270
11271
11272
11273
11274
11275
11276
11277
11278
11279
11280
11281
11282
11283
11284
11285
11286
11287
11288
11289
11290
11291
11292
11293
11294
11295
11296
11297
11298
11299
11300
11301
11302
11303
11304
11305
11306
11307
11308
11309
11310
11311
11312
11313
11314
11315
11316
11317
11318
11319
11320
11321
11322
11323
11324
11325
11326
11327
11328
11329
11330
11331
11332
11333
11334
11335
11336
11337
11338
11339
11340
11341
11342
11343
11344
11345
11346
11347
11348
11349
11350
11351
11352
11353
11354
11355
11356
11357
11358
11359
11360
11361
11362
11363
11364
11365
11366
11367
11368
11369
11370
11371
11372
11373
11374
11375
11376
11377
11378
11379
11380
11381
11382
11383
11384
11385
11386
11387
11388
11389
11390
11391
11392
11393
11394
11395
11396
11397
11398
11399
11400
11401
11402
11403
11404
11405
11406
11407
11408
11409
11410
11411
11412
11413
11414
11415
11416
11417
11418
11419
11420
11421
11422
11423
11424
11425
11426
11427
11428
11429
11430
11431
11432
11433
11434
11435
11436
11437
11438
11439
11440
11441
11442
11443
11444
11445
11446
11447
11448
11449
11450
11451
11452
11453
11454
11455
11456
11457
11458
11459
11460
11461
11462
11463
11464
11465
11466
11467
11468
11469
11470
11471
11472
11473
11474
11475
11476
11477
11478
11479
11480
11481
11482
11483
11484
11485
11486
11487
11488
11489
11490
11491
11492
11493
11494
11495
11496
11497
11498
11499
11500
11501
11502
11503
11504
11505
11506
11507
11508
11509
11510
11511
11512
11513
11514
11515
11516
11517
11518
11519
11520
11521
11522
11523
11524
11525
11526
11527
11528
11529
11530
11531
11532
11533
11534
11535
11536
11537
11538
11539
11540
11541
11542
11543
11544
11545
11546
11547
11548
11549
11550
11551
11552
11553
11554
11555
11556
11557
11558
11559
11560
11561
11562
11563
11564
11565
11566
11567
11568
11569
11570
11571
11572
11573
11574
11575
11576
11577
11578
11579
11580
11581
11582
11583
11584
11585
11586
11587
11588
11589
11590
11591
11592
11593
11594
11595
11596
11597
11598
11599
11600
11601
11602
11603
11604
11605
11606
11607
11608
11609
11610
11611
11612
11613
11614
11615
11616
11617
11618
11619
11620
11621
11622
11623
11624
11625
11626
11627
11628
11629
11630
11631
11632
11633
11634
11635
11636
11637
11638
11639
11640
11641
11642
11643
11644
11645
11646
11647
11648
11649
11650
11651
11652
11653
11654
11655
11656
11657
11658
11659
11660
11661
11662
11663
11664
11665
11666
11667
11668
11669
11670
11671
11672
11673
11674
11675
11676
11677
11678
11679
11680
11681
11682
11683
11684
11685
11686
11687
11688
11689
11690
11691
11692
11693
11694
11695
11696
11697
11698
11699
11700
11701
11702
11703
11704
11705
11706
11707
11708
11709
11710
11711
11712
11713
11714
11715
11716
11717
11718
11719
11720
11721
11722
11723
11724
11725
11726
11727
11728
11729
11730
11731
11732
11733
11734
11735
11736
11737
11738
11739
11740
11741
11742
11743
11744
11745
11746
11747
11748
11749
11750
11751
11752
11753
11754
11755
11756
11757
11758
11759
11760
11761
11762
11763
11764
11765
11766
11767
11768
11769
11770
11771
11772
11773
11774
11775
11776
11777
11778
11779
11780
11781
11782
11783
11784
11785
11786
11787
11788
11789
11790
11791
11792
11793
11794
11795
11796
11797
11798
11799
11800
11801
11802
11803
11804
11805
11806
11807
11808
11809
11810
11811
11812
11813
11814
11815
11816
11817
11818
11819
11820
11821
11822
11823
11824
11825
11826
11827
11828
11829
11830
11831
11832
11833
11834
11835
11836
11837
11838
11839
11840
11841
11842
11843
11844
11845
11846
11847
11848
11849
11850
11851
11852
11853
11854
11855
11856
11857
11858
11859
11860
11861
11862
11863
11864
11865
11866
11867
11868
11869
11870
11871
11872
11873
11874
11875
11876
11877
11878
11879
11880
11881
11882
11883
11884
11885
11886
11887
11888
11889
11890
11891
11892
11893
11894
11895
11896
11897
11898
11899
11900
11901
11902
11903
11904
11905
11906
11907
11908
11909
11910
11911
11912
11913
11914
11915
11916
11917
11918
11919
11920
11921
11922
11923
11924
11925
11926
11927
11928
11929
11930
11931
11932
11933
11934
11935
11936
11937
11938
11939
11940
11941
11942
11943
11944
11945
11946
11947
11948
119
```


Program on C3 powerPLmC

```

0001 PROGRAM PLC_PRG
0002 VAR
0003     Inputs : C3_Input;
0004     Power : MC_Power;
0005     MoveAbs : MC_MoveAbsolute;
0006     Status : MC_ReadStatus;
0007     TouchProbeDone: BOOL;
0008 END_VAR
0009
0010
0011 DriveExecuteStart(ADR(Compax3_Group));
0012
0013 Inputs(Axis := Axis1);
0014 Status(Axis := Axis1);
0015
0016 IF(Inputs.I0 AND NOT Inputs.I3) THEN
0017     Power.Enable := TRUE;
0018 ELSE
0019     Power.Enable := FALSE;
0020 END_IF
0021
0022 IF(Inputs.I4) THEN
0023     MoveAbs.Position := Position1;
0024     MoveAbs.Velocity := Velocity1;
0025     MoveAbs.Acceleration := 100;
0026     MoveAbs.Deceleration := 100;
0027     MoveAbs.Jerk := 10000;
0028     MoveAbs.JerkDecel := 10000;
0029     MoveAbs.Execute := TRUE;
0030 END_IF
0031
0032 IF(Inputs.I4 AND Status.DiscreteMotion) THEN
0033     (* set control bit to start C3_TouchProbe in local program *)
0034     Axis1.PLmCtoC3_INT1.1 := TRUE;
0035 END_IF
0036
0037 IF(Axis1.C3ToPLmC_INT1.0) THEN
0038     (* C3_TouchProbe in local program is done *)
0039     TouchProbeDone := TRUE;
0040 END_IF
0041
0042 Power(Axis := Axis1);
0043 MoveAbs(Axis := Axis1);
0044
0045 DriveExecuteEnd(ADR(Compax3_Group));
0046

```


5.9 IEC examples

In this chapter you can read about:

Example in CFC: Using Compax3-specific function modules and Compax3 objects	332
Example in CFC: Positioning 1	333
Example in CFC: Positioning 2	334
Example in CFC: Positioning with set selection.....	335
Example in CFC: Cycle mode.....	336
Example in ST: Cycle mode with a Move module	337


5.9.1. Example in CFC: Using Compax3-specific function modules and Compax3 objects

- ◆ Read in the process image of the digital inputs with the InputStatus module.
- ◆ Generate a process image of the digital outputs with the OutputStatus module.
- ◆ Digital input I0, used for counting an external event. The event is only detected as an event if
 - ◆ The I0 input is at TRUE for at least 0.5 seconds and
 - ◆ The voltage on analog input 0 exceeds the threshold value of 3.5 volts.
- ◆ When 5 of these events have been counted, the digital output is set to O0. At the same time, the program prevents additional events on the I0 from being counted. The counter state can be reset again with Input I1 as soon as it reaches a value of 5.




5.9.2. Example in CFC: Positioning 1

- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts an absolute positioning process with fixed parameters
- ◆ Input I6 is used to stop the movement
- ◆ After positioning is complete, there will be a return to Position 0 as soon as Input I1 has been activated




5.9.3. Example in CFC: Positioning 2

- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts an absolute positioning process
- ◆ If an event (I1) occurs during the positioning, the target position will be moved back by 20 ("MoveAdditive")
- ◆ If an event occurs while positioning is not in progress, it has no effect



5.9.4. Example in CFC: Positioning with set selection


- ◆ Input I7 enables the power output stage
- ◆ The position, speed and ramps can be stored in the array (table) (for example input with the Compax3 ServoManager)
- ◆ The desired set can be selected with inputs I1 through I5 (binary coded)
- ◆ Input I0 starts the positioning (absolute positioning)
- ◆ Positioning that is in progress can be stopped with Input I6



5.9.5. Example in CFC: Cycle mode

Example a: Cycle mode

- ◆ Input I7 enables the power output stage
- ◆ Input I0 starts cyclical positioning. During this process, two positions are approached in alternation.
- ◆ Input I6 stops cycle mode



5.9.6. Example in ST: Cycle mode with a Move module

Input I2 enables the power output stage.

- ◆ Input I0 starts cycle mode. Two positions are approached alternately.
- ◆ There is a pause of 1 second after the first position is reached.
- ◆ There is a pause of 1.5 seconds after the second position is reached.
- ◆ Input I1 stops cycle mode.

```

0001 PROGRAM PLC_PRG
0002 VAR
0003   Inputs: C3_Input;
0004   Outputs: C3_Output;
0005   StartTrigger: R_TRIG;
0006   POSA_MC_MoveAbsolute;
0007   Timer1: TON;
0008   Stop: MC_Stop;
0009   Power: MC_Power;
0010   State: INT;
0011 END_VAR
0012
0001 Inputs(); (* Read Input process Image*)
0002
0003 (* Enable Power stage *)
0004 Power(Enable:=Inputs.I2, Axis:=AXIS_REF_LocalAxis, Status=>Outputs.O0);
0005
0006 (* State machine Start *)
0007 StartTrigger(CLK:=Inputs.I0); (* detect a rising edge on Input I0 *)
0008 IF(StartTrigger.Q) THEN (* Rising Edge ? *)
0009   State:=1; (* -> Start State machine *)
0010 END_IF
0011
0012 (* State machine *)
0013 CASE State OF
0014 1: (* Prepare first Move command *)
0015   POSA.Execute:=FALSE;
0016   POSA.Position:=30.0;
0017   POSA.Velocity:=15.0;
0018   State:=2;
0019 2: (* Start first Move command *)
0020   POSA.Execute:=TRUE;
0021   State:=3;
0022 3: (* Wait until position 1 reached *)
0023   IF(POSA.Done) THEN
0024     State:=4;
0025   END_IF

```

```

0026 4: (* 1 Sekunde Pause *)
0027   Timer1(IN:=TRUE , PT:=T#1.0s);
0028   IF(Timer1.Q) THEN
0029     Timer1(IN:=FALSE);
0030     Zustand:=5;
0031   END_IF
0032 5: (* Positionierung 2 vorbereiten *)
0033   POSA.Execute:=FALSE;
0034   POSA.Position:=0.0;
0035   POSA.Velocity:=25.0;
0036   Zustand:=6;
0037 6: (* Positionierung 2 Start *)
0038   POSA.Execute:=TRUE;
0039   Zustand:=7;
0040 7: (* Warten bis Position 2 erreicht *)
0041   IF(POSA.Done) THEN
0042     Zustand:=8;
0043   END_IF
0044 8: (* 1.5 Sekunden Pause *)
0045   Timer1(IN:=TRUE , PT:=T#1.5s);
0046   IF(Timer1.Q) THEN
0047     Timer1(IN:=FALSE);
0048     Zustand:=1; (* Schrittkette erneut starten *)
0049   END_IF
0050 END_CASE
0051 (* Positionierbaustein aufrufen *)
0052 POSA(Acceleration:=100, Deceleration:=100, Jerk:=10000, JerkDecel:=10000, Axis:=AXIS_REF_LocalAxis);
0053 (* Stop Eingang *)
0054 Stop(Execute:=Inputs.I1 , Deceleration:=200 , Jerk:=20000 , Axis:=AXIS_REF_LocalAxis);
0055 IF(Inputs.I1) THEN (* Stop Eingang = TRUE *)
0056   Zustand:=0; (* Schrittkette zurücksetzen *)
0057   Timer1(IN:=FALSE); (* Timer zurücksetzen *)
0058   POSA.Execute:=FALSE;
0059 END_IF
0060 Outputs(); (* PA Ausgänge schreiben *)

```


5.10 Profibus: Simulate Profdrive profile (C3_ProfiDrive_Statemachine)

The function module can be found in the "C3_Profiles_lib" library and must be integrated via the library manager before use.

Notes on the use:

- ◆ The input values coming from the master control via the Profibus can be changed before they are transmitted to the Statemachine (e.g. I/Os).
- ◆ In the simplest case, the control word and the motion parameters (which may come from the Profibus) are manipulated by the IEC program.
- ◆ If the Statemachine is active, all motions must be executed via the Statemachine. Motions such as for example MoveAbsolute, MoveRelative; MoveAdditive; MoveVelocity; Gearing, Reg-related positioning are possible. Or with Compax3F: Force/pressure regulating.
- ◆ With the "control via PLC" bit (CW1 bit 10 = 1), the Statemachine takes the control for the drive (is active). This means that no functions concerning the device status (such as Power, MoveX) by other function/program modules are permitted. If "no control" is selected (CW1 bit 10 = 0), the device status can be changed via function/program modules.
- ◆ The Profdrive Statemachine works independently from the Profibus. I.e. it can also be used in connection with other busses.
- ◆ The Profdrive Statemachine contains states, which cannot be mapped to the PLCopen status machine.

FB name	C3_ProfiDrive_Statemachine	
With the aid of the Profibus function module, the PROFdrive profile can be simulated. The profile is described in the help of the Compax3 I20T11 technology function (set operation is however not possible). The inputs of the module can be assigned as required.		
VAR_IN_OUT		
--	--	--
VAR_INPUT		
CW1	WORD	Control word according to Profdrive (see below)
CWadd	INT	additional control word: the following functions can be triggered in the positioning mode 0: no action 1: NOP (No Operation) 2: Stop 3: Homing Execution takes place with the "activate motion order" of CW1. The value must be reset to zero after the execution!
OperationMode	INT	Operating mode after Profdrive 1: Speed control 2: Positioning
Position	REAL	Position setpoint value for all positioning commands (MoveAbs, MoveRel, MoveAdd, RegSearch, RegMove preparation)
Velocity	REAL	Setpoint speed in operating mode 1 (speed control) and for MoveVelocity (not for positioning)
VelocityForPosition	REAL	Setpoint travel speed for positioning
VelocityForJog	REAL	Speed for manual (JOG)
Acceleration	DINT	Setpoint acceleration
Deceleration	DINT	Setpoint deceleration
DecelerationForStop	DINT	Deceleration for Stop
Jerk	DINT	Setpoint jerk

Master	INT	Constant for the master signal source (see on page 277) Configuration (see on page 143) of the signal sources
RatioNumerator	REAL	Numerator for Gearing
RatioDenominator	INT	Denominator for Gearing
PositionForRegMove	REAL	Position for RegMove, necessary if RegSearch is executed and registration is detected. Note: The input is connected to the PositionOfRegMove output in the simplest case.
VelocityForRegMove	REAL	Speed for RegMove, necessary if RegSearch is executed and registration is detected Note: The input is connected to the VelocityOfRegMove output in the simplest case.
CStatus1ForRegMove	WORD	- do not use - Command status 1 for RegMove end; necessary if RegSearch is executed and registration is detected
CStatus2ForRegMove	WORD	reserved!
ShortRampForRegMove	BOOL	Permits the Compax3 to calculate individual parameters for the RegMove positioning, if the set parameters would not reach the target.
RegMoveMode	INT	reserved!
IgnoreZoneStart	REAL	Mark-related positioning: Beginning of lock-out zone
IgnoreZoneStop	REAL	Mark-related positioning: End of lock-out zone
PositionReachedMode	BOOL	Mode for the generation of the PositionReached in the status word (CW1.10). TRUE: link to setpoint value
DisablePositiveDirection	BOOL	Block for positive direction
DisableNegativeDirection	BOOL	Block for negative direction
LimitErrorExtern	BOOL	reserved!
Override	REAL	reserved!
CStatus1In	WORD W	reserved!
CStatus2In	WORD	reserved!
VAR_OUTPUT		
ZSW1	WORD	Status word after Profidrive
OperationModeActual	INT	Active operating mode
PositionOfRegMove	REAL	Position transmitted to the RegMove command (cache memory) Note: The output is connected to the PositionForRegMove input in the simplest case.
VelocityOfRegMove	REAL	Velocity transmitted to the RegMove command (cache memory) Note: The input is connected to the VelocityForRegMove output in the simplest case.
CStatus2OfRegMove	WORD	reserved!
StatusMotor_off	BOOL	Motor is currentless (TRUE)
StatusMotor_standstill	BOOL	Status motor is energized at standstill (setpoint value) (TRUE)
CStatus1	WORD	reserved!
CStatus2	WORD	reserved!
Notes: <ul style="list-style-type: none"> ◆ You can call up directly the help for the Compax3 Profidrive device (I20T11) via the help installer (C3 ServoManager "?" Start C3 ServoManager Help Installer...) (select and open in the left window). ◆ On the Compax3 CD you will find an application example with additional explanations for the use of this module: C3 CD - directory....\Examples\Profidrive with T30T40\ 		

5.11 Emulate CanOpen DS402 (C3_DS402_Statemachine)

- ◆ The function module can be found in the "C3_Profiles_lib" library and must be integrated via the library manager before use.
 - ◆ The module, implementing as with T11 (I21, I22, I30, I31) a DS402 Statemachine, can be operated with the Bus CANopen, DeviceNet, Ethernet Powerlink, EtherCAT.
 - ◆ The DS402 Statemachine contains states, which cannot be mapped to the PLCopen status machine.
 - ◆ The input values coming from the master control via the Bus can be changed before they are transmitted to the Statemachine (e.g. I/Os).
 - ◆ In the simplest case, the control word and the motion parameters (which may come from the Bus) are manipulated by the IEC program.
 - ◆ With the input "Enable" the Statemachine takes the control for the drive (is active). This means that no functions concerning the device status (such as Power, MoveX) by other function/program modules are permitted. If the Statemachine is active, all motions must be executed via the Statemachine. Motions such as for example MoveAbsolut, MoveRelativ; MoveAdditiv; MoveVelocity; Gearing, Reg-related positioning are possible. If the Enable input is inactive, the device status can be changed vis PLC-Open Function-/Program modules.
- Description of the module available on request!

6. Communication

Here you will find the description of the fieldbus interfaces, which can be configured in the Compax3 ServoManager under the tree entry "configuring the communication".

Please note: The configuration of the process data (Mapping) is made wizard-guided with the Compax3 ServoManager.
If you perform the mapping directly via the master, you must go through this fieldbus wizard once; the Compax3 ServoManager will perform the necessary initializations.

In this chapter you can read about:

Compax3 communication variants	342
COM port protocol	352
Remote diagnosis via Modem.....	357
Profibus/Profinet.....	360
CANopen.....	371
DeviceNet.....	387
Ethernet Powerlink / EtherCAT	390
HEDA Bus	392
Normalization factors	414

6.1 Compax3 communication variants

In this chapter you can read about:

PC <-> Compax3 (RS232).....	343
PC <-> Compax3 (RS485).....	345
PC <-> C3M device combination (USB).....	346
USB-RS485 Moxa Uport 1130 adapter.....	347
ETHERNET-RS485 NetCOM 113 adapter.....	348
Modem MB-Connectline MDH 500 / MDH 504.....	349
C3 settings for RS485 two wire operation	350
C3 settings for RS485 four wire operation.....	351
Overview of all possible communication modes between Compax3 devices and a PC.	

6.1.1. PC <-> Compax3 (RS232)

PC <-> Compax3 (RS232): Connections to a device

PC (RS232 COM)



115kb



PC (Virtueller ComPort)



USB/RS232



115kb



PC (Virtueller ComPort)



10/100/1000Mb




Ethernet (LAN)

Ethernet/RS232


115kb



PC (RS232 COM)



PC (Virtueller ComPort)





PC (Virtueller ComPort)




6.1.2. PC <-> Compax3 (RS485)

PC <-> Compax3 (RS485)



6.1.3. PC <-> C3M device combination (USB)


PC <-> C3M device combination



6.1.4. USB-RS485 Moxa Uport 1130 adapter



Male DB9




PIN	RS-422/4-wire RS-485	2-wire RS-485
1	TxD-(A)	-
2	TxD+(B)	-
3	RxD+(B)	Data+(B)
4	RxD-(A)	Data-(A)

PIN	RS-422/4-wire RS-485	2-wire RS-485
5	GND	GND
6	-	-
7	-	-
8	-	-

The serial UPort 1130 USB adapter offers a simple and comfortable method of connecting an RS-422 or RS-485 device to your laptop or PC. The UPort 1130 is connected to the USB port of your computer and complements your workstation with a DB9 RS-422/485 serial interface. For simple installation and configuration, Windows drivers are already integrated. The UPort 1130 can be used with new or legacy serial devices and supports both 2- and 4-wire RS-485. It is especially suited for mobile, instrumentation and point-of-sale (POS) applications.

Manufacturer link http://www.moxa.com/product/UPort_1130_1130I.htm


Connection plan for Compax3S:



6.1.5. ETHERNET-RS485 NetCOM 113 adapter



Manufacturer link: <http://www.vscom.de/666.htm>
 (<http://www.vscom.de/666.htm>)




DIP Switch settings NetCom 113 for two-wire operation:

1ON 2ON 3off 4off (Mode: RS485 by ART (2 wire without Echo))


Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

Connection plan NetCom113 <-> C3S :



Connection plan NetCom113 <-> C3M X31:



6.1.6. Modem MB-Connectline MDH 500 / MDH 504


With the modems MDH500 and MDH504 manufactured by MB-Connectline, you can establish an independent connection. A virtual COM port is generated and the communication with the PC as well as the Compax3 takes place via RS232 or RS485.

It is not necessary to make any modem settings on the Compax3.

6.1.7. C3 settings for RS485 two wire operation

C3 ServoManager RS485 wizard settings:

download with configuration in RS232 mode!




Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

6.1.8. C3 settings for RS485 four wire operation

C3 ServoManager RS485 wizard settings:

download with configuration in RS232 mode



Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	0 (4 wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

6.2 COM port protocol

You can communicate with Compax3 in order to read or write objects via plug X10 (or X3 on the mains module of Compax3M) on the front via a COM port (max. 32 nodes).

As a rule 2 records are possible:

- ◆ ASCII record: simple communication with Compax3
- ◆ Binary record: fast and secure communication with Compax3 by the aid of block securing.

Switching between the ASCII and the binary record via automatic record detection.

Interface settings (see on page 507)

Wiring RS232: **SSK1** (see on page 480)
 RS485: as **SSK27** (see on page 481) / RS485 is activated by +5V on X10/1.
 USB: SSK33/03 (only for Compax3M)

In this chapter you can read about:

RS485 settings values	352
ASCII - record	352
Binary record	353

6.2.1. RS485 settings values

If "Master=Pop" is selected, only the settings compatible with the Pops (Parker Operator Panels) made by Parker are possible.

**Please note that the connected Pop has the same RS485 setting values.
 You can test this with the "PopDesigner" software.**

"Master=General" makes all Compax3 settings possible.

Multicast Address You can use this address to allow the master to access multiple devices simultaneously.

Device Address The device address of the connected Compax3 can be set here.

Baud rate Adjust the transfer speed (baud rate) to the master.

Cable type Please choose between **two-wire and four-wire RS485** (see on page 58).

Protocol Adjust the protocol settings to the settings of your master.

6.2.2. ASCII - record

The general layout of a command string for Compax3 is as follows:

[Adr] command CR

Adr	RS232: no address RS485: Compax3 address in the range 0 ... 99 Address settings can be made in the C3 ServoManager under "RS485 settings"
Command	valid Compax3 command
CR	End sign (carriage return)

Command A command consists of the representable ASCII characters (0x21 .. 0x7E). Small letters are converted automatically into capitals and blanks (0x20) are deleted, if they are not placed between two quotation marks.
 Separator between places before and after the decimal is the decimal point (0x2E). A numeric value can be given in the Hex-format if it is preceded by the "\$" sign. Values can be requested in the Hex-format if the CR is preceded additionally by the "\$" sign.

Answer strings All commands requesting a numeric value from Compax3 are acknowledged with the respective numeric value in the ASCII format followed by a CR without preceding command repetition and following statement of unit. The length of these answer strings differs depending on the value.
 Commands requesting an Info-string (e.g. software version), are only acknowledged with the respective ASCII character sequence followed by a CR, without preceding command repetition. The length of these answer strings is here constant.
 Commands transferring a value to Compax3 or triggering a function in Compax3 are acknowledged by:

>CR

if the value can be accepted resp. if the function can be executed at that point in time. If this is not the case or if the command syntax was invalid, the command is acknowledged with

!xxxxCR

The 4 digit error number **xxxx** is given in the HEX format; you will find the meaning in the **appendix** (see on page 439).

RS485 answer string When using RS485, each answer string is preceded by a "*" (ASCII - character: 0x2A).

Compax3 commands

Read object *RS232: O [\$] Index , [\$] Subindex [\$]*

RS485: Address O [\$] Index , [\$] Subindex [\$]

The optional "\$" after the subindex stands for "hex-output" which means that an object value can also be requested in hex;
 For example "O \$0192.2\$": (Object 402.2)

Write object *RS232: O [\$] Index , [\$] Subindex = [\$] Value [; Value2 ; Value3 ; ...]*

RS485: Address O [\$] Index , [\$] Subindex = [\$] Value [; Value2 ; Value3 ; ...]

The optional "\$" preceding Index, Subindex and value stands for "Hex-input" which means that Index, Subindex and the value to be transferred can also be entered in hex (e.g. O \$0192.2=\$C8).

6.2.3. Binary record

The binary record with block securing is based on 5 different telegrams:

- ◆ 2 request telegrams which the control sends to Compax3 and
- ◆ 3 response telegrams which Compax3 returns to the control.

Telegram layout

Basic structure:

Start code	Address	Number of data bytes - 1	Data				Block securing	
SZ	A	L	D0	D1	...	Dn	Crc(Hi)	Crc(Lo)

The start code defines the frame type and is composed as follows:

Bit	7	6	5	4	3	2	1	0
Frame type	Frame identification				PLC		Gateway	Address
RdObj read object	1	0	1	0	x	1	x	x
WrObj write object	1	1	0	0	x	1	x	x
Rsp response	0	0	0	0	0	1	0	1
Ack positive command acknowledgement	0	0	0	0	0	1	1	0
Nak Negative command acknowledgement	0	0	0	0	0	1	1	1

Bits 7, 6, 5 and 4 of the start code form the telegram identification; Bit 2 is always "1". Bits 3, 1 and 0 have different meanings for the request and response telegrams. The address is only necessary for RS484.

Request telegrams

-> Compax3

- ◆ the address bit (Bit 0 = 1) shows if the start code is followed by an address (only for RS485; for RS232 Bit 0 = 0)
- ◆ the gateway bit (Bit 1 = 1) shows if the message is to be passed on. (Please set Bit 1 = 0, as this function is not yet available)
- ◆ the PLC bit (Bit 3 = 1) allows access to objects in the PLC/Pop format
 U16, U32: for integer formats (see bus formats: Ix, Ux, V2)
 IEEE 32Bit Floating Point: for non integer formats (bus formats: E2_6, C4_3, Y2, Y4; without scaling)
 With Bit 3 = 0 the objects are transmitted in the DSP format.
 DSP formats:
 24 Bit = 3 Bytes: Integer INT24 or Fractional FRACT24
 48 Bit = 6 Bytes: Real REAL48 (3 Byte Int, 3 Byte Fract) / Double Integer DINT48 / Double Fractional DFRACT48

Response telegram

Compax3 ->

- ◆ Bits 0 and 1 are used to identify the response
- ◆ Bit 3 is always 0

The maximum number of data bytes in the request telegram is 256, in the response telegram 253.

The block securing (CRC16) is made via the CCITT table algorithm for all characters.

After receiving the start code, the timeout monitoring is activated in order to avoid that Compax3 waits in vain for further codes (e.g. connection interrupted) The timeout period between 2 codes received is fixed to 5ms (5 times the code time at 9600Baud)

Write object - WrObj telegram

SZ	Adr	L	D0	D1	D2	D3 ... Dn	Crc(Hi)	Crc(Lo)
0xCX		n	Index(Hi)	Index(Lo)	Subindex	Value	0x..	0x..

Describing an object by a value.

Positive acknowledgement - Ack-telegram

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x06	1	0	0	0x..	0x..

Answer from Compax3 if a writing process was successful, i.e. the function could be executed and is completed in itself.

Negative acknowledgement - Nak - telegram

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x07	1	F-No.(Hi)	F-No.(Lo)	0x..	0x..

Answer from Compax3 if access to the object was denied (e.g. function cannot be executed at that point in time or object has no reading access). The error no. is coded according to the DriveCom profile resp. the CiA Device Profile DSP 402.

Read object - RdObj - telegram

SZ	Adr	L	D0	D1	D2	D3	D4	D5	...	Dn	Crc(Hi)	Crc(Lo)
0xAX		n	Index1(Hi)	Index1(Lo)	Subindex1	Index2(Hi)	Index2(L o)	Subindex2	0x..	0x..

Reading one or several objects

Answer - Rsp - telegram

SZ	L	D0 ... Dx-1	Dx ... Dy-1	Dy-D..	D ... D..	D ... Dn	Crc(Hi)	Crc(Lo)
0x05	n	Value1	Value 2	Value 3	Value ..	Value n	0x..	0x..

Answer from Compax3 if the object can be read.

If the object has no reading access, Compax3 answers with the Nak - telegram.

Example:**Reading object "StatusPositionActual" (o680.5):**

Request: A5 03 02 02 A8 05 E1 46

Response: 05 05 FF FF FF FF FE 2D 07 B4

Writing into an Array (o1901.1 = 2350)

Request: C5 02 08 07 6D 01 00 09 2E 00 00 00 95 D5

Response: 06 01 00 00 BA 87

Block securing: Checksum calculation for the CCITT table algorithm

The block securing for all codes is performed via the following function and the corresponding table:

The "CRC16" variable is set to "0" before sending a telegram.

Function call:

```
CRC16 = UpdateCRC16(CRC16, Character);
```

This function is called up for each Byte (Character) of the telegram.

The result forms the last two bytes of the telegram

Compax3 checks the CRC value on receipt and reports CRC error in the case of a deviation.

```
Function const unsigned int _P CRC16_table[256] = {
    0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
    0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
    0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
    0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
    0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
    0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
    0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
    0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
    0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
    0xc9cc, 0xd9ed, 0xe98e, 0xf9af, 0x8948, 0x9969, 0xa90a, 0xb92b,
    0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
    0xdbfd, 0xcbdc, 0xfbbf, 0xeb9e, 0x9b79, 0x8b58, 0xbb3b, 0xab1a,
    0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
    0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
    0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
    0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
    0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
    0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
    0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
    0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
    0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
    0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
    0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
    0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
    0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
    0x5844, 0x4865, 0x3806, 0x2827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
    0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
    0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
    0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
    0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
    0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
    0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
};

unsigned int UpdateCRC16(unsigned int crc,unsigned char wert) {

unsigned int crc16;

crc16 = (CRC16_table[(crc >> 8) & 0x00FF] ^ (crc << 8)
^ (unsigned int)(value));

return crc16;

}

```

You will find this function on the Compax3 DVD under RS232_485\Function UpdateCRC16.txt!

6.3 Remote diagnosis via Modem

Caution!

As the transmission via modem may be very slow and interference-prone, the operation of the Compax3 ServoManager via modem connection is on your own risk!

The function setup mode as well as the ROLL mode of the oscilloscope are not available for remote diagnosis!

It is not recommended to use the logic analyzer in the Compax3 IEC61131-3 debugger due to the limited bandwidth.

Requirements:


For modem operation, a direct and stable telephone connection is required. Operation via a company-internal telephone system is not recommended.

In this chapter you can read about:

Structure.....	357
Configuration of local modem 1	358
Configuration of remote modem 2.....	359
Recommendations for preparing the modem operation.....	359

6.3.1. Structure

Layout and configuration of a modem connection ServoManager - Compax3:



The green part of the drawing shows the proceeding for Compax3 release versions < R5-0!

The proceeding for Compax3 release versions < R5-0 is described in an application example (.../modem/C3_Appl_A1016_language.pdf on the Compax3 CD).

Connection Compax3 ServoManager <=> Compax3

The Compax3 ServoManager (1) establishes a RS232 connection with modem 1 (PC internal or external).

Modem 1 dials modem 2 via a telephone connection (3).


Modem 2 communicates with Compax3 (6) via RS232.

Configuration

Modem 1 is configured via the Compax3 ServoManager (1)

Modem 2 can be configured via Compax3 (on place), triggered by putting **SSK31** (see on page 484) on X10. For this, the device must be configured before. This can be made locally before the system / machine is delivered with the aid of the Compax3 ServoManager (8).

6.3.2. Configuration of local modem 1

- ◆ Menu "Options: Communication settings RS232/RS485..." must be opened
- ◆ Select "Connection via Modem"
- ◆ Under "name" you can enter a name for the connection
- ◆ Enter the target telephone number.
 - Note: If an ISDN telephone system is operated within a company network, an additional "0" may be required in order to get out of the local system into the company network before reaching the outside line with an additional "0".
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.
 - Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.
- ◆ Select the COM interface where the modem is connected.
- ◆ Close the window and establish the connection with button  (open/close COM port).
- ◆ The connection is interrupted when the COM port is closed.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.
 - Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.

6.3.3. Configuration of remote modem 2

Settings in Compax3 under "configure communication: Modem settings":

- ◆ Modem initialization = "ON": After the SSK31 modem cable has been connected, Compax3 initializes the modem
- ◆ Modem initialization after Power On = "ON": After Power on of Compax3, the device initializes the modem
- ◆ Modem check = "ON": a modem check is performed
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands. Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.
- ◆ In the following wizard window, a specific download of the modem configuration can be made.

Note:

If a configuration download is interrupted, the original settings in the non volatile memory of the Compax3 are still available.

You have to finish the communication on the PC side and to reset the Compax3 via the 24V supply before you can start a new trial.

Reinitialization of the remote modem 2


Remove cable on Compax3 X10 and connect again!

6.3.4. Recommendations for preparing the modem operation

Preparations:

- ◆ Settings in Compax3 under "configure communication: Modem settings":
 - ◆ Modem initialization: "ON"
 - ◆ Modem initialization after Power On: "ON"
 - ◆ Modem check: "ON"
- ◆ Deposit SSK31 cable in the control cabinet.
- ◆ Install modem in the control cabinet and connect to telephone line.

Remote diagnosis required:

- ◆ On site:
 - ◆ Connect modem to Compax3 X10 via SSK31
 - ◆ Modem is automatically initialized
- ◆ Local:
 - ◆ Connect modem to telephone line
 - ◆ Establish cable connection to modem (COM interface)
 - ◆ Select "connection via modem" under "options: communication settings RS232/RS485...".
 - ◆ Select modem under "selection"
 - ◆ Enter telephone number
 - ◆ Select COM interface (PC - modem)
 - ◆ Establish connection with button  (open/close COM port).

6.4 Profibus/Profinet

The Profibus option is available on the Compax3 devices C3I20Txx!

The Profibus option is available on the Compax3 devices C3I32Txx!

Notes on the configuration of the Profibus master / Profinet controller

Before configuring the Profibus master / Profinet controller (e.g. S7), you will have to configure the Compax3 axis.

In the **Profibus/Profinet window** (see on page 360) of the configuration wizard you will receive the status message "Profibus/Profinet Telegram" with the information on the telegram which can be set in the master (PPO type).

In this chapter you can read about:

Typical application with Bus and IEC61131	360
Profibus / Profinet configuration	360
Cyclic process data channel	362
Acyclic parameter channel	363

6.4.1. Typical application with Bus and IEC61131

We recommend the following procedure to control the IEC61131-3 program via Profibus/Profinet:

- ◆ Use the control word (DeviceControl_Controlword_1) to control the PLCOpen function modules (Execute, Enable) to activate the modules via Profibus/Profinet.
- ◆ The logical module outputs can be placed on the status word (DeviceState_Statusword_1).
- ◆ Place the control word and the status word on the cyclic process data channel.
- ◆ Connect variable module outputs of your IEC61131-3 program with the recipe array.
 - ◆ For rapid access, the values from the first 5 rows of the recipe array can be placed in the cyclic channel.
 - ◆ Additional values of the recipe array can be written acyclically.

Now you can use the bus to assign values, to activate function modules with the control word and to read the current status with the control word.

6.4.2. Profibus / Profinet configuration

In this chapter you can read about:

Configuration of the process-data channel	361
PKW parameter channel	362
Error Reaction on Bus Failure	362
DCP fieldbus configuration wizard animation shown with Profibus as an example:	

Due to continuous optimization, individual monitor displays may have changed. This does however hardly influence the general proceeding.

Following are described the input windows of the Profibus/Profinet configuration wizard.

Can be called up in the tree (Compax3 ServoManager, left window) under "configure communication".

6.4.2.1 Configuration of the process-data channel

You can use the Process Data Channel (PZD) to exchange actual and Setpoint values cyclically between the Compax3 and the Profibus master / Profinet controller. Adjusting the cyclic PZD:

The PZD is adjusted separately for the following transfer directions:

- ◆ Profibus-Master / Profinet controller ⇒ Compax3 (PAD)
 - ◆ Compax3 ⇒ Profibus-Master / Profinet controller (PED)
- set separately.

Maximum size of the process-data channel:
 8 words (16 bytes) PAD and
 8 words (16 bytes) PED

The objects that can be put on the process data channel can be found in the "Compax3 Objects (see on page 415)"!

Assignment of the process data channel

Assignment of the process data channel is automated in Compax3 ServoManager. You select the objects which you want to put one after the other to the process input data (PED: Compax3 => PLC) and to the process output data (PAD: PLC => Compax3). ServoManager continuously checks areas of the PZD that are free and enables additional input options correspondingly.

PPO type / PKW type, telegram size

Depending on the configuration that is set, the resulting PPO type is displayed in the "Profibus telegram" wizard window (in the status line of the wizard window). You can use this value for the configuration of the Profibus master. With Profinet, you can read out the PKW type and the telegram size for setting in the Profinet Controller.


Assignment of the PZD

When data is read out of the Process Data Channel (PZD), the word width of the individual objects must be carefully noted.


Example: Assignment:

Object	Word width	Assignment	Address
POSITION_position	2	AW(n) & AW(n+1)	AD(n)
POSITION_speed	2	AW(n+2) & AW(n+3)	AD(n+2)
AnalogOutput0_DemandValue	1	AW(n+4)	AW(n+4)
AnalogOutput1_DemandValue	1	AW(n+5)	AW(n+5)
Array_Col1_Row1	2	AW(n+6) & AW(n+7)	AD(n+6)

PLC → Compax3



Compax3 → PLC



6.4.2.2 PKW parameter channel

Parameter access with DPV0

In addition to cyclic data exchange, you can use the PKW mechanism for acyclic access to parameters.


The PKW mechanism is implemented for Profibus master / Profinet controller without DPV1 functionality.

PKW: Parameter identification value

You can select between:

- ◆ **no PKW** - without acyclic parameter access.
- ◆ **PKW** - parameter access via a PKW length of 8 bytes.

PKW structure



Additional information on the **structure of the PKW** (see on page 363)

6.4.2.3 Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

6.4.3. Cyclic process data channel

The structure of the PZD is defined in the configuration menu: "Profibus/Profinet telegram" of the ServoManager.

6.4.3.1 Control and status word

The cyclic process data channel contains a control word and a status word both, freely available and 16 bits in size:

Control word: Profibus-Master / Profinet controller ⇒ Compax3

Status word: Compax3 ⇒ Profibus-Master / Profinet controller

6.4.4. Acyclic parameter channel

Compax3 supports parameter access with DPV1. The available parameters or objects can be found **here** (see on page 415).

In this chapter you can read about:

Parameter access with DPV0: Required data channel 363
 Data formats of the bus objects 368

6.4.4.1 Parameter access with DPV0: Required data channel

You can use the PKW mechanism for acyclic access to parameters in cyclic data exchange as well. This is made available to make it possible for the master/controller to have access to the important device parameters without DPV1 functionality. The master/controller formulates an order in the PKW mechanism. Compax3 processes the order and formulates the response.

PKW structure:

Byte 1	Octet 2	Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8
PKE	IND		PWE				

- PKW: Parameter identification value
- PKE: Parameter identification (1st and 2nd byte) (see below)
- IND: subindex* (3rd byte), 4th byte is reserved
- PWE: Parameter value (5th through 8th byte or 5th through 12th byte with expanded PKW)


PKE structure:

Byte 1							Octet 2								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
AK				SPM		PNU									

- AK: Order or response identification (value range 0 ... 15)
- SPM: reserved
- PNU: Parameter number

***Reference to the subindex**

The information for PNU subindex (parameter number) also applies to PROFIdrive profile Version 3, i.e., that the subindex is counted starting at 0, while for PROFIdrive profile Version 2 the subindex is counted starting at 1:



The result of this is as follows:

Profibus master based on PROFIdrive profile Version 3

The subindex of the Profibus No. (PNU) specified in the object list is directly valid. Example: Example: PNU object forward speed control = 400.1 (as specified).

Profibus master based on PROFIdrive profile Version 2

The subindex of the Profibus No. (PNU) specified in the object list must be incremented by 1.

Example: PNU object forward speed control = 400.2

Order and response processing

Order/response identifications are defined so that it is apparent from the identification which fields of the PKW interface (IND, PWE) also need to be evaluated. To this may be added the distinction between parameter value and parameter description.

Order identification	Order Master/Controller → Compax3	response identification Compax3 → Master/Controller
0	No order	0
1	Request parameter value	1.2
2	Change parameter value (word)	1
3	Change parameter value (double word)	2
6	Request parameter value (array)	4.5
7	Change parameter value (array of word)	4
8	Change parameter value (array of double word)	5
9	Request number of array elements	6
14	Change object	14
15	Request object	15

Response identifications 7 and 8 are used for negative acknowledgements for problems.

Sequence

- ◆ The master/controller transfers an order to a Compax3.
- ◆ The master/controller repeats this order at least until a response is received from Compax3.
This procedure ensures the transfer of orders / responses on the user level.
- ◆ Only one order is ever being processed at a time.
- ◆ Compax3 continues to make the response available until the master/controller formulates a new order.
- ◆ For responses containing parameter values, Compax3 always responds upon repetition with the current value (cyclic processing). This applies to all responses to the orders "Request parameter value", "Request parameter value (Array)" and "Request object".
- ◆ The PWE transfer of word sizes takes place with byte 7 and 8, while the transfer of double word sizes takes place with byte 5 through 8.

Explanation of response identification

Response identification	Compax3 → Master/Controller response
0	No response
1	Transfer value (word)
2	Transfer parameter value (double word)
4	Transfer parameter value (array of word)
5	Transfer parameter value (array of double word)
7	Order cannot be executed (with error No. (see on page 439))
8	No user level for PKW interface
9	factory use
10	factory use
14	Object value transferred
15	Object value transferred

Example: Changing the stiffness

Task:

Parameter / object change via PKW (DPV0)

The object "stiffness" will be set to 200%

Object stiffness: PNU 402.2; valid after VP

Format UNSIGNED 16 == 1 word == order identification = 2 == "Change parameter value (word)"

The master sends to Compax3:

PLC - Compax3

Octet 1		Octet 2				Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8										
PKE						IND		PWE													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-	MSB			LSB
AK		PNU																			
2		0		402				3		0		200									
0	0	1	0	0	0	0	1	1	0	0	1	0	0	1	0						
0x21				0x92				0x3	0x0	0x0	0x0	0x0	0x0	0xC8							

Compax3 responds with the same content, except with response identification = 1:

Compax3 - PLC

Octet 1		Octet 2				Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8										
PKE						IND		PWE													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-	MSB			LSB
AK		PNU																			
1		0		402				3				200									
0	0	0	1	0	0	0	1	1	0	0	1	0	0	1	0						
0x11				0x92				0x3	0x0	0x0	0x0	0x0	0x0	0xC8							

If no additional object needs to be changed, the new value can be set to valid with VP:

Object: Set objects to valid PNU 338.10 (because of DPV0 the **Subindex must be incremented by one** (see on page 363))

PLC - Compax3

Octet 1		Octet 2				Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8										
PKE						IND		PWE													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-	MSB			LSB
AK		PNU																			
2		0		338				11				1									
0	0	1	0	0	0	0	1	0	1	0	1	0	0	1	0						
0x21				0x52				0xB	0x0	0x0	0x0	0x0	0x0	0x1							

Compax3 responds with the same content, except with response identification = 1:

Compax3 - PLC

Octet 1		Octet 2				Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8										
PKE						IND		PWE													
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex	-	MSB			LSB
AK		PNU																			
1		0		338				11				1									
0	0	0	1	0	0	0	1	0	1	0	1	0	0	1	0						
0x11				0x52				0xB	0x0	0x0	0x0	0x0	0x0	0x1							

Reading back the object set objects to valid makes it possible to check whether the command was performed. Byte 8 will the contain the value 0.

The change can be stored and will not be lost even if with a power failure by using the object "Save objects permanently".

Object: Save objects permanently PNU 339

PLC - Compax3

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
2											0											339																0																1															
0	0	1	0	0	0	0	1	0	1	0	1	0	0	1	1																																																						
0x21											0x53											0x0								0x0								0x0								0x0								0x0								0x1							

Compax3 responds with the same content, except with response identification = 1:

Compax3 - PLC

Octet 1											Octet 2											Octet 3								Octet 4								Octet 5								Octet 6								Octet 7								Octet 8							
PKE											IND											PWE																																															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Subindex								-								MSB																LSB																					
AK											PNU																																																										
1											0											339																0																1															
0	0	0	1	0	0	0	1	0	1	0	1	0	0	1	1																																																						
0x11											0x53											0x0								0x0								0x0								0x0								0x0								0x1							

Object Upload/download via Profibus/Profinet

All settings of Compax3 can be read using the Profibus/Profinet and written back to Compax3. This makes it easy to replace a device, for example.

Condition:

Compax3 must be configured (once running through the configuration wizard followed by a download is enough; the configuration settings are, however, not relevant)

To implement this, the PKW mechanism has been changed.

Structure of modified PKW:

Byte 1	Octet 2	Octet 3	Octet 4	Octet 5	Octet 6	Octet 7	Octet 8
PKE		IND		PWE			

- PKW: Parameter identification value
- PKE: Parameter identification (1st and 2nd byte) (see below)
- IND: object index (3rd byte high 4th byte low)
- PWE: Parameter value (5th to 8th byte)

Structure of modified PKE:

Byte 1							Octet 2								
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
AK=14 or 15				SPM	DF	DPZ		SI							

- AK: Order or response identification
- SPM: reserved
- DF: Data format (DF=1 constant)
- DPZ: data buffer access
- SI: object subindex

Data buffer access:

For each object, 16 bytes must be read or written Since the size of the PWE channel is 4 bytes, each object must be read or written 4 times.

Sequence for reading / writing and object:

- DPZ=0: Object byte 1 ... 4 can be read / is being written
Order executed
 - DPZ=1 Object byte 5...8 can be read / is being written
 - DPZ=2 Object byte 9...12 can be read / is being written
 - DPZ=3 Object byte 13...16 can be read / is being written
- The data will either be read from the PWE or written into the PWE.

Access algorithm for reading objects

- ◆ Object 20.2 written with value 0 (object 20.2 is a counter that specifies the next object to be read; the starting value is 0).
- ◆ Read object index and subindex in object 20.5.
Format I32 of Object 20.5:

Not assigned	Index (high byte)	Index (low byte)	Subindex
--------------	-------------------	------------------	----------

- ◆ Read the object with the index and subindex read in object 20.5 and in save it in a table with the following structure: Index (2Byte), Subindex (1Byte), Contents (16Byte).
 - ◆ Read the next object-Index and subindex in object 20.5.
 - ◆
- This must be performed until index = 0xFFFF and until subindex = 0xFF.

Writing objects

Write the entire table to Compax3. Each index and subindex is written with the value stored in the table.

It should be noted in this regard that each time an object is written, the internal buffer must first be written with DPZ=1, 2, 3 and then the entire order is written with DPZ0.

6.4.4.2 Data formats of the bus objects

In this chapter you can read about:

Integer formats	368
Unsigned - Formats	368
Fixed point format E2_6	368
Fixed point format C4_3	369
Bus format Y2 and Y4.....	369
Bit sequence VZ	370
Byte string OS	370

Integer formats

Twos complement representation;

The highest order bit (MSB) is the bit after the sign bit (VZ) in the first byte.

VZ == 0: positive numbers and zero; VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
Integer 8 length: 1 Byte		VZ	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Integer 16	MSB	VZ	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
Length: 1 Word	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Integer 32	MSB	VZ	2 ³⁰	2 ²⁹	2 ²⁸	2 ²⁷	2 ²⁶	2 ²⁵	2 ²⁴
Length: 2 Words		2 ²³	2 ²²	2 ²¹	2 ²⁰	2 ¹⁹	2 ¹⁸	2 ¹⁷	2 ¹⁶
		2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰

Unsigned - Formats

Type	Bit	8	7	6	5	4	3	2	1
Unsigned 8 Length: 1 Byte		2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Unsigned 16	MSB	2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
Length: 1 Word	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Unsigned 32	MSB	2 ³¹	2 ³⁰	2 ²⁹	2 ²⁸	2 ²⁷	2 ²⁶	2 ²⁵	2 ²⁴
Length: 2 Words		2 ²³	2 ²²	2 ²¹	2 ²⁰	2 ¹⁹	2 ¹⁸	2 ¹⁷	2 ¹⁶
		2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰

Fixed point format E2_6

Linear fixed point value with six binary places after the decimal point. 0 corresponds to 0, 256 corresponds to 2¹⁴ (0x4000).

Twos complement representation;

MSB is the bit after the sign bit

VZ == 0: positive numbers and zero;

VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
E2_6	MSB	VZ	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²
Length: 1 Word	LSB	2 ¹	2 ⁰	2 ⁻¹	2 ⁻²	2 ⁻³	2 ⁻⁴	2 ⁻⁵	2 ⁻⁶

Fixed point format C4_3

Linear fixed point value with three decimal places after the decimal point. 0 corresponds to 0 and 0,001 corresponds to 2^0 (0x0000 0001).
Structure like data type Integer32, value of the bits reduced by a factor of 1000.
Length: 2 Words

Bus format Y2 and Y4

Structure:

- ◆ Y2 like data type Integer16
- ◆ Y4 like data type Integer32

The values can be adjusted by a normalization factor.
The following rules apply:

- ◆ Normalization factor for Y2: Object 200.1, ... 200.5
 - ◆ Normalization factor for Y4: Object 201.1, ... 201.5
- There are different normalization factors for individual values

1. Y2 - normalization factors

- ◆ Object 200.1: NormFactorY2_Speed: Normalization factor for Y2 speeds
- ◆ Object 200.2: NormFactorY2_Position: Normalization factor for Y2 positions
- ◆ Object 200.3: NormFactorY2_Voltage: Normalization factor for Y2 voltages
- ◆ Object 200.4: Normalization factor for 1100.8 (T30, T40)
- ◆ Object 200.5: NormFactorY2_Array_Col2: Normalization factor for Column 2 of the recipe array
- ◆ Object 200.6: Normalization factor for 1100.9 (T30, T40)
- ◆ Object 200.7 Normalization factor for 1000.8
- ◆ Object 200.8: Normalization factor for 1000.9 (T30, T40)
- ◆ Object 200.9: Normalization factor for 1100.14 (T30, T40)
- ◆ Object 200.10: Normalization factor for 1000.14 (T30, T40)
- ◆ Object 200.11: Normalization factor for Y2 currents (638.35 ... 638.40) (T30, T40)

2. Y4 - normalization factors

- ◆ Object 201.1: NormFactorY4_Speed: Normalization factor for Y4 speeds
- ◆ Object 201.2: NormFactorY4_Position: Normalization factor for Y4 positions
- ◆ Object 201.3: NormFactorY4_Voltage: Normalization factor for Y4 voltages
- ◆ Object 201.4: NormFactorY4_Array_Col1: Normalization factor for Column 1 of the recipe array
- ◆ Object 201.5: Normalization factor for 1100.6
- ◆ Object 201.6: Normalization factor for 1100.7
- ◆ Object 201.7 Normalization factor for 1000.6 (T30, T40)
- ◆ Object 201.8: Normalization factor for 1000.7 (T30, T40)
- ◆ Object 201.11: Normalization factor for bus interpolation
CANSync/EthernetPowerLink
 - ◆ 1100.6 = DeviceControl_DemandValue1 (DS 402 : Target position 0x607A in the "Cyclic Synchronous Position" Operation Mode)
 - ◆ 3921.1 = FBI_SignalProcessing0_Input (DS 402 : Interpolation data record 0x60C1.1 in the "Interpolated Position" Operation Mode) (resulting in 3921.6 = FBI_SignalProcessing0_Output and
 - ◆ 3921.7 = FBI_SignalProcessing0_OutputGreat)
- ◆ Object 201.12: Normalization factor for 1100.13 = DeviceControl_DemandValue8 (DS 402: Target Velocity 0x60FF in "Profile velocity (pv)" and "cyclic synchronous velocity (csv)" Operation Mode)
- ◆ Object 201.13: Normalization factor for 1000.13 = DeviceState_ActualValue8 (T30, T40)
- ◆ Object 201.14: Normalization factor for 3925.20 = FBR_InterpolationAccelInput
- ◆ Object 201.15: Normalization factor for 3925.21 = FBR_InterpolationAccelInput

Meaning of the normalization factors

- ◆ Bit 5: Meaning of the normalization factor:
 - ◆ Bit 5 = "0": decimal factors 1, 1/10, 1/100, ..
- Bit 4 ... Bit 0: Normalization factor**

#	Bit 4...0	Factor dec (Bit 5 = 0) yy0x xxxx	
0	00000	10^0	1
1	00001	10^{-1}	0.1
2	00010	10^{-2}	0.01
3	00011	10^{-3}	0.001
4	00100	10^{-4}	0.0001
5	00101	10^{-5}	0.00001
6	00110	10^{-6}	0.000001
7	00111	10^{-7}	0.0000001
8	01000	10^{-8}	0.00000001
9	01001	10^{-9}	0.000000001

- ◆ Bit 5 = "1": binary factors 1, 1/2, 1/4, 1/8, ...
- Bit 4 ... Bit 0: Normalization factor**

#	Bit 4...0	Factor bin (Bit 5 = 1) yy1x xxxx	
32	00000	2^0	1
33	00001	2^{-1}	0.5
34	00010	2^{-2}	0.25
35	00011	2^{-3}	0.125
36	00100	2^{-4}	0.0625
37	00101	2^{-5}	0.03125
38	00110	2^{-6}	0.015625
39	00111	2^{-7}	0.0078125
40	01000	2^{-8}	0.00390625
41	01001	2^{-9}	0.001953125
42	01010	2^{-10}	0.0009765625
43	01011	2^{-11}	0.00048828125
44	01100	2^{-12}	0.000244140625
45	01101	2^{-13}	0.0001220703125
46	01110	2^{-14}	0.00006103515625
47	01111	2^{-15}	0.000030517578125
48	10000	2^{-16}	0.0000152587890625
49	10001	2^{-17}	0.00000762939453125
50	10010	2^{-18}	0.000003814697265625
51	10011	2^{-19}	0.0000019073486328125
52	10100	2^{-20}	0.00000095367431640625
53	10101	2^{-21}	0.000000476837158203125
54	10110	2^{-22}	0.0000002384185791015625
55	10111	2^{-23}	0.00000011920928955078125
56	11000	2^{-24}	0.000000059604644775390625

- ◆ Bit 15 ... Bit 6: reserved

Bit sequence V2

The V2 bus format is a bit sequence with a length of 16 bits.

Byte string OS

Octet string OS: String with variable length.

You can find the modules on the Compax3 DVD or in the internet under <http://www.compax3.info/startup> <http://www.compax3.info/startup>. You will find a description of these function modules in the help file !

6.5 CANopen

The CANopen option is available with the Compax3 devices C3I21Txx!

In this chapter you can read about:

CANopen - Configuration.....	371
Supporting IEC modules.....	373
CANopen communication profile.....	380
Acyclic parameter channel.....	385

6.5.1. CANopen - Configuration

In this chapter you can read about:

CANopen Operating Mode.....	371
Error Reaction on Bus Failure.....	372
Baud rate.....	372
Possible PDO assignment.....	372
Transmission cycle time.....	373

Following are described the input windows of the CANopen configuration wizard. Can be called up in the tree (Compax3 ServoManager, left window) under "configure communication".

6.5.1.1 CANopen Operating Mode

CANopen Operating Modes:

◆ **Slave on C3 powerPLmC:**

Compax3 as Slave on C3 powerPLmC integrated via the DriveInterface
Note for C3I21T40: The cam programming is made in the slave axis

◆ **Slave**

Compax3 is Slave of a CANopen Master; the CANopen configuration is made via the ServoManager

◆ **Slave with configuration via Master**

Compax3 is Slave of a CANopen Master; the CANopen configuration is made via the Master

◆ **Master for PIOs**

Compax3 as CANopen Master only for the operation of external digital and analog PIOs (Parker Input and Output modules).

Please note: The device cannot be operated with an additional CANopen Master!

◆ **Slave on C3 powerPLmC (Cam programming on C3 powerPLmC)**

Operating mode only available with I21T40!

The programming of the device (C3I21T40) is only made on the C3 powerPLmC.

C3 Master PIO

In the "C3 Master PIO" operating mode, the input window for the CANopen PIO mapping is following:

Please state, how many words the process image of the PIOs will need, 1.. 4 words are possible.

The process image is transmitted via the process data objects as follows:

Digital Inputs: RPDO1

Analog Inputs: RPDO2

Digital Outputs: TPDO1

Analog Outputs: TPDO2

The inputs and outputs are stored in objects (O150.x ... O153.x).

Object 150.x: Digital Inputs

Object 151.x: Digital Outputs

Object 152.x: Analog Inputs

Object 153.x: Analog Outputs

The digital inputs and outputs can be read or written into in the IEC program via **modules** (see on page 322) in order to get an exact process image. Modules:

PIO_Input0_15, PIO_Input16_31, PIO_Input32_47, PIO_Input48_63,

PIO_Output0_15, PIO_Output16_31, PIO_Output32_47, PIO_Output48_63.

Before that, you must execute some initializations; this can be made with the aid of the **PIO_INIT** (see on page 322) module.

6.5.1.2 Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

6.5.1.3 Baud rate

Selecting the Baud rate.

Bear in mind that the maximum cable length depends on the Baud rate:

Baud rate	Maximum length
1Mbit/s	25m
800kbit/s	50m
500kbit/s	100 m
250kbit/s	250m
125kbit/s	500m
100kbit/s	700m
50kbit/s	1000m
20kbit/s	2500m

6.5.1.4 Possible PDO assignment

Via the process data objects (PDOs) actual values and Setpoint values are continually exchanged between Compax3 and the CANopen client.

4 cyclic PDOs are possible, they are configured with the help of the Compax3 ServoManager:

The PDOs are set separately for the transmission directions

- ◆ CANopen - Client ⇒ Compax3 (**RPDO**) (max. 16 words)
 - ◆ Compax3 ⇒ CANopen - Client (**TPDO**) (max. 16 words)
- set separately.

The objects that can be put on the process data channel can be found in the "**Compax3 Objects** (see on page 415)!"

6.5.1.5 Transmission cycle time

For the TPDOs a transmission cycle time can be set in each case. This time specifies the time intervals at which Compax3 applies the cyclic data new to the respective PDO. The minimum value is thereby 1ms.


6.5.2. Supporting IEC modules

In this chapter you can read about:


This module is used to determine the status of the CANopen NMT status machine (C3_CANopen_State)..... 373
 This module is used to determine the status during Nodeguarding (C3_CANopen_GuardingState) 374
 Insert new CANopen node (C3_CANopen_AddNode) 375
 Establishing PDO connection between 2 CANopen nodes (C3_CANopen_ConfigNode)..... 376
 Sending NMT messages (C3_CANopen_NMT) 377
 Reading an object in another node (C3_CANopen_SDO_Read4) 378
 Writing an object in another node (C3_CANopen_SDO_Write4)..... 379

6.5.2.1 This module is used to determine the status of the CANopen NMT status machine (C3_CANopen_State)

FB name	C3_CANopen_State	
This module is used to determine the status of the CANopen NMT status machine		
VAR_INPUT		
Enable	BOOL	Activating the module
VAR_OUTPUT		
Stopped	BOOL	CANopen node is in "Stopped" state
Operational	BOOL	CANopen node is in the "Operational" state (communication via process data and service data objects is possible)
PreOperational	BOOL	CANopen node is in the "PreOperational" state (communication via process data and service data objects is possible)



CANopen states




- 6: Start Remote Node
- 7: Stop Remote Node
- 8: Enter Pre-Operational State
- 10: Reset Node
- 11: Reset Communication

The "Initialization" state is no fixed state but only a transition state.


6.5.2.2 This module is used to determine the status during Nodeguarding (C3_CANopen_GuardingState)

FB name	C3_CANopen_GuardingState	
This module is used to determine the status during Nodeguarding		
VAR_INPUT		
Enable	BOOL	Activating the module
VAR_OUTPUT		
GuardingStarted	BOOL	The NMT master started the Nodeguarding procedure
LostGuarding	BOOL	The node did not receive a Nodeguarding RTR telegram from the NMT master during the Guarding time.
LostConnection	BOOL	The node did not receive a RTR telegram from the NMT Master during the "Node Life Time" (GuardingTime * LifeTimeFactor) and therefore considers the connection as interrupted.




6.5.2.3 Insert new CANopen node (C3_CANopen_AddNode)

FB name	C3_CANopen_AddNode	
This module inserts a new CANopen node into the management list of the NMT master with the stated Node Guarding parameters and the current CANopen status PRE_OPERATIONAL.		
VAR_INPUT		
Execute	BOOL	Activating the module
Device	INT	Node-ID (1 ... 127)
GuardTime	INT	Guard time = 0
LifeTimeFactor	INT	Life Time Factor = 0
VAR_OUTPUT		
Done	BOOL	Function executed without error
Error	BOOL	Error occurred
ErrorCode	WORD	You will find the error code in the Compax3 error list (see on page 439).
AbortCode	DWORD	CANopen SDO abort code (see on page 385) upon error 65377 C3 CANopen stack error (see on page 377) no. upon error 65376
MyNode_ID	INT	Own Node_ID (NMT master)
Note: Compax3 must be CANopen master.		




6.5.2.4 Establishing PDO connection between 2 CANopen nodes (C3_CANopen_ConfigNode)

FB name	C3_CANopen_ConfigNode	
This module establishes a PDO connection between two CANopen nodes. To do this, the module changes the COB-Ids of the 2nd node (RemoteDevice) to the COB-Ids of the 1st. node (ReferenceDevice).		
VAR_INPUT		
Execute	BOOL	Activating the module
ReferenceDevice	INT	Node ID of the 1st. node (1 ... 127)
RemoteDevice	INT	Node ID of the 2nd. node (1 ... 127)
ReferenceTxPDO	INT	TxPDO number of the 1st. node (1 ... 4)
RemoteRxPDO	INT	TxPDO number of the 2nd. node (1 ... 4)
ReferenceRxPDO	INT	TxPDO number of the 1st. node (1 ... 4)
RemoteTxPDO	INT	TxPDO number of the 2nd. node (1 ... 4) "0" do not establish connection
VAR_OUTPUT		
Done	BOOL	Function executed without error
Error	BOOL	Error occurred
ErrorCode	WORD	You will find the error code in the Compax3 error list (see on page 439).
AbortCode	DWORD	CANopen SDO abort code (see on page 385) upon error 65377 C3 CANopen stack error (see on page 377) no. upon error 65376
Note: Compax3 must be CANopen master.		




6.5.2.5 Sending NMT messages (C3_CANopen_NMT)

FB name		C3_CANopen_NMT
This module allows to send NMT messages.		
VAR_INPUT		
Execute	BOOL	Activating the module
Device	INT	Node ID (0 ... 127) 0 = NMT-message is valid for all nodes
State	INT	State which the node must take on: START_REMOTE_NODE STOP_REMOTE_NODE ENTER_PRE_OPERATIONAL RESET_NODE RESET_COMMUNICATION (these are no constants; please enter therefore directly)
VAR_OUTPUT		
Done	BOOL	Function executed without error
Error	BOOL	Error occurred
ErrorCode	WORD	CANopen-Stack error no. 1 = not sufficient memory 2 = node is not in the management list 3 = node is already in the management list 4 = nodes are in the wrong state 11 = network object not available 12 = node 0 was selected 65378 = C3 has no master functionality
Note: Compax3 must be CANopen master.		




6.5.2.6 Reading an object in another node (C3_CANopen_SDO_Read4)

FB name	C3_CANopen_SDO_Read4	
This module allows to read an object with a max. length of 4 bytes in another node via SDO.		
VAR_INPUT		
Execute	BOOL	Activating the module
Device	INT	Node ID of the other node (1 ... 127)
Index	WORD	Object Index (CAN-No.)
Subindex	WORD	Object Subindex (CAN-No.)
VAR_OUTPUT		
Data	DWORD	Object data read in
Length	WORD	Data length in Byte
Done	BOOL	Function executed without error
Error	BOOL	Error occurred
ErrorCode	WORD	You will find the error code in the Compax3 error list (see on page 439).
AbortCode	DWORD	CANopen SDO abort code (see on page 385) upon error 65377 C3 CANopen stack error (see on page 377) no. upon error 65376
Note: Compax3 must be CANopen master.		



6.5.2.7 Writing an object in another node (C3_CANopen_SDO_Write4)

FB name	C3_CANopen_SDO_Write4	
This module allows to read an object with a max. length of 4 bytes in another node via SDO.		
VAR_INPUT		
Execute	BOOL	Activating the module
Device	INT	Node ID of the other node (1 ... 127)
Index	WORD	Object Index
Subindex	WORD	Object subindex
Data	DWORD	Object data which must be written
Length	WORD	Data length in Byte
VAR_OUTPUT		
Done	BOOL	Function executed without error
Error	BOOL	Error occurred
ErrorCode	WORD	You will find the error code in the Compax3 error list (see on page 439).
AbortCode	DWORD	CANopen SDO abort code (see on page 385) upon error 65377 C3 CANopen stack error (see on page 377) no. upon error 65376
Note: Compax3 must be CANopen master.		



6.5.3. CANopen communication profile

The CANopen communication objects described in this chapter are either set to sensible standard values or they are set under menu control with the help of the ServoManager.

The communication objects described below must be modified only for special deviating settings.

- ◆ CAN is an open system which has been standardized in the ISO 11898 and OSI reference model ISO 7498.
- ◆ CAN is Multi-Master compatible.
- ◆ Data transmission takes place with up to 8 Bytes useful data.
- ◆ The CAN objects are designated with an 11 Bit identifier (ID or COB-ID: CAN Object identifier). The identifier specifies the priority of the objects (the smaller the value of the object ID is, the higher is the priority level of the object).
- ◆ The COB-ID consists of the function code and the node ID:

Structure of the COB-ID

Bit 10	9	8	7	6	5	4	3	2	1	0
Function code				NodeID (1 ... 127)						

NodeID: The Compax3 device address is used here as standard value

CANopen characteristics (I21)

Baud rate [kBit/s]	◆ 20, 50, 100, 125, 250, 500, 800, 1000
EDS file	◆ C3.EDS
Service data object	◆ SDO1
Process data objects	◆ PDO1, ... PDO4

6.5.3.1 Object types

The following table shows the preset COB-IDs:

Communication object type	Function code	COB - Identifier (dec)	COB - Identifier (hex)	Defined in Index...	Description	
Broadcast objects						
NMT	0000b	0	0h	-	Network management and identifier assignment	
SYNC	0001b	128	80h	1005h	CANSYNC	
TIME	0010b	256	100h	1012h	TIME is not implemented in Compax3.	
Point to point objects						
EMCY	0001b	129-255	81h-FFh	1014h	Error messages	
T-PDO1	0011b	385-511	181h-1FFh	1800h	Assignment via Index 1A00h	Transmit process data object (Compax3) max. 8 Byte
T-PDO2	0101b	641-767	281h-2FFh	1801h	Assignment via Index 1A01h	
T-PDO3	0111b	897-1023	381h-3FFh	1802h	Assignment via Index 1A02h	
T-PDO4	1001b	1153-1279	481h-1279h	1803h	Assignment via Index 1A03h	
R-PDO1	0100b	513-639	201h-27Fh	1400h	Assignment via Index 1600h	Receive process data objects (Compax3) max. 8 Byte
R-PDO2	0110b	769-895	301h-37Fh	1401h	Assignment via Index 1601h	
R-PDO3	1000b	1025-1151	401h-47Fh	1402h	Assignment via Index 1602h	
R-PDO4	1010b	1281-1407	501h-57Fh	1403h	Assignment via Index 1603h	
T-SDO1	1011b	1409-1535	581h-5FFh	1200h	Transmit service data object 1	
T-SDO2	-*	-*	-	1201h	Transmit service data object 2	
R-SDO1	1100b	1537-1663	601h-67Fh	1200h	Receive service data object 1	
R-SDO2	-*	-*	-	1201h	Receive service data object 2	
Node guard	1110b	1793-1919	701h-77Fh	100Eh	Check bus subscribers.	

* The SDO2 are not activated.

The standard value of the COB-ID for an object is calculated as follows: COB-ID = (Function code * 128) + Device address

The standard values of the COB-IDs can be changed via communication objects via SDOs.

Application of the communication object types

Transmission of real time data (faster transmission because higher priority)

T-PDO Transmit process data object: Compax3 reply.

R-PDO Receive process data object: send to Compax3.

Once only transmission, e. g. of parameters or program lines

T-SDO Transmit service data object: Compax3 reply.

R-SDO Receive service data object: send to Compax3.

6.5.3.2 Communication objects

General note:

Every CAN object which is created as array (with subindex) contains the number of entries in subindex 0.

CAN communication objects overview sorted according to CAN No.

CAN-No	Name	Bus format	Standard value	Minimum value	Maximum value	Access
0x1000	Device Type	Unsigned32	0x00020192	0x00000000	0xFFFFFFFF	const
0x1001	Error Register	Unsigned8	0x00	0x00	0xFF	ro
0x1005	COB-ID SYNC	Unsigned32	0x80000080	0x00000001	0xFFFFFFFF	rw
0x1006	Communication Cycle Period	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1007	Synchronous Window Length	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1008	Manufacturer Device Name	Visible_String	C3xxxxxxxxxxxxxxxxxxxx			const
0x1009	Manufacturer Hardware Version	Visible_String	CTPxxxxxxxxLEIxxxxxxx			const
0x100A	Manufacturer Software Version	Visible_String	Vxxxxxxxxxxxxxxxxxxxx			const
0x100C	Guard Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x100D	Life Time Factor	Unsigned8	0x00	0x0	0xFF	rw
0x1014	COB-ID EMCY	Unsigned32	0x000000FF	0x00000001	0xFFFFFFFF	rw
0x1015	Inhibit Time Emergency	Unsigned16	0x0	0x0	0xFFFF	rw
0x1018	Identity Object (see on page 384)	-				
0x1018.1	Vendor Id	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.2	Product Code	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.3	Revision number	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1018.4	Serial number	Unsigned32	0x0	0x0	0xFFFFFFFF	ro
0x1200	Server SDO1 Parameter	-				
0x1200.1	SDO1: COB-ID Client -> Server	Unsigned32	0x0000067F	0x00000001	0xFFFFFFFF	ro
0x1200.2	SDO1: COB-ID Server -> Client	Unsigned32	0x000005FF	0x00000001	0xFFFFFFFF	ro
0x1200.3	Node ID of the SDO1 client	Unsigned8	0x00	0x00	0xFF	rw
0x1201	Server SDO2 Parameter	-				
0x1201.1	SDO2: COB-ID Client -> Server	Unsigned32	0x800006E0	0x00000001	0xFFFFFFFF	rw
0x1201.2	SDO2: COB-ID Server -> Client	Unsigned32	0x800006E0	0x00000001	0xFFFFFFFF	rw
0x1201.3	Node ID of the SDO2 Client	Unsigned8	0x00	0x00	0xFF	rw
0x1400	Receive PDO1 communication parameters	-				
0x1400.1	RPDO1: COB-ID	Unsigned32	0x0000027F	0x00000001	0xFFFFFFFF	rw
0x1400.2	RPDO1: Transmission Type	Unsigned8	0xFE	0x00	0xFF	rw
0x1400.3	RPDO1: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1400.5	RPDO1: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1401	Receive PDO2 communication parameters	-				
0x1401.1	RPDO2: COB-ID	Unsigned32	0x0000037F	0x00000001	0xFFFFFFFF	rw
0x1401.2	RPDO2: Transmission Type	Unsigned8	0xFE	0x00	0xFF	rw
0x1401.3	RPDO2: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1401.5	RPDO2: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1402	Receive PDO3 communication parameter	-				
0x1402.1	RPDO3: COB-ID	Unsigned32	0x0000047f	0x0	0xFFFFFFFF	rw
0x1402.2	RPDO3: Transmission Type	Unsigned8	0xFE	0x0	0xFF	rw
0x1402.3	RPDO3: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1402.5	RPDO3: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1403	Receive PDO4 communication parameter	-				
0x1403.1	RPDO4: COB-ID	Unsigned32	0x0000057f	0x0	0xFFFFFFFF	rw
0x1403.2	RPDO4: Transmission Type	Unsigned8	0xFE	0x0	0xFF	rw
0x1403.3	RPDO4: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1403.5	RPDO4: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1600	Receive PDO1 mapping parameter	-				
0x1600.1	RPDO1 Mapping Entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.2	RPDO1 mapping entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.3	RPDO1 Mapping Entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1600.4	RPDO1 Mapping Entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw

0x1600.5	RPDO1 Mapping Entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601	Receive PDO2 mapping parameter	-				
0x1601.1	RPDO2 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.2	RPDO2 Mapping Entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.3	RPDO2 Mapping Entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.4	RPDO2 Mapping Entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1601.5	RPDO2 Mapping Entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1602	Receive PDO3 mapping parameter	-				
0x1602.1	RPDO3 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.2	RPDO3 Mapping Entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.3	RPDO3 Mapping Entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.4	RPDO3 Mapping Entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1602.5	RPDO3 Mapping Entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603	Receive PDO3 mapping parameter	-				
0x1603.1	RPDO4 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.2	RPDO4 Mapping Entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.3	RPDO4 Mapping Entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.4	RPDO4 Mapping Entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1603.5	RPDO4 Mapping Entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1800	Transmit PDO1 communication parameter	-				
0x1800.1	TPDO1: COB-ID	Unsigned32	0x000001FF	0x00000001	0xFFFFFFFF	rw
0x1800.2	TPDO1: Transmission Type	Unsigned8	0xFE	0x00	0xFF	rw
0x1800.3	TPDO1: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1800.5	TPDO1: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1801	Transmit PDO2 communication parameter	-				
0x1801.1	TPDO2: COB-ID	Unsigned32	0x000002FF	0x00000001	0xFFFFFFFF	rw
0x1801.2	TPDO2: Transmission Type	Unsigned8	0xFE	0x00	0xFF	rw
0x1801.3	TPDO2: Inhibit Time	Unsigned16	0x0000	0x0000	0xFFFF	rw
0x1801.5	TPDO2: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1802	Transmit PDO3 communication parameter	-				
0x1802.1	TPDO3: COB-ID	Unsigned32	0x000003ff	0x0	0xFFFFFFFF	rw
0x1802.2	TPDO3: Transmission Type	Unsigned8	0xFE	0x0	0xFF	rw
0x1802.3	TPDO3: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1802.5	TPDO3: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1803	Transmit PDO4 communication parameter	-				
0x1803.1	TPDO4: COB-ID	Unsigned32	0x000004ff	0x0	0xFFFFFFFF	rw
0x1803.2	TPDO4: Transmission Type	Unsigned8	0xFE	0x0	0xFF	rw
0x1803.3	TPDO4: Inhibit Time	Unsigned16	0x0000	0x0	0xFFFF	rw
0x1803.5	TPDO4: Event Timer	Unsigned16	0x0	0x0	0xFFFF	rw
0x1A00	Transmit PDO1 mapping parameter	-				
0x1A00.1	TPDO1 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.2	TPDO1 Mapping Entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.3	TPDO1 Mapping Entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.4	TPDO1 Mapping Entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A00.5	TPDO1 Mapping Entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01	Transmit PDO2 mapping parameter	-				
0x1A01.1	TPDO2 mapping entry 1	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.2	TPDO2 Mapping Entry 2	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.3	TPDO2 Mapping Entry 3	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.4	TPDO2 Mapping Entry 4	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A01.5	TPDO2 Mapping Entry 5	Unsigned32	0x00000000	0x00000000	0xFFFFFFFF	rw
0x1A02	Transmit PDO3 mapping parameter	-				
0x1A02.1	TPDO3 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.2	TPDO3 Mapping Entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.3	TPDO3 Mapping Entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A02.4	TPDO3 Mapping Entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw

0x1A02.5	TPDO3 Mapping Entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03	Transmit PDO4 mapping parameter	-				
0x1A03.1	TPDO4 mapping entry 1	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.2	TPDO4 Mapping Entry 2	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.3	TPDO4 Mapping Entry 3	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.4	TPDO4 Mapping Entry 4	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw
0x1A03.5	TPDO4 Mapping Entry 5	Unsigned32	0x00000000	0x0	0xFFFFFFFF	rw

Identity Object (0x1018)

This object is composed as follows:

Vendor-ID (0x1018.1)

Is stored in the FBI-EEPROM binarily from addr. 56...59 (low...high). Current value = 0x02000089.

Product-Code (0x1018.2)

Is composed of the part of the order code "Faa lbb Tcc Mdd" to 0xaabbccdd, i.e. the device with the order code C3S025V2F10I21T40M11 has the product code 0x10214011.

The product code is hex coded, but can be read decimally.

Revision number (0x1018.3)

Is composed of 5 digits of the software version no. of the DSP software and 3 digits of the SV no. of the FBI software, i.e. the device with the DSP SV no. 01.08.02 and the FBI SV no. 1.21 has the revision no. 0x10802121.

Serial number (0x1018.4)

Is stored in the CTP-EEPROM as a 10 digit ASCII string from addr. 56...65 (series number of the device). A C3 with the series number 1423440001 has the serial number 0x54D7F881.

The description of the CANopen communication objects can be found in the corresponding help file.

6.5.4. Acyclic parameter channel

In this chapter you can read about:

Service Data Objects (SDO).....	385
Object Up-/Download via RS232 / RS485.....	386
Data formats of the bus objects	386

6.5.4.1 Service Data Objects (SDO)

Asynchronous access to the object directory of Compax3 is implemented with the help of the SDOs. The SDOs serve for parameter configuration and status interrogation. Access to an individual object takes place via the RS232 / RS485 index and subindex of the object directory.

Attention!

A SDO is a confirmed service, therefore the SDO reply telegram must always be awaited before a new telegram may be transmitted.

CiA405_SDO_Error (Abort Code): UDINT

In the case of an incorrect SDO transmission, the error cause is returned via the "abort code".

Abort Code	Description
0x0503 0000	"Toggle Bit" was not alternated
0x0504 0000	SDO Protocol "time out"
0x0504 0001	Client/server command designator invalid or unknown
0x0504 0002	Unknown block size (block mode only)
0x0504 0003	Unknown block number (block mode only)
0x0504 0004	CRC error (block mode only)
0x0504 0005	Outside of memory
0x0601 0000	Access to this object is not supported
0x0601 0001	Attempted read access to a write only object
0x0601 0002	Attempted write access to a read only object
0x0602 0000	The object does not exist in the object directory
0x0604 0041	Object cannot be mapped in a PDO
0x0604 0042	Size and number of "mapped" objects exceeds max. PDO length
0x0604 0043	General parameter incompatibility
0x0604 0047	General incompatibility in the device
0x0606 0000	Access infringement due to a hardware error
0x0607 0010	Data type does not fit, length of the service parameter does not fit
0x0607 0012	Data type does not fit, length of the service parameter too large
0x0607 0013	Data type does not fit, length of the service parameter too small
0x0609 0011	Subindex does not exist
0x0609 0030	Outside parameter value range (only for write access operations)
0x0609 0031	Parameter value too large
0x0609 0032	Parameter value too small
0x0609 0036	Maximum value smaller than minimum value
0x0800 0000	General error
0x0800 0020	Date cannot be transmitted or saved
0x0800 0021	Date cannot be transmitted or saved due to local device management
0x0800 0022	Date cannot be transmitted or stored due to device status
0x0800 0023	Dynamic generation of the object directory is impossible or no object directory exists (the object directory is created from a file and an error occurs due to a defective file)

6.5.4.2 Object Up-/Download via RS232 / RS485

The up-/download takes place via the RS232 / RS485 objects C3_Request (Index 0x2200) and C3_Response (Index 0x2201). These have the data type octet string with a length of 20 bytes (octets). Write/read of a C3 object is carried out by writing of C3_Request with the corresponding data. When a C3 object is read, the data appear in the C3_Response object .

Meaning of the data from C3_Request

Byte 1	Octet 2	Octet 3	Octet 4	Octet 5	Octet 6	Octet 19	Octet 20		
Request header				C3 object data (write)							
AK	Subindex	Index		D1	D2	D15	D16		

AK: Job identifier; 3=read, 4= write

OD1..OD16: Object data; OD1 = High, OD16 = Low

Meaning of the data from C3_Response

Byte 1	Octet 2	Octet 3	Octet 4	Octet 5	Octet 6	Octet 19	Octet 20		
Reply header				C3 object data (read)							
-	-	-	-	OD1	OD2	OD15	OD16		

OD1..OD16: Object data; OD1 = High, OD16 = Low

Upload

RS232 / RS485	O 1	O 2	O 3	O 4	O 5	O 6	O 7	O 8	...	O 20	
Access	Object			C3 object request/reply			C3 object data				
1. Write C3 object 20.2 with the value 0											
Write	0x2200.0	4	2	0	20	0	0	0	x	...	x
2. read next C3 object index/subindex in C3 object 20.5											
Write	0x2200.0	3	5	0	20	x	x	x	x	...	x
Read	0x2201.0	x	x	x	x	I_hi	I_lo	Subi	x	...	x
3. read the C3 object with the in index/subindex read in the C3 object 20.5											
Write	0x2200.0	3	Subi	I_hi	I_lo	x	x	x	x	...	x
Read	0x2201.0	x	x	x	x	D1	D2	D3	D4	...	D16
4. Store C3 object index, subindex and data D1...D16 in table											
5. Repeat steps 2 to 4 until I_hi = I_lo = Subi = 0xFF											

Download: Write the entire table of C3 objects.

RS232 / RS485	O 1	O 2	O 3	O 4	O 5	O 6	O 7	O 8	...	O 20	
Access	Object			C3 object request/reply			C3 object data				
1. Write C3 object from the table											
Write	0x2200.0	4	Subi	I_hi	I_lo	D1	D2	D3	D4	...	D16
2. Repeat step 1 until the end of the table											

6.5.4.3 Data formats of the bus objects

Data formats of the bus objects (see on page 368)

6.6 DeviceNet

Please note:

A changed assignment (mapping) of the Input/Output Message is accepted with Power off / Power on!

The length of the Input / Output Message is adapted to the real assignment (mapping) (2 ... 32).

Statement of Conformance

http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf (in the Internet)

Address or Baud rate settings (see on page 66)

Pin assignment (see on page 66)

In this chapter you can read about:

DeviceNet Configuration	387
DeviceNet object classes	388
Data formats of the bus objects	389

6.6.1. DeviceNet Configuration

In this chapter you can read about:

Error Reaction on Bus Failure	387
-------------------------------------	-----

Following are described the input windows of the configuration wizard.
Can be called up in the tree (Compax3 ServoManager, left window) under "configure communication".

6.6.1.1 Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

6.6.2. DeviceNet object classes

The DeviceNet object classes described in this chapter are either set to sensible standard values or they are set under menu control with the help of the ServoManager.

The communication objects described below must be modified only for special deviating settings.

In this chapter you can read about:

Overview of the DeviceNet object classes 389

DeviceNet characteristics (I22)

DeviceNet	<ul style="list-style-type: none"> ◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
Implemented object classes	◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
Baud rate [kBit/s]	◆ 125, 250, 500
permissible cable length	<ul style="list-style-type: none"> ◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
Max. Number of participants	◆ 63 Slave
Insulation	◆ Isolated Device Physical Layer
EDS file	◆ C3_DeviceNet.EDS
Conformance (file in the Internet)	<ul style="list-style-type: none"> ◆ Statement of Conformance http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf
Further information:	◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory"

6.6.2.1 Overview of the DeviceNet object classes

Object name	Class ID	Instance ID	Description
Identify	0x01	1	Mandatory
Message Router	0x02	1	Mandatory
DeviceNet	0x03	1	Mandatory
Assembly	0x04	101-103	I/O Messages
Connection	0x05	1	Explicit Messages
		2	Polled I/O Data
		3	Bit Strobe
		4	Change of State (COS), Cyclic I/O Data
Acknowledge Handler	0x2B	1	Necessary for connection class ID 05hex, instance ID 04
Image of I/O Data	0x64	1	Manufacturer-specific object class image of I/O data
C3 object	0x65	20-3300	Manufacturer-specific object class C3 object

Detailed information on the topic of "object classes" can be found in the online help of the device.

6.6.3. Data formats of the bus objects

Data formats of the bus objects (see on page 368)

6.7 Ethernet Powerlink / EtherCAT

The Ethernet Powerlink option is available with the Compax3 devices
C3I30Txx!

The EtherCAT option is available on the Compax3 devices C3I31Txx!

In this chapter you can read about:

Configuring Ethernet Powerlink / EtherCAT 390

6.7.1. Configuring Ethernet Powerlink / EtherCAT

In this chapter you can read about:

CN Controlled Node (Slave) 390
 Slave mit Konfiguration via Master 390
 Error Reaction on Bus Failure 390
 Possible PDO assignment 391

The Ethernet Powerlink or Ethercat configuration is made in a wizard. Can be called up in the tree (Compax3 ServoManager, left window) under "configure communication".

6.7.1.1 CN Controlled Node (Slave)

Compax3 is the slave of an Ethernet / EtherCAT master; the bus configuration is made via the ServoManager

6.7.1.2 Slave mit Konfiguration via Master

Select "Slave mit Konfiguration via Master" if you make the operating mode setting and mapping via the master.
 Then run through the wizard completely.

6.7.1.3 Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

6.7.1.4 Possible PDO assignment

Via the process data objects (RPDO and TPDO), actual values and Setpoint values are cyclically exchanged between Compax3 and the Ethernet Powerlink Controlled Nodes (Slaves). Please note that they put more strain on the fieldbus communication than the transmission via SDO:

The cyclic PDOs are configured with the aid of the Compax3 ServoManager:

The PDOs are set separately for the transmission directions

- ◆ Slave ⇒ Compax3 (**RPDO**)
- ◆ Compax3 ⇒ Slave (**TPDO**)

The objects that can be put on the process data channel can be found in the "**Compax3 Objects** (see on page 415)"!

Acyclic data can be transmitted via SDO.

6.8 HEDA Bus

HEDA: High Efficiency Data Access: Option M10 or M11

- ◆ Real-time data transfer
- ◆ High-stage axis synchronization
- ◆ fixed transfer rate of 10MBit/s
- ◆ Jitter < 300ns (Bus) which results in a high synchronicity
- ◆ Peer-to-Peer communication
- ◆ maximum cable length 50m (greater lengths on request)
- ◆ 1 Master / 31 Slave: Individual HEDA axis address in the range between /1...32
- ◆ fixed cycle time of 0.5ms
- ◆ Synchronization of the scanning grid of the digital control loops and of the setpoint generation
- ◆ cyclic data exchange
- ◆ acyclic data exchange of time-uncritical values

HEDA wiring (see on page 486)

Function of the HEDA LEDs

Green LED (left)

HEDA module energized

Red LED (right)

Error in the receive area

Possible causes:

- ◆ at the Master
 - ◆ no slave sending back
 - ◆ Wrong cabling
 - ◆ Terminal plug is missing
 - ◆ several masters are sending in the same slot
- ◆ at the slave
 - ◆ several masters in the system
 - ◆ no master active
 - ◆ Terminal plug is missing
 - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)

The configuration may take place in two different ways:

- ◆ HEDA standard: Simple Master -> Slave communication
- ◆ HEDA advanced: Extensive communication Master <-> Slave and Slave <-> Slave.

In this chapter you can read about:

HEDA standard mode.....	393
HEDA expansion (HEDA advanced).....	395
Coupling objects.....	413

6.8.1. HEDA standard mode

In this chapter you can read about:

Error Reaction on Bus Failure.....	393
HEDA-Master	394
HEDA-Slave	394


The HEDA option (option M10 or M11) can be used to send 4 process values in the "HEDA standard" operating mode from master to slave. A return transmission from Slave to Master is possible with "HEDA advanced".

First choose, if Compax3 is HEDA Master or HEDA Slave:

- ◆ HEDA Master in order to send process values
- ◆ HEDA Slave in order to receive process values

Please respect that only 1 HEDA station can be Master.

Principle:



- 1) Configuration in HEDA-Master of the process values placed in the four HEDA channels.
- 2) In the HEDA-Slave the process value of the four channels are assigned to objects.

6.8.1.1 Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

6.8.1.2 HEDA-Master

You can transmit 4 process values (one process value per channel) with max. 7 words (one process value per channel).


The 1st. process value (takes 3 words) is reserved for the axis synchronization.

You may choose between:

- ◆ Setpoint position value (Object 2000.1)
- ◆ Actual position (Object 2200.2)
- ◆ Setpoint position value from virtual Master (object 2000.2)
- ◆ External position value (Object 2020.1)

Signal read into the master via <Analog channel_C3_C3F>, Encoder input or step/direction input.

Principle:



Attention in the case of a configuration download with master-slave coupling (electronic gearbox, cam)

Switch Compax3 to currentless before starting the configuration download:

Master and Slave axis

- ◆ Position from virtual Master (object 2000.2)

Additional 3 process values with altogether max. 4 words data can be transmitted. You can make your choice between the Compax3 PD objects.

Note: Please use the **coupling objects** (see on page 413) for axis coupling.

6.8.1.3 HEDA-Slave

In the HEDA slave, the transmitted process values are read.

The transferred process values can be assigned to objects in the configuration wizard (e.g. array objects).

Objects with appropriate data width (corresponding to the process values read in) must be assigned.

The 1st process value is used as input process value (object 3920.1: HEDA SignalProcessing Input) for axis synchronization. The target for the process values 2, 3, 4 can be selected from a list in the configuration wizard.

The Measure reference for the Master position is selected under **Configuration: Configuration of the signal source: HEDA** (see on page 147).

6.8.2. HEDA expansion (HEDA advanced)

In this chapter you can read about:

The possibilities of the HEDA expansion.....	395
Technical data of the HEDA interface / overview	395
Definitions.....	396
Calling up the HEDA wizard in the C3 ServoManager.....	396
Configuration of the HEDA communication	396

6.8.2.1 The possibilities of the HEDA expansion

The HEDA option (option M10 or M11) can be used to exchange process values in the "HEDA advanced" operating mode.

- ◆ from Slave to Master
- ◆ from Slave to Master and
- ◆ from Slave to Slave.

6.8.2.2 Technical data of the HEDA interface / overview


General HEDA data

- ◆ Synchronous, bidirectional, deterministic real-time bus.
- ◆ Bus access via time sharing (slots), Master/Slave, Producer/Consumer. ((synchronization exactitude <math><1\mu\text{s}</math>).
- ◆ Bus cycle time 500µs, distributed into 20 time slots à 25µs.
- ◆ 18 slots cyclic transmitting and receiving data channels (Slot 0 .. 17).
- ◆ 2 slots reserved for acyclic communication.
- ◆ Telegrams (frames) with max. 7 words à 16 bit can be sent and received in a slot.
- ◆ Freely configurable assignment of the cyclic transmit(Tx)/receive(rx)-slots to the stations.
- ◆ The transmitting and receiving data are freely definable via mapping tables.
- ◆ Master-Slave as well as Slave-Slave communication (cross-communication) are possible.
- ◆ A master=>slave frame in slot x can be received by every slave.
- ◆ A master=>slave frame (cross-communication) in slot x can be received by every station.

Compax3-specific HEDA data:

- ◆ The Compaxa3 system cycle time is synchronized with the bus cycle time.
- ◆ System cycle time 500µs, distributed into 4 position control cycles à 125µs.
- ◆ For system-immanent reasons, only one slot is able to send and receive during the same position control cycle (every 125µs).
- ◆ Transmit- and receive slot can differ within one position controller cycle.
- ◆ The Master can receive frames from max. 4 Slaves received.

Principle:



Displayed are the number of the possible telegrams (Frames).

6.8.2.3 Definitions

DSP Format	Objects with this format: <ul style="list-style-type: none"> ◆ are not reset ◆ are not limited: they have a value range between -2^{23} and $2^{23}-1$ ◆ are suitable as coupling objects If the DSP Format is not selected, the objects are transmitted in the described formats (see on page 415). Please note that the Bus formats Y2 and Y4 (see on page 369) are set against the normalization factors.
Frame	Telegram of process values with a data width of 7 words.
Mapping	Image of process data on a communication channel (slot)
Mapping table	Overview of process values that can be put on a communication channel (slot).
Coupling objects	Are suitable as master signals for electronic coupling and must be in the DSP format.
Receive	Received
Slot	communication channel
Transmit	Send
Process data	Objects, which are suitable for use in the cyclic data channel.

6.8.2.4 Calling up the HEDA wizard in the C3 ServoManager

The "HEDA Advanced" wizard can be found in the C3 ServoManager tree under communication.

Please observe:

The "HEDA advanced" wizard settings overwrite the settings of the HEDA standard wizard!

6.8.2.5 Configuration of the HEDA communication

In this chapter you can read about:

Error Reaction on Bus Failure.....	396
Data transfer Master - Slave and back.....	397
Example: Communication Master - Slave and back.....	405
Data transfer from Slave to Slave.....	408

Error Reaction on Bus Failure

Here you can adjust how Compax3 will respond to a **fieldbus error** (see on page 439):

Possible settings for the error reaction are:


- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

Data transfer Master - Slave and back

In this chapter you can read about:

Setting the HEDA master.....399
 Setting the HEDA slave403


In standard applications the master sends process values to the slaves and reads the answers from the slaves.



- * only one of the assigned slots per frame group may be activated on the slave transmit side (this is blocked by the C3 ServoManager)
- * only one of the assigned slots per frame group may be activated on the master or slave receive side (this is blocked by the C3 ServoManager)

Print version available on the Internet

<http://divapps.parker.com/divapps/eme/EME/downloads/compax3/HEDA-Formulare/HE-DA-Standard.pdf>



Functionality:

The master can send 4 different frames (F1,... F4). A frame can be sent from several slots:

Frame:	F1	F2	F3	F4
possible slots:	0 ... 2	3 ... 7	8 ... 12	13 ... 17

Each frame is assigned a mapping table number.

The individual slaves read in the slot from where their relevant data are sent.

It is necessary to define a mapping table in the slave, stating where the individual process data are to be written (e.g. into an array-object).


The assignment of the mapping table is made via the mapping table number which is transferred via HEDA.

For this reason, the receive mapping table number and the transfer mapping table number must always be the same.

Important: Receive-Mapping table number = Transmit-Mapping-Table-Number

Setting the HEDA master

HEDA master settings:



- ◆ activate HEDA Master
- ◆ Axis address = 0
- ◆ Setting the error reaction (from Compax3) at bus failure:
 - ◆ activated: Compax3 switches to error state in the case of a bus error.
 - ◆ deactivated: Compax3 will ignore a bus error.
- ◆ By activating "Master setpoint delay (SG1)", actualization takes place at the same time on the master and on the slave (by a delay on the master setpoint value).

Master transmission slots (Transmit Slots)

Important:


For standard applications (data transfer master - slave and back) all slots in the master must be transmitting.

- ◆ for this reason you should activate all transmit slots (0...17, in the lower area of the wizard window).
- ◆ Please assign, according to your requirements, a mapping table to each of the 4 transmit frames.

The contents of the transmit mapping table is defined in the next wizard window.

Master receive slots

Activate the receive slots from which the slave sends data (corresponding to the settings in the slave).



In each of the 125 μ s cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be received only via one slot, see also the **HEDA communication structure** (see on page 397).

The assignment of the data is made via the mapping table number (which was defined in the slave), this number is also received.

In the Wizard window "Receive Mapping table", it is defined under this mapping table number where the data received are to be written to.

Master Transmit Mapping Table (max. 4)

Here the transmit mapping tables, which were assigned to the max. assigned to 4 transmit 125µs cycles.

Procedure:

- ◆ Selection of the corresponding transmit mapping table.
- ◆ Selection of the Compax3 objects to be transmitted.
 - ◆ The assignment of the mapping table is permanently identified and displayed.
 - ◆ Up to 7 words are possible.
 - ◆ How many words are used by an **object** (see on page 415) depends on the **bus format** (see on page 368) / DSP format

Note: For axis coupling, please use the **coupling objects** (see on page 413) in the **DSP format** (see on page 396) (selected by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

Master Receive Mapping Table (max. 4)

Please select the mapping table number, which was defined in the slave (under transmit mapping table).

Please enter now, where the received data are to be written. (e. B. on an array object).

Please use the data formats as defined in the mapping table of the slave.

Note: For axis coupling, please use the **coupling object** (see on page 413) O3920.1 in the **DSP format** (see on page 396) as an input (selection by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

Setting the HEDA slave

HEDA slave settings:

- ◆ Activating the HEDA Slave
- ◆ Assigning the axis address = 0 (can be changed by clicking)
- ◆ Setting the error reaction (from Compax3) at bus failure:
 - ◆ activated: Compax3 switches to error state in the case of a bus error.
 - ◆ deactivated: Compax3 will ignore a bus error.

Slave receive slots

Activate the receive slots, from where the slave is to receive the data.

In each of the four 125µs cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be received only via one slot, see also the **HEDA communication structure** (see on page 397).

The assignment of the data is made via the mapping table number (which was defined in the master), this number is also received.

In the Wizard window "Receive Mapping table", it is defined under this mapping table number where the data received are to be written to.

Slave transmission slots (Transmit Slots)

Activate the transmit slots, from where the slave is to send the data.

In each of the four 125µs cycles (slot 0...2, slot 3...7, slot 8...12, slot 13...17) data can be transmitted only via one slot, see also the **HEDA communication structure** (see on page 397).

Please make sure, that no other slave can send on this slot.

Now you can assign a mapping table to each individual activated slot.

Please consider, that transmit mapping table numbers are only used once in one transmit/receive range.

The contents of the transmit mapping table is defined in the next wizard window.

Slave Transmit Mapping table

Here the transmit mapping tables, which were assigned to the transmit slots activated before, are defined.

Procedure:

- ◆ Selection of the corresponding transmit mapping table.
- ◆ Selection of the Compax3 objects to be transmitted.
 - ◆ The assignment of the mapping table is permanently identified and displayed.
 - ◆ Up to 7 words are possible.
 - ◆ How many words are used by an **object** (see on page 415) depends on the **bus format** (see on page 368).

Note: For axis coupling, please use the **coupling objects** (see on page 413) in the **DSP format** (see on page 396) (selected by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

Slave Receive Mapping table

Please select the mapping table number, which was defined in the master (under transmit mapping table).


Please enter now, where the received data are to be written.

Please use the data formats as defined in the mapping table of the master.

Note: For axis coupling, please use the **coupling object** (see on page 413) O3920.1 in the **DSP format** (see on page 396) as an input (selection by clicking on the DSP switch). Please make sure that the DSP switch is activated on the master and the slave side in DSP format.

Example: Communication Master - Slave and back

HEDA communication structure:



Master and Slave 1 to 3 (from left to right).

Task:

Master Transmit

- ◆ Master sends on:
 - ◆ Slot 0...2: Mapping table 1
 - ◆ Slot 3...7: Mapping table 2
 - ◆ Slot 8...12: Mapping table 4
 - ◆ Slot 13...17: Mapping table 5

Slave Receive

- ◆ Slave 1 reads on:
 - ◆ Slot 2: Mapping table 1
 - ◆ Slot 3: Mapping table 2 and
 - ◆ Slot 8: Mapping table 4
- ◆ Slave 2 reads on:
 - ◆ Slot 6: Mapping table 2
 - ◆ Slot 9: Mapping table 4 and
 - ◆ Slot 13: Mapping table 5.
- ◆ Slave 3 reads on
 - ◆ Slot 1: Mapping table 1 and
 - ◆ Slot 9: Mapping table 4.

Slave Transmit

- ◆ Slave 1 sends on:
 - ◆ Slot 1: Mapping table 1
 - ◆ Slot 5: Mapping table 6
- ◆ Slave 2 sends on:
 - ◆ Slot 8: Mapping table 7
- ◆ Slave 3 sends on:
 - ◆ Slot 17: Mapping table 8

Master Receive

- ◆ Master receives on:
 - ◆ Slot 1: Mapping table 1
 - ◆ Slot 5: Mapping table 6
 - ◆ Slot 8: Mapping table 7
 - ◆ Slot 17: Mapping table 8

C3 ServoManger settings:

Slot - settings Master:

Example for transmit mapping table 1 on the master or slave

Transmit Mapping Table 1

TxPD Obj 1.1	PositionController_ActualValue [2200.2] 3w DSP
TxPD Obj 1.2	Array_Col07_Row01 [1907.1] 3w DSP
TxPD Obj 1.3	leer
TxPD Obj 1.4	leer
TxPD Obj 1.5	leer
TxPD Obj 1.6	leer
TxPD Obj 1.7	leer

1 Worte frei

Slot settings slave 1:

Receive Slot : \$10C (268)

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

0 .. 125 us 125 .. 250 us 250 .. 375 us 375 .. 500 us

Transmit Slot : \$22 (34)

#	#	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
---	---	---	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----

Mapping Table 1 Mapping Table 6 Mapping Table 1 Mapping Table 1

Example for receive mapping table 1 at slave 1 (is also valid for slave 3, master)


RECEIVE MAPPING TABLE 1

RxPD Obj 1.1	HEDA_SignalProcessing_Input [3920.1] 3w DSP
RxPD Obj 1.2	leer
RxPD Obj 1.3	leer
RxPD Obj 1.4	leer
RxPD Obj 1.5	leer
RxPD Obj 1.6	leer
RxPD Obj 1.7	leer

4 Worte frei

Data transfer from Slave to Slave.

HEDA communication structure with data transfer from Slave to Slave:



Print version available on the Internet

http://divapps.parker.com/divapps/eme/EME/downloads/compax3/HEDA-Formulare/HE DA_adv.pdf

If a transmit slot of the HEDA master is not assigned, the master will pass the received data directly on to the slaves (independent of his reading from this slot or not).

I.e. if a transmit slot of the master where a slave is sending is disabled, the data will be passed on and can be received from any slave on this slot.

It is, however, valid:

All transmit slots must send!

This is also true, if a slave sends on this slot.


Please note:

Please ensure that all slots are used for transmission, the C3 ServoManager cannot verify this fact!

In order to verify this, please use the HEDA communication structure.

Example 1: Communication Master - Slave and Slave - Slave.


Task:



MT1 ... MT7: Mapping table 1... 7

Step-by-step setting of the HEDA communications:

Firstly, activate all transmit slots of the master in order to ensure that all transmit slots of the master are sending:




The mapping tables are now distributed to different slots:

Mapping Table	Slot	
MT1	1	Slave transmit range
MT2	4	
MT3	11	
MT4	16	
MT5	2 (& 0, 1)	Master transmit range
MT6	9 (& 8, 10, 12)	
MT7	13 (& 14, 15, 17)	

Note: The transmit slots where a slave-slave communication is taking place (Slot 11 & 16), must be deactivated in the master! Otherwise, the master would overwrite the data of the slave.

This results in the following image:



The following objects are transmitted:

TRANSMIT (send)			RECEIVE	
Mapping Table	Source	Objects	Target	
1	S1	C3Array.Col01Row01 (1901.1)	M	C3Array.Col01Row01 (1901.1)
2	S1	C3Plus.DeviceState_Statusword1 (1000.3)	M	C3Array.Col03Row01 (1903.1)
3	S1	C3Plus.ProfileGenerators_SG1Position (2000.1)	M S2	C3Array.Col01Row02 (1902.1) C3Plus.HEDA_SignalProcessing_Input (3920.1)
4	S2	C3Plus.PositionController_DemandValue (2200.1)	S3	C3Plus.HEDA_SignalProcessing_Input (3920.1)
5	M	C3Plus.ProfilGenerators_PG2Position (2000.2)	S1 S2 S3	C3Plus.HEDA_SignalProcessing_Input (3920.1) C3Array.Col01Row05 (1901.5) C3Array.Col01Row05 (1901.5)
6	M	C3Plus.DeviceControl_Controlword1 (1100.3)	S1	C3Plus.DeviceControl_Controlword1 (1100.3)
7	M	C3Array.Col06Row01 (1906.1)	S1	C3Array.Col06Row01 (1906.1)

M: Master


S1, S2, S3: Slave 1 ... 3

Word form for the objects to be transmitted on the internet**<http://divapps.parker.com/divapps/eme/EME/downloads/compax3/HEDA-Formulare/communications-table.doc>**

Example 2: 4-axis application with HEDA

“Task:

- ◆ four-axis processing machine
- ◆ Setting the steps via virtual master
- ◆ Forwards and backwards movement with the master (closed curve)
- ◆ Linearized feed movement with Slave 1 = rotating blade (open curve)
- ◆ Position synchronous operation of slave 2 with respect to slave 1 with slip correction (use of C3_Shift_Position, only T40)
- ◆ Fixed position assignment of a turning axis slave 3 to slave 2 with consideration of the correction movement of slave 2




Master / Slave Configuration of the reference system

Configuration	Master	Slave 1	Slave 2	Slave 3
Travel distance per motor revolution				
◆ Numerator	127	233	100	360
◆ Denominator	10	5	3	7
Reset distance				
◆ Numerator	100	100	100	360
◆ Denominator	1	1	1	1
Signal source (Master axis)				
◆ Virtual Master				
◆ Reset distance	360			
◆ Use as current signal source	yes			
Source HEDA (Slave axis)				
◆ "Virtual master" as HEDA Master		yes	no	no
◆ Path per motor revolution of the HEDA Master				
◆ Numerator		not required	233	100
◆ Denominator			5	3
◆ Create cams with the CamDesinger				
◆ Distance Counter Reset Position - Numerator	360	360	100	100
◆ Distance Counter Reset Position - Denominator	1	1	1	1

The C3 ServoManager projects (configuration) can be found on the Compax3 CD:...\Examples\HEDAMaster.c3p, slave1.c3p, slave2.c3p, slave3.c3p

6.8.3. Coupling objects

Coupling objects (framed objects) are suitable as master signal for electronic coupling and should be in the **DSP Format** (see on page 396).



Input value for HEDA couplings is object 3920.1.

Note: * These values are not even reset by a home run.
Direction -1 / +1: With direction inversion (in the configuration wizard) these coupling values are inverted, relative to the drive direction (factor -1).

6.9 Normalization factors

Under "configuring communication: normalization factors Y2/Y4", you can change the validation for individual objects (objects in the Y2 and Y4 format) via scaling factors.

In the wizard window, the object numbers that can be influenced are displayed at the right side of the factors.

7. Compax3 - Objects

Compax3 objects are encapsulated in the "C3, C3Array, ..." modules in the IEC61131-3 programming environment (CoDeSys).

Enter the object names before the "." and the corresponding list of objects will appear.

Objects that are not described here are reserved objects!

Note on searching objects:

- ◆ If the object number is known, you can enter it directly in the index.
- ◆ In addition you can find the CoDeSys name of the objects in the index.

Note on bus numbers (PNU, CAN-No.):

The bus numbers of the array can be found in the description on column 1, line 1 (Object 1901.1)

In this chapter you can read about:

Object overview sorted by object name (T30)	415
T30 Objects for the Process-Data-Channel / the Messages	426
Object overview sorted by object groups (T30)	428

setting objects to valid

Please note that certain objects are not valid (read by Compax3) immediately after a change. This is described in the heading "Valid after".

These objects are converted to internal variables from the Compax3 "VP" command (write in object 210.10 with value <> 0).

saving objects permanently

It should also be noted that modified objects are not permanently stored in the Compax3, i.e. the changes are lost after the power (24 VDC) is turned off.

The object "Save objects permanently" (write in object 20.11 with value <> 0) can be used to save objects in a flash memory so they are retained even if the power fails.

Please note the following:

- ◆ The IEC cycle time increases considerably (to approx. 1.5 seconds) during memorization.
- ◆ We therefore recommend NOT to execute this function during time-sensitive parts of the IEC program.
- ◆ PLC cycle time monitoring is deactivated when accessing this object.
- ◆ Perform this command only when needed. The write cycles of the memory module are limited (up to 100 000 cycles).
- ◆ The function is edge triggered and is executed upon a rising edge.

7.1 Object overview sorted by object name (T30)

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
1.21	Device_FirmwareRelease	Version of firmware package		0x20FF	I32	nein	Immediat ely	False	True
20.1	ObjectDir_Objeks-->FLASH	Store objects permanently (bus)	339	0x2017	I16	nein	Immediat ely	False	True
20.10	C3.ObjectDir_ReadObjects	reading objects from Flash			I16	nein	Immediat ely	True	True
20.11	C3.ObjectDir_WriteObjects	saving objects permanently			I16	nein	Immediat ely	True	True
50.1	C3Plus.PLC_DemandCycleTime	cycle time specification	352	0x201F.1	U16	nein	Immediat ely	True	True
50.3	C3Plus.PLC_ActualCycleTime	Status of cycle time of the control program	353	0x201F.2	U16	nein	-	False	True
50.4	C3Plus.PLC_ActualCycleTimeMax	Status of maximum cycle time	354	0x201F.3	U16	nein	Immediat ely	False	True
84.2	DeviceSupervision_ThisDevice	Device number in the C3M combination			U16	nein	-	True	True
84.3	DeviceSupervision_DeviceCounter	Number of devices in the C3M combination			U16	nein	-	True	True
84.4	DeviceSupervision_DeviceAdr	Current RS485 address of the C3M			U16	nein	-	True	True
84.5	DeviceSupervision_OperatingTime	Hours of operation of the PSUP in s			U32	nein	-	True	True
85.1	Diagnostics_DeviceState	PSUP operating state			V2	nein	Immediat ely	True	True
85.2	C3Plus.Diagnostics_DCbus_Voltage	PSUP DC intermediate voltage			I16	nein	-	True	True
85.3	C3Plus.Diagnostics_DCbus_Current	PSUP intermediate current			I16	nein	-	True	True
85.4	C3Plus.Diagnostics_TemperatureHeatSink	PSUP heat dissipator temperature			I16	nein	-	True	True
85.5	C3Plus.Diagnostics_RectifierLoad	PSUP usage in %			I16	nein	-	True	True
85.7	Diagnostics_ChopperOn_Voltage	Chopper Switch-on threshold in V			I16	nein	-	True	True
85.8	Diagnostics_ChopperOff_Voltage	Chopper Switch-off threshold in V			I16	nein	-	True	True
85.9	Diagnostics_DCbus_VoltageMax	Reduced DC bus voltage in V			I16	nein	-	True	True
86.1	ErrorHistoryPointer_LastEntry	Pointer to current error			U16	nein	-	True	True
87.1	ErrorHistoryNumber_1	Error 1			U16	nein	-	True	True
88.1	ErrorHistoryTime_1	Error point in time 1			U32	nein	-	True	True
100.1	C3Plus.Controller_ControlwordDemand	Controller control word setpoint value			U16	nein	Immediat ely	True	True
100.2	C3Plus.Controller_Controlword	Controller control word actual value			U16	ja	Immediat ely	True	True
110.1	C3Plus.Switch_DeviceFunction	Value of the function switch on C3M			U16	nein	-	True	True
120.2	C3.DigitalInput_Value	Status of digital inputs			V2	ja	-	True	True
120.3	DigitalInput_DebouncedValue	Status of digital inputs	21	0x6100.1	V2	ja	-	True	True
120.7	C3.DigitalInput_DebounceTime	Debounce time for dig. Inputs			I16	nein	Immediat ely	True	True
120.8	C3.DigitalInput_DebounceMask	Debounce mask for dig. Inputs			I16	nein	Immediat ely	True	True
121.2	C3.DigitalInputAddition_Value	input word of I/O option	175	0x6100.2	V2	ja	-	True	True
133.2	C3.DigitalOutputAddition_Error	error in I/O option	351	0x6300.4	V2	nein	-	True	True
133.3	C3.DigitalOutputAddition_Value	output word for I/O option	176	0x6300.2	V2	ja	Immediat ely	True	True
133.4	C3.DigitalOutputAddition_Enable	activating input/output option M10/M12	350	0x6300.3	V2	nein	Immediat ely	True	True
140.3	C3.DigitalOutputWord_DemandState	Command value of the digital outputs	22	0x6300.1	V2	ja	Immediat ely	False	True
150.1	C3Plus.RemoteDigInput_I0_15	Digital PIO inputs 0...15		0x2080.1	V2	ja	Immediat ely	False	True
150.2	C3Plus.RemoteDigInput_I16_31	Digital PIO inputs 16...31		0x2080.2	V2	ja	Immediat ely	False	True
150.3	C3Plus.RemoteDigInput_I32_47	Digital PIO inputs 32...47		0x2080.3	V2	ja	Immediat ely	False	True
150.4	C3Plus.RemoteDigInput_I48_63	Digital PIO inputs 48...63		0x2080.4	V2	ja	Immediat ely	False	True
151.1	C3Plus.RemoteDigOutput_O0_15	Digital PIO outputs 0...15		0x2081.1	V2	ja	Immediat ely	False	True
151.2	C3Plus.RemoteDigOutput_O16_31	Digital PIO outputs 16...31		0x2081.2	V2	ja	Immediat ely	False	True
151.3	C3Plus.RemoteDigOutput_O32_47	Digital PIO outputs 32...47		0x2081.3	V2	ja	Immediat ely	False	True
151.4	C3Plus.RemoteDigOutput_O48_63	Digital PIO outputs 48...63		0x2081.4	V2	ja	Immediat ely	False	True
152.1	C3Plus.RemoteAnalogInput_I0	PIO analog input 0		0x2082.1	I16	ja	Immediat ely	False	True
152.2	C3Plus.RemoteAnalogInput_I1	PIO analog input 1		0x2082.2	I16	ja	Immediat ely	False	True
152.3	C3Plus.RemoteAnalogInput_I2	PIO analog input 2		0x2082.3	I16	ja	Immediat ely	False	True
152.4	C3Plus.RemoteAnalogInput_I3	PIO analog input 3		0x2082.4	I16	ja	Immediat ely	False	True
153.1	C3Plus.RemoteAnalogOutput_O0	PIO analog output 0		0x2083.1	I16	ja	Immediat ely	False	True
153.2	C3Plus.RemoteAnalogOutput_O1	PIO analog output 1		0x2083.2	I16	ja	Immediat ely	False	True
153.3	C3Plus.RemoteAnalogOutput_O2	PIO analog output 2		0x2083.3	I16	ja	Immediat ely	False	True
153.4	C3Plus.RemoteAnalogOutput_O3	PIO analog output 3		0x2083.4	I16	ja	Immediat ely	False	True
170.2	AnalogInput0_Gain	Gain analog input 0			C4_3	nein	VP	True	True
170.3	C3Plus.AnalogInput0_FilterCoefficient	Filter of analog input 0			I16	nein	VP	True	True
170.4	AnalogInput0_Offset	Analog input Offset 0			I16	nein	Immediat ely	True	True
171.2	AnalogInput1_Gain	Gain analog input 1			C4_3	nein	VP	True	True
171.3	C3Plus.AnalogInput1_FilterCoefficient	Filter of analog input 1			I16	nein	VP	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
171.4	AnalogInput1_Offset	Analog input offset 1			I16	nein	Immediat ely	True	True
190.1	C3Plus.M2x_InputControl_Enable_Inputs_X20	Enable analog inputs X20 M2x			I16	nein	VP	True	True
190.2	C3Plus.M2x_InputControl_Enable_Inputs_X21	Enable analog inputs X21 M2x			I16	nein	VP	True	True
191.1	C3.M2x_Input0_Gain	User gain M2x Input 0			C4_3	nein	VP	True	True
191.2	C3.M2x_Input0_Offset	User offset M2x Input 0			Y2	nein	VP	True	True
191.3	C3Plus.M2x_Input0_FilterCoefficient	Filter time constant M2x Input 0			I16	nein	VP	True	True
192.1	C3.M2x_Input1_Gain	User gain M2x Input 1			C4_3	nein	VP	True	True
192.2	C3.M2x_Input1_Offset	User offset M2x Input 1			Y2	nein	VP	True	True
192.3	C3Plus.M2x_Input1_FilterCoefficient	Filter time constant M2x Input 1			I16	nein	VP	True	True
193.1	C3.M2x_Input2_Gain	User gain M2x Input 2			C4_3	nein	VP	True	True
193.2	C3.M2x_Input2_Offset	User offset M2x Input 2			Y2	nein	VP	True	True
193.3	C3Plus.M2x_Input2_FilterCoefficient	Filter time constant M2x Input 2			I16	nein	VP	True	True
194.1	C3.M2x_Input3_Gain	User gain M2x Input 3			C4_3	nein	VP	True	True
194.2	C3.M2x_Input3_Offset	User offset M2x Input 3			Y2	nein	VP	True	True
194.3	C3Plus.M2x_Input3_FilterCoefficient	Filter time constant M2x Input 3			I16	nein	VP	True	True
195.1	C3.M2x_Input4_Gain	User gain M2x Input 4			C4_3	nein	VP	True	True
195.2	C3.M2x_Input4_Offset	User offset M2x Input 4			Y2	nein	VP	True	True
195.3	C3Plus.M2x_Input4_FilterCoefficient	Filter time constant M2x Input 4			I16	nein	VP	True	True
196.1	C3.M2x_Input5_Gain	User gain M2x Input 5			C4_3	nein	VP	True	True
196.2	C3.M2x_Input5_Offset	User offset M2x Input 5			Y2	nein	VP	True	True
196.3	C3Plus.M2x_Input5_FilterCoefficient	Filter time constant M2x Input 5			I16	nein	VP	True	True
200.1	NormFactorY2_Speed	Normalization factor for Y2 speeds	355.1	0x2020.1	V2	nein	Immediat ely	False	True
200.3	NormFactorY2_Voltage	Normalization factor for Y2 voltages	355.3	0x2020.3	V2	nein	Immediat ely	False	True
200.4	NormFactorY2_DemandValue3	Normalization factor for 1100.8	355.4	0x2020.4	V2	nein	Immediat ely	False	True
200.5	NormFactorY2_Array_Col2	Normalization factor recipe arrays column 2	355.5	0x2020.5	V2	nein	Immediat ely	False	True
200.6	NormFactorY2_DemandValue4	Normalization factor for 1100.9	355.6	0x2020.6	V2	nein	Immediat ely	False	True
200.7	NormFactorY2_ActualValue3	Normalization factor for 1000.8	355.7	0x2020.7	V2	nein	Immediat ely	False	True
200.8	NormFactorY2_ActualValue4	Normalization factor for 1000.9	355.8	0x2020.8	V2	nein	Immediat ely	False	True
200.9	NormFactorY2_DemandValue2_Y2	Normalization factor for 1100.14@1100.14		0x2020.9	V2	nein	Immediat ely	False	True
200.10	NormFactorY2_ActualValue2_Y2	Normalization factor for 1000.14			V2	nein	Immediat ely	False	True
200.11	NormFactorY2_Current	Normalization factor for Y2 currents	355.11	0x2020.11	V2	nein	Immediat ely	False	True
201.1	NormFactorY4_Speed	Scaling factor for Y4 speeds	356.1	0x2021.1	V2	nein	Immediat ely	False	True
201.2	C3Plus.NormFactorY4_Position	Scaling factor for Y4 positions	356.2	0x2021.2	V2	nein	Immediat ely	False	True
201.3	NormFactorY4_Voltage	Scaling factor for Y4 voltages	356.3	0x2021.3	V2	nein	Immediat ely	False	True
201.4	NormFactorY4_Array_Col1	Scaling factor recipe arrays column 1	356.4	0x2021.4	V2	nein	Immediat ely	False	True
201.5	NormFactorY4_DemandValue1	Normalization factor for 1100.6	356.5	0x2021.5	V2	nein	Immediat ely	False	True
201.6	NormFactorY4_DemandValue2	Normalization factor for 1100.7	356.6	0x2021.6	V2	nein	Immediat ely	False	True
201.7	NormFactorY4_ActualValue1	Normalization factor for 1000.6	356.7	0x2021.7	V2	nein	Immediat ely	False	True
201.8	NormFactorY4_ActualValue2	Normalization factor for 1000.7	356.8	0x2021.8	V2	nein	Immediat ely	False	True
201.11	NormFactorY4_FBI_SignalProcessing_Position	Normalization factor for bus interpolation CANSync/EthernetPowerLink	356.11	0x2021.11	V2	nein	Immediat ely	False	True
201.12	NormFactorY4_DemandValue8	Normalization factor for 1100.13	356.12	0x2021.12	V2	nein	Immediat ely	False	True
201.13	NormFactorY4_ActualValue8	Normalization factor for 1000.13	356.13	0x2021.13	V2	nein	Immediat ely	False	True
201.14	NormFactorY4_FBI_SignalProcessing_Speed	Normalization factor for 3925.20		0x2021.14	V2	nein	Immediat ely	False	True
201.15	NormFactorY4_FBI_SignalProcessing_Accel	Normalization factor for 3925.21		0x2021.15	V2	nein	Immediat ely	False	True
210.1	C3Plus.ValidParameter_CurrentController	Set current controller to valid			U16	nein	Immediat ely	True	True
210.2	C3Plus.ValidParameter_FiltersRSDP	Set filter parameter to valid			U16	nein	Immediat ely	True	True
210.3	C3Plus.ValidParameter_SpeedController	Set parameter velocity controller/velocity observer to valid.			U16	nein	Immediat ely	True	True
210.4	C3Plus.ValidParameter_PositionController	Set position controller to valid			U16	nein	Immediat ely	True	True
210.5	C3Plus.ValidParameter_FeedForward	Set feedforward parameters to valid.			U16	nein	Immediat ely	True	True
210.6	C3.ValidParameter_Limits	setting limit values to valid.			U16	nein	Immediat ely	True	True
210.8	C3Plus.ValidParameter_Autocommutation	Set position auto commutation parameters to valid			U16	nein	Immediat ely	True	True
210.10	C3.ValidParameter_Global	setting objects to valid	338.10	0x2016.10	U16	nein	Immediat ely	True	True
230.23	C3Plus.ProjectData_DSPFirmwareVersion	DSP firmware version			U32	nein	Immediat ely	True	True
280.3	Resolver_LevelAdaption	Resolver signal scaling			I16	nein	Immediat ely	True	True
280.5	Resolver_ExcitationLevel	Resolver excitation level			U16	nein	Immediat ely	True	True
295.10	SSI_Feedback_Incr_Position	SSI feedback position (Increments)			I32	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
295.11	C3Plus.SSI_Feedback_Absolut_Position				I32	nein	-	True	True
295.12	C3Plus.SSI_Feedback_PositionGreat	Rotation position			I32	nein	-	True	True
402.1	C3.Limit_SpeedPositive	maximum permissible positive speed	317	0x2009	I16	nein	VP	True	True
402.2	C3.Limit_SpeedNegative	maximum permissible negative speed	318	0x200A	I16	nein	VP	True	True
402.3	C3.Limit_CurrentPositive	maximum permissible positive current	319	0x200B	I16	nein	VP	True	True
402.4	C3.Limit_CurrentNegative	maximum permissible negative current	320	0x200C	I16	nein	VP	True	True
402.6	C3Plus.Limit_CurrentFine	Factor for the current limits	465	0x2093	I16	ja	Immediat ely	True	True
402.7	C3Plus.Limit_MaxTorque	Torque limit or force limit		0x6072	U16	ja	Immediat ely	True	True
410.2	C3.LimitPosition_Positive	Positive Travel Limit	321	0x607D.2	C4_3	nein	Immediat ely	True	True
410.3	C3.LimitPosition_Negative	Negative SW travel limit	322	0x607D.1	C4_3	nein	Immediat ely	True	True
410.6	C3.LimitPosition_LoadControlMaxPosDiff	Position difference load-motor (error threshold)			C4_3	nein	VP	True	True
420.1	C3.PositioningAccuracy_Window	positioning window for position reached	328	0x6067	C4_3	nein	VP	True	True
420.2	C3.PositioningAccuracy_FollowingErrorWindow	Following error limit	330	0x6065	C4_3	nein	VP	True	True
420.3	C3.PositioningAccuracy_FollowingErrorTimeout	Following Error Time	331	0x6066	U16	nein	Immediat ely	True	True
420.6	C3.PositioningAccuracy_PositionReached	Position reached			I32	nein	-	True	True
420.7	C3.PositioningAccuracy_WindowTime	In Position Window Time	329	0x6068	U16	nein	Immediat ely	True	True
550.1	C3Plus.ErrorHistory_LastError	current error (n)	115/947.0	0x603F/0x201D.1	U16	ja	-	True	True
550.2	ErrorHistory_1	Error (n-1) in the error history	947.1	0x201D.2	U16	nein	-	False	True
620.6	C3Plus.EncoderEmulation_Offset	Zero pulse offset encoder emulation			C4_3	nein	VP	True	True
620.7	C3Plus.EncoderEmulation_SetEmulationZero	Encoder simulation teaching zero pulse			I16	nein	Immediat ely	True	True
620.10	C3Plus.EncoderEmulation_Setpoint_without_offset	Demand position of encoder simulation (without offset)			C4_3	nein	-	True	True
634.4	C3.AnalogOutput0_DemandValue	Setpoint for analog output 0	24	0x2019	I16	ja	Immediat ely	True	True
634.6	AnalogOutput0_Offset_Hardware	Offset value for the D/A monitor 0			I16	nein	VP	True	True
634.7	AnalogOutput0_Gain_Hardware	Additional gain factor for the D/A monitor 0			C4_3	nein	VP	True	True
635.4	C3.AnalogOutput1_DemandValue	Setpoint for analog output 1	103	0x201A	I16	ja	Immediat ely	True	True
635.6	AnalogOutput1_Offset_Hardware	Offset value for the D/A Monitor 1			I16	nein	VP	True	True
635.7	AnalogOutput1_Gain_Hardware	Additional gain factor for the D/A monitor 1			C4_3	nein	VP	True	True
670.1	C3Plus.StatusTorqueForce_SetpointTorque	Status of setpoint torque			I32	nein	-	True	True
670.2	C3Plus.StatusTorqueForce_ActualTorque	Status of actual torque	209		I32	ja	-	True	True
670.3	C3Plus.StatusTorqueForce_SetpointForce	Status of setpoint force			I32	nein	-	True	True
670.4	C3Plus.StatusTorqueForce_ActualForce	Status of actual force			I32	nein	-	True	True
670.9	C3Plus.StatusTorqueForce_RatedTorqueForce	Reference torque or from the reference force		0x6076	U32	nein	-	True	True
677.11	C3Plus.StatusPressureForce_ForceDemandValue	Demand force controller			C4_3	nein	-	True	True
677.12	C3Plus.StatusPressureForce_ForceActualValue	Actual force controller			C4_3	nein	-	True	True
677.13	C3Plus.StatusPressureForce_ForceError	Control deviation of force controller			C4_3	nein	-	True	True
677.20	C3Plus.StatusPressureForce_ControllerIpart	Status of I-term of pressure or force/torque control			C4_3	nein	-	True	True
677.21	C3Plus.StatusPressureForce_ControllerPpart	Status of P-term of pressure or force/torque control			C4_3	nein	-	True	True
677.22	C3Plus.StatusPressureForce_ControllerDpart	Status of D-term of pressure or force/torque control			C4_3	nein	-	True	True
677.23	C3Plus.StatusPressureForce_ControllerVpart	Status of speed feedback of pressure or force/torque control			C4_3	nein	-	True	True
677.24	C3Plus.StatusPressureForce_ControllerFFWpart	Status actual torque/force injection force/torque controller			C4_3	nein	-	True	True
677.27	C3Plus.StatusPressureForce_ControllerOut	Status of total control signal pressure or force/torque control			C4_3	nein	-	True	True
680.1	C3.StatusPosition_DemandValue1	Position command value of Profile transmitter1	0	0x2052	Y4	ja	-	True	True
680.4	C3.StatusPosition_DemandValue	Status demand position	323	0x60FC	C4_3	ja	-	True	True
680.5	C3.StatusPosition_Actual	Status actual position	28	0x2104	C4_3	ja	-	True	True
680.6	C3.StatusPosition_FollowingError	Status of tracking error	100	0x60F4	C4_3	ja	-	True	True
680.8	StatusPosition_ActualY4	Status of actual position in bus format Y4	119	0x2022/0x6064	I32	ja	-	False	True
680.10	C3.StatusPosition_EncoderInput5V	Status of encoder input 0 (5V)		0x2095.2	C4_3	ja	-	True	True
680.11	C3.StatusPosition_EncoderInput24V	Status of encoder input 0 (24V)			C4_3	ja	-	True	True
680.12	C3.StatusPosition_DemandController	Status demand position without absolute reference			C4_3	nein	-	True	True
680.13	C3.StatusPosition_ActualController	Status actual position without absolute reference			C4_3	nein	-	True	True
680.14	StatusPosition_FeedbackAbsolute	Feedback absolute position in feedback increments			I32	nein	-	True	True
680.18	C3.StatusPosition_ActualNotReset	Status actual position (not reset)			C4_3	ja	-	True	True
680.20	StatusPosition_LoadControlDeviation	Position difference load-motor (unfiltered)			C4_3	nein	-	True	True
680.21	C3.StatusPosition_LoadControlDeviationMax	Maximum position difference load-motor			C4_3	nein	-	True	True
680.22	C3.StatusPosition_LoadControlDeviationFiltered	Position difference load-motor (filtered)			C4_3	nein	-	True	True
680.23	C3.StatusPosition_LoadControlActual	Actual position of the load			C4_3	nein	-	True	True
680.24	C3Plus.StatusPosition_SSI_AbsolutPosition_LoadUnits	AbsolutPosition of the SSI-feedback load unit			C4_3	nein	-	True	True
680.25	C3Plus.StatusPosition_SSI_AbsolutPosition_MasterUnits	AbsolutPosition of the SSI-feedback master unit			C4_3	nein	-	True	True
680.30	C3.StatusPosition_Referenced	Status of axis referenced			I16	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
680.32	C3Plus.StatusPosition_EncoderIncrements5V	Encoder position 0 (5V) in increments		0x2095.3	I32	ja	Immediately	True	True
681.1	C3.StatusSpeed_DemandValue1	Speed setpoint value of profile generator 1		0x2053	Y4	ja	-	True	True
681.4	C3.StatusSpeed_DemandValue	Status demand speed of setpoint generator	324	0x606B	C4_3	ja	-	True	True
681.5	C3.StatusSpeed_Actual	Status actual speed unfiltered		0x6069	C4_3	ja	-	True	True
681.6	C3.StatusSpeed_Error	Status control deviation of speed	101	0x2027	C4_3	ja	-	True	True
681.7	StatusSpeed_ActualFilteredY2	Status of the actual filtered speed in the Y2 format	6	0x2023	Y2	ja	-	False	True
681.8	StatusSpeed_ActualFilteredY4	Status of the actual filtered speed in the Y4 format	117	0x2024	Y4	ja	-	False	True
681.9	C3.StatusSpeed_ActualFiltered	Status actual speed filtered	8	0x606C	C4_3	ja	-	True	True
681.10	C3.StatusSpeed_DemandSpeedController	Status demand speed controller input			C4_3	ja	-	True	True
681.11	C3.StatusSpeed_FeedForwardSpeed	Status speed feed forward			C4_3	nein	-	True	True
681.12	C3.StatusSpeed_ActualScaled	Filtered actual speed in per cent			C4_3	nein	-	True	True
681.13	C3.StatusSpeed_DemandScaled	Setpoint speed of the setpoint generator			C4_3	nein	-	True	True
681.20	C3.StatusSpeed_LoadControl	Speed of the load feedback (unfiltered)			C4_3	nein	-	True	True
681.21	C3.StatusSpeed_LoadControlFiltered	Speed of the load feedback (filtered)			C4_3	nein	-	True	True
681.24	C3.StatusSpeed_PositiveLimit	Positive speed limit currently effective			C4_3	nein	-	True	True
681.25	C3.StatusSpeed_NegativeLimit	Negative speed limit currently effective			C4_3	nein	-	True	True
681.26	C3.StatusSpeed_ActualUnitrpmORmps	Status of actual speed filtered in 1/min or m/s	226	0x2105	C4_3	ja	-	True	True
682.4	C3.StatusAccel_DemandValue	Status demand acceleration	325	0x200E	I32	nein	-	True	True
682.5	C3.StatusAccel_Actual	Status of actual acceleration unfiltered			I32	nein	-	True	True
682.6	C3.StatusAccel_ActualFilter	Status of filtered actual acceleration			I32	nein	-	True	True
682.7	StatusAccel_FeedForwardAccel	Status acceleration feed forward			C4_3	nein	-	True	True
683.1	C3.StatusDevice_ActualCurrent	Status of actual current value	112	0x6077 (not EtherCAT with mapping via master)	E2_6	ja	-	True	True
683.2	C3.StatusDevice_ActualDeviceLoad	Status of device load	334	0x2011	E2_6	nein	-	True	True
683.3	C3.StatusDevice_ActualMotorLoad	Status of long-term motor utilization	335	0x2012	E2_6	nein	-	True	True
683.4	C3.StatusDevice_DynamicMotorLoad	Status of short-term motor load			E2_6	nein	-	True	True
683.5	C3.StatusDevice_ObservedDisturbance	Status of observed disturbance			C4_3	nein	-	True	True
683.6	StatusDevice_BallastResistorLoad	Status of long-term braking resistor utilization			C4_3	nein	-	True	True
683.7	StatusDevice_BallastResistorDynamicLoad	Status of short-term braking resistor utilization			C4_3	nein	-	True	True
683.8	C3Plus.StatusDevice_MotorCurrent	Motor current in per thousand of the actual current limit		0x2094	I16	ja	-	False	True
683.9	C3.StatusDevice_ActualDeviceLoadLowFrequency	Status of device utilization at small electrical turning frequency			E2_6	nein	-	True	True
683.11	StatusDevice_BallastResistorONThreshold	Braking resistor switch-on voltage			C4_3	nein	-	True	True
683.12	StatusDevice_BallastResistorOFFThreshold	Braking resistor switch-off voltage			C4_3	nein	-	True	True
683.13	StatusDevice_ActualTorqueDS402	Actual torque or force DS402 opmode 10		0x6077 (only EtherCAT with mapping via master)	I16	ja	-	False	True
684.1	C3.StatusTemperature_PowerStage	Status of power output stage temperature	337	0x2014	U16	nein	-	True	True
684.2	C3.StatusTemperature_Motor	Status of motor temperature	336	0x2013	I16	nein	-	True	True
684.4	C3Plus.StatusTemperature_TmotResistance	Status of motor temperature resistance value			U16	nein	-	True	True
685.1	C3.StatusVoltage_AuxiliaryVoltage	Status of auxiliary voltage	326	0x200F	E2_6	nein	-	True	True
685.2	C3.StatusVoltage_BusVoltage	Status DC bus voltage	327		E2_6	nein	-	True	True
685.3	C3.StatusVoltage_AnalogInput0	Status of analog input 0	23	0x2025	Y2	ja	-	True	True
685.4	C3.StatusVoltage_AnalogInput1	Status of analog input 1	102	0x2026	Y2	ja	-	True	True
685.5	StatusVoltage_BusVoltageC43	Status DC bus voltage C4_3		0x6079	C4_3	ja	-	False	True
685.6	C3.StatusVoltage_M2xAnalogInput0	Filtered actual value of the M2x voltage input 0			Y2	ja	-	True	True
685.7	C3.StatusVoltage_M2xAnalogInput1	Filtered actual value of the M2x voltage input 1			Y2	ja	-	True	True
685.8	C3.StatusVoltage_M2xAnalogInput2	Filtered actual value of the M2x voltage input 2			Y2	ja	-	True	True
685.9	C3.StatusVoltage_M2xAnalogInput3	Filtered actual value of the M2x voltage input 3			Y2	ja	-	True	True
685.10	C3.StatusVoltage_M2xAnalogInput4	Filtered actual value of the M2x voltage input 4			Y2	ja	-	True	True
685.11	C3.StatusVoltage_M2xAnalogInput5	Filtered actual value of the M2x voltage input 5			Y2	ja	-	True	True
688.1	C3.StatusCurrent_Reference	Status of setpoint current RMS (torque forming)			E2_6	nein	-	True	True
688.2	C3.StatusCurrent_Actual	Status of actual current RMS (torque producing)			E2_6	ja	-	True	True
688.8	StatusCurrent_ControlDeviationIq	Status control deviation current control RMS			C4_3	nein	-	True	True
688.9	StatusCurrent_PhaseU	Status of current phase U			C4_3	nein	-	True	True
688.10	StatusCurrent_PhaseV	Status of current phase V			C4_3	nein	-	True	True
688.11	StatusCurrent_ReferenceVoltageUq	Status of current control control signal			C4_3	nein	-	True	True
688.13	C3.StatusCurrent_ReferenceJerk	Status of demand jerk setpoint generator			I32	nein	-	True	True
688.14	StatusCurrent_FeedForwardCurrentJerk	Status of current & jerk feedforward			C4_3	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
688.17	C3Plus.StatusCurrent_FieldWeakeningFactor	Reciprocal of the field weakening factor FF			C4_3	nein	-	True	True
688.18	C3.StatusCurrent_ReferenceDINT	Demand current rms			I32	nein	-	True	True
688.19	C3.StatusCurrent_ActualDINT	Actual current rms	230		I32	ja	-	True	True
688.22	StatusCurrent_ReferenceVoltageVector	Provided voltage pointer			C4_3	nein	-	True	True
688.29	StatusCurrent_VoltageUq	Provided voltage of quadrature current controller			C4_3	nein	-	True	True
688.30	StatusCurrent_VoltageUd	Provided voltage of direct current controller			C4_3	nein	-	True	True
688.31	StatusCurrent_DecouplingVoltageUd	Signal decoupling of direct current controller			C4_3	nein	-	True	True
688.32	StatusCurrent_FeedForwardbackEMF	Signal EMC feed forward			C4_3	nein	-	True	True
688.33	C3.StatusCurrent_PositiveLimit	Positive current limit effective at present			I32	nein	-	True	True
688.34	C3.StatusCurrent_NegativeLimit	Negative current limit effective at present			I32	nein	-	True	True
688.35	C3.StatusCurrent_M2xAnalogInput0	Filtered actual value of the M2x current input 0			Y2	ja	-	True	True
688.36	C3.StatusCurrent_M2xAnalogInput1	Filtered actual value of the M2x current input 1			Y2	ja	-	True	True
688.37	C3.StatusCurrent_M2xAnalogInput2	Filtered actual value of the M2x current input 2			Y2	ja	-	True	True
688.38	C3.StatusCurrent_M2xAnalogInput3	Filtered actual value of the M2x current input 3			Y2	ja	-	True	True
688.39	C3.StatusCurrent_M2xAnalogInput4	Filtered actual value of the M2x current input 4			Y2	ja	-	True	True
688.40	C3.StatusCurrent_M2xAnalogInput5	Filtered actual value of the M2x current input 5			Y2	ja	-	True	True
690.5	StatusAutocommutation_Iterations	Current increase steps automatic commutation			U16	nein	-	True	True
692.1	StatusFeedback_FeedbackSineDSP	Status of sine in signal processing			I32	ja	-	True	True
692.2	StatusFeedback_FeedbackCosineDSP	Status of cosine in signal processing			I32	ja	-	True	True
692.3	StatusFeedback_EncoderSine	Status of analog input sine			I32	nein	-	True	True
692.4	StatusFeedback_EncoderCosine	Status of analog input cosine			I32	nein	-	True	True
692.5	StatusFeedback_FeedbackVoltage[Vpp]	Status of feedback level			C4_3	ja	-	True	True
692.9	StatusFeedback_ResolverLevel	Status resolver level			C4_3	nein	-	True	True
692.10	StatusFeedback_RefChannel	Status feedback index track			I16	nein	-	True	True
692.21	StatusFeedback_FeedbackSineDSPvolts	Status of sine in signal processing			C4_3	ja	-	True	True
692.22	StatusFeedback_FeedbackCosineDSPvolts	Status of cosine in signal processing			C4_3	ja	-	True	True
692.23	StatusFeedback_EncoderSineVolts	Status of analog input sine (Volt)			C4_3	nein	-	True	True
692.24	StatusFeedback_EncoderCosineVolts	Status of analog input cosine (Volt)			C4_3	nein	-	True	True
699.4	StatusJerk_DemandValue	Status of demand jerk setpoint generator			I32	nein	-	True	True
814.10	C3Plus.SafetyMonitor_OperatingState	Status S3			U16	nein	-	True	
814.11	C3Plus.SafetyMonitor_AlarmCode	Alarm no. S3			U16	nein	-	True	
814.12	C3Plus.SafetyMonitor_ErrorCode	Error no. S3			U16	nein	-	True	
814.13	C3Plus.SafetyMonitor_DiagnosticsBits0_15	DiagnoseBits0_15 S3			U16	nein	-	True	
814.14	C3Plus.SafetyMonitor_DiagnosticsBits16_31	DiagnoseBits16_31 S3			U16	nein	-	True	
814.15	C3Plus.SafetyMonitor_DiagnosticsBits32_47	DiagnoseBits32_47 S3			U16	nein	-	True	
814.16	C3Plus.SafetyMonitor_DiagnosticsBits48_55	DiagnoseBits48_55 S3			U16	nein	-	True	
814.20	SafetyMonitor_ProcessData	Total process data S3			OS	nein	-	True	
814.21	C3Plus.SafetyMonitor_ProcessData_U16_1	Process data U16_1 of S3 (first 2 Bytes)			U16	nein	-	True	
814.22	C3Plus.SafetyMonitor_ProcessData_U16_2	Process data U16_2 of S3 (Byte 3 and 4)			U16	nein	-	True	
814.23	C3Plus.SafetyMonitor_ProcessData_U16_3	Process data U16_3 of S3 (Byte 5 and 6)			U16	nein	-	True	
814.24	C3Plus.SafetyMonitor_ProcessData_U16_4	Process data U16_4 of S3 (Byte 7 and 8)			U16	nein	-	True	
814.25	C3Plus.SafetyMonitor_ProcessData_U32_1	Process data U32_1 of S3 (first 4 Bytes)			U32	nein	-	True	
814.26	C3Plus.SafetyMonitor_ProcessData_U32_2	Process data U32_2 of S3 (Byte 5 to 8)			U32	nein	-	True	
814.27	C3Plus.SafetyMonitor_ProcessData_U32_3	Process data U32_3 of S3 (Byte 3 to 6)			U32	nein	-	True	
820.3	C3Plus.CANopen_Node_ID	CANopen_Node_ID			U16	nein	-	False	True
820.8	C3Plus.CANopen_ComCyclePeriod	Sync bus cycle time CANSync, Powerlink, EtherCat		0x1006, 0x60C2	U32	nein	Immediat	False	True
820.9	C3Plus.CANopen_State	Status of the fieldbus state machine			U16	nein	-	False	True
820.23	C3Plus.CANopen_SyncPulseCounter	Captured sync pulses			I32	nein	Immediat	False	True
820.24	CANopen_SyncMode	Configuration of the bus synchronization process		0x205E	I16	nein	Immediat	False	True
820.27	CANopen_SyncErrorCounter	Error counter for CANSync, Powerlink, EtherCat			I32	nein	Immediat	False	True
820.28	C3Plus.CANopen_SyncPeriod	Current period duration of the sync signal			C4_3	nein	-	False	True
830.1	Profibus_Protocol	PPO-type selection switch			U16	nein	Immediat	False	True
830.2	Profibus_Baudrate	Baud rate			U32	nein	-	False	True
830.3	Profibus_NodeAddress	Node address	918		U16	nein	-	False	True
830.4	Profibus_TelegramSelect	Telegram selection switch	922		U16	nein	Immediat	False	True
830.6	Profibus_StandardSignalTable	List of Profidrive standard signals	923.x		U16	nein	-	False	True
950.1	FBI_RxPD_Mapping_Object_1	1. Object of the setpoint PZD (Profibus)	915.0		U16	nein	Immediat	False	True
950.2	FBI_RxPD_Mapping_Object_2	2. object of the Setpoint value PZD	915.1		U16	nein	Immediat	False	True
950.3	FBI_RxPD_Mapping_Object_3	3. object of the Setpoint value PZD	915.2		U16	nein	Immediat	False	True
950.4	FBI_RxPD_Mapping_Object_4	4. object of the Setpoint value PZD	915.3		U16	nein	Immediat	False	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
950.5	FBI_RxPD_Mapping_Object_5	5. object of the Setpoint value PZD	915.4		U16	nein	Immediat ely	False	True
950.6	FBI_RxPD_Mapping_Object_6	6. object of the Setpoint value PZD	915.5		U16	nein	Immediat ely	False	True
950.7	FBI_RxPD_Mapping_Object_7	7. object of the Setpoint value PZD	915.6		U16	nein	Immediat ely	False	True
950.8	FBI_RxPD_Mapping_Object_8	8. object of the Setpoint value PZD	915.7		U16	nein	Immediat ely	False	True
951.1	FBI_TxPD_Mapping_Object_1	1. object of actual value PZD	916.0		U16	nein	Immediat ely	False	True
951.2	FBI_TxPD_Mapping_Object_2	2. object of actual value PZD	916.1		U16	nein	Immediat ely	False	True
951.3	FBI_TxPD_Mapping_Object_3	3. object of actual value PZD	916.2		U16	nein	Immediat ely	False	True
951.4	FBI_TxPD_Mapping_Object_4	4. object of actual value PZD	916.3		U16	nein	Immediat ely	False	True
951.5	FBI_TxPD_Mapping_Object_5	5. object of actual value PZD	916.4		U16	nein	Immediat ely	False	True
951.6	FBI_TxPD_Mapping_Object_6	6. object of actual value PZD	916.5		U16	nein	Immediat ely	False	True
951.7	FBI_TxPD_Mapping_Object_7	7. object of actual value PZD	916.6		U16	nein	Immediat ely	False	True
951.8	FBI_TxPD_Mapping_Object_8	8. object of actual value PZD	916.7		U16	nein	Immediat ely	False	True
990.1	Delay_MasterDelay	Setpoint delay for bus master			I16	nein	Immediat ely	True	True
1000.3	C3Plus.DeviceState_Statusword_1	status word ZSW	2	0x6041	V2	ja	Immediat ely	False	True
1000.4	C3Plus.DeviceState_Statusword_2	Status word 2	4	0x201C	V2	ja	Immediat ely	False	True
1000.5	C3Plus.DeviceState_ActualOperationMode	operating mode display	128	0x6061	I16	ja	Immediat ely	False	True
1100.1	C3Plus.DeviceControl_CommandOnRequest	Control command	108	0x2028	I16	ja	Immediat ely	True	True
1100.3	C3Plus.DeviceControl_Controlword_1	STW control word	1	0x6040	V2	ja	Immediat ely	False	True
1100.4	C3Plus.DeviceControl_Controlword_2	Control word 2	3	0x201B	V2	ja	Immediat ely	False	True
1100.5	C3Plus.DeviceControl_OperationMode	Operating mode (Nominal value)	127/930	0x6060	I16	ja	Immediat ely	False	True
1100.24	C3Plus.DeviceControl_TorqueOffset	Offset Demand torque or force DS402 opmode 10		0x60B2	I16	ja	Immediat ely	True	True
1111.1	C3Plus.POSITION_position	Target position	27 (Profibus only)		C4_3	ja	Immediat ely	True	True
1111.2	C3Plus.POSITION_speed	Speed for positioning	111		C4_3	ja	Immediat ely	True	True
1111.3	C3Plus.POSITION_accel	Acceleration for positioning	114	0x6083	U32	ja	Immediat ely	True	True
1111.4	C3Plus.POSITION_decel	Deceleration for positioning	178/312	0x6084	U32	ja	Immediat ely	True	True
1111.5	C3Plus.POSITION_jerk_accel	Acceleration jerk for positioning	313	0x2005	U32	nein	Immediat ely	True	True
1111.6	C3Plus.POSITION_jerk_decel	Deceleration jerk for positioning	314	0x2006	U32	nein	Immediat ely	True	True
1111.8	C3Plus.POSITION_resetpositon_mode	Continuous mode	0	0	U16	nein	Immediat ely	True	True
1111.9	POSITION_speed_Y2	Speed for Positioning in Y2 Format	110		Y2	ja	Immediat ely	False	True
1111.11	POSITION_position_Y4		118		Y4	ja	Immediat ely	False	True
1111.13	C3Plus.POSITION_direction	Manipulation of the motion direction in reset mode			I32	nein	Immediat ely	True	True
1111.17	C3Plus.POSITION_turnaround	Direction inversion - lock			U16	nein	Immediat ely	True	True
1127.3	C3Plus.SPEED_speed	Setpoint speed in speed control operating mode	7		C4_3	ja	Immediat ely	True	True
1130.1	C3Plus.HOMING_accel	Acceleration / deceleration homing run	300	0x609A	U32	nein	Immediat ely	True	True
1130.2	C3Plus.HOMING_jerk	jerk for machine reference run	357	0x201E	U32	nein	Immediat ely	True	True
1130.3	C3Plus.HOMING_speed	speed for machine reference run	301	0x6099.1	C4_3	nein	Immediat ely	True	True
1130.4	C3Plus.HOMING_mode	adjusting the machine reference mode	302	0x6098	U16	nein	Immediat ely	True	True
1130.7	C3Plus.HOMING_edge_sensor_distance	Initiator adjustment	304	0x2000	C4_3	nein	Immediat ely	True	True
1130.13	HOMING_edge_position	Distance MN (zero) initiator - motor zero			C4_3	nein	Immediat ely	True	True
1141.4	C3Plus.GEAR_mode	Source selection Gearing		0x2055	U16	nein	Immediat ely	True	True
1141.7	GEAR_actual_masterposition	Position input value for Gearing		0x2058	C4_3	nein	-	True	True
1141.8	GEAR_actual_master_speed	Master speed for Gearing			C4_3	nein	-	True	True
1141.10	GEAR_FFW_mode	Control bits for feedforward with source CANSync/EthernetPowerLink/EtherC at		0x2097	U16	nein	Immediat ely	False	True
1211.13	C3Plus.PG2POSITION_direction	Manipulation of the motion direction in reset mode			I32	nein	Immediat ely	True	True
1900.1	C3Array.Pointer_Row	pointer to table row	180	0x2300	U16	ja	Immediat ely	True	True
1901.1	C3Array.Col01_Row01	variable Column 1 Row 1	130/341.1	0x2301.1	Y4	ja	Immediat ely	True	True
1901.2	C3Array.Col01_Row02	Variable Column 1 Row 2	131/341.2	0x2301.2	Y4	ja	Immediat ely	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
1901.3	C3Array.Col01_Row03	Variable Column 1 Row 3	132/341.3	0x2301.3	Y4	ja	Immediat ely	True	True
1901.4	C3Array.Col01_Row04	Variable Column 1 Row 4	133/341.4	0x2301.4	Y4	ja	Immediat ely	True	True
1901.5	C3Array.Col01_Row05	Variable Column 1 Row 5	134/341.5	0x2301.5	Y4	ja	Immediat ely	True	True
1902.1	C3Array.Col02_Row01	variable Column 2 Row 1	135/342.1	0x2302.1	Y2	ja	Immediat ely	True	True
1902.2	C3Array.Col02_Row02	variable Column 2 Row 2	136/342.2	0x2302.2	Y2	ja	Immediat ely	True	True
1902.3	C3Array.Col02_Row03	variable Column 2 Row 3	137/342.3	0x2302.3	Y2	ja	Immediat ely	True	True
1902.4	C3Array.Col02_Row04	Variable Column 2 Row 4	138/342.4	0x2302.4	Y2	ja	Immediat ely	True	True
1902.5	C3Array.Col02_Row05	Variable Column 2 Row 5	139/342.5	0x2302.5	Y2	ja	Immediat ely	True	True
1903.1	C3Array.Col03_Row01	variable Column 3 Row 1	140/343.1	0x2303.1	I16	ja	Immediat ely	True	True
1903.2	C3Array.Col03_Row02	Variable Column 3 Row 2	141/343.2	0x2303.2	I16	ja	Immediat ely	True	True
1903.3	C3Array.Col03_Row03	Variable Column 3 Row 3	142/343.3	0x2303.3	I16	ja	Immediat ely	True	True
1903.4	C3Array.Col03_Row04	Variable Column 3 Row 4	143/343.4	0x2303.4	I16	ja	Immediat ely	True	True
1903.5	C3Array.Col03_Row05	Variable Column 3 Row 5	144/343.5	0x2303.5	I16	ja	Immediat ely	True	True
1904.1	C3Array.Col04_Row01	variable Column 4 Row 1	145/344.1	0x2304.1	I16	ja	Immediat ely	True	True
1904.2	C3Array.Col04_Row02	Variable Column 4 Row 2	146/344.2	0x2304.2	I16	ja	Immediat ely	True	True
1904.3	C3Array.Col04_Row03	Variable Column 4Row 3	147/344.3	0x2304.3	I16	ja	Immediat ely	True	True
1904.4	C3Array.Col04_Row04	Variable Column 4 Row 4	148/344.4	0x2304.4	I16	ja	Immediat ely	True	True
1904.5	C3Array.Col04_Row05	Variable Column 4 Row 5	149/344.5	0x2304.5	I16	ja	Immediat ely	True	True
1905.1	C3Array.Col05_Row01	variable Column 5 Row 1	150/345.1	0x2305.1	I16	ja	Immediat ely	True	True
1905.2	C3Array.Col05_Row02	Variable Column 5 Row 2	151/345.2	0x2305.2	I16	ja	Immediat ely	True	True
1905.3	C3Array.Col05_Row03	Variable Column 5 Row 3	152/345.3	0x2305.3	I16	ja	Immediat ely	True	True
1905.4	C3Array.Col05_Row04	Variable Column 5 Row 4	153/345.4	0x2305.4	I16	ja	Immediat ely	True	True
1905.5	C3Array.Col05_Row05	Variable Column 5Row 5	154/345.5	0x2305.5	I16	ja	Immediat ely	True	True
1906.1	C3Array.Col06_Row01	variable Column 6 Row 1	155/346.1	0x2306.1	I32	ja	Immediat ely	True	True
1906.2	C3Array.Col06_Row02	Variable Column 6 Row 2	156/346.2	0x2306.2	I32	ja	Immediat ely	True	True
1906.3	C3Array.Col06_Row03	Variable Column 6 Row 3	157/346.3	0x2306.3	I32	ja	Immediat ely	True	True
1906.4	C3Array.Col06_Row04	Variable Column 6 Row 4	158/346.4	0x2306.4	I32	ja	Immediat ely	True	True
1906.5	C3Array.Col06_Row05	Variable Column 6 Row 5	159/346.5	0x2306.5	I32	ja	Immediat ely	True	True
1907.1	C3Array.Col07_Row01	variable Column 7 Row 1	160/347.1	0x2307.1	I32	ja	Immediat ely	True	True
1907.2	C3Array.Col07_Row02	Variable Column 7 Row 2	161/347.2	0x2307.2	I32	ja	Immediat ely	True	True
1907.3	C3Array.Col07_Row03	Variable Column 7 Row 3	162/347.3	0x2307.3	I32	ja	Immediat ely	True	True
1907.4	C3Array.Col07_Row04	Variable Column 7 Row 4	163/347.4	0x2307.4	I32	ja	Immediat ely	True	True
1907.5	C3Array.Col07_Row05	Variable Column 7 Row 5	164/347.5	0x2307.5	I32	ja	Immediat ely	True	True
1908.1	C3Array.Col08_Row01	variable Column 8 Row 1	165/348.1	0x2308.1	I32	ja	Immediat ely	True	True
1908.2	C3Array.Col08_Row02	Variable Column 8 Row 2	166/348.2	0x2308.2	I32	ja	Immediat ely	True	True
1908.3	C3Array.Col08_Row03	Variable Column 8 Row 3	167/348.3	0x2308.3	I32	ja	Immediat ely	True	True
1908.4	C3Array.Col08_Row04	Variable Column 8 Row 4	168/348.4	0x2308.4	I32	ja	Immediat ely	True	True
1908.5	C3Array.Col08_Row05	Variable Column 8 Row 5	169/348.5	0x2308.5	I32	ja	Immediat ely	True	True
1909.1	C3Array.Col09_Row01	variable Column 9 Row 1	170/349.1	0x2309.1	I32	ja	Immediat ely	True	True
1909.2	C3Array.Col09_Row02	Variable Column 9 Row 2	171/349.2	0x2309.2	I32	ja	Immediat ely	True	True
1909.3	C3Array.Col09_Row03	Variable Column 9 Row 3	172/349.3	0x2309.3	I32	ja	Immediat ely	True	True
1909.4	C3Array.Col09_Row04	Variable Column 9 Row 4	173/349.4	0x2309.4	I32	ja	Immediat ely	True	True
1909.5	C3Array.Col09_Row05	Variable Column 9 Row 5	174/349.5	0x2309.5	I32	ja	Immediat ely	True	True
1910.1	C3Array.Indirect_Col01	indirect table access Column 1	181	0x2311	Y4	ja	Immediat ely	True	True
1910.2	C3Array.Indirect_Col02	Indirect table access Column 2	182	0x2312	Y2	ja	Immediat ely	True	True
1910.3	C3Array.Indirect_Col03	Indirect table access Column 3	183	0x2313	I16	ja	Immediat ely	True	True
1910.4	C3Array.Indirect_Col04	Indirect table access Column 4	184	0x2314	I16	ja	Immediat ely	True	True
1910.5	C3Array.Indirect_Col05	Indirect table access Column 5	185	0x2315	I16	ja	Immediat ely	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
1910.6	C3Array.Indirect_Col06	Indirect table access Column 6	186	0x2316	I32	ja	Immediately	True	True
1910.7	C3Array.Indirect_Col07	Indirect table access Column 7	187	0x2317	I32	ja	Immediately	True	True
1910.8	C3Array.Indirect_Col08	Indirect table access Column 8	188	0x2318	I32	ja	Immediately	True	True
1910.9	C3Array.Indirect_Col09	Indirect table access Column 9	189	0x2319	I32	ja	Immediately	True	True
2000.1	C3Plus.ProfilGenerators_SG1Position	Position value of the setpoint encoder		0x2060	C4_3	ja	-	True	True
2000.4	ProfilGenerators_SG1Speed	Speed of the setpoint encoder		0x2063	I32	ja	-	True	True
2010.1	C3.FeedForward_Speed	Velocity Feed Forward	400.1	0x2101.1	U16	nein	VP	True	True
2010.2	C3.FeedForward_Accel	Acceleration feedforward	400.2	0x2101.2	U16	nein	VP	True	True
2010.4	C3.FeedForward_Current	Current feed-forward	400.4	0x2101.4	U16	nein	VP	True	True
2010.5	C3.FeedForward_Jerk	Jerk feed-forward	400.5	0x2101.5	U16	nein	VP	True	True
2010.19	C3Plus.FeedForward_UserCurrent	Additive Current			I32	ja	Immediately	True	True
2010.20	FeedForward_EMF	EMC feed forward			U16	ja	VP	True	True
2010.21	FeedForward_Valve	Valve feedforward			U16	nein	VP	True	True
2010.23	C3.FeedForward_Speed_FFW	Speed feedforward (A1)			C4_3	nein	VP	True	True
2010.24	C3.FeedForward_Accel_FFW	Acceleration feedforward (A1)			C4_3	nein	VP	True	True
2010.25	C3Plus.FeedForward_GainUserCurrent	Gain factor for additive user current			C4_3	nein	Immediately	True	True
2011.1	C3.FeedForwardExternal_FilterSpeed	External Speed Feed Forward Filter Time Constant	401.1	0x2102.1	U16	nein	VP	True	True
2011.2	C3.FeedForwardExternal_FilterAccel	External Acceleration Feed Forward Filter Time Constant	401.2	0x2102.2	U16	nein	VP	True	True
2011.4	C3.FeedForwardExternal_FilterSpeed_us	Filter time constant ext. speed			U16	nein	VP	True	True
2011.5	C3.FeedForwardExternal_FilterAccel_us	Filter time constant ext. Acceleration			U16	nein	VP	True	True
2020.1	C3.ExternalSignal_Position	Position from external signal source		0x2095.1	C4_3	ja	-	True	True
2020.2	C3.ExternalSignal_Speed	speed from external signal source			C4_3	ja	-	True	True
2020.6	C3Plus.ExternalSignal_Speed_Munits	Speed value of the external signal source			C4_3	ja	-	True	True
2020.7	C3Plus.ExternalSignal_Accel_Munits	Acceleration of the external signal source			I32	ja	-	True	True
2050.8	FeedForward_2_Valve	Valve feedforward auxiliary axis			U16	nein	VP	True	True
2050.9	C3.FeedForward_2_Speed_FFW	Speed feedforward (A2)			C4_3	nein	VP	True	True
2050.10	C3.FeedForward_2_Accel_FFW	Acceleration feedforward (A2)			C4_3	nein	VP	True	True
2100.2	C3.ControllerTuning_Stiffness	Stiffness (speed controller)	402.2	0x2100.2/ 0x2100.1	U16	nein	VP	True	True
2100.3	C3.ControllerTuning_Damping	damping (rotation speed controller)	402.3	0x2100.3	U16	nein	VP	True	True
2100.4	C3.ControllerTuning_Inertia	Inertia	402.4	0x2100.4	U16	nein	VP	True	True
2100.5	C3.ControllerTuning_FilterSpeed	Filter-actual velocity	402.5	0x2100.5	U16	nein	VP	True	True
2100.6	C3.ControllerTuning_FilterAccel	Filter - Actual acceleration	402.6	0x2100.6	U16	nein	VP	True	True
2100.7	C3.ControllerTuning_SpeedDFactor	D-component of speed controller	402.7	0x2100.7	U16	nein	VP	True	True
2100.8	C3.ControllerTuning_CurrentBandwidth	Current regulator bandwidth	402.8	0x2100.8	U16	nein	VP	True	True
2100.9	C3.ControllerTuning_CurrentDamping	Current loop - Damping	402.9	0x2100.9	U16	nein	VP	True	True
2100.10	C3.ControllerTuning_FilterSpeed2	Filter actual velocity 2			U16	nein	VP	True	True
2100.11	C3.ControllerTuning_FilterAccel2	Filter actual acceleration 2			U16	nein	VP	True	True
2100.20	C3.ControllerTuning_FilterSpeed_us	Control signal filter of velocity control			U16	nein	VP	True	True
2100.21	C3.ControllerTuning_FilterAccel_us	Filter - Actual acceleration			U16	nein	VP	True	True
2107.1	C3Plus.TrackingfilterPhysicalSource_TRFSpeed	Time constant tracking filter physical source			U16	nein	VP	True	True
2109.1	C3Plus.TrackingfilterHEDA_TRFSpeed	Time constant tracking filter HEDA-process position			I16	nein	VP	True	True
2110.1	C3Plus.TrackingfilterSG1_TRFSpeed	Time constant tracking filter setpoint encoder		0x2096	I16	nein	VP	True	True
2110.3	C3Plus.TrackingfilterSG1_FilterSpeed	Filter effect of speed filter setpoint encoder			U16	nein	VP	True	True
2110.4	C3Plus.TrackingfilterSG1_AccelFilter	Filter effect of acceleration filter setpoint encoder			U16	nein	VP	True	True
2110.6	C3Plus.TrackingfilterSG1_FilterSpeed_us	Filter time constant velocity setpoint generator			U16	nein	VP	True	True
2110.7	C3Plus.TrackingfilterSG1_AccelFilter_us	Filter time constant acceleration setpoint generator			U16	nein	VP	True	True
2120.1	SpeedObserver_TimeConstant	Rapidity of the speed monitor			U32	nein	VP	True	True
2120.5	SpeedObserver_DisturbanceFilter	Time constant disturbance filter			U32	nein	VP	True	True
2120.7	SpeedObserver_DisturbanceAdditionEnable	Switch to enable disturbance compensation			I16	nein	VP	True	True
2150.1	C3Plus.NotchFilter_FrequencyFilter1	Center frequency of notch filter 1			I16	nein	VP	True	True
2150.2	C3Plus.NotchFilter_BandwidthFilter1	Bandwidth of notch filter 1			I16	nein	VP	True	True
2150.3	C3Plus.NotchFilter_DepthFilter1	Depth of notch filter 1			I32	nein	VP	True	True
2150.4	C3Plus.NotchFilter_FrequencyFilter2	Center frequency of notch filter 2			I16	nein	VP	True	True
2150.5	C3Plus.NotchFilter_BandwidthFilter2	Bandwidth of notch filter 2			I16	nein	VP	True	True
2150.6	C3Plus.NotchFilter_DepthFilter2	Depth of notch filter 2			I32	nein	VP	True	True
2190.1	AutoCommutationControl_Ramptime	Ramp slope current slope AK			U16	nein	VP	True	True
2190.2	AutoCommutationControl_InitialCurrent	Start current of automatic commutation			U16	nein	VP	True	True
2190.3	AutoCommutationControl_PositionThreshold	Motion limit for automatic commutation			U16	nein	VP	True	True
2190.4	AutoCommutationControl_MotionReduction	Motion reduction Automatic commutation			U16	nein	VP	True	True
2190.7	AutoCommutationControl_StandstillThreshold	Optimization of the standstill threshold			U16	nein	VP	True	True
2190.8	AutoCommutationControl_PeakCurrent	Reduction of the peak current			U16	nein	VP	True	True
2190.10	AutoCommutationControl_Reset	Reset automatic commutation			U16	nein	Immediately	True	True
2200.1	C3Plus.PositionController_DemandValue	Position setpoint value (sequentially)			C4_3	ja	-	True	True
2200.2	C3Plus.PositionController_ActualValue	Position actual value (sequentially)			C4_3	ja	-	True	True
2200.3	PositionController_ProportionalPart	Optimization parameters for the position controller P component (KV factor)			U16	nein	VP	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
2200.11	C3Plus.PositionController_TrackingErrorFilter	Following error filter of the position controller			U16	nein	VP	True	True
2200.20	C3Plus.PositionController_DeadBand	Deadband of position controller			C4_3	nein	VP	True	True
2200.21	PositionController_FrictionCompensation	Friction compensation			I32	nein	VP	True	True
2200.24	PositionController_TrackingErrorFilter_us	Time constant following error filter of position controller			U16	nein	VP	True	True
2200.25	PositionController_IntegralPart	I term of position controller			U16	nein	VP	True	True
2201.1	C3Plus.LoadControl_Enable	Activate load control		0x205F	I16	nein	Immediately	True	True
2201.2	C3Plus.LoadControl_Command	Load control command mode			I16	nein	Immediately	True	True
2201.3	LoadControl_Status	Load control status bits			I16	nein	-	True	True
2201.11	C3Plus.LoadControl_FilterLaggingPart	Time constant of position difference filter			U32	nein	VP	True	True
2201.12	C3Plus.LoadControl_VelocityFilter	Time constant of the load-speed filter			I16	nein	VP	True	True
2201.13	C3Plus.LoadControl_VelocityLimit	Load control intervention speed limitation			I16	nein	VP	True	True
2210.1	SpeedController_DemandValue	Velocity setpoint value			I32	ja	-	True	True
2210.2	SpeedController_ActualValue	Actual (rotational) speed			I32	ja	-	True	True
2210.4	SpeedController_P_Part_Gain	P term quantifier			U16	nein	VP	True	True
2210.5	SpeedController_I_Part_Gain	Weighting "I" term			U16	nein	VP	True	True
2210.14	SpeedController_DemandValueAdditive	Manual or external velocity specification			I32	ja	Immediately	True	True
2210.17	SpeedController_ActualBandwidth	Replacement time constant for the velocity control			I32	nein	-	True	True
2210.19	C3Plus.SpeedController_ScalingDemandValueAdditive	Scaling for manual or external velocity specification			C4_3	nein	Immediately	True	True
2215.5	C3Plus.PressureForceController_ProportionalPart_Kp	P-term of force/pressure control	420		C4_3	nein	VP	True	True
2215.6	C3Plus.PressureForceController_IntegrationPart_KI	I-term of force/pressure control	421		C4_3	nein	VP	True	True
2215.7	C3Plus.PressureForceController_InsideWindowIPart	Internal window I-term of force/pressure control	422		C4_3	nein	VP	True	True
2215.8	C3Plus.PressureForceController_OutsideWindowIPart	External window I-term of force/pressure control	423		C4_3	nein	VP	True	True
2215.9	C3Plus.PressureForceController_SpeedFeedback_Kvp_or_DampingFactor	Speed feedback of force/pressure control, damping term of force control	424		C4_3	nein	VP	True	True
2215.10	C3Plus.PressureForceController_PressureForce_Disturbance_KFFWp	Force/pressure injection			C4_3	nein	VP	True	True
2215.13	C3Plus.PressureForceController_SpeedFeedbackLimit	Signal limitation of speed feedback	425		U16	nein	VP	True	True
2220.1	Q_CurrentController_Q_DemandValue	Quadrature Current CommandValue			I16	ja	-	True	True
2220.2	Q_CurrentController_Q_DemandValueAdditive	Manual or external cross current specification			I16	ja	Immediately	True	True
2220.3	C3Plus.Q_CurrentController_Scaling_Q_DemandValueAdditive	Scaling for manual or external current specification			I16	nein	Immediately	True	True
2220.4	Q_CurrentController_Q_ActualValue	Cross-flow actual value			I16	ja	-	True	True
2220.5	Q_CurrentController_CurrentControlProportionalPart	Current Loop - "P" Term			I16	nein	VP	True	True
2220.6	Q_CurrentController_CurrentControlIntegralPart	Current Loop I term			I16	nein	VP	True	True
2220.20	Q_CurrentController_Inductance	Parameter motor inductance			I16	nein	VP	True	True
2220.21	Q_CurrentController_Resistance	Parameter motor resistance			I16	nein	VP	True	True
2220.22	Q_CurrentController_BackEMF	Parameter motor force constant			I16	nein	VP	True	True
2220.27	Q_CurrentController_StructureSelection	Structure switch of current control			I16	nein	VP	True	True
2230.20	D_CurrentController_Ld_Lq_Ratio	Ratio direct to quadrature inductance			U16	nein	VP	True	True
2230.24	D_CurrentController_VoltageDecouplingEnable	Activation of the voltage decoupling			I16	nein	VP	True	True
2240.2	Magnetisierungsstromregler_I_mrn_DemandValueTuning	Magnetization current quantifier (ASM)			I16	nein	VP	True	True
2240.4	Magnetisierungsstromregler_Damping	Magnetization current controller attenuation(ASM)			I16	nein	VP	True	True
2240.7	Magnetisierungsstromregler_Bandwidth	Magnetization current controller bandwidth (ASM)			I16	nein	VP	True	True
2240.9	Magnetisierungsstromregler_SlipFrequency	Slip frequency quantifier (ASM)			I16	nein	VP	True	True
2240.10	Magnetisierungsstromregler_RotorTimeConstant	Motor Time Constant quantifier			I16	nein	VP	True	True
2240.11	Magnetisierungsstromregler_Fieldweakening speed	Reference speed quantifier (ASM)			I16	nein	VP	True	True
3310.1	C3.Multiturnemulation_Status	Status of Multiturn emulation			I16	nein	-	True	True
3920.1	C3Plus.HEDA_SignalProcessing_Input	Process input signal Slave			C4_3	ja	Immediately	True	True
3920.7	C3Plus.HEDA_SignalProcessing_OutputGreat	Output of the Heda Tracking Filter			C4_3	nein	-	True	True
3921.1	FBI_SignalProcessing0_Input_Y4	Interpolation input CanSync, PowerLink		0x2050/0x60C1.1	I32	ja	Immediately	False	True
3921.2	C3Plus.FBI_SignalProcessing0_ResetDistance	Upper modulo limit CANSYNC, Powerlink, EtherCAT in Mrev		0x2051	I32	nein	Immediately	False	True
3921.3	FBI_SignalProcessing0_ResetDistanceLow	Lower modulo limit CanSync, PowerLink, EtherCat in Mrev		0x2103.1	I32	nein	Immediately	False	True
3921.5	FBI_SignalProcessing0_OutputFBIncr	Interpolation output position CanSync, PowerLink, EtherCat in Fbincr.			I32	nein	-	False	True
3921.7	C3Plus.FBI_SignalProcessing0_OutputGreat	Interpolation output position CanSync, PowerLink, EtherCat in Mrev - free running.			Y4	nein	-	False	True
3921.8	C3Plus.FBI_SignalProcessing0_Source	Switching the position source of the interpolator			I16	nein	Immediately	False	True
3921.9	C3Plus.FBI_SignalProcessing0_ResetDistance_Incr	Modulo limit CanSync, PowerLink, EtherCat in Fbincr		0x2103.1	I32	nein	Immediately	False	True
3921.10	FBI_SignalProcessing0_ResetDistanceLow_Incr	Lower modulo limit CanSync, PowerLink, EtherCat in Fbincr		0x2103.2	I32	nein	Immediately	False	True
3921.11	C3Plus.FBI_SignalProcessing0_IncrModuloEnable	Selection switch Modulo limit CanSync, PowerLink, EtherCat		0x2103.3	I32	nein	Immediately	False	True
3925.1	C3Plus.FBI_Interpolation_SubModeSelect	Interpolation method		0x60C0	I16	nein	Immediately	False	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
							ely		
3925.20	FBI_Interpolation_VelocityInput	Velocity specification GEARING CanSync/EthernetPowerLink/EtherC at		0x2098	I32	ja	Immediat ely	False	True
3925.21	FBI_Interpolation_AccelInput	Acceleration specification GEARING CanSync/EthernetPowerLink/EtherC at		0x2099	I32	ja	Immediat ely	False	True
3925.22	FBI_Interpolation_VelocityStatus	Speed output value for CanSync/EthernetPowerLink/EtherC at			C4_3	nein	-	False	True
3925.23	FBI_Interpolation_AccelStatus	Acceleration output value for CanSync/EthernetPowerLink/EtherC at			I32	nein	-	False	True
3925.24	FBI_Interpolation_PositionStatus	Interpolation position input value for CanSync/EthernetPowerLink/EtherC at			I32	nein	-	False	True

7.2 T30 Objects for the Process-Data-Channel / the Messages

No.	Object name	Object	PNU	PZD	CAN-No	PD	Bus format	Word length
121.2	input word of I/O option	C3.DigitalInputAddition_Value	175	PED	0x6100.2	TPDO	V2	1
133.3	output word for I/O option	C3.DigitalOutputAddition_Value	176	PED/PAD	0x6300.2	R/TPDO	V2	1
140.3	Command value of the digital outputs	C3.DigitalOutputWord_DemandState	22	PED/PAD	0x6300.1	R/TPDO	V2	1
2020.1	Position from external signal source	C3.ExternalSignal_Position		PED	0x2095.1	TPDO	C4_3	2
3925.20	Velocity specification GEARING CanSync/EthernetPowerLink/EtherCat	C3.FBI_Interpolation_VelocityInput		PED/PAD	0x2098	R/TPDO	I32	2
120.3	Status of digital inputs	C3.DigitalInput_DebouncedValue	21	PED	0x6100.1	TPDO	V2	1
3925.21	Acceleration specification GEARING CanSync/EthernetPowerLink/EtherCat	C3.FBI_Interpolation_AccelInput		PED/PAD	0x2099	R/TPDO	I32	2
3921.1	Interpolation input CanSync, PowerLink	C3.FBI_SignalProcessing0_Input_Y4		PED/PAD	0x2050/0x60C1.1	R/TPDO	I32	2
688.19	Actual current rms	C3.StatusCurrent_ActualDINT	230	PED		TPDO	I32	2
683.1	Status of actual current value	C3.StatusDevice_ActualCurrent	112	PED	0x6077 (not EtherCAT with mapping via master)	TPDO	E2_6	1
683.13	Actual torque or force DS402 opmode 10	C3.StatusDevice_ActualTorqueDS402		PED	0x6077 (only EtherCAT with mapping via master)	TPDO	I16	1
681.26	Status of actual speed filtered in 1/min or m/s	C3.StatusSpeed_ActualUnitrpmORmps	226	PED	0x2105	TPDO	C4_3	2
680.5	Status actual position	C3.StatusPosition_Actual	28	PED	0x2104	TPDO	C4_3	2
680.4	Status demand position	C3.StatusPosition_DemandValue	323	PED	0x60FC	TPDO	C4_3	2
680.1	Position command value of Profile transmitter1	C3.StatusPosition_DemandValue1	0	PED	0x2052	TPDO	Y4	2
680.10	Status of encoder input 0 (5V)	C3.StatusPosition_EncoderInput5V		PED	0x2095.2	TPDO	C4_3	2
680.6	Status of tracking error	C3.StatusPosition_FollowingError	100	PED	0x60F4	TPDO	C4_3	2
681.5	Status actual speed unfiltered	C3.StatusSpeed_Actual		PED	0x6069	TPDO	C4_3	2
681.9	Status actual speed filtered	C3.StatusSpeed_ActualFiltered	8	PED	0x606C	TPDO	C4_3	2
681.7	Status of the actual filtered speed speed in the Y2 format	C3.StatusSpeed_ActualFilteredY2	6	PED	0x2023	TPDO	Y2	1
681.8	Status of the actual filtered speed in the Y4 format	C3.StatusSpeed_ActualFilteredY4	117	PED	0x2024	TPDO	Y4	2
681.4	Status demand speed of setpoint generator	C3.StatusSpeed_DemandValue	324	PED	0x606B	TPDO	C4_3	2
681.1	Speed setpoint value of profile generator 1	C3.StatusSpeed_DemandValue1		PED	0x2053	TPDO	Y4	2
681.6	Status control deviation of speed	C3.StatusSpeed_Error	101	PED	0x2027	TPDO	C4_3	2
685.3	Status of analog input 0	C3.StatusVoltage_AnalogInput0	23	PED	0x2025	TPDO	Y2	1
685.4	Status of analog input 1	C3.StatusVoltage_AnalogInput1	102	PED	0x2026	TPDO	Y2	1
685.5	Status DC bus voltage C4_3	C3.StatusVoltage_BusVoltageC43		PED	0x6079	TPDO	C4_3	2
1901.1	variable Column 1 Row 1	C3Array.Col01_Row01	130/341.1	PED/PAD	0x2301.1	R/TPDO	Y4	2
1901.2	Variable Column 1 Row 2	C3Array.Col01_Row02	131/341.2	PED/PAD	0x2301.2	R/TPDO	Y4	2
1901.3	Variable Column 1 Row 3	C3Array.Col01_Row03	132/341.3	PED/PAD	0x2301.3	R/TPDO	Y4	2
1901.4	Variable Column 1 Row 4	C3Array.Col01_Row04	133/341.4	PED/PAD	0x2301.4	R/TPDO	Y4	2
1901.5	Variable Column 1 Row 5	C3Array.Col01_Row05	134/341.5	PED/PAD	0x2301.5	R/TPDO	Y4	2
1902.1	variable Column 2 Row 1	C3Array.Col02_Row01	135/342.1	PED/PAD	0x2302.1	R/TPDO	Y2	1
1902.2	variable Column 2 Row 2	C3Array.Col02_Row02	136/342.2	PED/PAD	0x2302.2	R/TPDO	Y2	1
1902.3	variable Column 2 Row 3	C3Array.Col02_Row03	137/342.3	PED/PAD	0x2302.3	R/TPDO	Y2	1
1902.4	Variable Column 2 Row 4	C3Array.Col02_Row04	138/342.4	PED/PAD	0x2302.4	R/TPDO	Y2	1
1902.5	Variable Column 2 Row 5	C3Array.Col02_Row05	139/342.5	PED/PAD	0x2302.5	R/TPDO	Y2	1
1903.1	variable Column 3 Row 1	C3Array.Col03_Row01	140/343.1	PED/PAD	0x2303.1	R/TPDO	I16	1
1903.2	Variable Column 3 Row 2	C3Array.Col03_Row02	141/343.2	PED/PAD	0x2303.2	R/TPDO	I16	1
1903.3	Variable Column 3 Row 3	C3Array.Col03_Row03	142/343.3	PED/PAD	0x2303.3	R/TPDO	I16	1
1903.4	Variable Column 3 Row 4	C3Array.Col03_Row04	143/343.4	PED/PAD	0x2303.4	R/TPDO	I16	1
1903.5	Variable Column 3 Row 5	C3Array.Col03_Row05	144/343.5	PED/PAD	0x2303.5	R/TPDO	I16	1
1904.1	variable Column 4 Row 1	C3Array.Col04_Row01	145/344.1	PED/PAD	0x2304.1	R/TPDO	I16	1
1904.2	Variable Column 4 Row 2	C3Array.Col04_Row02	146/344.2	PED/PAD	0x2304.2	R/TPDO	I16	1
1904.3	Variable Column 4 Row 3	C3Array.Col04_Row03	147/344.3	PED/PAD	0x2304.3	R/TPDO	I16	1
1904.4	Variable Column 4 Row 4	C3Array.Col04_Row04	148/344.4	PED/PAD	0x2304.4	R/TPDO	I16	1
1904.5	Variable Column 4 Row 5	C3Array.Col04_Row05	149/344.5	PED/PAD	0x2304.5	R/TPDO	I16	1
1905.1	variable Column 5 Row 1	C3Array.Col05_Row01	150/345.1	PED/PAD	0x2305.1	R/TPDO	I16	1
1905.2	Variable Column 5 Row 2	C3Array.Col05_Row02	151/345.2	PED/PAD	0x2305.2	R/TPDO	I16	1
1905.3	Variable Column 5 Row 3	C3Array.Col05_Row03	152/345.3	PED/PAD	0x2305.3	R/TPDO	I16	1
1905.4	Variable Column 5 Row 4	C3Array.Col05_Row04	153/345.4	PED/PAD	0x2305.4	R/TPDO	I16	1
1905.5	Variable Column 5 Row 5	C3Array.Col05_Row05	154/345.5	PED/PAD	0x2305.5	R/TPDO	I16	1
1906.1	variable Column 6 Row 1	C3Array.Col06_Row01	155/346.1	PED/PAD	0x2306.1	R/TPDO	I32	2
1906.2	Variable Column 6 Row 2	C3Array.Col06_Row02	156/346.2	PED/PAD	0x2306.2	R/TPDO	I32	2
1906.3	Variable Column 6 Row 3	C3Array.Col06_Row03	157/346.3	PED/PAD	0x2306.3	R/TPDO	I32	2
1906.4	Variable Column 6 Row 4	C3Array.Col06_Row04	158/346.4	PED/PAD	0x2306.4	R/TPDO	I32	2
1906.5	Variable Column 6 Row 5	C3Array.Col06_Row05	159/346.5	PED/PAD	0x2306.5	R/TPDO	I32	2
1907.1	variable Column 7 Row 1	C3Array.Col07_Row01	160/347.1	PED/PAD	0x2307.1	R/TPDO	I32	2
1907.2	Variable Column 7 Row 2	C3Array.Col07_Row02	161/347.2	PED/PAD	0x2307.2	R/TPDO	I32	2
1907.3	Variable Column 7 Row 3	C3Array.Col07_Row03	162/347.3	PED/PAD	0x2307.3	R/TPDO	I32	2
1907.4	Variable Column 7 Row 4	C3Array.Col07_Row04	163/347.4	PED/PAD	0x2307.4	R/TPDO	I32	2
1907.5	Variable Column 7 Row 5	C3Array.Col07_Row05	164/347.5	PED/PAD	0x2307.5	R/TPDO	I32	2
1908.1	variable Column 8 Row 1	C3Array.Col08_Row01	165/348.1	PED/PAD	0x2308.1	R/TPDO	I32	2
1908.2	Variable Column 8 Row 2	C3Array.Col08_Row02	166/348.2	PED/PAD	0x2308.2	R/TPDO	I32	2
1908.3	Variable Column 8 Row 3	C3Array.Col08_Row03	167/348.3	PED/PAD	0x2308.3	R/TPDO	I32	2
1908.4	Variable Column 8 Row 4	C3Array.Col08_Row04	168/348.4	PED/PAD	0x2308.4	R/TPDO	I32	2
1908.5	Variable Column 8 Row 5	C3Array.Col08_Row05	169/348.5	PED/PAD	0x2308.5	R/TPDO	I32	2
1909.1	variable Column 9 Row 1	C3Array.Col09_Row01	170/349.1	PED/PAD	0x2309.1	R/TPDO	I32	2
1909.2	Variable Column 9 Row 2	C3Array.Col09_Row02	171/349.2	PED/PAD	0x2309.2	R/TPDO	I32	2

No.	Object name	Object	PNU	PZD	CAN-No	PD	Bus format	Word length
1909.3	Variable Column 9 Row 3	C3Array.Col09_Row03	172/349.3	PED/PAD	0x2309.3	R/TPDO	I32	2
1909.4	Variable Column 9 Row 4	C3Array.Col09_Row04	173/349.4	PED/PAD	0x2309.4	R/TPDO	I32	2
1909.5	Variable Column 9 Row 5	C3Array.Col09_Row05	174/349.5	PED/PAD	0x2309.5	R/TPDO	I32	2
1910.1	Indirect table access Column 1	C3Array.Indirect_Col01	181	PED/PAD	0x2311	R/TPDO	Y4	2
1910.2	Indirect table access Column 2	C3Array.Indirect_Col02	182	PED/PAD	0x2312	R/TPDO	Y2	1
1910.3	Indirect table access Column 3	C3Array.Indirect_Col03	183	PED/PAD	0x2313	R/TPDO	I16	1
1910.4	Indirect table access Column 4	C3Array.Indirect_Col04	184	PED/PAD	0x2314	R/TPDO	I16	1
1910.5	Indirect table access Column 5	C3Array.Indirect_Col05	185	PED/PAD	0x2315	R/TPDO	I16	1
1910.6	Indirect table access Column 6	C3Array.Indirect_Col06	186	PED/PAD	0x2316	R/TPDO	I32	2
1910.7	Indirect table access Column 7	C3Array.Indirect_Col07	187	PED/PAD	0x2317	R/TPDO	I32	2
1910.8	Indirect table access Column 8	C3Array.Indirect_Col08	188	PED/PAD	0x2318	R/TPDO	I32	2
1910.9	Indirect table access Column 9	C3Array.Indirect_Col09	189	PED/PAD	0x2319	R/TPDO	I32	2
1900.1	pointer to table row	C3Array.Pointer_Row	180	PED/PAD	0x2300	R/TPDO	U16	1
402.6	Factor for the current limits	C3Plus.Limit_CurrentFine	465	PED/PAD	0x2093	R/TPDO	I16	1
1100.1	Control command	C3Plus.DeviceControl_CommandOnRequest	108	PED/PAD	0x2028	R/TPDO	I16	1
1100.3	STW control word	C3Plus.DeviceControl_Controlword_1	1	PED/PAD	0x6040	R/TPDO	V2	1
1100.4	Control word 2	C3Plus.DeviceControl_Controlword_2	3	PED/PAD	0x201B	R/TPDO	V2	1
1100.5	Operating mode (Nominal value)	C3Plus.DeviceControl_OperationMode	127/930	PED/PAD	0x6060	R/TPDO	I16	1
1100.24	Offset Demand torque or force DS402 opmode 10	C3Plus.DeviceControl_TorqueOffset		PED/PAD	0x60B2	R/TPDO	I16	1
1000.5	operating mode display	C3Plus.DeviceState_ActualOperationMode	128	PED/PAD	0x6061	R/TPDO	I16	1
1000.3	status word ZSW	C3Plus.DeviceState_Statusword_1	2	PED/PAD	0x6041	R/TPDO	V2	1
1000.4	Status word 2	C3Plus.DeviceState_Statusword_2	4	PED/PAD	0x201C	R/TPDO	V2	1
550.1	current error (n)	C3Plus.ErrorHistory_LastError	115/947.0	PED	0x603F/0x201D.1	TPDO	U16	1
402.7	Torque limit or force limit	C3Plus.Limit_MaxTorque		PED/PAD	0x6072	R/TPDO	U16	1
1111.3	Acceleration for positioning	C3Plus.POSITION_accel	114	PED/PAD	0x6083	R/TPDO	U32	2
1111.4	Deceleration for positioning	C3Plus.POSITION_decel	178/312	PED/PAD	0x6084	R/TPDO	U32	2
1111.1	Target position	C3Plus.POSITION_position	27 (Profibus only)	PED/PAD		R/TPDO	C4_3	2
1111.11		C3Plus.POSITION_position_Y4	118	PED/PAD		R/TPDO	Y4	2
1111.2	Speed for positioning	C3Plus.POSITION_speed	111	PED/PAD		R/TPDO	C4_3	2
1111.9	Speed for Positioning in Y2 Format	C3Plus.POSITION_speed_Y2	110	PED/PAD		R/TPDO	Y2	1
2000.1	Position value of the setpoint encoder	C3Plus.ProfilGenerators_SG1Position		PED	0x2060	TPDO	C4_3	2
2000.4	Speed of the setpoint encoder	C3Plus.ProfilGenerators_SG1Speed		PED	0x2063	TPDO	I32	2
152.1	PIO analog input 0	C3Plus.RemoteAnalogInput_I0		PED/PAD	0x2082.1	R/TPDO	I16	1
152.2	PIO analog input 1	C3Plus.RemoteAnalogInput_I1		PED/PAD	0x2082.2	R/TPDO	I16	1
152.3	PIO analog input 2	C3Plus.RemoteAnalogInput_I2		PED/PAD	0x2082.3	R/TPDO	I16	1
152.4	PIO analog input 3	C3Plus.RemoteAnalogInput_I3		PED/PAD	0x2082.4	R/TPDO	I16	1
153.1	PIO analog output 0	C3Plus.RemoteAnalogOutput_O0		PED/PAD	0x2083.1	R/TPDO	I16	1
153.2	PIO analog output 1	C3Plus.RemoteAnalogOutput_O1		PED/PAD	0x2083.2	R/TPDO	I16	1
153.3	PIO analog output 2	C3Plus.RemoteAnalogOutput_O2		PED/PAD	0x2083.3	R/TPDO	I16	1
153.4	PIO analog output 3	C3Plus.RemoteAnalogOutput_O3		PED/PAD	0x2083.4	R/TPDO	I16	1
150.1	Digital PIO inputs 0...15	C3Plus.RemoteDigInput_I0_15		PED/PAD	0x2080.1	R/TPDO	V2	1
150.2	Digital PIO inputs 16...31	C3Plus.RemoteDigInput_I16_31		PED/PAD	0x2080.2	R/TPDO	V2	1
150.3	Digital PIO inputs 32...47	C3Plus.RemoteDigInput_I32_47		PED/PAD	0x2080.3	R/TPDO	V2	1
150.4	Digital PIO inputs 48...63	C3Plus.RemoteDigInput_I48_63		PED/PAD	0x2080.4	R/TPDO	V2	1
151.1	Digital PIO outputs 0...15	C3Plus.RemoteDigOutput_O0_15		PED/PAD	0x2081.1	R/TPDO	V2	1
151.2	Digital PIO outputs 16...31	C3Plus.RemoteDigOutput_O16_31		PED/PAD	0x2081.2	R/TPDO	V2	1
151.3	Digital PIO outputs 32...47	C3Plus.RemoteDigOutput_O32_47		PED/PAD	0x2081.3	R/TPDO	V2	1
151.4	Digital PIO outputs 48...63	C3Plus.RemoteDigOutput_O48_63		PED/PAD	0x2081.4	R/TPDO	V2	1
1127.3	Setpoint speed in speed control operating mode	C3Plus.SPEED_speed	7	PED/PAD		R/TPDO	C4_3	2
683.8	Motor current in per thousand of the actual current limit	C3Plus.StatusDevice_MotorCurrent		PED	0x2094	TPDO	I16	1
680.8	Status of actual position in bus format Y4	C3Plus.StatusPosition_ActualY4	119	PED	0x2022/0x6064	TPDO	I32	2
680.32	Encoder position 0 (5V) in increments	C3Plus.StatusPosition_EncoderIncrements5V		PED/PAD	0x2095.3	R/TPDO	I32	2
670.2	Status of actual torque	C3Plus.StatusTorqueForce_ActualTorque	209	PED		TPDO	I32	2
634.4	Setpoint for analog output 0	C3.AnalogOutput0_DemandValue	24	PED/PAD	0x2019	R/TPDO	I16	1
635.4	Setpoint for analog output 1	C3.AnalogOutput1_DemandValue	103	PED/PAD	0x201A	R/TPDO	I16	1

7.3 Object overview sorted by object groups (T30)

In this chapter you can read about:

C3 Objects.....428
 C3Array Objects430
 C3Plus Objects.....431
 C3 objects (without CoDeSys objects).....434

7.3.1. C3 Objects

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
634.4	C3.AnalogOutput0_DemandValue	Setpoint for analog output 0	24	0x2019	I16	ja	Immediately	True	True
635.4	C3.AnalogOutput1_DemandValue	Setpoint for analog output 1	103	0x201A	I16	ja	Immediately	True	True
2100.8	C3.ControllerTuning_CurrentBandwidth	Current regulator bandwidth	402.8	0x2100.8	U16	nein	VP	True	True
2100.9	C3.ControllerTuning_CurrentDamping	Current loop - Damping	402.9	0x2100.9	U16	nein	VP	True	True
2100.3	C3.ControllerTuning_Damping	damping (rotation speed controller)	402.3	0x2100.3	U16	nein	VP	True	True
2100.6	C3.ControllerTuning_FilterAccel	Filter - Actual acceleration	402.6	0x2100.6	U16	nein	VP	True	True
2100.21	C3.ControllerTuning_FilterAccel_us	Filter - Actual acceleration			U16	nein	VP	True	True
2100.11	C3.ControllerTuning_FilterAccel2	Filter actual acceleration 2			U16	nein	VP	True	True
2100.5	C3.ControllerTuning_FilterSpeed	Filter-actual velocity	402.5	0x2100.5	U16	nein	VP	True	True
2100.20	C3.ControllerTuning_FilterSpeed_us	Control signal filter of velocity control			U16	nein	VP	True	True
2100.10	C3.ControllerTuning_FilterSpeed2	Filter actual velocity 2			U16	nein	VP	True	True
2100.4	C3.ControllerTuning_Inertia	Inertia	402.4	0x2100.4	U16	nein	VP	True	True
2100.7	C3.ControllerTuning_SpeedDFactor	D-component of speed controller	402.7	0x2100.7	U16	nein	VP	True	True
2100.2	C3.ControllerTuning_Stiffness	Stiffness (speed controller)	402.2	0x2100.2/ 0x2100.1	U16	nein	VP	True	True
120.8	C3.DigitalInput_DebounceMask	Debounce mask for dig. Inputs			I16	nein	Immediately	True	True
120.7	C3.DigitalInput_DebounceTime	Debounce time for dig. Inputs			I16	nein	Immediately	True	True
120.2	C3.DigitalInput_Value	Status of digital inputs			V2	ja	-	True	True
121.2	C3.DigitalInputAddition_Value	input word of I/O option	175	0x6100.2	V2	ja	-	True	True
133.4	C3.DigitalOutputAddition_Enable	activating input/output option M10/M12	350	0x6300.3	V2	nein	Immediately	True	True
133.2	C3.DigitalOutputAddition_Error	error in I/O option	351	0x6300.4	V2	nein	-	True	True
133.3	C3.DigitalOutputAddition_Value	output word for I/O option	176	0x6300.2	V2	ja	Immediately	True	True
140.3	C3.DigitalOutputWord_DemandState	Command value of the digital outputs	22	0x6300.1	V2	ja	Immediately	False	True
2020.1	C3.ExternalSignal_Position	Position from external signal source		0x2095.1	C4_3	ja	-	True	True
2020.2	C3.ExternalSignal_Speed	speed from external signal source			C4_3	ja	-	True	True
2050.10	C3.FeedForward_2_Accel_FFW	Acceleration feedforward (A2)			C4_3	nein	VP	True	True
2050.9	C3.FeedForward_2_Speed_FFW	Speed feedforward (A2)			C4_3	nein	VP	True	True
2010.2	C3.FeedForward_Accel	Acceleration feedforward	400.2	0x2101.2	U16	nein	VP	True	True
2010.24	C3.FeedForward_Accel_FFW	Acceleration feedforward (A1)			C4_3	nein	VP	True	True
2010.4	C3.FeedForward_Current	Current feed-forward	400.4	0x2101.4	U16	nein	VP	True	True
2010.5	C3.FeedForward_Jerk	Jerk feed-forward	400.5	0x2101.5	U16	nein	VP	True	True
2010.1	C3.FeedForward_Speed	Velocity Feed Forward	400.1	0x2101.1	U16	nein	VP	True	True
2010.23	C3.FeedForward_Speed_FFW	Speed feedforward (A1)			C4_3	nein	VP	True	True
2011.2	C3.FeedForwardExternal_FilterAccel	External Acceleration Feed Forward Filter Time Constant	401.2	0x2102.2	U16	nein	VP	True	True
2011.5	C3.FeedForwardExternal_FilterAccel_us	Filter time constant ext. Acceleration			U16	nein	VP	True	True
2011.1	C3.FeedForwardExternal_FilterSpeed	External Speed Feed Forward Filter Time Constant	401.1	0x2102.1	U16	nein	VP	True	True
2011.4	C3.FeedForwardExternal_FilterSpeed_us	Filter time constant ext. speed			U16	nein	VP	True	True
402.4	C3.Limit_CurrentNegative	maximum permissible negative current	320	0x200C	I16	nein	VP	True	True
402.3	C3.Limit_CurrentPositive	maximum permissible positive current	319	0x200B	I16	nein	VP	True	True
402.2	C3.Limit_SpeedNegative	maximum permissible negative speed	318	0x200A	I16	nein	VP	True	True
402.1	C3.Limit_SpeedPositive	maximum permissible positive speed	317	0x2009	I16	nein	VP	True	True
410.6	C3.LimitPosition_LoadControlMaxPosDiff	Position difference load-motor (error threshold)			C4_3	nein	VP	True	True
410.3	C3.LimitPosition_Negative	Negative SW travel limit	322	0x607D.1	C4_3	nein	Immediately	True	True
410.2	C3.LimitPosition_Positive	Positive Travel Limit	321	0x607D.2	C4_3	nein	Immediately	True	True
191.1	C3.M2x_Input0_Gain	User gain M2x Input 0			C4_3	nein	VP	True	True
191.2	C3.M2x_Input0_Offset	User offset M2x Input 0			Y2	nein	VP	True	True
192.1	C3.M2x_Input1_Gain	User gain M2x Input 1			C4_3	nein	VP	True	True
192.2	C3.M2x_Input1_Offset	User offset M2x Input 1			Y2	nein	VP	True	True
193.1	C3.M2x_Input2_Gain	User gain M2x Input 2			C4_3	nein	VP	True	True
193.2	C3.M2x_Input2_Offset	User offset M2x Input 2			Y2	nein	VP	True	True
194.1	C3.M2x_Input3_Gain	User gain M2x Input 3			C4_3	nein	VP	True	True
194.2	C3.M2x_Input3_Offset	User offset M2x Input 3			Y2	nein	VP	True	True
195.1	C3.M2x_Input4_Gain	User gain M2x Input 4			C4_3	nein	VP	True	True
195.2	C3.M2x_Input4_Offset	User offset M2x Input 4			Y2	nein	VP	True	True
196.1	C3.M2x_Input5_Gain	User gain M2x Input 5			C4_3	nein	VP	True	True
196.2	C3.M2x_Input5_Offset	User offset M2x Input 5			Y2	nein	VP	True	True
3310.1	C3.Multiturnemulation_Status	Status of Multiturn emulation			I16	nein	-	True	True
20.10	C3.ObjectDir_ReadObjects	reading objects from Flash			I16	nein	Immediately	True	True
20.11	C3.ObjectDir_WriteObjects	saving objects permanently			I16	nein	Immediately	True	True
420.3	C3.PositioningAccuracy_FollowingErrorTimeout	Following Error Time	331	0x6066	U16	nein	Immediately	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
420.2	C3.PositioningAccuracy_FollowingErrorWindow	Following error limit	330	0x6065	C4_3	nein	VP	True	True
420.6	C3.PositioningAccuracy_PositionReached	Position reached			I32	nein	-	True	True
420.1	C3.PositioningAccuracy_Window	positioning window for position reached	328	0x6067	C4_3	nein	VP	True	True
420.7	C3.PositioningAccuracy_WindowTime	In Position Window Time	329	0x6068	U16	nein	Immediately	True	True
682.5	C3.StatusAccel_Actual	Status of actual acceleration unfiltered			I32	nein	-	True	True
682.6	C3.StatusAccel_ActualFilter	Status of filtered actual acceleration			I32	nein	-	True	True
682.4	C3.StatusAccel_DemandValue	Status demand acceleration	325	0x200E	I32	nein	-	True	True
688.2	C3.StatusCurrent_Actual	Status of actual current RMS (torque producing)			E2_6	ja	-	True	True
688.19	C3.StatusCurrent_ActualDINT	Actual current rms	230		I32	ja	-	True	True
688.35	C3.StatusCurrent_M2xAnalogInput0	Filtered actual value of the M2x current input 0			Y2	ja	-	True	True
688.36	C3.StatusCurrent_M2xAnalogInput1	Filtered actual value of the M2x current input 1			Y2	ja	-	True	True
688.37	C3.StatusCurrent_M2xAnalogInput2	Filtered actual value of the M2x current input 2			Y2	ja	-	True	True
688.38	C3.StatusCurrent_M2xAnalogInput3	Filtered actual value of the M2x current input 3			Y2	ja	-	True	True
688.39	C3.StatusCurrent_M2xAnalogInput4	Filtered actual value of the M2x current input 4			Y2	ja	-	True	True
688.40	C3.StatusCurrent_M2xAnalogInput5	Filtered actual value of the M2x current input 5			Y2	ja	-	True	True
688.34	C3.StatusCurrent_NegativeLimit	Negative current limit effective at present			I32	nein	-	True	True
688.33	C3.StatusCurrent_PositiveLimit	Positive current limit effective at present			I32	nein	-	True	True
688.1	C3.StatusCurrent_Reference	Status of setpoint current RMS (torque forming)			E2_6	nein	-	True	True
688.18	C3.StatusCurrent_ReferenceDINT	Demand current rms			I32	nein	-	True	True
688.13	C3.StatusCurrent_ReferenceJerk	Status of demand jerk setpoint generator			I32	nein	-	True	True
683.1	C3.StatusDevice_ActualCurrent	Status of actual current value	112	0x6077 (not EtherCAT with mapping via master)	E2_6	ja	-	True	True
683.2	C3.StatusDevice_ActualDeviceLoad	Status of device load	334	0x2011	E2_6	nein	-	True	True
683.9	C3.StatusDevice_ActualDeviceLoadLowFrequency	Status of device utilization at small electrical turning frequency			E2_6	nein	-	True	True
683.3	C3.StatusDevice_ActualMotorLoad	Status of long-term motor utilization	335	0x2012	E2_6	nein	-	True	True
683.4	C3.StatusDevice_DynamicMotorLoad	Status of short-term motor load			E2_6	nein	-	True	True
683.5	C3.StatusDevice_ObservedDisturbance	Status of observed disturbance			C4_3	nein	-	True	True
680.5	C3.StatusPosition_Actual	Status actual position	28	0x2104	C4_3	ja	-	True	True
680.13	C3.StatusPosition_ActualController	Status actual position without absolute reference			C4_3	nein	-	True	True
680.18	C3.StatusPosition_ActualNotReset	Status actual position (not reset)			C4_3	ja	-	True	True
680.12	C3.StatusPosition_DemandController	Status demand position without absolute reference			C4_3	nein	-	True	True
680.4	C3.StatusPosition_DemandValue	Status demand position	323	0x60FC	C4_3	ja	-	True	True
680.1	C3.StatusPosition_DemandValue1	Position command value of Profile transmitter 1	0	0x2052	Y4	ja	-	True	True
680.11	C3.StatusPosition_EncoderInput24V	Status of encoder input 0 (24V)			C4_3	ja	-	True	True
680.10	C3.StatusPosition_EncoderInput5V	Status of encoder input 0 (5V)		0x2095.2	C4_3	ja	-	True	True
680.6	C3.StatusPosition_FollowingError	Status of tracking error	100	0x60F4	C4_3	ja	-	True	True
680.23	C3.StatusPosition_LoadControlActual	Actual position of the load			C4_3	nein	-	True	True
680.22	C3.StatusPosition_LoadControlDeviationFiltered	Position difference load-motor (filtered)			C4_3	nein	-	True	True
680.21	C3.StatusPosition_LoadControlDeviationMax	Maximum position difference load-motor			C4_3	nein	-	True	True
680.30	C3.StatusPosition_Referenced	Status of axis referenced			I16	nein	-	True	True
681.5	C3.StatusSpeed_Actual	Status actual speed unfiltered		0x6069	C4_3	ja	-	True	True
681.9	C3.StatusSpeed_ActualFiltered	Status actual speed filtered	8	0x606C	C4_3	ja	-	True	True
681.12	C3.StatusSpeed_ActualScaled	Filtered actual speed in per cent			C4_3	nein	-	True	True
681.26	C3.StatusSpeed_ActualUnitrpmORmps	Status of actual speed filtered in 1/min or m/s	226	0x2105	C4_3	ja	-	True	True
681.13	C3.StatusSpeed_DemandScaled	Setpoint speed of the setpoint generator			C4_3	nein	-	True	True
681.10	C3.StatusSpeed_DemandSpeedController	Status demand speed controller input			C4_3	ja	-	True	True
681.4	C3.StatusSpeed_DemandValue	Status demand speed of setpoint generator	324	0x606B	C4_3	ja	-	True	True
681.1	C3.StatusSpeed_DemandValue1	Speed setpoint value of profile generator 1		0x2053	Y4	ja	-	True	True
681.6	C3.StatusSpeed_Error	Status control deviation of speed	101	0x2027	C4_3	ja	-	True	True
681.11	C3.StatusSpeed_FeedForwardSpeed	Status speed feed forward			C4_3	nein	-	True	True
681.20	C3.StatusSpeed_LoadControl	Speed of the load feedback (unfiltered)			C4_3	nein	-	True	True
681.21	C3.StatusSpeed_LoadControlFiltered	Speed of the load feedback (filtered)			C4_3	nein	-	True	True
681.25	C3.StatusSpeed_NegativeLimit	Negative speed limit currently effective			C4_3	nein	-	True	True
681.24	C3.StatusSpeed_PositiveLimit	Positive speed limit currently effective			C4_3	nein	-	True	True
684.2	C3.StatusTemperature_Motor	Status of motor temperature	336	0x2013	I16	nein	-	True	True
684.1	C3.StatusTemperature_PowerStage	Status of power output stage temperature	337	0x2014	U16	nein	-	True	True
685.3	C3.StatusVoltage_AnalogInput0	Status of analog input 0	23	0x2025	Y2	ja	-	True	True
685.4	C3.StatusVoltage_AnalogInput1	Status of analog input 1	102	0x2026	Y2	ja	-	True	True
685.1	C3.StatusVoltage_AuxiliaryVoltage	Status of auxiliary voltage	326	0x200F	E2_6	nein	-	True	True
685.2	C3.StatusVoltage_BusVoltage	Status DC bus voltage	327		E2_6	nein	-	True	True
685.6	C3.StatusVoltage_M2xAnalogInput0	Filtered actual value of the M2x voltage input 0			Y2	ja	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
685.7	C3.StatusVoltage_M2xAnalogInput1	Filtered actual value of the M2x voltage input 1			Y2	ja	-	True	True
685.8	C3.StatusVoltage_M2xAnalogInput2	Filtered actual value of the M2x voltage input 2			Y2	ja	-	True	True
685.9	C3.StatusVoltage_M2xAnalogInput3	Filtered actual value of the M2x voltage input 3			Y2	ja	-	True	True
685.10	C3.StatusVoltage_M2xAnalogInput4	Filtered actual value of the M2x voltage input 4			Y2	ja	-	True	True
685.11	C3.StatusVoltage_M2xAnalogInput5	Filtered actual value of the M2x voltage input 5			Y2	ja	-	True	True
210.10	C3.ValidParameter_Global	setting objects to valid	338.10	0x2016.10	U16	nein	Immediat ely	True	True
210.6	C3.ValidParameter_Limits	setting limit values to valid.			U16	nein	Immediat ely	True	True

7.3.2. C3Array Objects

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1901.1	C3Array.Col01_Row01	variable Column 1 Row 1	130/341.1	0x2301.1	Y4	ja	Immediat ely	True	True
1901.2	C3Array.Col01_Row02	Variable Column 1 Row 2	131/341.2	0x2301.2	Y4	ja	Immediat ely	True	True
1901.3	C3Array.Col01_Row03	Variable Column 1 Row 3	132/341.3	0x2301.3	Y4	ja	Immediat ely	True	True
1901.4	C3Array.Col01_Row04	Variable Column 1 Row 4	133/341.4	0x2301.4	Y4	ja	Immediat ely	True	True
1901.5	C3Array.Col01_Row05	Variable Column 1 Row 5	134/341.5	0x2301.5	Y4	ja	Immediat ely	True	True
1902.1	C3Array.Col02_Row01	variable Column 2 Row 1	135/342.1	0x2302.1	Y2	ja	Immediat ely	True	True
1902.2	C3Array.Col02_Row02	variable Column 2 Row 2	136/342.2	0x2302.2	Y2	ja	Immediat ely	True	True
1902.3	C3Array.Col02_Row03	variable Column 2 Row 3	137/342.3	0x2302.3	Y2	ja	Immediat ely	True	True
1902.4	C3Array.Col02_Row04	Variable Column 2 Row 4	138/342.4	0x2302.4	Y2	ja	Immediat ely	True	True
1902.5	C3Array.Col02_Row05	Variable Column 2 Row 5	139/342.5	0x2302.5	Y2	ja	Immediat ely	True	True
1903.1	C3Array.Col03_Row01	variable Column 3 Row 1	140/343.1	0x2303.1	I16	ja	Immediat ely	True	True
1903.2	C3Array.Col03_Row02	Variable Column 3 Row 2	141/343.2	0x2303.2	I16	ja	Immediat ely	True	True
1903.3	C3Array.Col03_Row03	Variable Column 3 Row 3	142/343.3	0x2303.3	I16	ja	Immediat ely	True	True
1903.4	C3Array.Col03_Row04	Variable Column 3 Row 4	143/343.4	0x2303.4	I16	ja	Immediat ely	True	True
1903.5	C3Array.Col03_Row05	Variable Column 3 Row 5	144/343.5	0x2303.5	I16	ja	Immediat ely	True	True
1904.1	C3Array.Col04_Row01	variable Column 4 Row 1	145/344.1	0x2304.1	I16	ja	Immediat ely	True	True
1904.2	C3Array.Col04_Row02	Variable Column 4 Row 2	146/344.2	0x2304.2	I16	ja	Immediat ely	True	True
1904.3	C3Array.Col04_Row03	Variable Column 4 Row 3	147/344.3	0x2304.3	I16	ja	Immediat ely	True	True
1904.4	C3Array.Col04_Row04	Variable Column 4 Row 4	148/344.4	0x2304.4	I16	ja	Immediat ely	True	True
1904.5	C3Array.Col04_Row05	Variable Column 4 Row 5	149/344.5	0x2304.5	I16	ja	Immediat ely	True	True
1905.1	C3Array.Col05_Row01	variable Column 5 Row 1	150/345.1	0x2305.1	I16	ja	Immediat ely	True	True
1905.2	C3Array.Col05_Row02	Variable Column 5 Row 2	151/345.2	0x2305.2	I16	ja	Immediat ely	True	True
1905.3	C3Array.Col05_Row03	Variable Column 5 Row 3	152/345.3	0x2305.3	I16	ja	Immediat ely	True	True
1905.4	C3Array.Col05_Row04	Variable Column 5 Row 4	153/345.4	0x2305.4	I16	ja	Immediat ely	True	True
1905.5	C3Array.Col05_Row05	Variable Column 5 Row 5	154/345.5	0x2305.5	I16	ja	Immediat ely	True	True
1906.1	C3Array.Col06_Row01	variable Column 6 Row 1	155/346.1	0x2306.1	I32	ja	Immediat ely	True	True
1906.2	C3Array.Col06_Row02	Variable Column 6 Row 2	156/346.2	0x2306.2	I32	ja	Immediat ely	True	True
1906.3	C3Array.Col06_Row03	Variable Column 6 Row 3	157/346.3	0x2306.3	I32	ja	Immediat ely	True	True
1906.4	C3Array.Col06_Row04	Variable Column 6 Row 4	158/346.4	0x2306.4	I32	ja	Immediat ely	True	True
1906.5	C3Array.Col06_Row05	Variable Column 6 Row 5	159/346.5	0x2306.5	I32	ja	Immediat ely	True	True
1907.1	C3Array.Col07_Row01	variable Column 7 Row 1	160/347.1	0x2307.1	I32	ja	Immediat ely	True	True
1907.2	C3Array.Col07_Row02	Variable Column 7 Row 2	161/347.2	0x2307.2	I32	ja	Immediat ely	True	True
1907.3	C3Array.Col07_Row03	Variable Column 7 Row 3	162/347.3	0x2307.3	I32	ja	Immediat ely	True	True
1907.4	C3Array.Col07_Row04	Variable Column 7 Row 4	163/347.4	0x2307.4	I32	ja	Immediat ely	True	True
1907.5	C3Array.Col07_Row05	Variable Column 7 Row 5	164/347.5	0x2307.5	I32	ja	Immediat ely	True	True
1908.1	C3Array.Col08_Row01	variable Column 8 Row 1	165/348.1	0x2308.1	I32	ja	Immediat ely	True	True
1908.2	C3Array.Col08_Row02	Variable Column 8 Row 2	166/348.2	0x2308.2	I32	ja	Immediat ely	True	True
1908.3	C3Array.Col08_Row03	Variable Column 8 Row 3	167/348.3	0x2308.3	I32	ja	Immediat ely	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
1908.4	C3Array.Col08_Row04	Variable Column 8 Row 4	168/348.4	0x2308.4	I32	ja	Immediately	True	True
1908.5	C3Array.Col08_Row05	Variable Column 8 Row 5	169/348.5	0x2308.5	I32	ja	Immediately	True	True
1909.1	C3Array.Col09_Row01	variable Column 9 Row 1	170/349.1	0x2309.1	I32	ja	Immediately	True	True
1909.2	C3Array.Col09_Row02	Variable Column 9 Row 2	171/349.2	0x2309.2	I32	ja	Immediately	True	True
1909.3	C3Array.Col09_Row03	Variable Column 9 Row 3	172/349.3	0x2309.3	I32	ja	Immediately	True	True
1909.4	C3Array.Col09_Row04	Variable Column 9 Row 4	173/349.4	0x2309.4	I32	ja	Immediately	True	True
1909.5	C3Array.Col09_Row05	Variable Column 9 Row 5	174/349.5	0x2309.5	I32	ja	Immediately	True	True
1910.1	C3Array.Indirect_Col01	indirect table access Column 1	181	0x2311	Y4	ja	Immediately	True	True
1910.2	C3Array.Indirect_Col02	Indirect table access Column 2	182	0x2312	Y2	ja	Immediately	True	True
1910.3	C3Array.Indirect_Col03	Indirect table access Column 3	183	0x2313	I16	ja	Immediately	True	True
1910.4	C3Array.Indirect_Col04	Indirect table access Column 4	184	0x2314	I16	ja	Immediately	True	True
1910.5	C3Array.Indirect_Col05	Indirect table access Column 5	185	0x2315	I16	ja	Immediately	True	True
1910.6	C3Array.Indirect_Col06	Indirect table access Column 6	186	0x2316	I32	ja	Immediately	True	True
1910.7	C3Array.Indirect_Col07	Indirect table access Column 7	187	0x2317	I32	ja	Immediately	True	True
1910.8	C3Array.Indirect_Col08	Indirect table access Column 8	188	0x2318	I32	ja	Immediately	True	True
1910.9	C3Array.Indirect_Col09	Indirect table access Column 9	189	0x2319	I32	ja	Immediately	True	True
1900.1	C3Array.Pointer_Row	pointer to table row	180	0x2300	U16	ja	Immediately	True	True

7.3.3. C3Plus Objects

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
170.3	C3Plus.AnalogInput0_FilterCoefficient	Filter of analog input 0			I16	nein	VP	True	True
171.3	C3Plus.AnalogInput1_FilterCoefficient	Filter of analog input 1			I16	nein	VP	True	True
820.8	C3Plus.CANopen_CyclePeriod	Sync bus cycle time CANsync, Powerlink, EtherCat		0x1006, 0x60C2	U32	nein	Immediately	False	True
820.3	C3Plus.CANopen_Node_ID	CANopen_Node_ID			U16	nein	-	False	True
820.9	C3Plus.CANopen_State	Status of the fieldbus state machine			U16	nein	-	False	True
820.28	C3Plus.CANopen_SyncPeriod	Current period duration of the sync signal			C4_3	nein	-	False	True
820.23	C3Plus.CANopen_SyncPulseCounter	Captured sync pulses			I32	nein	Immediately	False	True
100.2	C3Plus.Controller_Controlword	Controller control word actual value			U16	ja	Immediately	True	True
100.1	C3Plus.Controller_ControlwordDemand	Controller control word setpoint value			U16	nein	Immediately	True	True
1100.1	C3Plus.DeviceControl_CommandOnRequest	Control command	108	0x2028	I16	ja	Immediately	True	True
1100.3	C3Plus.DeviceControl_Controlword_1	STW control word	1	0x6040	V2	ja	Immediately	False	True
1100.4	C3Plus.DeviceControl_Controlword_2	Control word 2	3	0x201B	V2	ja	Immediately	False	True
1100.5	C3Plus.DeviceControl_OperationMode	Operating mode (Nominal value)	127/930	0x6060	I16	ja	Immediately	False	True
1100.24	C3Plus.DeviceControl_TorqueOffset	Offset Demand torque or force DS402 opmode 10		0x60B2	I16	ja	Immediately	True	True
1000.5	C3Plus.DeviceState_ActualOperationMode	operating mode display	128	0x6061	I16	ja	Immediately	False	True
1000.3	C3Plus.DeviceState_Statusword_1	status word ZSW	2	0x6041	V2	ja	Immediately	False	True
1000.4	C3Plus.DeviceState_Statusword_2	Status word 2	4	0x201C	V2	ja	Immediately	False	True
85.3	C3Plus.Diagnostics_DCbus_Current	PSUP intermediate current			I16	nein	-	True	True
85.2	C3Plus.Diagnostics_DCbus_Voltage	PSUP DC intermediate voltage			I16	nein	-	True	True
85.5	C3Plus.Diagnostics_RectifierLoad	PSUP usage in %			I16	nein	-	True	True
85.4	C3Plus.Diagnostics_TemperatureHeatSink	PSUP heat dissipator temperature			I16	nein	-	True	True
620.6	C3Plus.EncoderEmulation_Offset	Zero pulse offset encoder emulation			C4_3	nein	VP	True	True
620.7	C3Plus.EncoderEmulation_SetEmulationZero	Encoder simulation teaching zero pulse			I16	nein	Immediately	True	True
620.10	C3Plus.EncoderEmulation_Setpoint_without_offset	Demand position of encoder simulation (without offset)			C4_3	nein	-	True	True
550.1	C3Plus.ErrorHistory_LastError	current error (n)	115/947.0	0x603F/0x201D.1	U16	ja	-	True	True
2020.7	C3Plus.ExternalSignal_Accel_Munits	Acceleration of the external signal source			I32	ja	-	True	True
2020.6	C3Plus.ExternalSignal_Speed_Munits	Speed value of the external signal source			C4_3	ja	-	True	True
3925.1	C3Plus.FBI_Interpolation_SubModeSelect	Interpolation method		0x60C0	I16	nein	Immediately	False	True
3921.11	C3Plus.FBI_SignalProcessing0_IncrModuloEnable	Selection switch Modulo limit CanSync, PowerLink, EtherCat		0x2103.3	I32	nein	Immediately	False	True
3921.7	C3Plus.FBI_SignalProcessing0_OutputGreat	Interpolation output position CanSync, PowerLink, EtherCat in Mrev - free running.			Y4	nein	-	False	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
3921.2	C3Plus.FBI_SignalProcessing0_ResetDistance	Upper modulo limit CANSYNC, Powerlink, EtherCAT in Mrev		0x2051	I32	nein	Immediat ely	False	True
3921.9	C3Plus.FBI_SignalProcessing0_ResetDistance Incr	Modulo limit CanSync, PowerLink, EtherCat in Fbincr		0x2103.1	I32	nein	Immediat ely	False	True
3921.8	C3Plus.FBI_SignalProcessing0_Source	Switching the position source of the interpolator			I16	nein	Immediat ely	False	True
2010.25	C3Plus.FeedForward_GainUserCurrent	Gain factor for additive user current			C4_3	nein	Immediat ely	True	True
2010.19	C3Plus.FeedForward_UserCurrent	Additive Current			I32	ja	Immediat ely	True	True
1141.4	C3Plus.GEAR_mode	Source selection Gearing		0x2055	U16	nein	Immediat ely	True	True
3920.1	C3Plus.HEDA_SignalProcessing_Input	Process input signal Slave			C4_3	ja	Immediat ely	True	True
3920.7	C3Plus.HEDA_SignalProcessing_OutputGreat	Output of the Heda Tracking Filter			C4_3	nein	-	True	True
1130.1	C3Plus.HOMING_accel	Acceleration / deceleration homing	300	0x609A	U32	nein	Immediat ely	True	True
1130.7	C3Plus.HOMING_edge_sensor_distance	Initiator adjustment	304	0x2000	C4_3	nein	Immediat ely	True	True
1130.2	C3Plus.HOMING_jerk	jerk for machine reference run	357	0x201E	U32	nein	Immediat ely	True	True
1130.4	C3Plus.HOMING_mode	adjusting the machine reference mode	302	0x6098	U16	nein	Immediat ely	True	True
1130.3	C3Plus.HOMING_speed	speed for machine reference run	301	0x6099.1	C4_3	nein	Immediat ely	True	True
402.6	C3Plus.Limit_CurrentFine	Factor for the current limits	465	0x2093	I16	ja	Immediat ely	True	True
402.7	C3Plus.Limit_MaxTorque	Torque limit or force limit		0x6072	U16	ja	Immediat ely	True	True
2201.2	C3Plus.LoadControl_Command	Load control command mode			I16	nein	Immediat ely	True	True
2201.1	C3Plus.LoadControl_Enable	Activate load control		0x205F	I16	nein	Immediat ely	True	True
2201.11	C3Plus.LoadControl_FilterLaggingPart	Time constant of position difference filter			U32	nein	VP	True	True
2201.12	C3Plus.LoadControl_VelocityFilter	Time constant of the load-speed filter			I16	nein	VP	True	True
2201.13	C3Plus.LoadControl_VelocityLimit	Load control intervention speed limitation			I16	nein	VP	True	True
191.3	C3Plus.M2x_Input0_FilterCoefficient	Filter time constant M2x Input 0			I16	nein	VP	True	True
192.3	C3Plus.M2x_Input1_FilterCoefficient	Filter time constant M2x Input 1			I16	nein	VP	True	True
193.3	C3Plus.M2x_Input2_FilterCoefficient	Filter time constant M2x Input 2			I16	nein	VP	True	True
194.3	C3Plus.M2x_Input3_FilterCoefficient	Filter time constant M2x Input 3			I16	nein	VP	True	True
195.3	C3Plus.M2x_Input4_FilterCoefficient	Filter time constant M2x Input 4			I16	nein	VP	True	True
196.3	C3Plus.M2x_Input5_FilterCoefficient	Filter time constant M2x Input 5			I16	nein	VP	True	True
190.1	C3Plus.M2x_InputControl_Enable_Inputs_X20	Enable analog inputs X20 M2x			I16	nein	VP	True	True
190.2	C3Plus.M2x_InputControl_Enable_Inputs_X21	Enable analog inputs X21 M2x			I16	nein	VP	True	True
201.2	C3Plus.NormFactorY4_Position	Scaling factor for Y4 positions	356.2	0x2021.2	V2	nein	Immediat ely	False	True
2150.2	C3Plus.NotchFilter_BandwidthFilter1	Bandwidth of notch filter 1			I16	nein	VP	True	True
2150.5	C3Plus.NotchFilter_BandwidthFilter2	Bandwidth of notch filter 2			I16	nein	VP	True	True
2150.3	C3Plus.NotchFilter_DepthFilter1	Depth of notch filter 1			I32	nein	VP	True	True
2150.6	C3Plus.NotchFilter_DepthFilter2	Depth of notch filter 2			I32	nein	VP	True	True
2150.1	C3Plus.NotchFilter_FrequencyFilter1	Center frequency of notch filter 1			I16	nein	VP	True	True
2150.4	C3Plus.NotchFilter_FrequencyFilter2	Center frequency of notch filter 2			I16	nein	VP	True	True
1211.13	C3Plus.PG2POSITION_direction	Manipulation of the motion direction in reset mode			I32	nein	Immediat ely	True	True
50.3	C3Plus.PLC_ActualCycleTime	Status of cycle time of the control program	353	0x201F.2	U16	nein	-	False	True
50.4	C3Plus.PLC_ActualCycleTimeMax	Status of maximum cycle time	354	0x201F.3	U16	nein	Immediat ely	False	True
50.1	C3Plus.PLC_DemandCycleTime	cycle time specification	352	0x201F.1	U16	nein	Immediat ely	True	True
1111.3	C3Plus.POSITION_accel	Acceleration for positioning	114	0x6083	U32	ja	Immediat ely	True	True
1111.4	C3Plus.POSITION_decel	Deceleration for positioning	178/312	0x6084	U32	ja	Immediat ely	True	True
1111.13	C3Plus.POSITION_direction	Manipulation of the motion direction in reset mode			I32	nein	Immediat ely	True	True
1111.5	C3Plus.POSITION_jerk_accel	Acceleration jerk for positioning	313	0x2005	U32	nein	Immediat ely	True	True
1111.6	C3Plus.POSITION_jerk_decel	Deceleration jerk for positioning	314	0x2006	U32	nein	Immediat ely	True	True
1111.1	C3Plus.POSITION_position	Target position	27 (Profibus only)		C4_3	ja	Immediat ely	True	True
1111.8	C3Plus.POSITION_resetpositon_mode	Continuous mode	0	0	U16	nein	Immediat ely	True	True
1111.2	C3Plus.POSITION_speed	Speed for positioning	111		C4_3	ja	Immediat ely	True	True
1111.17	C3Plus.POSITION_turnaround	Direction inversion - lock			U16	nein	Immediat ely	True	True
2200.2	C3Plus.PositionController_ActualValue	Position actual value (sequentially)			C4_3	ja	-	True	True
2200.20	C3Plus.PositionController_DeadBand	Deadband of position controller			C4_3	nein	VP	True	True
2200.1	C3Plus.PositionController_DemandValue	Position setpoint value (sequentially)			C4_3	ja	-	True	True
2200.11	C3Plus.PositionController_TrackingErrorFilter	Following error filter of the position controller			U16	nein	VP	True	True
2215.7	C3Plus.PressureForceController_InsideWindow IPart	Internal window I-term of force/pressure control	422		C4_3	nein	VP	True	True
2215.6	C3Plus.PressureForceController_Integration_P art_KI	I-term of force/pressure control	421		C4_3	nein	VP	True	True
2215.8	C3Plus.PressureForceController_OutsideWindo w_IPart	External window I-term of force/pressure control	423		C4_3	nein	VP	True	True
2215.10	C3Plus.PressureForceController_PressureForc e_Disturbance_KFFWp	Force/pressure injection			C4_3	nein	VP	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
2215.5	C3Plus.PressureForceController_Proportional_Part_Kp	P-term of force/pressure control	420		C4_3	nein	VP	True	True
2215.9	C3Plus.PressureForceController_SpeedFeedback_Kvp_or_DampingFactor	Speed feedback of force/pressure control, damping term of force control	424		C4_3	nein	VP	True	True
2215.13	C3Plus.PressureForceController_SpeedFeedback_Limit	Signal limitation of speed feedback	425		U16	nein	VP	True	True
2000.1	C3Plus.ProfilGenerators_SG1Position	Position value of the setpoint encoder		0x2060	C4_3	ja	-	True	True
230.23	C3Plus.ProjectData_DSPFirmwareVersion	DSP firmware version			U32	nein	Immediately	True	True
2220.3	C3Plus.Q_CurrentController_Scaling_Q_DemandValueAdditive	Scaling for manual or external current specification			I16	nein	Immediately	True	True
152.1	C3Plus.RemoteAnalogInput_I0	PIO analog input 0		0x2082.1	I16	ja	Immediately	False	True
152.2	C3Plus.RemoteAnalogInput_I1	PIO analog input 1		0x2082.2	I16	ja	Immediately	False	True
152.3	C3Plus.RemoteAnalogInput_I2	PIO analog input 2		0x2082.3	I16	ja	Immediately	False	True
152.4	C3Plus.RemoteAnalogInput_I3	PIO analog input 3		0x2082.4	I16	ja	Immediately	False	True
153.1	C3Plus.RemoteAnalogOutput_O0	PIO analog output 0		0x2083.1	I16	ja	Immediately	False	True
153.2	C3Plus.RemoteAnalogOutput_O1	PIO analog output 1		0x2083.2	I16	ja	Immediately	False	True
153.3	C3Plus.RemoteAnalogOutput_O2	PIO analog output 2		0x2083.3	I16	ja	Immediately	False	True
153.4	C3Plus.RemoteAnalogOutput_O3	PIO analog output 3		0x2083.4	I16	ja	Immediately	False	True
150.1	C3Plus.RemoteDigInput_I0_15	Digital PIO inputs 0...15		0x2080.1	V2	ja	Immediately	False	True
150.2	C3Plus.RemoteDigInput_I16_31	Digital PIO inputs 16...31		0x2080.2	V2	ja	Immediately	False	True
150.3	C3Plus.RemoteDigInput_I32_47	Digital PIO inputs 32...47		0x2080.3	V2	ja	Immediately	False	True
150.4	C3Plus.RemoteDigInput_I48_63	Digital PIO inputs 48...63		0x2080.4	V2	ja	Immediately	False	True
151.1	C3Plus.RemoteDigOutput_O0_15	Digital PIO outputs 0...15		0x2081.1	V2	ja	Immediately	False	True
151.2	C3Plus.RemoteDigOutput_O16_31	Digital PIO outputs 16...31		0x2081.2	V2	ja	Immediately	False	True
151.3	C3Plus.RemoteDigOutput_O32_47	Digital PIO outputs 32...47		0x2081.3	V2	ja	Immediately	False	True
151.4	C3Plus.RemoteDigOutput_O48_63	Digital PIO outputs 48...63		0x2081.4	V2	ja	Immediately	False	True
814.11	C3Plus.SafetyMonitor_AlarmCode	Alarm no. S3			U16	nein	-	True	
814.13	C3Plus.SafetyMonitor_DiagnosticsBits0_15	DiagnoseBits0_15 S3			U16	nein	-	True	
814.14	C3Plus.SafetyMonitor_DiagnosticsBits16_31	DiagnoseBits16_31 S3			U16	nein	-	True	
814.15	C3Plus.SafetyMonitor_DiagnosticsBits32_47	DiagnoseBits32_47 S3			U16	nein	-	True	
814.16	C3Plus.SafetyMonitor_DiagnosticsBits48_55	DiagnoseBits48_55 S3			U16	nein	-	True	
814.12	C3Plus.SafetyMonitor_ErrorCode	Error no. S3			U16	nein	-	True	
814.10	C3Plus.SafetyMonitor_OperatingState	Status S3			U16	nein	-	True	
814.21	C3Plus.SafetyMonitor_ProcessData_U16_1	Process data U16_1 of S3 (first 2 Bytes)			U16	nein	-	True	
814.22	C3Plus.SafetyMonitor_ProcessData_U16_2	Process data U16_2 of S3 (Byte 3 and 4)			U16	nein	-	True	
814.23	C3Plus.SafetyMonitor_ProcessData_U16_3	Process data U16_3 of S3 (Byte 5 and 6)			U16	nein	-	True	
814.24	C3Plus.SafetyMonitor_ProcessData_U16_4	Process data U16_4 of S3 (Byte 7 and 8)			U16	nein	-	True	
814.25	C3Plus.SafetyMonitor_ProcessData_U32_1	Process data U32_1 of S3 (first 4 Bytes)			U32	nein	-	True	
814.26	C3Plus.SafetyMonitor_ProcessData_U32_2	Process data U32_2 of S3 (Byte 5 to 8)			U32	nein	-	True	
814.27	C3Plus.SafetyMonitor_ProcessData_U32_3	Process data U32_3 of S3 (Byte 3 to 6)			U32	nein	-	True	
1127.3	C3Plus.SPEED_speed	Setpoint speed in speed control operating mode	7		C4_3	ja	Immediately	True	True
2210.19	C3Plus.SpeedController_ScalingDemandValueAdditive	Scaling for manual or external velocity specification			C4_3	nein	Immediately	True	True
295.11	C3Plus.SSI_Feedback_Absolut_Position				I32	nein	-	True	True
295.12	C3Plus.SSI_Feedback_PositionGreat	Rotation position			I32	nein	-	True	True
688.17	C3Plus.StatusCurrent_FieldWeakeningFactor	Reciprocal of the field weakening factor FF			C4_3	nein	-	True	True
683.8	C3Plus.StatusDevice_MotorCurrent	Motor current in per thousand of the actual current limit		0x2094	I16	ja	-	False	True
680.32	C3Plus.StatusPosition_EncoderIncrements5V	Encoder position 0 (5V) in increments		0x2095.3	I32	ja	Immediately	True	True
680.24	C3Plus.StatusPosition_SSI_AbsolutPosition_LoadUnits	AbsolutPosition of the SSI-feedback load unit			C4_3	nein	-	True	True
680.25	C3Plus.StatusPosition_SSI_AbsolutPosition_MasterUnits	AbsolutPosition of the SSI-feedback master unit			C4_3	nein	-	True	True
677.22	C3Plus.StatusPressureForce_ControllerDpart	Status of D-term of pressure or force/torque control			C4_3	nein	-	True	True
677.24	C3Plus.StatusPressureForce_ControllerFFWpart	Status actual torque/force injection force/torque controller			C4_3	nein	-	True	True
677.20	C3Plus.StatusPressureForce_ControllerIpart	Status of I-term of pressure or force/torque control			C4_3	nein	-	True	True
677.27	C3Plus.StatusPressureForce_ControllerOut	Status of total control signal pressure or force/torque control			C4_3	nein	-	True	True
677.21	C3Plus.StatusPressureForce_ControllerPpart	Status of P-term of pressure or force/torque control			C4_3	nein	-	True	True
677.23	C3Plus.StatusPressureForce_ControllerVpart	Status of speed feedback of pressure or force/torque control			C4_3	nein	-	True	True
677.12	C3Plus.StatusPressureForce_ForceActualValue	Actual force controller			C4_3	nein	-	True	True
677.11	C3Plus.StatusPressureForce_ForceDemandValue	Demand force controller			C4_3	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
677.13	C3Plus.StatusPressureForce_ForceError	Control deviation of force controller			C4_3	nein	-	True	True
684.4	C3Plus.StatusTemperature_TmotResistance	Status of motor temperature resistance value			U16	nein	-	True	True
670.4	C3Plus.StatusTorqueForce_ActualForce	Status of actual force			I32	nein	-	True	True
670.2	C3Plus.StatusTorqueForce_ActualTorque	Status of actual torque	209		I32	ja	-	True	True
670.9	C3Plus.StatusTorqueForce_RatedTorqueForce	Reference torque or from the reference force		0x6076	U32	nein	-	True	True
670.3	C3Plus.StatusTorqueForce_SetpointForce	Status of setpoint force			I32	nein	-	True	True
670.1	C3Plus.StatusTorqueForce_SetpointTorque	Status of setpoint torque			I32	nein	-	True	True
110.1	C3Plus.Switch_DeviceFunction	Value of the function switch on C3M			U16	nein	-	True	True
2109.1	C3Plus.TrackingfilterHEDA_TRFSpeed	Time constant tracking filter HEDA-process position			I16	nein	VP	True	True
2107.1	C3Plus.TrackingfilterPhysicalSource_TRFSpeed	Time constant tracking filter physical source			U16	nein	VP	True	True
2110.4	C3Plus.TrackingfilterSG1_AccelFilter	Filter effect of acceleration filter setpoint encoder			U16	nein	VP	True	True
2110.7	C3Plus.TrackingfilterSG1_AccelFilter_us	Filter time constant acceleration setpoint generator			U16	nein	VP	True	True
2110.3	C3Plus.TrackingfilterSG1_FilterSpeed	Filter effect of speed filter setpoint encoder			U16	nein	VP	True	True
2110.6	C3Plus.TrackingfilterSG1_FilterSpeed_us	Filter time constant velocity setpoint generator			U16	nein	VP	True	True
2110.1	C3Plus.TrackingfilterSG1_TRFSpeed	Time constant tracking filter setpoint encoder		0x2096	I16	nein	VP	True	True
210.8	C3Plus.ValidParameter_AutoCommutation	Set position auto commutation parameters to valid			U16	nein	Immediately	True	True
210.1	C3Plus.ValidParameter_CurrentController	Set current controller to valid			U16	nein	Immediately	True	True
210.5	C3Plus.ValidParameter_FeedForward	Set feedforward parameters to valid.			U16	nein	Immediately	True	True
210.2	C3Plus.ValidParameter_FiltersRSDP	Set filter parameter to valid			U16	nein	Immediately	True	True
210.4	C3Plus.ValidParameter_PositionController	Set position controller to valid			U16	nein	Immediately	True	True
210.3	C3Plus.ValidParameter_SpeedController	Set parameter velocity controller/velocity observer to valid.			U16	nein	Immediately	True	True

7.3.4. C3 objects (without CoDeSys objects)

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
170.2	AnalogInput0_Gain	Gain analog input 0			C4_3	nein	VP	True	True
170.4	AnalogInput0_Offset	Analog input Offset 0			I16	nein	Immediately	True	True
171.2	AnalogInput1_Gain	Gain analog input 1			C4_3	nein	VP	True	True
171.4	AnalogInput1_Offset	Analog input offset 1			I16	nein	Immediately	True	True
634.7	AnalogOutput0_Gain_Hardware	Additional gain factor for the D/A monitor 0			C4_3	nein	VP	True	True
634.6	AnalogOutput0_Offset_Hardware	Offset value for the D/A monitor 0			I16	nein	VP	True	True
635.7	AnalogOutput1_Gain_Hardware	Additional gain factor for the D/A monitor 1			C4_3	nein	VP	True	True
635.6	AnalogOutput1_Offset_Hardware	Offset value for the D/A Monitor 1			I16	nein	VP	True	True
2190.2	AutoCommutationControl_InitialCurrent	Start current of automatic commutation			U16	nein	VP	True	True
2190.4	AutoCommutationControl_MotionReduction	Motion reduction Automatic commutation			U16	nein	VP	True	True
2190.8	AutoCommutationControl_PeakCurrent	Reduction of the peak current			U16	nein	VP	True	True
2190.3	AutoCommutationControl_PositionThreshold	Motion limit for automatic commutation			U16	nein	VP	True	True
2190.1	AutoCommutationControl_Ramptime	Ramp slope current slope AK			U16	nein	VP	True	True
2190.10	AutoCommutationControl_Reset	Reset automatic commutation			U16	nein	Immediately	True	True
2190.7	AutoCommutationControl_StandstillThreshold	Optimization of the standstill threshold			U16	nein	VP	True	True
820.27	CANopen_SyncErrorCounter	Error counter for CANSync, Powerlink, EtherCat			I32	nein	Immediately	False	True
820.24	CANopen_SyncMode	Configuration of the bus synchronization process		0x205E	I16	nein	Immediately	False	True
2230.20	D_CurrentController_Ld_Lq_Ratio	Ratio direct to quadrature inductance			U16	nein	VP	True	True
2230.24	D_CurrentController_VoltageDecouplingEnable	Activation of the voltage decoupling			I16	nein	VP	True	True
990.1	Delay_MasterDelay	Setpoint delay for bus master			I16	nein	Immediately	True	True
1.21	Device_FirmwareRelease	Version of firmware package		0x20FF	I32	nein	Immediately	False	True
1.15	Device_ProfileID	Profibus profile number	965		OS	nein	-	False	True
84.4	DeviceSupervision_DeviceAdr	Current RS485 address of the C3M			U16	nein	-	True	True
84.3	DeviceSupervision_DeviceCounter	Number of devices in the C3M combination			U16	nein	-	True	True
84.5	DeviceSupervision_OperatingTime	Hours of operation of the PSUP in s			U32	nein	-	True	True
84.2	DeviceSupervision_ThisDevice	Device number in the C3M combination			U16	nein	-	True	True
85.8	Diagnostics_ChopperOff_Voltage	Chopper Switch-off threshold in V			I16	nein	-	True	True
85.7	Diagnostics_ChopperOn_Voltage	Chopper Switch-on threshold in V			I16	nein	-	True	True
85.9	Diagnostics_DCbus_VoltageMax	Reduced DC bus voltage in V			I16	nein	-	True	True
85.1	Diagnostics_DeviceState	PSUP operating state			V2	nein	Immediately	True	True
120.3	DigitalInput_DebouncedValue	Status of digital inputs	21	0x6100.1	V2	ja	-	True	True
550.2	ErrorHistory_1	Error (n-1) in the error history	947.1	0x201D.2	U16	nein	-	False	True
87.1	ErrorHistoryNumber_1	Error 1			U16	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
86.1	ErrorHistoryPointer_LastEntry	Pointer to current error			U16	nein	-	True	True
88.1	ErrorHistoryTime_1	Error point in time 1			U32	nein	-	True	True
3925.21	FBI_Interpolation_AccelInput	Acceleration specification GEARING CanSync/EthernetPowerLink/EtherCat		0x2099	I32	ja	Immediately	False	True
3925.23	FBI_Interpolation_AccelStatus	Acceleration output value for CanSync/EthernetPowerLink/EtherCat			I32	nein	-	False	True
3925.24	FBI_Interpolation_PositionStatus	Interpolation position input value for CanSync/EthernetPowerLink/EtherCat			I32	nein	-	False	True
3925.20	FBI_Interpolation_VelocityInput	Velocity specification GEARING CanSync/EthernetPowerLink/EtherCat		0x2098	I32	ja	Immediately	False	True
3925.22	FBI_Interpolation_VelocityStatus	Speed output value for CanSync/EthernetPowerLink/EtherCat			C4_3	nein	-	False	True
950.1	FBI_RxPD_Mapping_Object_1	1. Object of the setpoint PZD (Profibus)	915.0		U16	nein	Immediately	False	True
950.2	FBI_RxPD_Mapping_Object_2	2. object of the Setpoint value PZD	915.1		U16	nein	Immediately	False	True
950.3	FBI_RxPD_Mapping_Object_3	3. object of the Setpoint value PZD	915.2		U16	nein	Immediately	False	True
950.4	FBI_RxPD_Mapping_Object_4	4. object of the Setpoint value PZD	915.3		U16	nein	Immediately	False	True
950.5	FBI_RxPD_Mapping_Object_5	5. object of the Setpoint value PZD	915.4		U16	nein	Immediately	False	True
950.6	FBI_RxPD_Mapping_Object_6	6. object of the Setpoint value PZD	915.5		U16	nein	Immediately	False	True
950.7	FBI_RxPD_Mapping_Object_7	7. object of the Setpoint value PZD	915.6		U16	nein	Immediately	False	True
950.8	FBI_RxPD_Mapping_Object_8	8. object of the Setpoint value PZD	915.7		U16	nein	Immediately	False	True
3921.1	FBI_SignalProcessing0_Input_Y4	Interpolation input CanSync, PowerLink		0x2050/0x60C1.1	I32	ja	Immediately	False	True
3921.5	FBI_SignalProcessing0_OutputFBIncr	Interpolation output position CanSync, PowerLink, EtherCat in Fbincr.			I32	nein	-	False	True
3921.3	FBI_SignalProcessing0_ResetDistanceLow	Lower modulo limit CanSync, PowerLink, EtherCat in Mrev		0x2103.1	I32	nein	Immediately	False	True
3921.10	FBI_SignalProcessing0_ResetDistanceLow_Incr	Lower modulo limit CanSync, PowerLink, EtherCat in Fbincr		0x2103.2	I32	nein	Immediately	False	True
951.1	FBI_TxPD_Mapping_Object_1	1. object of actual value PZD	916.0		U16	nein	Immediately	False	True
951.2	FBI_TxPD_Mapping_Object_2	2. object of actual value PZD	916.1		U16	nein	Immediately	False	True
951.3	FBI_TxPD_Mapping_Object_3	3. object of actual value PZD	916.2		U16	nein	Immediately	False	True
951.4	FBI_TxPD_Mapping_Object_4	4. object of actual value PZD	916.3		U16	nein	Immediately	False	True
951.5	FBI_TxPD_Mapping_Object_5	5. object of actual value PZD	916.4		U16	nein	Immediately	False	True
951.6	FBI_TxPD_Mapping_Object_6	6. object of actual value PZD	916.5		U16	nein	Immediately	False	True
951.7	FBI_TxPD_Mapping_Object_7	7. object of actual value PZD	916.6		U16	nein	Immediately	False	True
951.8	FBI_TxPD_Mapping_Object_8	8. object of actual value PZD	916.7		U16	nein	Immediately	False	True
2050.8	FeedForward_2_Valve	Valve feedforward auxiliary axis			U16	nein	VP	True	True
2010.20	FeedForward_EMF	EMC feed forward			U16	ja	VP	True	True
2010.21	FeedForward_Valve	Valve feedforward			U16	nein	VP	True	True
1141.8	GEAR_actual_master_speed	Master speed for Gearing			C4_3	nein	-	True	True
1141.7	GEAR_actual_masterposition	Position input value for Gearing		0x2058	C4_3	nein	-	True	True
1141.10	GEAR_FFW_mode	Control bits for feedforward with source CANSync/EthernetPowerLink/EtherCat		0x2097	U16	nein	Immediately	False	True
1130.13	HOMING_edge_position	Distance MN (zero) initiator - motor zero			C4_3	nein	Immediately	True	True
2201.3	LoadControl_Status	Load control status bits			I16	nein	-	True	True
2240.7	Magnetisierungsstromregler_Bandwidth	Magnetization current controller bandwidth (ASM)			I16	nein	VP	True	True
2240.4	Magnetisierungsstromregler_Damping	Magnetization current controller attenuation(ASM)			I16	nein	VP	True	True
2240.11	Magnetisierungsstromregler_Field weakening speed	Reference speed quantifier (ASM)			I16	nein	VP	True	True
2240.2	Magnetisierungsstromregler_I_mrn_DemandValveTuning	Magnetization current quantifier (ASM)			I16	nein	VP	True	True
2240.10	Magnetisierungsstromregler_RotorTimeConstant	Motor Time Constant quantifier			I16	nein	VP	True	True
2240.9	Magnetisierungsstromregler_SlipFrequency	Slip frequency quantifier (ASM)			I16	nein	VP	True	True
200.10	NormFactorY2_ActualValue2_Y2	Normalization factor for 1000.14			V2	nein	Immediately	False	True
200.7	NormFactorY2_ActualValue3	Normalization factor for 1000.8	355.7	0x2020.7	V2	nein	Immediately	False	True
200.8	NormFactorY2_ActualValue4	Normalization factor for 1000.9	355.8	0x2020.8	V2	nein	Immediately	False	True
200.5	NormFactorY2_Array_Col2	Normalization factor recipe arrays column 2	355.5	0x2020.5	V2	nein	Immediately	False	True
200.11	NormFactorY2_Current	Normalization factor for Y2 currents	355.11	0x2020.11	V2	nein	Immediately	False	True
200.9	NormFactorY2_DemandValue2_Y2	Normalization factor for 1100.14@1100.14		0x2020.9	V2	nein	Immediately	False	True
200.4	NormFactorY2_DemandValue3	Normalization factor for 1100.8	355.4	0x2020.4	V2	nein	Immediately	False	True
200.6	NormFactorY2_DemandValue4	Normalization factor for 1100.9	355.6	0x2020.6	V2	nein	Immediately	False	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
200.1	NormFactorY2_Speed	Normalization factor for Y2 speeds	355.1	0x2020.1	V2	nein	Immediat ely	False	True
200.3	NormFactorY2_Voltage	Normalization factor for Y2 voltages	355.3	0x2020.3	V2	nein	Immediat ely	False	True
201.7	NormFactorY4_ActualValue1	Normalization factor for 1000.6	356.7	0x2021.7	V2	nein	Immediat ely	False	True
201.8	NormFactorY4_ActualValue2	Normalization factor for 1000.7	356.8	0x2021.8	V2	nein	Immediat ely	False	True
201.13	NormFactorY4_ActualValue8	Normalization factor for 1000.13	356.13	0x2021.13	V2	nein	Immediat ely	False	True
201.4	NormFactorY4_Array_Col1	Scaling factor recipe arrays column 1	356.4	0x2021.4	V2	nein	Immediat ely	False	True
201.5	NormFactorY4_DemandValue1	Normalization factor for 1100.6	356.5	0x2021.5	V2	nein	Immediat ely	False	True
201.6	NormFactorY4_DemandValue2	Normalization factor for 1100.7	356.6	0x2021.6	V2	nein	Immediat ely	False	True
201.12	NormFactorY4_DemandValue8	Normalization factor for 1100.13	356.12	0x2021.12	V2	nein	Immediat ely	False	True
201.15	NormFactorY4_FBI_SignalProcessing_Accel	Normalization factor for 3925.21		0x2021.15	V2	nein	Immediat ely	False	True
201.11	NormFactorY4_FBI_SignalProcessing_Position	Normalization factor for bus interpolation CANSync/EthernetPowerLink	356.11	0x2021.11	V2	nein	Immediat ely	False	True
201.14	NormFactorY4_FBI_SignalProcessing_Speed	Normalization factor for 3925.20		0x2021.14	V2	nein	Immediat ely	False	True
201.1	NormFactorY4_Speed	Scaling factor for Y4 speeds	356.1	0x2021.1	V2	nein	Immediat ely	False	True
201.3	NormFactorY4_Voltage	Scaling factor for Y4 voltages	356.3	0x2021.3	V2	nein	Immediat ely	False	True
20.1	ObjectDir_Objekts-->FLASH	Store objects permanently (bus)	339	0x2017	I16	nein	Immediat ely	False	True
1111.11	POSITION_position_Y4		118		Y4	ja	Immediat ely	False	True
1111.9	POSITION_speed_Y2	Speed for Positioning in Y2 Format	110		Y2	ja	Immediat ely	False	True
2200.21	PositionController_FrictionCompensation	Friction compensation			I32	nein	VP	True	True
2200.25	PositionController_IntegralPart	I term of position controller			U16	nein	VP	True	True
2200.3	PositionController_ProportionalPart	Optimization parameters for the position controller P component (KV factor)			U16	nein	VP	True	True
2200.24	PositionController_TrackingErrorFilter_us	Time constant following error filter of position controller			U16	nein	VP	True	True
830.2	Profibus_Baudrate	Baud rate			U32	nein	-	False	True
830.3	Profibus_NodeAddress	Node address	918		U16	nein	-	False	True
830.1	Profibus_Protocol	PPO-type selection switch			U16	nein	Immediat ely	False	True
830.6	Profibus_StandardSignalTable	List of Profidrive standard signals	923.x		U16	nein	-	False	True
830.4	Profibus_TelegramSelect	Telegram selection switch	922		U16	nein	Immediat ely	False	True
2000.4	ProfilGenerators_SG1Speed	Speed of the setpoint encoder		0x2063	I32	ja	-	True	True
2220.22	Q_CurrentController_BackEMF	Parameter motor force constant			I16	nein	VP	True	True
2220.6	Q_CurrentController_CurrentControlIntegralPart	Current Loop I term			I16	nein	VP	True	True
2220.5	Q_CurrentController_CurrentControlProportionalPart	Current Loop - "P" Term			I16	nein	VP	True	True
2220.20	Q_CurrentController_Inductance	Parameter motor inductance			I16	nein	VP	True	True
2220.4	Q_CurrentController_Q_ActualValue	Cross-flow actual value			I16	ja	-	True	True
2220.1	Q_CurrentController_Q_DemandValue	Quadrature Current CommandValue			I16	ja	-	True	True
2220.2	Q_CurrentController_Q_DemandValueAdditive	Manual or external cross current specification			I16	ja	Immediat ely	True	True
2220.21	Q_CurrentController_Resistance	Parameter motor resistance			I16	nein	VP	True	True
2220.27	Q_CurrentController_StructureSelection	Structure switch of current control			I16	nein	VP	True	True
280.5	Resolver_ExcitationLevel	Resolver excitation level			U16	nein	Immediat ely	True	True
280.3	Resolver_LevelAdaption	Resolver signal scaling			I16	nein	Immediat ely	True	True
814.20	SafetyMonitor_ProcessData	Total process data S3			OS	nein	-	True	
2210.17	SpeedController_ActualBandwidth	Replacement time constant for the velocity control			I32	nein	-	True	True
2210.2	SpeedController_ActualValue	Actual (rotational) speed			I32	ja	-	True	True
2210.1	SpeedController_DemandValue	Velocity setpoint value			I32	ja	-	True	True
2210.14	SpeedController_DemandValueAdditive	Manual or external velocity specification			I32	ja	Immediat ely	True	True
2210.5	SpeedController_I_Part_Gain	Weighting "I" term			U16	nein	VP	True	True
2210.4	SpeedController_P_Part_Gain	P term quantifier			U16	nein	VP	True	True
2120.7	SpeedObserver_DisturbanceAdditionEnable	Switch to enable disturbance compensation			I16	nein	VP	True	True
2120.5	SpeedObserver_DisturbanceFilter	Time constant disturbance filter			U32	nein	VP	True	True
2120.1	SpeedObserver_TimeConstant	Rapidity of the speed monitor			U32	nein	VP	True	True
295.10	SSI_Feedback_Incr_Position	SSI feedback position (Increments)			I32	nein	-	True	True
682.7	StatusAccel_FeedForwardAccel	Status acceleration feed forward			C4_3	nein	-	True	True
690.5	StatusAutocommutation_Iterations	Current increase steps automatic commutation			U16	nein	-	True	True
688.8	StatusCurrent_ControlDeviationIq	Status control deviation current control RMS			C4_3	nein	-	True	True
688.31	StatusCurrent_DecouplingVoltageUd	Signal decoupling of direct current controller			C4_3	nein	-	True	True
688.32	StatusCurrent_FeedForwardbackEMF	Signal EMC feed forward			C4_3	nein	-	True	True
688.14	StatusCurrent_FeedForwardCurrentJerk	Status of current & jerk feedforward			C4_3	nein	-	True	True
688.9	StatusCurrent_PhaseU	Status of current phase U			C4_3	nein	-	True	True
688.10	StatusCurrent_PhaseV	Status of current phase V			C4_3	nein	-	True	True
688.11	StatusCurrent_ReferenceVoltageUq	Status of current control control signal			C4_3	nein	-	True	True

No.	Object name	Object	I20,I32 Bus No	I21,I30,I31 Bus No	Format	PD	Valid	Device assignment	
								I11	Bus
688.22	StatusCurrent_ReferenceVoltageVector	Provided voltage pointer			C4_3	nein	-	True	True
688.30	StatusCurrent_VoltageUd	Provided voltage of direct current controller			C4_3	nein	-	True	True
688.29	StatusCurrent_VoltageUq	Provided voltage of quadrature current controller			C4_3	nein	-	True	True
683.13	StatusDevice_ActualTorqueDS402	Actual torque or force DS402 opmode 10		0x6077 (only EtherCAT with mapping via master)	I16	ja	-	False	True
683.7	StatusDevice_BallastResistorDynamicLoad	Status of short-term braking resistor utilization			C4_3	nein	-	True	True
683.6	StatusDevice_BallastResistorLoad	Status of long-term braking resistor utilization			C4_3	nein	-	True	True
683.12	StatusDevice_BallastResistorOFFThreshold	Braking resistor switch-off voltage			C4_3	nein	-	True	True
683.11	StatusDevice_BallastResistorONThreshold	Braking resistor switch-on voltage			C4_3	nein	-	True	True
692.4	StatusFeedback_EncoderCosine	Status of analog input cosine			I32	nein	-	True	True
692.24	StatusFeedback_EncoderCosineVolts	Status of analog input cosine (Volt)			C4_3	nein	-	True	True
692.3	StatusFeedback_EncoderSine	Status of analog input sine			I32	nein	-	True	True
692.23	StatusFeedback_EncoderSineVolts	Status of analog input sine (Volt)			C4_3	nein	-	True	True
692.2	StatusFeedback_FeedbackCosineDSP	Status of cosine in signal processing			I32	ja	-	True	True
692.22	StatusFeedback_FeedbackCosineDSPvolts	Status of cosine in signal processing			C4_3	ja	-	True	True
692.1	StatusFeedback_FeedbackSineDSP	Status of sine in signal processing			I32	ja	-	True	True
692.21	StatusFeedback_FeedbackSineDSPvolts	Status of sine in signal processing			C4_3	ja	-	True	True
692.5	StatusFeedback_FeedbackVoltage[Vpp]	Status of feedback level			C4_3	ja	-	True	True
692.10	StatusFeedback_RefChannel	Status feedback index track			I16	nein	-	True	True
692.9	StatusFeedback_ResolverLevel	Status resolver level			C4_3	nein	-	True	True
699.4	StatusJerk_DemandValue	Status of demand jerk setpoint generator			I32	nein	-	True	True
680.8	StatusPosition_ActualY4	Status of actual position in bus format Y4	119	0x2022/0x6064	I32	ja	-	False	True
680.14	StatusPosition_FeedbackAbsolute	Feedback absolute position in feedback increments			I32	nein	-	True	True
680.20	StatusPosition_LoadControlDeviation	Position difference load-motor (unfiltered)			C4_3	nein	-	True	True
681.7	StatusSpeed_ActualFilteredY2	Status of the actual filtered speed in the Y2 format	6	0x2023	Y2	ja	-	False	True
681.8	StatusSpeed_ActualFilteredY4	Status of the actual filtered speed in the Y4 format	117	0x2024	Y4	ja	-	False	True
685.5	StatusVoltage_BusVoltageC43	Status DC bus voltage C4_3		0x6079	C4_3	ja	-	False	True

A detailed object list can be found in the corresponding online help.

8. Status values

In this chapter you can read about:

D/A-Monitor 438

A list of the status values supports you in optimization and commissioning. Open the optimization function in the C3 ServoManager (double-click on optimization in the tree)

You will find the available status values in the lower right part of the window under selection (TAB) "Status values".

You can pull them into the oscilloscope (upper part of the left side) or into the status display (upper part of the right side) by the aid of the mouse (drag and drop).

The status values are divided into 2 groups (user levels):

standard: here you can find all important status values

advanced: Advanced status values, require a better knowledge

Switching of the user level

The user level can be changed in the optimization window (left hand side lower part under selection (TAB) "optimization") with the following button.



8.1 D/A-Monitor

A part of the status values can be output via the D/A monitor channel 0 (X11/4) and channel 1 (X11/3). In the following status list under D/A monitor output: possible / not possible).

The reference for the output voltage can be entered individually in the reference unit of the status value.

Example: Output Object 2210.2: (actual speed unfiltered)

In order to get an output voltage of 10V at 3000rpm , please enter rev/s (=3000rpm) as "value of the signal at 10V".

Hint

The unit of measurement of the D/A monitor values differs from the unit of measurement of the status values.

Additional information on the topic of "status values" can be found in the online help of the device.

9. Error

Standard error reactions:

Reaction 2: Downramp with "de-energize" then apply brake (see on page 267) and finally de-energize.

For errors with standard reaction 2 the **error reaction can be changed** (see on page 314, see on page 141).

Reaction 5: de-energize immediately (without ramps), apply brake.

Caution! A Z-axis may drop down due to the brake delay times

Pending errors can be acknowledged with Quit!

Object 550.1 displays error:
value 1 means "no error".

The errors as well as the error history can be viewed in the C3 ServoManager under optimization (at the top right of the optimization window).

Detailed information on the topic of the "error list" can be found in the online help of the device.

10. Order code

In this chapter you can read about:

Order code device: Compax3	441
Order code for mains module: PSUP	442
Order code for accessories	442

10.1 Order code device: Compax3

Example: C3S025V2F10I10T10M00



Device type: Compax3

Single axis	S									--
Highpower	H									--
Multi-axis device	M									

Device currents static/dynamic; supply voltage

2.5A / 5A ; 230VAC (single phase)	S	025	V2							--
6.3 A / 12.6 A ; 230VAC (1 phase)	S	063	V2							--
10A / 20A ; 230VAC (three phase)	S	100	V2							--
15A / 30A ; 230VAC (three phase)	S	150	V2							--
1.5A / 4.5A ; 400VAC (three phase)	S	015	V4							--
3.8 A / 7.5 A ; 400VAC (3 phase)	S	038	V4							--
7.5 A / 15.0 A ; 400VAC (3 phase)	S	075	V4							--
15.0 A / 30.0 A ; 400VAC (3 phase)	S	150	V4							--
30.0 A / 60.0 A ; 400VAC (3 phase)	S	300	V4							--
50A / 75A ; 400VAC (three phase)	H	050	V4							--
90A / 135A ; 400VAC (three phase)	H	090	V4							--
125A / 187.5A ; 400VAC (three phase)*	H	125	V4							--
155A / 232.5A ; 400VAC (three phase)*	H	155	V4							--
5.0A / 10,0A ; 400VAC (three phase)	M	050	D6							
10A / 20A ; 400VAC (three phase)	M	100	D6							
15A / 30A ; 400VAC (three phase)	M	150	D6							
60A 30A / ; 400VAC (three phase)	M	300	D6							

Feedback:

Resolver										F10
SinCos© (Hiperface)										F11
Encoder, Sine-cosine with/without hall										F12

Interface:

Step/direction / analogue input										I10	T10	M00
Positioning with inputs/outputs										I11	T11	M00
Positioning via I/Os or RS232 / RS485/USB										I12		
Profibus DP V0/V1/V2 (12Mbaud)										I20		
CANopen										I21		
DeviceNet										I22		
Ethernet Powerlink										I30		
EtherCAT										I31		
Profinet										I32		
C3 powerPLmC (Multi-axis control)										C20		M00

Technology functions:

Positioning												T11
Motion control programmable according to IEC61131-3												T30
Motion control programmable according to IEC61131-3 & electronic cam extension												T40

Options:

no additional supplement												M00
Expansion 12 digital I/Os & HEDA (Motionbus)												M10
HEDA (Motionbus)												M11
Expansion, 12 digital I/Os												M12

Safety technology only C3M:


Safe torque off	M		D6									S1
Extended safety technology	M		D6									S3

*external voltage supply for ventilator fan required. Available in two versions for single phase feed:

Standard: 220/240VAC: 140W, on request: 110/120VAC: 130W

10.2 Order code for mains module: PSUP

Example: PSUP10D6USBM00



10.3 Order code for accessories

In this chapter you can read about:

Order code for feedback cables	443
Order Code braking resistors	443
Order code mains filter (C3S)	444
Order code capacitor module	444
Interface cable order code	444
Order Code input/output terminals (PIO)	445
Order note	446

Order Code connection set for Compax3S

The corresponding connection sets are furnished with the device.

for C3S0xxV2	ZBH 02/01	ZBH	0 2	/	0 1			
for C3S0xxV4 / S150V4 / S1xxV2	ZBH 02/02	ZBH	0 2	/	0 2			
for C3S300V4	ZBH 02/03	ZBH	0 2	/	0 3			

Order code for PSUP/Compax3M connection set

The corresponding connection sets are furnished with the device.

for C3M050D6, C3M100D6, C3M150D6	ZBH 04/01	ZBH	0 4	/	0 1			
for C3M300D6	ZBH 04/02	ZBH	0 4	/	0 2			
for PSUP10	ZBH 04/03	ZBH	0 4	/	0 3			
PSUP20, PSUP30	ZBH 04/04	ZBH	0 4	/	0 4			

10.3.1. Order code for feedback cables

for resolver ⁽²⁾	for MH / SMH motors		REK	4 2 / ⁽¹⁾
for resolver ⁽²⁾	for MH / SMH motors	(cable chain compatible)	REK	4 1 / ⁽¹⁾
for SinCos© – feedback ⁽²⁾	for MH / SMH motors	(cable chain compatible)	GBK	2 4 / ⁽¹⁾
for EnDat 2.1 ⁽²⁾	for MH / SMH motors	(cable chain compatible)	GBK	3 8 / ⁽¹⁾
for EnDat 2.2 ⁽²⁾	for MH / SMH motors	(cable chain compatible)	GBK	5 6 / ⁽¹⁾
Encoder – Compax3			GBK	2 3 / ⁽¹⁾
for LXR linear motors		(cable chain compatible)	GBK	3 3 / ⁽¹⁾
for BLMA linear motors		(cable chain compatible)	GBK	3 2 / ⁽¹⁾

^(x) **Note on cable** (see on page 446)

Motor cable order code ⁽²⁾

for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A)		MOK	5 5 / ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A)	(cable chain compatible)	MOK	5 4 / ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A)		MOK	5 6 / ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A)	(cable chain compatible)	MOK	5 7 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A)		MOK	6 0 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A)	(cable chain compatible)	MOK	6 3 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A)		MOK	5 9 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A)	(cable chain compatible)	MOK	6 4 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(6mm ² ; up to 32.3A)	(cable chain compatible)	MOK	6 1 / ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(10mm ² ; up to 47.3A)	(cable chain compatible)	MOK	6 2 / ⁽¹⁾

^(x) **Note on cable** (see on page 446)

10.3.2. Order Code braking resistors

Order Code braking resistors

for C3S063V2 or C3S075V4	56Ω / 0.18kW _{cont.}		BRM	0 5 / 0 1	
for C3S075V4	56Ω / 0.57kW _{cont.}		BRM	0 5 / 0 2	
for C3S025V2 or C3S038V4	100Ω / 60W _{cont.}		BRM	0 8 / 0 1	
for C3S150V4	47Ω / 0.57kW _{cont.}		BRM	1 0 / 0 1	
for C3S150V2, C3S300V4 and PSUP20D6	4/01:15Ω / 0.57kW _{cont.} 4/02:15Ω / 0.74kW _{cont.}		BRM	0 4 / 0 ...	
for C3S300V4 and PSUP20D6	4/03:15Ω / 1.5kW _{cont.}				
for C3S100V2	22Ω / 0.45kW _{cont.}		BRM	0 9 / 0 1	
for C3H0xxV4	27Ω / 3.5kW _{cont.}		BRM	1 1 / 0 1	
for PSUP10D6 and PSUP20D6 / PSUP30D6 (2x30Ω parallel)	30Ω / 0.5kW _{cont.}		BRM	1 3 / 0 1	
for PSUP10D6 (2x15Ω in series), PSUP20D6, PSUP30D6	15Ω / 0.5kW _{cont.}		BRM	1 4 / 0 1	
for C3H1xxV4, PSUP30D6	18Ω / 4.5kW _{cont.}		BRM	1 2 / 0 1	

10.3.3. Order code mains filter (C3S)

Order code mains filter Compax3S

for C3S025V2 or S063V2	NFI	0	1	/	0 1
for C3S0xxV4, S150V4 or S1xxV2	NFI	0	1	/	0 2
for C3S300V4	NFI	0	1	/	0 3

Order code mains filter Compax3H

for C3H050V4	NFI	0	2	/	0 1
for C3H090V4	NFI	0	2	/	0 2
for C3H1xxV4	NFI	0	2	/	0 3

Order Code mains filter PSUP

for PSUP10	Reference axis combination 3x480V 25A 6x10m motor cable length	NFI	0	3	/ 0 1
for PSUP10	Reference axis combination 3x480V 25A 6x50m motor cable length	NFI	0	3	/ 0 2
for PSUP20 & PSUP30	Reference axis combination 3x480V 50A 6x50m motor cable length	NFI	0	3	/ 0 3

Order code for mains filters

for PSUP30	Mains filter	LCG-0055-0.45 mH
for PSUP30	Mains filter with UL approval	LCG-0055-0.45 mH-UL

Order code for motor output filter (for Compax3S, Compax3M >20m motor cable)

up to 6,3 A rated motor current	MDR	0	1	/	0 4
Up to 16 A rated motor current	MDR	0	1	/	0 1
Up to 30A A rated motor current	MDR	0	1	/	0 2

10.3.4. Order code capacitor module

Order code capacitor module

for C3S300V4	1100µF	Module			C4

10.3.5. Interface cable order code

Order code for interface cables and connectors

PC – Compax3 (RS232)	SSK	0 1 /	⁽¹⁾
PC – PSUP (USB)	SSK	3 3 /	
on X11 (Ref/Analog) and X13 with C3F001D2	SSK	2 1 /	⁽¹⁾
on X12 / X22 (digital I/Os)	SSK	2 2 /	⁽¹⁾
on X11 (Ref /Analog)	SSK	2 3 /	⁽¹⁾
on X12 / X22 (digital I/Os)	SSK	2 4 /	⁽¹⁾
PC ⇔ POP (RS232)	SSK	2 5 /	⁽¹⁾
Compax3 ⇔ POP (RS485) for several C3H on request	SSK	2 7 /	⁽⁶⁾
Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC					
Compax3 I30 ⇔ Compax3 I30 or C3M-multi-axis communication	SSK	2 8 /	⁽⁵⁾
Profinet, EtherCAT, Ethernet Powerlink					
Compax3 X11 ⇔ Compax3 X11 (encoder coupling of 2 axes)	SSK	2 9 /	⁽¹⁾
Compax3 X10 ⇔ Modem	SSK	3 1 /	
Compax3H adapter cable ⇔ SSK01 (length 15cm, delivered with the device)	SSK	3 2 / 2	0	0	
Compax3H X10 RS232 connection control ⇔ Programming interface (delivered with the device)	VBK	1 7 / 0	1	1	
Bus terminal connector (for the 1st and last Compax3 in the HEDA Bus/or multi-axis system)	BUS	0 7 / 0	1	1	
Profibus cable ⁽²⁾	SSL	0 1	⁽⁷⁾
Profibus connector	BUS	0 8 / 0	1	1	
CAN bus cable ⁽²⁾	SSL	0 2	⁽⁷⁾
CAN bus connector	BUS	1 0 / 0	1	1	

^(x) Note on cable (see on page 446)

Order Code operating module

Operating module (for Compax3S and Compax3F)	BDM	0 1 / 0	1	1	

Order Code terminal block

for I/Os without luminous indicator	EAM	0 6 / 0	1	1	
for I/Os with luminous indicator	EAM	0 6 / 0	2	2	

10.3.6. Order Code input/output terminals (PIO)

Order Code decentralized input terminals

PIO 2DI 24VDC 3.0ms	PIO	4 0 0			
PIO 4DI 24VDC 3.0ms	PIO	4 0 2			
PIO 8DI 24VDC 3.0ms	PIO	4 3 0			
PIO 2AI DC ±10V differential input	PIO	4 5 6			
PIO 4AI 0-10VDC S.E.	PIO	4 6 8			
PIO 2AI 0-20mA differential input	PIO	4 8 0			

Order Code decentralized output terminals

PIO 2DO 24VDC 0.5A	2 channel digital output terminal (output voltage 0.5A)	PIO	5	0	1	
PIO 4DO 24VDC 0.5A	4 channel digital output terminal (output voltage 0.5A)	PIO	5	0	4	
PIO 8DO 24VDC 0.5A	8 channel digital output terminal (output voltage 0.5A)	PIO	5	3	0	
PIO 2AO 0-10VDC	2 channel analog output terminal (0-10V signal voltage)	PIO	5	5	0	
PIO 2AO 0-20mA	2-channel analog output terminal (0-20mA signal voltage)	PIO	5	5	2	
PIO 2AO DC ±10V	2-channel analog output terminal (±10V signal voltage)	PIO	5	5	6	

Order Code CANopen Fieldbus Coupler

CANopen Standard	max. Vectorial sum current for bus terminals 1650mA at 5V	PIO	3	3	7	
CANopen ECO	max. Vectorial sum current for bus terminals 650mA at 5V	PIO	3	4	7	

10.3.7. Order note

¹ Length code 1

Length [m]	1.0	2.5	5.0	7.5	10.0	12.5	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0
Code	01	02	03	04	05	06	07	08	09	10	11	12	13	14

Other adaptation can be developed on request!

Example:

SSK01/09: Length 25m

² Colors according to DESINA

³ with motor connector

⁴ with cable eye for motor terminal box

⁵ length code 2 for SSK28

Length [m]	0.17	0.25	0.5	1.0	3.0	5.0	10.0
Order code	23	20	21	01	22	03	05

⁶ Order code: **SSK27/nn/..**

Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)

Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)

Number n (the last two digits)

Examples include:

SSK27/05/.. for connecting from Pop to 5 Compax3.

SSK27/01/.. for connecting from Pop to one Compax3

MOK55 and MOK54 can also be used for linear motors LXR406, LXR412 and BLMA.

⁷ sold by the meter: Length in meters (order in number of items)

⁸ Note on cable (see on page 446)

11. Compax3 Accessories

In this chapter you can read about:

Parker servo motors	447
EMC measures	450
Connections to the motor	458
External braking resistors	463
Capacitor module C4	476
Operator control module BDM	477
EAM06: terminal block for inputs and outputs	477
Interface cable	480
Options M1x	485
Profibus plug BUS08/01	490
CAN - plug BUS10/01	491
PIO: External Inputs/Outputs	492

11.1 Parker servo motors

In this chapter you can read about:

Direct drives	447
Rotary servo motors	449

11.1.1. Direct drives

In this chapter you can read about:

Transmitter systems for direct drives	448
Linear motors	449
Torque motors	449

11.1.1.1 Transmitter systems for direct drives

The Feedback option F12 makes it possible to operate linear motors as well as torque motors. Compax3 supports the following transmitter systems:

Special Feedback Systems	Option F12
Analog hall sensors	<ul style="list-style-type: none"> ◆ Sine-Cosine signal (max. 5Vpp*; typical 1Vpp) 90° offset ◆ U-V signal (max. 5Vpp*; typical 1Vpp) 120° offset.
Encoder (linear or rotary)	<ul style="list-style-type: none"> ◆ Sine-Cosine (max. 5Vpp*; typical 1Vpp) (max. 400kHz) or ◆ TTL (RS422) (max. 5MHz; track A or B) ◆ Bypass function for encoder signals (limit frequency** 5MHz, track A or B) with the following modes of commutation: <ul style="list-style-type: none"> ◆ Automatic commutation (see on page 448) or ◆ U, V, W or R, S, T commutation signals (NPN open collector) e.g. digital hall sensors, incremental encoders made by Hengstler (F series with electrical ordering variant 6)
EnDat*** with incremental (Sine - Cosine) track	<ul style="list-style-type: none"> ◆ EnDat 2.1 or EnDat 2.2 (Endat01, Endat02) feedback ◆ linear or rotary ◆ max. 400kHz Sine-Cosine
EnDat 2.2*** (fully digital)	<ul style="list-style-type: none"> ◆ EnDat 2.2 (Endat01, Endat02) feedback ◆ linear or rotary ◆ max. Cable length: 25 m
EnDat2.1*** (fully digital)	<ul style="list-style-type: none"> ◆ EnDat 2.1 without incremental track ◆ Supported types: EQI11xx, ECI11xx, ECI11x ◆ max. Cable length: 90 m
Distance coded feedback systems	<ul style="list-style-type: none"> ◆ Distance coding with 1 VSS interface ◆ Distance coding with RS422 - Interface (Encoder)

*Max. differential input between SIN- (X13/7) and SIN+ (X13/8).

** Limit frequency = 1MHz for Compax3M (higher bandwidths on request)

*** Digital, bidirectional interface

The motor performs automatic commutation after:

- ◆ Power on,
- ◆ A configuration download or
- ◆ An IEC program download

The time duration (typically 5-10 sec) of automatic commutation can be optimized with the start current (see in the optimization display of the C3 ServoManager; given as a percentage of the reference current). Note that values that are too high will cause Error 0x73A6 to be triggered.

Typically the motor moves by 4% of the pitch length or, with rotary direct drives 4% of 360°/number of pole pairs - maximum 50%.

Note the following conditions for automatic commutation

- ◆ During automatic commutation the end limits are not monitored.
- ◆ Actively working load torques are not permitted during automatic commutation.
- ◆ Static friction deteriorates the effect of automatic commutation.
- ◆ With the exception of missing commutation information, the controller/motor combination is configured and ready for operation (parameters correctly assigned for the linear motor/drive). The transmitter and the direction of the field of rotation in effect must match.
- ◆ The auto-commutating function must be adapted to fit the mechanics if necessary during commissioning.

11.1.1.2 Linear motors

Parker offers you a number of systems of linear motor drives:

Linear motors	Feed force (continuous/dynamic)	Stroke length:
LMDT ironless linear servo motors:	26 ... 1463N	almost any
LMI iron-cored linear servo motors:	52 ... 6000N	64 ... 999mm
LXR Series Linear Motors	315N / 1000N	up to 3m
Linear motor module BLMA:	605N / 1720N	up to 6m

11.1.1.3 Torque motors

Parker offers you an extensive range of torque motors that can be adapted to your application. Please contact us for information.

Additional information can be found on the **Internet** <http://www.parker.com/eme> in the direct drives section.

11.1.2. Rotary servo motors

Parker offers you an extensive range of servo motors that can be adapted to your application. Please contact us for information.

Additional information can be found on the **Internet** <http://www.parker.com/eme/smh> or on the DVD supplied in the documentations file.

Suitable servo motors for Compax3H are available on request!

11.2 EMC measures

In this chapter you can read about:

Mains filter.....	450
Motor output filter.....	455
Mains chokes	457

11.2.1. Mains filter

For radio disturbance suppression and for complying with the emission limit values for CE conform operation we offer mains filters:

Observe the maximum permitted length of the connection between the mains filter and the device:

- ◆ unshielded <0.5m;
- ◆ shielded: <5m (fully shielded on ground e.g. ground of control cabinet)

Order code mains filter Compax3S

for C3S025V2 or S063V2	NFI	0	1	/	0	1		
for C3S0xxV4, S150V4 or S1xxV2	NFI	0	1	/	0	2		
for C3S300V4	NFI	0	1	/	0	3		

Order Code mains filter PSUP

for PSUP10	Reference axis combination 3x480V 25A 6x10m motor cable length	NFI	0	3	/	0	1	
for PSUP10	Reference axis combination 3x480V 25A 6x50m motor cable length	NFI	0	3	/	0	2	
for PSUP20 & PSUP30	Reference axis combination 3x480V 50A 6x50m motor cable length	NFI	0	3	/	0	3	

Order code for mains filters

for PSUP30	Mains filter	LCG-0055-0.45 mH
for PSUP30	Mains filter with UL approval	LCG-0055-0.45 mH-UL


Order code mains filter Compax3H

for C3H050V4	NFI	0	2	/	0	1		
for C3H090V4	NFI	0	2	/	0	2		
for C3H1xxV4	NFI	0	2	/	0	3		

11.2.1.1 Mains filter NFI01/01

for Compax3 S025 V2 and Compax3 S063 V2


Dimensional drawing:



11.2.1.2 Mains filter NFI01/02

for Compax3 S0xx V4, Compax3 S150 V4 and Compax3 S1xx V2

Dimensional drawing:




Stated in mm

11.2.1.3 Mains filter for NFI01/03

for Compax3 S300

Dimensional drawing:




Stated in mm

11.2.1.4 Mains filter NFI02/0x

Filter for mounting below the Compax3 Hxxx V4 housing

Dimensional drawing:




	Filter type	Dimensions				Fixing Centers			Distances		Weight	Grounding clamp	Connection clamp
		W	H2	H	D	W1	H1	D1	BFU	HFU			
		mm				mm			mm		kg		
C3H050V4	NFI02/01	233	515	456	70	186	495	40	150	440	4.3	M6	16mm ²
C3H090V4	NFI02/02	249	715	649	95	210	695	40	150	630	8.5	M8	50mm ²
C3H1xxV4	NFI02/03	249	830	719	110				150	700	15.0	M10	95mm ²

11.2.1.5 Mains filter NFI03/01 & NFI03/03


for PSUP10D6 and PSUP20D6

Dimensional drawing:


Bottom view




Side view



Front view



Top view




Filter type	A	B	C	D	I	F	G	H	Weight	GND(I)	Connection clamp
									kg		
NFI03/01	240	50	85	270	0.8	30	255	5.4	1.5	M5	10mm ²
NFI03/03	220	85	90	250	1.0	60	235	5.4	2.4	M6	16mm ²

Stated in mm

11.2.1.6 Mains filter NFI03/02

for PSUP10D6

Dimensional drawing:



11.2.2. Motor output filter

We offer motor output filters for disturbance suppression when the motor connecting cables are long (>20m):

Order code for motor output filter (for Compax3S, Compax3M >20m motor cable)

up to 6,3 A rated motor current	MDR	0	1	/	0 4
Up to 16 A rated motor current	MDR	0	1	/	0 1
Up to 30A A rated motor current	MDR	0	1	/	0 2

Larger motor output filters are available on request!


In this chapter you can read about:

Motor output filter MDR01/04	455
Motor output filter MDR01/01	455
Motor output filter MDR01/02	456
Wiring of the motor output filter	456

11.2.2.1 Motor output filter MDR01/04

up to 6.3A nominal motor current (3.6mH)

Dimensional drawing:




Stated in mm

11.2.2.2 Motor output filter MDR01/01

Up to 16 A nominal motor current (2mH)

Dimensional drawing:




Stated in mm

11.2.2.3 Motor output filter MDR01/02

up to 30A nominal motor current (1.1mH)


Dimensional drawing:



Weight: 5.8kg

Stated in mm

11.2.2.4 Wiring of the motor output filter



11.2.3. Mains chokes

Mains filters serve for reducing the low-frequency interferences on the mains side.


11.2.3.1 Mains filter for PSUP30

Required mains filter for the PSUP30: 0.45 mH / 55 A


We offer the following mains filters:

- ◆ LCG-0055-0.45 mH (WxDxH: 180 mm x 140 mm x 157 mm; 10 kg)
- ◆ LCG-0055-0.45 mH-UL (with UL approval) (WxDxH: 180 mm x 170 mm x 157 mm; 15 kg)

Dimensional drawing: LCG-0055-0.45 mH



Dimensional drawing: LCG-0055-0.45 mH-UL



11.3 Connections to the motor

Under the designation "REK.." (resolver cables) and "MOK.."(motor cables) we can deliver motor connecting cables in various lengths to order. If you wish to make up your own cables, please consult the cable plans shown below:

Motor cable order code ⁽²⁾

for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A)	MOK	5	5	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	5	4	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A)	MOK	5	6	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	5	7	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A)	MOK	6	0	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	6	3	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A)	MOK	5	9	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	6	4	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(6mm ² ; up to 32.3A) (cable chain compatible)	MOK	6	1	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(10mm ² ; up to 47.3A) (cable chain compatible)	MOK	6	2	/ ⁽¹⁾

^(x) **Note on cable** (see on page 446)

for resolver ⁽²⁾	for MH / SMH motors	REK	4	2	/ ⁽¹⁾
for resolver ⁽²⁾	for MH / SMH motors (cable chain compatible)	REK	4	1	/ ⁽¹⁾
for SinCos© – feedback ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	2	4	/ ⁽¹⁾
for EnDat 2.1 ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	3	8	/ ⁽¹⁾
for EnDat 2.2 ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	5	6	/ ⁽¹⁾
Encoder – Compax3		GBK	2	3	/ ⁽¹⁾
for LXR linear motors	(cable chain compatible)	GBK	3	3	/ ⁽¹⁾
for BLMA linear motors	(cable chain compatible)	GBK	3	2	/ ⁽¹⁾


^(x) **Note on cable** (see on page 446)

In this chapter you can read about:

Resolver cable.....	459
SinCos© cable.....	460
EnDat cable.....	460
Motor cable.....	461
Encoder cable	462

11.3.1. Resolver cable


REK42/..



The same cable (with changed conductor coloring) is available under the designation REK41/.. in a version which is suitable for cable chain systems. You can find the length code in the Chapter **Order Code Accessories** (see on page 442).

11.3.2. SinCos© cable


GBK24/...: Cable chain compatible



You can find the length code in the Chapter **Order Code Accessories** (see on page 442).

11.3.3. EnDat cable

GBK38/...: (cable chain compatible) for EnDat2.1




GBK56/...: (cable chain compatible) for EnDat2.2 (cable plan on request)
 You will find the length code in the **accessories order code** (see on page 442).

11.3.4. Motor cable

Cross-section / max. permanent load	Motor connector SMH motors MH56, MH70, MH105		Motor terminal box MH145, MH205	
	standard	cable chain compatible	standard	cable chain compatible
1.5 mm ² / up to 13.8 A	MOK55	MOK54	MOK60	MOK63
2.5 mm ² / up to 18.9 A	MOK56	MOK57	MOK59	MOK64
6 mm ² / up to 32.3 A	-	-	-	MOK61
10 mm ² / up to 47.3 A		--	-	MOK62

11.3.4.1 Connection of terminal box MH145 & MH205




Terminal	Assignment
A	Phase U
B	Phase V
C	Phase W
E	Protective earth terminal
F	Brake (+ red for MH205)
G	Brake (- blue for MH205)

Additional designations can be found on the connection cable clamping board - motor (internal).

11.3.5. Encoder cable

GBK23/...: Connection Compax3 - Encoder



You can find the length code in the **Order Code Accessories** (see on page 442)

11.4 External braking resistors



Danger!

Hazards when handling ballast resistors!

Housing temperature up to 200°C!

Dangerous voltage!

The device may be operated only in the mounted state!

The external braking resistors must be installed such that protection against contact is ensured (IP20).

Install the connecting leads at the bottom.

The braking resistors must be grounded.

We recommend to use a thrust washer for the BRM13 and BRM14.

Observe the instructions on the resistors (warning plate).

Please note that the length of the supply cable must not exceed 2m!

In this chapter you can read about:

Permissible braking pulse powers of the braking resistors 464

Dimensions of the braking resistors 473

Ballast resistors Compax3

Ballast resistor (see on page 463)	Device	Nominal Power
BRM08/01 (100 Ω)	Compax3S025V2 Compax3S015V4 Compax3S038V4	60 W
BRM05/01 (56 Ω)	Compax3S063V2 Compax3S075V4	180 W
BRM05/02 (56 Ω)	Compax3S075V4	570 W
BRM10/01 (47 Ω)	Compax3S150V4	570 W
BRM10/02 (47 Ω)	Compax3S150V4	1500 kW
BRM04/01 (15 Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	570 W
BRM04/02 (15 Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	740 W
BRM04/03 (15 Ω)	Compax3S300V4 PSUP20D6	1500 W
BRM09/01 (22 Ω)	Compax3S100V2	570 W
BRM11/01 (27 Ω)	Compax3H0xxV4	3500 W
BRM13/01 (30 Ω)	PSUP10D6 PSUP20D6** PSUP30D6**	500 W
BRM14/01 (15 Ω)	PSUP10D6* PSUP20D6 PSUP30D6	500 W
BRM12/01 (18 Ω)	Compax3H1xxV4 PSUP30D6	4500 W

*for PSUP10D6 2x15Ω in series

**for PSUP20D6 and PSUP30D6 2x30Ω parallel


11.4.1. Permissible braking pulse powers of the braking resistors

In this chapter you can read about:

Calculation of the BRM cooling time	464
Permissible braking pulse power: BRM08/01 with C3S015V4 / C3S038V4	465
Permissible braking pulse power: BRM08/01 with C3S025V2	466
Permissible braking pulse power: BRM09/01 with C3S100V2	466
Permissible braking pulse power: BRM10/01 with C3S150V4	467
Permissible braking pulse power: BRM10/02 with C3S150V4	467
Permissible braking pulse power: BRM05/01 with C3S063V2	468
Permissible braking pulse power: BRM05/01 with C3S075V4	468
Permissible braking pulse power: BRM05/02 with C3S075V4	469
Permissible braking pulse power: BRM04/01 with C3S150V2	469
Permissible braking pulse power: BRM04/01 with C3S300V4	470
Permissible braking pulse power: BRM04/02 with C3S150V2	470
Permissible braking pulse power: BRM04/02 with C3S300V4	471
Permissible braking pulse power: BRM04/03 with C3S300V4	471
Permissible braking pulse power: BRM11/01 with C3H0xxV4	472
Permissible braking pulse power: BRM12/01 with C3H1xxV4	472
Permissible braking pulse power: BRM13/01 with PSUP10D6	473
Permissible braking pulse power: BRM14/01 with PSUP10D6	473

The diagrams show the permissible braking pulse powers of the braking resistors in operation with the assigned Compax3.

11.4.1.1 Calculation of the BRM cooling time



F = Factor

Cooling time = F * braking time

Example 1: For a braking time of 1s, a braking power of 1kW is required. The

Diagram shows the following:

The required values can be found in the range between characteristic F = 0.5 and F = 1. In order to achieve operating safety, please select the higher factor, this means that the required cooling time is 1s.

$$F * \text{Braking time} = \text{cooling time}$$

$$1 * 1s = 1s$$


Example 2: For a braking time of 0.5s, a braking power of 3kW is required. The Diagram shows the following:

The required values can be found in the range between characteristic F = 2 and F = 5. In order to achieve operating safety, please select the higher factor, this means that the required cooling time is 2.5s.


$$F * \text{Braking time} = \text{cooling time}$$

$$5 * 0.5s = 2.5s$$


11.4.1.2 Permissible braking pulse power: BRM08/01 with C3S015V4 / C3S038V4




11.4.1.3 Permissible braking pulse power: BRM08/01 with C3S025V2




11.4.1.4 Permissible braking pulse power: BRM09/01 with C3S100V2




11.4.1.5 Permissible braking pulse power: BRM10/01 with C3S150V4




11.4.1.6 Permissible braking pulse power: BRM10/02 with C3S150V4




11.4.1.7 Permissible braking pulse power: BRM05/01 with C3S063V2




11.4.1.8 Permissible braking pulse power: BRM05/01 with C3S075V4




11.4.1.9 Permissible braking pulse power: BRM05/02 with C3S075V4




11.4.1.10 Permissible braking pulse power: BRM04/01 with C3S150V2




11.4.1.11 Permissible braking pulse power: BRM04/01 with C3S300V4




11.4.1.12 Permissible braking pulse power: BRM04/02 with C3S150V2




11.4.1.13 Permissible braking pulse power: BRM04/02 with C3S300V4




11.4.1.14 Permissible braking pulse power: BRM04/03 with C3S300V4



11.4.1.15 Permissible braking pulse power: BRM11/01 with C3H0xxV4



11.4.1.16 Permissible braking pulse power: BRM12/01 with C3H1xxV4



11.4.1.17 **Permissible braking pulse power: BRM13/01 with PSUP10D6**

on request

11.4.1.18 **Permissible braking pulse power: BRM14/01 with PSUP10D6**

on request


11.4.2. Dimensions of the braking resistors

In this chapter you can read about:

BRM8/01braking resistors.....	473
BRM5/01 braking resistor	473
Braking resistor BRM5/02, BRM9/01 & BRM10/01	474
Braking resistor BRM4/0x and BRM10/02.....	474
Braking resistor BRM11/01 & BRM12/01	475
Ballast resistor BRM13/01 & BRM14/01	475

11.4.2.1 **BRM8/01braking resistors**


Dimensional drawing:



Stated in mm

11.4.2.2 **BRM5/01 braking resistor**


Dimensional drawing:



Stated in mm


11.4.2.3 Braking resistor BRM5/02, BRM9/01 & BRM10/01

Dimensional drawing:



11.4.2.4 Braking resistor BRM4/0x and BRM10/02

Dimensional drawing:




1: thermal overcurrent relay

		BRM4/01	BRM4/02	BRM4/03 & BRM10/02
A	mm	250	300	540
B	mm	330	380	620
C	mm	64	64	64

11.4.2.5 Braking resistor BRM11/01 & BRM12/01


Dimensional drawing:



		BRM11/01	BRM12/02
W	mm	330	
W1	mm	295	
W2	mm	270	
H	mm	260	
Weight	kg	6.0	7.0

11.4.2.6 Ballast resistor BRM13/01 & BRM14/01

Dimensional drawing:



11.5 Capacitor module C4

Order code capacitor module


Module	C4

for C3S300V4


1100µF

Technical Data

Type	Capacity	Cable length
Module C4	1100µF	~30 cm



Module C4	A	B	C	C1	D	I	F	G	H
	mm								
	430	190	90	120	370	15	18	30	∅6



11.6 Operator control module BDM

Order Code operating module

			/		
BDM	0	1	/	0	1

Operating module (for Compax3S and Compax3F)

Flexible service and maintenance



Functions:

- ◆ Mobile or stationary handling: can remain on the unit for display and diagnostic purposes, or can be plugged into any unit.
- ◆ Can be plugged in while in operation
- ◆ Power supply via Compax3 servo control
- ◆ Display with 2 times 16 places.
- ◆ Menu-driven operation using 4 keys.
- ◆ Displays and changing of values.
- ◆ Display of Compax3 messages.
- ◆ Duplication of device properties and IEC61131-3 program to another Compax3 with identical hardware.
- ◆ Additional information can be found in the BDM manual This can be found on the Compax3 CD or on our Homepage: **BDM-manual** (http://divapps.parker.com/divapps/EME/EME/Literature_List/dokumentation/BDM.pdf).

11.7 EAM06: terminal block for inputs and outputs

Order Code terminal block

			/		
EAM	0	6	/	0	1

for I/Os without luminous indicator

for X11, X12, X22

for I/Os with luminous indicator

for X12, X22

EAM 0 6 / 0 2


The terminal block EAM06/.. can be used to route the Compax3 plug connector X11 or X12 for further wiring to a terminal strip and to a Sub-D plug connector.

Via a supporting rail (Design: or) the terminal unit can be attached to a mounting rail in the switch cabinet.

EAM06/ is available in 2 variants:

- ◆ EAM06/01: Terminal block for X11, X12, X22 without luminous indicator
 - ◆ EAM06/02: Terminal block for X12, X22 with luminous indicator
- Corresponding connecting cables EAM06 - Compax3 are available:
- ◆ from X11 - EAM06/01: SSK23/..
 - ◆ from X12, X22 - EAM06/xx: SSK24/..


EAM6/01: Terminal block without luminous indicator for X11, X12 or X22



Width: 67.5mm

Figure similar


EAM6/02: Terminal block with luminous indicator for X12, X22




Width: 67.5mm

Figure similar

Cable plan SSK23/...: X11 to EAM 06/01



Cable plan SSK24/...: X12 to EAM 06/xx



11.8 Interface cable

In this chapter you can read about:

RS232 - cable / SSK1	480
RS485 cable to Pop / SSK27	481
I/O-interface X12 / X22 / SSK22	482
Ref X11 / SSK21	482
Encoder coupling of 2 Compax3 axes / SSK29.....	483
Modem cable SSK31	484
Adapter cable SSK32/20	484

Order code for interface cables and connectors

PC – Compax3 (RS232)	SSK	0	1	/ ⁽¹⁾
PC – PSUP (USB)	SSK	3	3	/
on X11 (Ref/Analog) and X13 with C3F001D2	SSK	2	1	/ ⁽¹⁾
on X12 / X22 (digital I/Os)	SSK	2	2	/ ⁽¹⁾
on X11 (Ref /Analog)	SSK	2	3	/ ⁽¹⁾
on X12 / X22 (digital I/Os)	SSK	2	4	/ ⁽¹⁾
PC ⇔ POP (RS232)	SSK	2	5	/ ⁽¹⁾
Compax3 ⇔ POP (RS485) for several C3H on request	SSK	2	7	/	.. / ... ⁽⁶⁾
Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC Compax3 I30 ⇔ Compax3 I30 or C3M-multi-axis communication Profinet, EtherCAT, Ethernet Powerlink	SSK	2	8	/	.. / ... ⁽⁵⁾
Compax3 X11 ⇔ Compax3 X11 (encoder coupling of 2 axes)	SSK	2	9	/ ⁽¹⁾
Compax3 X10 ⇔ Modem	SSK	3	1	/
Compax3H adapter cable ⇔ SSK01 (length 15cm, delivered with the device)	SSK	3	2	/	2 0
Compax3H X10 RS232 connection control ⇔ Programming interface (delivered with the device)	VBK	1	7	/	0 1
Bus terminal connector (for the 1st and last Compax3 in the HEDA Bus/or multi-axis system)	BUS	0	7	/	0 1
Profibus cable ⁽²⁾	SSL	0	1	 ⁽⁷⁾
Profibus connector	BUS	0	8	/	0 1
CAN bus cable ⁽²⁾	SSL	0	2	 ⁽⁷⁾
CAN bus connector	BUS	1	0	/	0 1


^(x) **Note on cable** (see on page 446)

11.8.1. RS232 - cable / SSK1

SSK1/..

X10 <---

--->PC




7 x 0,25mm + Schirm/Shield

You will find the length code in the **accessories order code** (see on page 442).

11.8.2. RS485 cable to Pop / SSK27

SSK27: Connection Pop - Compax3 - Compax3 - ...



R21 = 220 Ohm

⁽⁶⁾ **Order code: SSK27/nn/..**

Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)

Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)

Number n (the last two digits)


Examples include:

SSK27/05/.. for connecting from Pop to 5 Compax3.

SSK27/01/.. for connecting from Pop to one Compax3

11.8.3. I/O-interface X12 / X22 / SSK22


SSK22/...: Cable for X12 / X22 with flying leads



You will find the length code in the **accessories order code** (see on page 442).

11.8.4. Ref X11 / SSK21


SSK21/...: Cable for X11 with flying leads



You will find the length code in the **accessories order code** (see on page 442).


11.8.5. Encoder coupling of 2 Compax3 axes / SSK29

SSK29/...: Cable from Compax3 X11 to Compax3 X11




Schirm großflächig auf Gehäuse legen
Place sheath over large area of housing


Schirm großflächig auf Gehäuse legen
Place sheath over large area of housing



- 1 NC
- 2 NC
- 3 NC
- 4 NC
- 5 NC
- 9 NC
- 10 NC
- 11 NC
- 15 NC



- NC 1
- NC 2
- NC 3
- NC 4
- NC 5
- NC 9
- NC 10
- NC 11
- NC 15




You will find the length code in the **accessories order code** (see on page 442).


Compax3 HEDA ↔ Compax3 HEDA or PC ↔ C3powerPLmC
Compax3 I30 ↔ Compax3 I30 or C3M-multi axis communication

Profinet, EtherCAT, Ethernet Powerlink

Layout of SSK28:




Schirm großflächig auf Gehäuse legen
Place sheath over large area of housing



11.8.6. Modem cable SSK31


SSK31/..



You can find the length code in the **Order Code Accessories** (see on page 442)

11.8.7. Adapter cable SSK32/20

SSK32/20



11.9 Options M1x

In this chapter you can read about:

Input/output option M12	485
HEDA (motion bus) - Option M11	486
Option M10 = HEDA (M11) & I/Os (M12).....	487
Analog current inputs and voltage inputs (Option M21).....	488

11.9.1. Input/output option M12


An optional input/output extension is available for Compax3. This option is named M12 and offers 12 digital 24V inputs/outputs (Ports) on X22.

The use of the option as inputs or outputs is programmable in groups of 4 (via the object 133.4).

The outputs are written via the object 133.3 "Output word for the I/O option"; this applies only for the ports defined as output.

The inputs are read via the object 121.2 " Input word for the I/O option"; all ports are being read, also the outputs.

11.9.1.1 Assignment of the X22 connector



Pin X22/	Input/output	I/O /X22 High density/Sub D	Access via IEC module:
1	n.c.	factory use	
2	O0/I0	Output 0 / Input 0 - adjustable	C3_IOAddition_0 (see on page 317)
3	O1/I1	Output 1 / Input 1 - adjustable	
4	O2/I2	Output 2 / Input 2 - adjustable	
5	O3/I3	Output 3 / Input 3 - adjustable	
6	O4/I4	Output 4 / Input 4 - adjustable	C3_IOAddition_1 (see on page 317)
7	O5/I5	Output 5 / Input 5 - adjustable	
8	O6/I6	Output 6 / Input 6 - adjustable	
9	O7/I7	Output 7 / Input 7 - adjustable	
10	O8/I8	Output 8 / Input 8 - adjustable	C3_IOAddition_2 (see on page 318) (not 24VDC)
11	I	24 VDC power supply	
12	O9/I9	Output 9 / Input 9 - adjustable	
13	O10/I10	Output 10 / Input 10 - adjustable	
14	O11/I11	Output 11 / Input 11 - adjustable	
15	I	GND24V	

The assignment can be adjusted.
 All inputs and outputs have 24V level.
 Maximum load on an output: 100mA


Maximum capacitive load: 50nF (max. 4 Compax3 inputs)

Caution! The 24VDC power supply (X22/11) must be supplied from an external source and must be protected by a 1.2A delayed fuse!


Connections of digital inputs and outputs M10 & M12

Input wiring of digital inputs
SPS/PLC

Compax3




Output wiring of digital outputs
Compax3



The outputs are short circuit proof; a short circuit generates an error.

F1: Quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

11.9.2. HEDA (motion bus) - Option M11



	RJ45 (X20)	RJ45 (X21)
Pin	HEDA in	HEDA out
1	Rx	Tx
2	Rx/	Tx/
3	Lx	Lx
4	-	factory use
5	-	factory use
6	Lx/	Lx/
7	-	factory use
8	-	factory use

Function of the HEDA LEDs

Green LED (left)

HEDA module energized

Red LED (right)

Error in the receive area


Possible causes:

- ◆ at the Master
 - ◆ no slave sending back
 - ◆ Wrong cabling
 - ◆ Terminal plug is missing
 - ◆ several masters are sending in the same slot
- ◆ at the slave
 - ◆ several masters in the system
 - ◆ no master active
 - ◆ Terminal plug is missing
 - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)



Layout of SSK28 (see on page 444, see on page 483)

Design of the HEDA bus terminator BUS 07/01:



Jumpers: 1-7, 2-8, 3-4, 5-6

11.9.3. Option M10 = HEDA (M11) & I/Os (M12)

The M10 option includes the M12 input/output option and the HEDA M11 option.


11.9.4. Analog current inputs and voltage inputs (Option M21)

With the Option M21 three analog current voltage & voltage inputs (0...20 mA) and (-10...+10 V) are available

In this chapter you can read about:

Connector assignment Option M21 X20488
 Connector assignment Option M21 X21489
 Layout of the analog inputs of Option M21489

11.9.4.1 Connector assignment Option M21 X20



X20: Current inputs (0 ... 20 mA)

Pin	Name	Function	Internal input channel
1	+24Vout	Sensor supply 0 (output) ¹⁾	AI0
2	in0+	Current input 0 + (0 ... 20 mA)	
3	GND	Sensor supply 0 (output) ¹⁾	
4	in0-	Current input 0 - (0 ... 20 mA)	AI1
5	+24Vout	Sensor supply 1 (output) 24 VDC out ¹⁾	
6	in1+	Current input 1 + (0 ... 20 mA)	
7	GND	Sensor supply 1 (output) ¹⁾	AI2
8	in1-	Current input 1 - (0 ... 20 mA)	
9	+24Vout	Sensor supply 2 (output) ¹⁾	
10	in2+	Current input 2 + (0 ... 20 mA)	Supply for pin 1/3, 5/7 and 9/11. ²⁾
11	GND	Sensor supply 2 (output) ¹⁾	
12	in2-	Current input 2 - (0 ... 20 mA)	
13	+24Vin	Sensor supply input 24 VDC in	
14	GND in	Sensor supply input	
15	Shield	Shield connection	
16	Shield	Shield connection	


Input resistor 250 Ω

¹⁾ For sensor supply - optional; the differential inputs may also be used. Supply takes also place via X20 pin 13 and 14.

²⁾ Only required if these voltage outputs are used for the sensor supply


Wiring of the analog current inputs

Input IN0



IN0 to IN3 do have the same wiring!
 Pin assignment X1

11.9.4.2 Connector assignment Option M21 X21



X21: Voltage inputs (-10 V... +10 V)


Pin	Name	Function	Internal input channel
1	+24Vout	Sensor supply 3 (output) ¹⁾	AI0
2	in3 +	Voltage input 3 + (-10 V... +10 V)	
3	GND	Sensor supply 3 (output) ¹⁾	
4	in3 -	Voltage input 3 - (-10... +10 V)	AI1
5	24 VDC out	Sensor supply 4 (output) ¹⁾	
6	in4 +	Voltage input 4 + (-10 V... +10 V)	
7	GND	Sensor supply 4 (output) ¹⁾	AI2
8	in4 -	Voltage input 4 - (-10... +10 V)	
9	24 VDC out	Sensor supply 5 (output) ¹⁾	
10	in5 +	Voltage input 5 + (-10 V... +10 V)	AI2
11	GND	Sensor supply 5 (output) ¹⁾	
12	in5 -	Voltage input 5 - (-10... +10 V)	

Input resistor 554 kΩ

¹⁾ For sensor supply - optional; the differential inputs may also be used. Supply takes also place via X20 pin 13 and 14.


Wiring of the analog voltage inputs

Input IN4



IN4 (X21/6 und X21/8) und IN5 (X21/10 und X21/12) do have the same wiring!

11.9.4.3 Layout of the analog inputs of Option M21



The assignment depends on the input channel


	+	-	Offset	Amplificatio n	Filter	Measuring value in units
IN0	X20.2	X20.4	191.2	191.1	191.3	688.35
IN1	X20.6	X20.8	192.2	192.1	192.3	688.36
IN2	X20.10	X20.12	193.2	193.1	193.3	688.37
IN3	X21.2	X21.4	194.2	194.1	194.3	685.9
IN4	X21.6	X21.8	195.2	195.1	195.3	685.10
IN5	X21.10	X21.10	196.2	196.1	196.3	685.11

11.10 Profibus plug BUS08/01

We offer a Profibus plug and special cable as sold by the meter for Profibus wiring:

- ◆ Profibus cable: SSL02/.. not prefabricated (color according to DESINA).
- ◆ Profibus plug: BUS08/01 with 2 cable inputs (for one incoming A1, B1 and one continuing Profibus cable- A2, B2 -) and screw terminals as well as a switch for activating the terminal resistor.

The terminal resistor must be activated on the first and on the last node (= switch setting ON).



11.11 CAN - plug BUS10/01

We offer a CAN plug and special cable in any length to order for the CAN-bus wiring:

- ◆ CAN cable: SSL02/.. not prefabricated (color according to DESINA).
- ◆ CAN plug: BUS10/01 with 2 cable inputs and screw terminals as well as a switch for activating the terminal resistor.


The terminal resistor must be activated on the first and on the last station (=switch setting ON).

Note for integrated C3 powerPLmC (Compax3 interface designation "C1x")


- ◆ The CAN bus of the C3 powerPLmC does already contain a terminal resistor.
- ◆ Therefore it applies for the **C3 powerPLmC**:
Put switch to OFF
wire C3 powerPLmC always at the end of the CAN bus!



CAN wiring



Schaltbild Circuit Diagram



11.12 PIO: External Inputs/Outputs

Additional external digital and analog inputs and outputs can be integrated via CANopen.

For this purpose we offer the Parker I/O system (PIO).

PIO offers the convenience of exceptionally simple installation. The individual modules can be installed and removed without any tools.

Available modules:

11.12.1. Order Code input/output terminals (PIO)

Order Code decentralized input terminals

PIO 2DI 24VDC 3.0ms	2-channel digital input terminal	PIO	4	0	0	
PIO 4DI 24VDC 3.0ms	4-channel digital input terminal	PIO	4	0	2	
PIO 8DI 24VDC 3.0ms	8-channel digital input terminal	PIO	4	3	0	
PIO 2AI DC ±10V differential input	2 channel analog input terminal (±10 V differential input)	PIO	4	5	6	
PIO 4AI 0-10VDC S.E.	4 channel analog input terminal (0-10V signal voltage)	PIO	4	6	8	
PIO 2AI 0-20mA differential input	2-channel analog input terminal (0-20mA differential input)	PIO	4	8	0	

Order Code decentralized output terminals

PIO 2DO 24VDC 0.5A	2 channel digital output terminal (output voltage 0.5A)	PIO	5	0	1	
PIO 4DO 24VDC 0.5A	4 channel digital output terminal (output voltage 0.5A)	PIO	5	0	4	
PIO 8DO 24VDC 0.5A	8 channel digital output terminal (output voltage 0.5A)	PIO	5	3	0	
PIO 2AO 0-10VDC	2 channel analog output terminal (0-10V signal voltage)	PIO	5	5	0	
PIO 2AO 0-20mA	2-channel analog output terminal (0-20mA signal voltage)	PIO	5	5	2	
PIO 2AO DC ±10V	2-channel analog output terminal (±10V signal voltage)	PIO	5	5	6	

Order Code CANopen Fieldbus Coupler

CANopen Standard	max. Vectorial sum current for bus terminals 1650mA at 5V	PIO	3	3	7	
CANopen ECO	max. Vectorial sum current for bus terminals 650mA at 5V	PIO	3	4	7	

For additional information please refer to our **catalog**

http://apps.parker.com/divapps/eme/EME/Literature_List/dokumentationen/PIO_Prospekt%20dt.pdf.

12. Technical Data

Mains connection Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Continuous working voltage	Single phase 230VAC/240VAC 80-253VAC / 50-60Hz	
Receiver current consumption	6Arms	13Arms
Maximum fuse rating per device	10 A (automatic circuit breaker K)	16A (automatic circuit breaker K)

Mains connection Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Supply voltage	Three phase 3* 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	10Arms	13Arms
Maximum fuse rating per device	16A	20A
	MCB miniature circuit breaker, K characteristic	

Mains connection Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Continuous working voltage	Three phase 3*400VAC/480VAC 80-528VAC / 50-60Hz				
Receiver current consumption	3Aeff	6Arms	10Arms	16Arms	22Arms
Maximum fuse rating per device	6A	10A	16A	20A	25A
	MCB miniature circuit breaker, K characteristic				D*

Mains connection PSUP10D6

Device type PSUP10	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	22Arms	22Arms	18Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	6kW	10 kW	10 kW
Pulse power (<5s)	12kW	20kW	20kW
Heat dissipation	60W	60W	60W
Maximum fuse rating per device	Measure for line and device protection: MCB miniature circuit breaker (K characteristic) 25A in accordance with UL category DIVQ Recommendation: (ABB) S203UP-K25 (480VAC)		

Mains connection PSUP20D6

Device type PSUP20	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	44Arms	44Arms	35Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	12kW	20kW	20kW
Pulse power (<5s)	24kW	40kW	40kW
Heat dissipation	120W	120W	120W
Maximum fuse rating per device 2 special purpose fuses in line are required	Cable protection measure: MCB (K characteristic) with a rating of 50A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K50 (440VAC) Device protection measure: Circuit breakers 80A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1366 or 170M1566D		

PSUP30D6 Mains connection

Device type PSUP30	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	50Arms	50Arms	42Arms
Output Voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	17kW	30kW	30kW
Pulse power (<5s)	34kW	60kW	60kW
Heat dissipation	140W	140W	140W
Maximum fuse rating per device 2 special purpose fuses in line are required	Cable protection measure: MCB (K characteristic) with a rating of 63A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K63 (440VAC) Device protection measure: Circuit breakers 125A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1368 or 170M1568D		

Mains connection Compax3HxxxV4 3*400VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Continuous working voltage	Three-phase 3*400VAC 350-528VAC / 50-60Hz			
Receiver current consumption	66Arms	95Arms	143Arms	164Arms
Output current	50Arms	90Arms	125Arms	155Arms
Maximum input fuse rating per device	80A	100A	160A	200A
Recommended line protection in accordance with UL	JDDZ Class K5 or H JDRX Class H			

Mains connection Compax3HxxxV4 3*480VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Continuous working voltage	Three-phase 3*480VAC 350-528VAC / 50-60Hz			
Receiver current consumption	54Arms	82Arms	118Arms	140Arms
Output current	43Arms	85Arms	110Arms	132Arms
Maximum input fuse rating per device	80A	100A	160A	200A
Recommended line protection in accordance with UL	JDDZ Class K5 or H JDRX Class H			

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

Control voltage 24 VDC PSUP

Device type	PSUP
Voltage range	21 - 27VDC
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes (class 2 mains module)
Current drain PSUP	PSUP10: 0.2A PSUP20 / PSUP30: 0.3A
Electric current drain Compax3M	C3M050D6: 0.85 3M100D6: 0.85A C3M150D6: 0.85A C3M300D6: 1.0 A + Total load of the digital outputs + current for the motor holding brake

Output data Compax3S0xx at 1*230VAC/240VAC

Controller type	S025V2	S063V2
Output voltage	3x 0-240V	3x 0-240V
Nominal output current	2.5Arms	6.3Arms
Pulse current for 5s	5.5Arms	12.6Arms
Power	1kVA	2.5kVA
Switching frequency	16kHz	16kHz
Power loss for In	30W	60W

Output data Compax3S1xx at 3*230VAC/240VAC

Controller type	S100V2	S150V2
Output voltage	3x 0-240V	3x 0-240V
Nominal output current	10Arms	15Arms
Pulse current for 5s	20Arms	30Arms
Power	4kVA	6kVA
Switching frequency	16kHz	8kHz
Power loss for In	80W	130W

Output data Compax3Sxxx at 3*400VAC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Output voltage	3x 0-400V				
Nominal output current	1.5Arms	3.8Arms	7.5Arms	15Arms	30Arms
Pulse current for 5s	4.5Arms	9.0Arms	15Arms	30Arms	60Arms*
Power	1kVA	2.5kVA	5kVA	10kVA	20kVA
Switching frequency	16kHz	16kHz	16kHz	8kHz	8kHz
Power loss for In	60W	80W	120W	160W	350W

* With cyclic peak currents (S8 or S9 operation), the device utilization (683.2) may not be > 70%; otherwise it is necessary to use a condenser module **"C4Module** (see on page 476)".

Output data Compax3Sxxx at 3*480VAC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Output voltage	3x 0-480V				
Nominal output current	1.5Arms	3.8Arms	6.5Arms	13.9Arms	30Arms
Pulse current for 5s	4.5Arms	7.5Arms	15Arms	30Arms	60Arms*
Power	1.25kVA	3.1kVA	6.2kVA	11.5kVA	25kVA
Switching frequency	16kHz	16kHz	16kHz	8kHz	8kHz
Power loss for In	60W	80W	120W	160W	350W

* With cyclic peak currents (S8 or S9 operation), the device utilization (683.2) may not be > 70%; otherwise it is necessary to use a condenser module **"C4Module** (see on page 476)".

Output data Compax3Mxxx at 3*230VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input Voltage	325VDC ±10%			
Output Voltage	3x 0-230V (0...500Hz)			
Output nominal current	5Arms	10Arms	15Arms	30Arms
Pulse current for 5s*	10Arms	20Arms	30Arms	60Arms
Power	2kVA	4kVA	6kVA	12kVA
Switching frequency of the motor current	8kHz	8kHz	8kHz	8kHz
Heat dissipation for In	70W+**	90W+**	120W+**	270W+**

* Turning frequency for pulse current: f>5 Hz; with an electrical turning frequency of f<5 Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Mxxx at 3*400VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input Voltage	565VDC \pm 10%			
Output Voltage	3x 0-400V (0...500Hz)			
Output nominal current	5Arms	10Arms	15Arms	30Arms
Pulse current for 5s*	10Arms	20Arms	30Arms	60Arms
Power	3.33kVA	6.66kVA	10kVA	20kVA
Switching frequency of the motor current	8kHz	8kHz	8kHz	8kHz
Heat dissipation for In	70W+**	90W+**	120W+**	270W+**

* Turning frequency for pulse current: $f > 5$ Hz; with an electrical turning frequency of $f < 5$ Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Mxxx at 3*480VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input Voltage	680VDC \pm 10%			
Output Voltage	3x 0-480V (0...500Hz)			
Output nominal current	4Arms	8Arms	12.5Arms	25Arms
Pulse current for 5s*	8Arms	16Arms	25Arms	50Arms
Power	3.33kVA	6.66kVA	10kVA	20kVA
Switching frequency of the motor current	8kHz	8kHz	8kHz	8kHz
Heat dissipation for In	70W+**	90W+**	120W+**	270W+**

* Turning frequency for pulse current: $f > 5$ Hz; with an electrical turning frequency of $f < 5$ Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Hxxx at 3*400VAC

Controller type	H050V4	H090V4	H125V4	H155V4
Output voltage	3x 0-400V			
Nominal output current	50Arms	90Arms	125Arms	155Arms
Pulse current for 5s *	75Arms	135Arms	187.5Arms	232.5Arms
Power	35kVA	62kVA	86kVA	107kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	880W	900W	1690W	1970W

* during low speeds, the overload time is reduced to 1s. Limit:

< 2.5 electric rev/s (= actual revolutions/s * number of pole pairs) resp. >2.5 pitch/s

Output data Compax3Hxxx at 3*480VAC

Controller type	H050V4	H090V4	H125V4	H155V4
Output voltage	3x 0-480V			
Nominal output current	43Arms	85Arms	110Arms	132Arms
Pulse current for 5s*	64.5Arms	127.5Arms	165Arms	198Arms
Power	35kVA	70kVA	91kVA	109kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	850W	1103W	1520W	1800W

* during low speeds, the overload time is reduced to 1s. Limit:

< 2.5 electric rev/s (= actual revolutions/s * number of pole pairs) resp. >2.5 pitch/s

Resulting nominal and peak currents depending on the switching frequency

Compax3S0xxV2 at 1*230VAC/240VAC

Switching frequency*		S025V2	S063V2
16kHz	I _{nom}	2.5A _{rms}	6.3A _{rms}
	I _{peak} (<5s)	5.5A _{rms}	12.6A _{rms}
32kHz	I _{nom}	2.5A _{rms}	5.5A _{rms}
	I _{peak} (<5s)	5.5A _{rms}	12.6A _{rms}

Compax3S1xxV2 at 3*230VAC/240VAC

Switching frequency*		S100V2	S150V2
8kHz	I _{nom}	-	15A _{rms}
	I _{peak} (<5s)	-	30A _{rms}
16kHz	I _{nom}	10A _{rms}	12.5A _{rms}
	I _{peak} (<5s)	20A _{rms}	25A _{rms}
32kHz	I _{nom}	8A _{rms}	10A _{rms}
	I _{peak} (<5s)	16A _{rms}	20A _{rms}

Compax3S0xxV4 at 3*400VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I _{nom}	-	-	-	15A _{rms}	30A _{rms}
	I _{peak} (<5s)	-	-	-	30A _{rms}	60A _{rms}
16kHz	I _{nom}	1.5A _{rms}	3.8A _{rms}	7.5A _{rms}	10.0A _{rms}	26A _{rms}
	I _{peak} (<5s)	4.5A _{rms}	9.0A _{rms}	15.0A _{rms}	20.0A _{rms}	52A _{rms}
32kHz	I _{nom}	1.5A _{rms}	2.5A _{rms}	3.7A _{rms}	5.0A _{rms}	14A _{rms}
	I _{peak} (<5s)	3.0A _{rms}	5.0A _{rms}	10.0A _{rms}	10.0A _{rms}	28A _{rms}

Compax3S0xxV4 at 3*480VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I _{nom}	-	-	-	13.9A _{rms}	30A _{rms}
	I _{peak} (<5s)	-	-	-	30A _{rms}	60A _{rms}
16kHz	I _{nom}	1.5A _{rms}	3.8A _{rms}	6.5A _{rms}	8.0A _{rms}	21.5A _{rms}
	I _{peak} (<5s)	4.5A _{rms}	7.5A _{rms}	15.0A _{rms}	16.0A _{rms}	43A _{rms}
32kHz	I _{nom}	1.0A _{rms}	2.0A _{rms}	2.7A _{rms}	3.5A _{rms}	10A _{rms}
	I _{peak} (<5s)	2.0A _{rms}	4.0A _{rms}	8.0A _{rms}	7.0A _{rms}	20A _{rms}

The values marked with grey are the pre-set values (standard values)!
 *corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3MxxxD6 at 3*400VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	5A _{rms}	10A _{rms}	15A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	10A _{rms}	20A _{rms}	30A _{rms}	60A _{rms}
16kHz	I_{nom}	3.8A _{rms}	7.5A _{rms}	10A _{rms}	20A _{rms}
	$I_{peak} (<5s)$	7.5A _{rms}	15A _{rms}	20A _{rms}	40A _{rms}
32kHz	I_{nom}	2.5A _{rms}	3.8A _{rms}	5A _{rms}	11A _{rms}
	$I_{peak} (<5s)$	5A _{rms}	7.5A _{rms}	10A _{rms}	22A _{rms}

Compax3MxxxD6 at 3*480VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	4A _{rms}	8A _{rms}	12.5A _{rms}	25A _{rms}
	$I_{peak} (<5s)$	8A _{rms}	16A _{rms}	25A _{rms}	50A _{rms}
16kHz	I_{nom}	3A _{rms}	5.5A _{rms}	8A _{rms}	15A _{rms}
	$I_{peak} (<5s)$	6A _{rms}	11A _{rms}	16A _{rms}	30A _{rms}
32kHz	I_{nom}	2A _{rms}	2.5A _{rms}	4A _{rms}	8.5A _{rms}
	$I_{peak} (<5s)$	4A _{rms}	5A _{rms}	8A _{rms}	17A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3HxxxV4 at 3*400VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	50A _{rms}	90A _{rms}	125A _{rms}	155A _{rms}
	$I_{peak} (<5s)$	75A _{rms}	135A _{rms}	187.5A _{rms}	232.5A _{rms}
16kHz	I_{nom}	33A _{rms}	75A _{rms}	82A _{rms}	100A _{rms}
	$I_{peak} (<5s)$	49.5A _{rms}	112.5A _{rms}	123A _{rms}	150A _{rms}
32kHz	I_{nom}	19A _{rms}	45A _{rms}	49A _{rms}	59A _{rms}
	$I_{peak} (<5s)$	28.5A _{rms}	67.5A _{rms}	73.5A _{rms}	88.5A _{rms}

Compax3HxxxV4 at 3*480VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	43A _{rms}	85A _{rms}	110A _{rms}	132A _{rms}
	$I_{peak} (<5s)$	64.5A _{rms}	127.5A _{rms}	165A _{rms}	198A _{rms}
16kHz	I_{nom}	27A _{rms}	70A _{rms}	70A _{rms}	84A _{rms}
	$I_{peak} (<5s)$	40.5A _{rms}	105A _{rms}	105A _{rms}	126A _{rms}
32kHz	I_{nom}	16A _{rms}	40A _{rms}	40A _{rms}	48A _{rms}
	$I_{peak} (<5s)$	24A _{rms}	60A _{rms}	60A _{rms}	72A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resolution of the motor position

For option F10: Resolver	<ul style="list-style-type: none"> ◆ Position resolution: 16 Bits (= 0.005°) ◆ Absolute accuracy: ±0.167°
For option F11: SinCos®	<ul style="list-style-type: none"> ◆ Position resolution: 13.5 Bits / Encoder sine period => 0.03107°/encoder resolution
For option F12:	<ul style="list-style-type: none"> ◆ Maximum position resolution <ul style="list-style-type: none"> ◆ Linear: 24 Bits per motor magnet spacing ◆ Rotary: 24 Bits per motor revolution ◆ For 1Vss Sine-Cosine encoders (e.g. EnDat): 13.5 bits / graduation of the scale of the encoder ◆ For RS 422 encoders: 4x encoder resolution ◆ Accuracy of the feedback zero pulse acquisition = accuracy of the feedback resolution. ◆ Resolution for analog hall sensors with 1Vpp signal: 13.5 Bits / motor magnet spacing

Accuracy

The exactitude of the position signal is above all determined by the exactitude of the feedback system used.

Supported Motor and Feedback Systems

<p>Motors</p> <p>Direct drives</p> <ul style="list-style-type: none"> ◆ Linear motors ◆ Torque motors 	<ul style="list-style-type: none"> ◆ Sinusoidally commutated synchronous motors <ul style="list-style-type: none"> ◆ Maximum electrical turning frequency: 1000Hz* ◆ Max. velocity on 8 pole motors: 15 000min⁻¹. ◆ General max. speed: 60*1000/number of pole pairs in [min⁻¹]. ◆ Max. number of poles = 600 ◆ Sinusoidal commutated asynchronous motors <ul style="list-style-type: none"> ◆ Maximum electrical turning frequency: 1000Hz ◆ Max. velocity: 60*1000/number of pole pairs - slip in [min⁻¹]. ◆ Field weakening: typically up to triple (higher on request). ◆ Temperature sensor: KTY84-130 (insulated in accordance with EN60664-1 or IEC60664-1) ◆ 3 phase synchronous direct drives
Position encoder (Feedback)	Option F10: Resolver
LTN:	◆ RE-21-1-A05, RE-15-1-B04
Tamagawa:	◆ TS2610N171E64, TS2620N21E11, TS2640N321E64, TS2660N31E64
Tyco (AMP)	◆ V23401-T2009-B202
	Option F11: SinCos®
	<ul style="list-style-type: none"> ◆ Rotary feedback with HIPERFACE® interface: <ul style="list-style-type: none"> ◆ Singleturn (SICK Stegmann) ◆ Multiturn (SICK Stegmann) Absolute position up to 4096 motor revolutions. ◆ For example: SRS50, SRM50, SKS36, SKM36, SEK52, SEK52, SEL52, SEK37, SEL37, SEK160, SEK90

* higher values on request

Special Feedback Systems	Option F12
Analog hall sensors	<ul style="list-style-type: none"> ◆ Sine-Cosine signal (max. 5Vpp*; typical 1Vpp) 90° offset ◆ U-V signal (max. 5Vpp*; typical 1Vpp) 120° offset.
Encoder (linear or rotary)	<ul style="list-style-type: none"> ◆ Sine-Cosine (max. 5Vpp*; typical 1Vpp) (max. 400kHz) or ◆ TTL (RS422) (max. 5MHz; track A or B) ◆ Bypass function for encoder signals (limit frequency** 5MHz, track A or B) with the following modes of commutation: <ul style="list-style-type: none"> ◆ Automatic commutation (see on page 448) or ◆ U, V, W or R, S, T commutation signals (NPN open collector) e.g. digital hall sensors, incremental encoders made by Hengstler (F series with electrical ordering variant 6)
EnDat*** with incremental (Sine - Cosine) track	<ul style="list-style-type: none"> ◆ EnDat 2.1 or EnDat 2.2 (Endat01, Endat02) feedback ◆ linear or rotary ◆ max. 400kHz Sine-Cosine
EnDat 2.2*** (fully digital)	<ul style="list-style-type: none"> ◆ EnDat 2.2 (Endat01, Endat02) feedback ◆ linear or rotary ◆ max. Cable length: 25 m
EnDat2.1***(fully digital)	<ul style="list-style-type: none"> ◆ EnDat 2.1 without incremental track ◆ Supported types: EQ111xx, ECI11xx, ECI11x ◆ max. Cable length: 90 m
Distance coded feedback systems	<ul style="list-style-type: none"> ◆ Distance coding with 1 VSS interface ◆ Distance coding with RS422 - Interface (Encoder)

*Max. differential input between SIN- (X13/7) and SIN+ (X13/8).

** Limit frequency = 1MHz for Compax3M (higher bandwidths on request)

*** Digital, bidirectional interface

Feedback error compensation

Feedback error compensation	<ul style="list-style-type: none"> ◆ Automatic feedback error compensation (offset & amplification) for analog hall sensors and sine-cosine encoder can be activated in the MotorManager.
-----------------------------	--

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A
Securing of brake Compax3M	3.15A

Braking operation Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Capacitance / storable energy	560µF / 15Ws	1120µF / 30Ws
Minimum braking- resistance	100Ω	56Ω
Recommended nominal power rating	20 ... 60W	60 ... 180W
Maximum continuous current	8A	15A

Braking operation Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Capacitance / storable energy	780µF / 21Ws	1170µF / 31Ws
Minimum braking- resistance	22Ω	15Ω
Recommended nominal power rating	60 ... 450W	60 ... 600W
Maximum continuous current	20A	20A

Braking operation Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Capacity / storable energy 400V / 480V	235µF 37 / 21 Ws	235µF 37 / 21 Ws	470µF 75 / 42 Ws	690µF 110 / 61 Ws	1230µF 176 / 98 Ws
Minimum ballast - resistance	100 Ω	100 Ω	56 Ω	47 Ω	15 Ω
Recommended nominal power rating	60 ... 100W	60 ... 250W	60 ... 500 W	60 ... 1000 W	60 ... 1000 W
Maximum continuous current	10A	10A	15A	20A	30A

Braking operation Compax3MxxxD6 (axis controller)

Device type Compax3	M050	M100	M150	M300
Capacity/ storable energy	110µF/ 18Ws at 400V 10Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	440µF/ 74Ws at 400V 42Ws at 480V

Braking operation of Compax3HxxxV4

Controller type	H050V4	H090V4	H125V4	H155V4
Capacitance / storable energy 400V / 480V	2600 µF 602 / 419 Ws	3150 µF 729 / 507 Ws	5000 µF 1158 / 806 Ws	5000 µF 1158 / 806 Ws
Minimum braking- resistance	24 Ω	15 Ω	8 Ω	8 Ω
Maximum continuous current	11 A	17 A	31 A	31 A

Braking operation PSUPxxD6 (mains module)

Device type	PSUP10	PSUP20	PSUP30
Capacitance / storable energy	550 µF/ 92 Ws at 400 V 53 Ws at 480 V	1175 µF/ 197 Ws at 400 V 114 Ws at 480 V	1175 µF/ 197 Ws at 400 V 114 Ws at 480 V
Minimum braking- resistance	27 Ω	15 Ω	10 Ω
Recommended nominal power rating	500 ... 1500 W	500 ... 3500 W	500 ... 5000 W
Pulse power rating for 1s	22 kW	40 kW	60 kW
Maximum permissible continuous current	13 A	15 A	15 A

Ballast resistors Compax3

Ballast resistor (see on page 463)	Device	Nominal Power
BRM08/01 (100 Ω)	Compax3S025V2 Compax3S015V4 Compax3S038V4	60 W
BRM05/01 (56 Ω)	Compax3S063V2 Compax3S075V4	180 W
BRM05/02 (56 Ω)	Compax3S075V4	570 W
BRM10/01 (47 Ω)	Compax3S150V4	570 W
BRM10/02 (47 Ω)	Compax3S150V4	1500 kW
BRM04/01 (15 Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	570 W
BRM04/02 (15 Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	740 W
BRM04/03 (15 Ω)	Compax3S300V4 PSUP20D6	1500 W
BRM09/01 (22 Ω)	Compax3S100V2	570 W
BRM11/01 (27 Ω)	Compax3H0xxV4	3500 W
BRM13/01 (30 Ω)	PSUP10D6 PSUP20D6** PSUP30D6**	500 W
BRM14/01 (15 Ω)	PSUP10D6* PSUP20D6 PSUP30D6	500 W
BRM12/01 (18 Ω)	Compax3H1xxV4 PSUP30D6	4500 W

*for PSUP10D6 2x15Ω in series

**for PSUP20D6 and PSUP30D6 2x30Ω parallel

Size / weight Compax3S

Controller type	Dimensions HxWxD [mm]	Weight [kg]
Compax3S025V2	191 x 84 x 172	2.0
Compax3S063V2	191 x 100 x 172	2.5
Compax3S015V4	248 x 84 x 172	3.1
Compax3S100V2	248 x 115 x 172	4.3
Compax3S150V2	248 x 158 x 172	6.8
Compax3S038V4	248 x 100 x 172	3.5
Compax3S075V4	248 x 115 x 172	4.3
Compax3S150V4	248 x 158 x 172	6.8
Compax3S300V4	380 x 175 x 172	10.9

Minimum mounting distance: 15mm at the sides, above & below 100mm

Protection type IP20

Drawings, Mounting (see on page 76, see on page 82)

Size / weight PSUP/Compax3M

Device type	Dimensions HxWxD [mm]	Weight [kg]
PSUP10D6	360 x 50 x 263	3.95
PSUP20D6 & PSUP30D6	360 x 100 x 263	6.3
Compax3M050D6	360 x 50 x 263	3.5
Compax3M100D6	360 x 50 x 263	3.6
Compax3M150D6	360 x 50 x 263	3.6
Compax3M300D6	360 x 100 x 263	5.25

Protection type IP20

Size / weight Compax3H

Mounting (see on page 76, see on page 82)

Controller type	Dimensions HxWxD [mm]	Weight [kg]
Compax3H050V4	453 x 252 x 245	17.4
Compax3H090V4	668.6 x 257 x 312	32.5
Compax3H125V4	720 x 257 x 355	41
Compax3H155V4	720 x 257 x 355	41

Protection class IP20 when mounted in a control cabinet (not for Compax3H1xxxV4)

Digital Inputs/outputs

Digital Inputs	<ul style="list-style-type: none"> ◆ 8 digital inputs ◆ Input resistor 22 kΩ ◆ Signal level <ul style="list-style-type: none"> ◆ > 9.15V = "1" (38.2% of the control voltage applied) ◆ < 8.05V = "0" (33.5% of the control voltage applied)
Digital Outputs	<ul style="list-style-type: none"> ◆ 4 digital outputs ◆ Load max. 100mA

Safety technology Compax3S

<p>Safe torque-off in accordance with EN ISO 13849: 2008, Category 3, PL d/e Certified. Test mark IFA 1003004</p>	<ul style="list-style-type: none"> ◆ For implementation of the “protection against unexpected start-up” function described in EN1037. ◆ Please note the circuitry examples (see on page 85).
---	---

Compax3S STO (=safe torque off)

Nominal voltage of the inputs	24 V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1 A
Grouping of safety level	<p><500 000 STO cycles per year are assumed.</p> <ul style="list-style-type: none"> ◆ STO switch-off via internal safety relay & digital input: PL e, PFHd=2.98E-8 ◆ STO switch-off via internal safety relay & fieldbus: PL d, PFHd=1.51E-7 (is applicable for a MTTFd=15 years of the external PLC) ◆ Lifetime: 20 Years

Safety technology Compax3M

Safe torque-off in accordance with EN ISO 13849-1: 2007, Category 3, PL=e Certified. Test mark MFS 09029	◆ Please respect the stated safety technology on the type designation plate (see on page 12) and the circuitry examples (see on page 98)
---	--

Compax3M S1 Option: Signal inputs for connector X14

Nominal voltage of the inputs	24V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1A
Number of inputs Signal inputs via optocoupler	2 Low = 0...7V DC or open High = 15...30V DC I_{in} at 24V DC: 8mA
STO1/	Low = STO activated High = STO deactivated Reaction time max. 3ms
STO2/	Low = STO activated High = STO deactivated Reaction time max. 3ms
Switch-off time with unequal input statuses	20 s (max. error reaction time)
Grouping of safety level	◆ Category 3 ◆ PL=e (according to table 4 in EN ISO 13849-1 this corresponds to SIL 3) ◆ PFHd=4.29E-8 ◆ Lifetime: 20 years

UL certification for Compax3S

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).

"UL" logo:



UL approval for Compax3M

Conform to UL:	◆ in accordance with UL508C
Certified	◆ E-File_No.: E235342

The UL approval is documented by a "UL" logo on the device (type specification plate).



Insulation requirements

Enclosure rating	Protection class in accordance with EN 60664-1
Protection against human contact with dangerous voltages	In accordance with EN 61800-5-1
Overvoltage category	Voltage category III in accordance with EN 60664-1
Degree of contamination	Degree of contamination 2 in accordance with EN 60664-1 and EN 61800-5-1

Environmental conditions Compax3S and Compax3H

General ambient conditions	In accordance with EN 60 721-3-1 to 3-3 Climate (temperature/humidity/barometric pressure): Class 3K3	
Permissible ambient temperature:		
Operation storage transport	0 to +45 °C class 3K3 -25 to +70 °C class 2K3 -25 to +70 °C class 2K3	
Tolerated humidity:	no condensation	
Operation storage transport	<= 85% class 3K3 <= 95% class 2K3 <= 95% class 2K3	(Relative humidity)
Elevation of operating site	<=1000m above sea level for 100% load ratings <=2000m above sea level for 1% / 100m power reduction please inquire for greater elevations	
Mechanic resonances:	EN 60068-2-6 (sinusoidal excitation)	
Sealing	Protection type IP20 in accordance with EN 60 529	

Cooling Compax3S and Compax3H

Cooling mode:	C3S025V2 ... S150V4: Convection C3S300V4 & C3H: Forced air ventilation with fan in the heat dissipator Air flow rate: 459m ³ /h (C3H)
Supply:	C3S300V4, C3H050, C3H090 internal C3H125, C3H155 external 220/240VAC: 140W, 2.5µF, Stator - 62Ω Optionally on request: 110/120VAC: 130W, 10µF, Stator - 16Ω Circuit breaker: 3A

EMC limit values Compax3S and Compax3H

EMC interference emission	Limit values in accordance with EN 61 800-3, Limit value class C3/C4 without additional mains filter: Information on C2 limit value classes (see on page 17)
EMC disturbance immunity	Industrial area limit values in accordance with EN 61 800-3

Ambient conditions PSUP/Compax3M

General ambient conditions	In accordance with EN 60 721-3-1 to 3-3 Climate (temperature/humidity/barometric pressure): Class 3K3	
Permissible ambient temperature:		
Operation storage transport	0 to +40 °C -25 to +70 °C -25 to +70 °C	Class 3K3
Tolerated humidity:	no condensation	
Operation storage transport	<= 85% class 3K3 <= 95% <= 95%	(Relative humidity)
Elevation of operating site	<=1000m above sea level for 100% load ratings <=2000m above sea level for 1% / 100m power reduction please inquire for greater elevations	
Sealing	Protection type IP20 in accordance with EN 60 529	
Mechanic resonances:	Class 2M3, 20m/s ² ;8-200Hz	

Cooling PSUP/Compax3M

Cooling mode:	Forced air ventilation with fan in the heat dissipator
----------------------	--

EMV limit values PSUP/Compax3M

EMC interference emission	Limit values in accordance with EN 61 800-3, Limit value class C3 with mains filter.
EMC disturbance immunity	Industrial area limit values in accordance with EN 61 800-3

EC directives and applied harmonized EC norms

EC low voltage directive 2006/95/EG	EN 61800-5-1 , Standard for electric power drives with settable speed; requirements to electric safety EN 60664-1 , isolation coordinates for electrical equipment in low-voltage systems EN 60204-1, machinery norm partly applied
EC-EMC-directive 2004/108/EC	EN 61800-3, EMC standard Product standard for variable speed drives

COM ports

RS232	<ul style="list-style-type: none"> ◆ 115200 baud ◆ Word length: 8 bits, 1 start bit, 1 stop bit ◆ Hardware handshake XON, XOFF
RS485 (2 or 4-wire)	<ul style="list-style-type: none"> ◆ 9600, 19200, 38400, 57600 or 115200 baud ◆ Word length 7/8 bit, 1 start bit, 1 stop bit ◆ Parity (can be switched off) even/odd ◆ 2 or 4-wire
USB (Compax3M)	◆ USB 2.0 Full Speed compatible

Load position control

Dual Loop Option	◆ 2. Feedback system for load position control (see on page 149) possible.
-------------------------	---

Signal interfaces

Signal inputs / signal sources	<ul style="list-style-type: none"> ◆ Encoder input track A/B (RS422) <ul style="list-style-type: none"> ◆ up to max. 10MHz ◆ Internal quadrature of the resolution ◆ Step / direction input (24V level) <ul style="list-style-type: none"> Max. 300kHz at $\geq 50\Omega$ source impedance and minimum pulse width of 1.6μs. ◆ +/-10V analog input <ul style="list-style-type: none"> 14Bit; 62.5μs scanning rate. ◆ SSI - feedback (see on page 145)
Signal outputs	<ul style="list-style-type: none"> ◆ Encoder simulation <ul style="list-style-type: none"> ◆ 1...16384 increments/revolution or pitch ◆ Limit frequency** 620kHz (track A or B) ◆ Bypass function for encoder feedback with feedback module F12 (Limit frequency* 5MHz, track A or B).
Signal transmission	<p>HEDA (Option M10 or M11)</p> <p>Transfer of process values:</p> <ul style="list-style-type: none"> ◆ from Master to Slave, ◆ from Slave to Master and ◆ from Slave to Slave.

** Limit frequency = 1MHz for Compax3M (higher bandwidths on request)

IEC6113-3 functions

General	<ul style="list-style-type: none"> ◆ Programming based on IEC61131-3 ◆ Up to 6000 instructions ◆ 650 16 bit variables ◆ 200 32 bit variables ◆ Recipe table with 288 variables ◆ 3x16-bit retain-variable ◆ 3x32-bit retain-variable
PLCOpen function modules	<ul style="list-style-type: none"> ◆ Positioning: absolute, relative, additive, continuous ◆ Electronic Gearbox (Gearing) ◆ Machine Zero ◆ Stop, activating the drive, quit ◆ Position, device status, reading axis error
IEC61131-3 standard modules	<ul style="list-style-type: none"> ◆ Up to 8 timers (TON, TOF, TP) ◆ Triggers (R_TRIG, F_TRIG) ◆ Flip-flops (RS, SR) ◆ Counters (CTU, CTD, CTUD)
Device-specific function modules	<ul style="list-style-type: none"> ◆ generates an input process image ◆ Generates an output process image ◆ Access to recipe table
Inputs/Outputs	<ul style="list-style-type: none"> ◆ 8 digital inputs (24V level) ◆ 4 digital outputs (24-V level) ◆ Optional addition of 12 inputs/outputs

Profibus ratings (I20)

Profile	◆ PROFIdrive Profile drive system V3
DP Versions	◆ DPV0/DPV1
Baud rate	◆ up to 12 MHz
Profibus ID	◆ C320
Device master file	◆ PAR_C320.GSD (can be found on the Compax3 - DVD)
Communication Simatic <-> Compax3	◆ Simatic S7-300/400 - modules for Compax3 I20 and a corresponding help file can be found on the Compax3 CD in the folder: ..\Profibus\S7-moduls\

Profinet Characteristics (I32)

Profile	◆ PROFIdrive profile drive technology V4.1
Profinet Version	◆ Profinet IO (RT)
Transmission mode	◆ 100BASE-TX (Full Duplex)
Profinet ID	◆ C332
Device master file	◆ GSDML-V2.1-Parker-Compax3-yyyymmdd.xml (can be found on the Compax3 DVD)
Communication Simatic <-> Compax3	◆ Simatic S7-300/400 - modules for Compax3 I32 and a corresponding help file can be found on the Compax3 CD in the folder..\Profibus\S7-moduls\ (the same modules as with Profibus)

CANopen characteristics (I21)

Baud rate [kBit/s]	◆ 20, 50, 100, 125, 250, 500, 800, 1000
EDS file	◆ C3.EDS
Service data object	◆ SDO1
Process data objects	◆ PDO1, ... PDO4

DeviceNet characteristics (I22)

DeviceNet	◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
Implemented object classes	◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
Baud rate [kBit/s]	◆ 125, 250, 500
permissible cable length	◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
Max. Number of participants	◆ 63 Slave
Insulation	◆ Isolated Device Physical Layer
EDS file	◆ C3_DeviceNet.EDS
Conformance (file in the Internet)	◆ Statement of Conformance http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf
Further information:	◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory"

Ethernet Powerlink (I30) / EtherCAT characteristics (I31)

Baud rate	◆ 100Mbits (FastEthernet)
Bus file	◆ Ethernet Powerlink: EtherCAT:
	◆ C3_EPL_cn.EDS ◆ C3_EtherCAT_xx.XML
Service data object	◆ SDO
Mapping objects	◆ 16 Words (16x16Bit)
Cycle time	◆ >=1ms
Synchronicity accuracy	◆ maximum jitter: +/-25µs

13. Index

+

+/-10V Master speed • 146

A

Absolute encoder • 118
 Absolute positioning (MC_MoveAbsolute) • 290
 Absolutposition im Geber speichern • 119
 Access to the Compax3 object directory • 274
 Access to the hazardous area • 94, 97
 Acknowledging errors (MC_Reset) • 312
 Activation • 233
 Adapterkabel SSK32/20 • 484
 Additional conditions of utilization • 19
 Additive positioning (MC_MoveAdditive) • 298
 Adjusting the basic address • 60
 Adjusting the bus address • 66
 Adjusting the bus address (Profibus I20) • 61
 Adjusting the bus address (Profinet I32) • 62
 Adjusting the machine zero proximity switch • 132
 Advanced • 196
 Advantages of using the • 86
 Aktivieren des Antriebs (MC_Power) • 280
 Alignment of the analog inputs • 229
 Allgemeine Gefahren • 14
 Analog Inputs/Outputs • 438
 Analoge Strom- und Spannungseingänge (Option M21) • 488
 Analogue / encoder (plug X11) • 73
 Analyses in the time range • 235
 Application parameters • 161
 Applikationsbeispiel STO (= Sicher abgeschaltetes Moment) • 91
 Approximation of a well-attenuated control loop • 180
 ASCII - record • 352
 Assignment of the process data channel • 361
 Assignment of the X22 connector • 485
 Asynchronmotoren • 174
 Asynchronous motors
 Extension of the controller structure • 177
 Attenuation of the excitation amplitude • 245
 Automated controller design • 187
 Automatic controller design • 178
 Azyklischer Parameterkanal • 363, 385

B

Ballast resistor • 35, 112, 501
 Ballast resistor BRM13/01 & BRM14/01 • 475
 Ballastwiderstand / Leistungsspannung Stecker X2 bei 1AC 230VAC/240VAC-Geräten • 35
 Basic functions: • 96
 Basic structure of the control with Compax3 • 160

Basics of frequency response measurement • 260
 Baud rate • 372
 Bedeutung der Status-LEDs - PSUP (Netzmodul) • 28
 Begrenzung der Sollgeschwindigkeit • 193
 Begrenzung des Sollstroms • 193
 Begriffsdefinitionen • 396
 Beispiel
 Elektronisches Getriebe mit Lageerfassung über Encoder • 144
 Beschaltung der analogen Spannungseingänge • 489
 Beschaltung der analogen Stromeingänge • 488
 Bestellhinweis Kabel • 446
 Bestellschlüssel Ein-/Ausgangsklemmen (PIO) • 445, 492
 Bestellschlüssel Feedbackkabel • 443
 Bestellschlüssel Kondensatormodul • 444
 Bestellschlüssel Netzfilter (C3S) • 444
 Bestellschlüssel Zubehör • 442
 Bewegungsobjekte in Compax3 • 225
 Bewegungszyklus ohne Vorsteuerung • 195
 Binary record • 353
 Bit sequence V2 • 370
 Boundary conditions • 227
 Brake delay times • 267
 Braking resistor / high voltage DC C3S connector X2 • 35
 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices • 37
 Braking resistor / high voltage supply plug X2 for 3AC 230VAC/240VAC devices • 35
 Braking resistor / supply voltage C3H • 57
 Braking resistor / temperature switch PSUP (mains module) • 46
 Braking resistor BRM11/01 & BRM12/01 • 475
 Braking resistor BRM4/0x and BRM10/02 • 474
 Braking resistor BRM5/02, BRM9/01 & BRM10/01 • 474
 BRM10/02 • 463, 467, 474
 BRM5/01 braking resistor • 473
 BRM8/01braking resistors • 473
 Busformat Y2 und Y4 • 369
 Byte string OS • 370

C

C3 • 317, 318
 C3 Master PIO • 372
 C3 Objects • 428
 C3 objects (without CoDeSys objects) • 434
 C3 ServoSignalAnalyzer • 231
 C3 settings for RS485 four wire operation • 351
 C3 settings for RS485 two wire operation • 350

- C3_CANopen_AddNode • 375
- C3_CANopen_ConfigNode • 376
- C3_CANopen_GuardingState • 374
- C3_CANopen_NMT • 377
- C3_CANopen_SDO_Read4 • 378
- C3_CANopen_SDO_Write4 • 379
- C3_CANopen_State • 373
- C3_Current • 309
- C3_ErrorMask • 315
- C3_Input • 316
- C3_IOAddition_0 • 317
- C3_IOAddition_1 • 317
- C3_IOAddition_2 • 318
- C3_Jog • 302
- C3_OpenBrake • 284
- C3_Output • 316
- C3_ProfiDrive_Statemachine • 339
- C3_ReadArray • 287
- C3_SetErrorReaction • 314
- C3_TorqueControl • 310
- C3_TouchProbe • 319
- C3Array Objects • 430
- C3Plus Objects • 431
- Calculation of the BRM cooling time • 464
- Calculation of the reference current from the characteristic line. • 164
- Calling up the HEDA wizard in the C3 ServoManager • 396
- Calling up the input simulation • 223
- CAN - plug BUS10/01 • 491
- CAN communication objects overview sorted according to CAN No. • 382
- CANopen • 371
- CANopen - Configuration • 371
- CANopen communication profile • 380
- CANopen connector X23 Interface I21 • 64
- CanOpen DS402 nachbilden (C3_DS402_Statemachine) • 341
- CANopen Operating Mode • 371
- CANopen states • 373
- Capacitors • 13
- Cascade control • 184
- Cascade structure of Compax3 • 185
- Change assignment direction reversal / limit switches • 137
- Change initiator logic • 137
- Changing the switching frequency and the reference point • 173
- Characteristics of a control loop setpoint response • 183
- CiA405_SDO_Error (Abort Code) UDINT • 385
- Circuit layout overview • 91
- Circuit: • 92, 95
- CN Controlled Node (Slave) • 390
- CoDeSys / Compax3 target system (Target Package) • 269
- COM port protocol • 352
- Commissioning the load control • 226
- Communication • 342
- Communication Compax3M • 59
- Communication interfaces • 58
- Communication objects • 381
- Commutation settings of the automatic commutation • 203
- Compax3 - Objekte • 415
- Compax3 communication variants • 342
- Compax3 device description • 27
- Compax3 ServoManager IEC61131-3 programming • 269
- Compax3H connections front plate • 52
- Compax3H plugs/connections • 50
- Compax3M STO application description • 101
- Compax3S connectors • 29
- Compax3Sxxx V2 • 34
- Compax3Sxxx V4 • 36
- Compilation, debugging and down/upload of IEC61131 programs • 275
- Conditions of utilization • 17
- Conditions of utilization for cables / motor filter • 18
- Conditions of utilization for CE-conform operation • 17
- Conditions of utilization for the STO function with Compax3M • 99
- Conditions of utilization for UL approval Compax3M • 21
- Conditions of utilization mains filter • 17
- Conditions of utilization STO (=safe torque off) Safety function • 90
- Configuration name / comments • 142
- Configuration of load control • 150
- Configuration of local modem 1 • 358
- Configuration of remote modem 2 • 359
- Configuration of the HEDA communication • 396
- Configuration of the process-data channel • 361
- Configuring Ethernet Powerlink / EtherCAT • 390
- Configuring the signal source • 143
- Connect braking resistor C3H • 57
- Connection of a braking resistor • 35, 37
- Connection of terminal box MH145 & MH205 • 461
- Connection of the digital Outputs/Inputs • 75
- Connection of the power voltage • 51
- Connection of the power voltage of 2 C3H 3AC devices • 57
- Connection of the power voltage of 2 C3S 3AC devices • 37
- Connections of Compax3H • 50
- Connections of Compax3S • 29
- Connections of digital inputs and outputs M10 & M12 • 486
- Connections of the axis combination • 42
- Connections of the encoder interface • 73
- Connections on the device bottom • 41
- Connections to the motor • 458
- Connector assignment Option M21 X20 • 488
- Connector assignment Option M21 X21 • 489
- Control and status word • 362
- Control functions • 279
- Control path • 162
- Control structures • 191, 196, 198

Control signal filter / filter of actual acceleration value • 196
 Control signal limitations • 192
 Control voltage 24 VDC • 32
 Control voltage 24 VDC C3H • 56
 Control voltage 24VDC / enable connector X4 C3S • 32
 Control voltage 24VDC PSUP (mains module) • 43
 Controller coefficients • 188
 Controller optimization • 160
 Controller optimization Advanced • 218
 Controller optimization disturbance and setpoint behavior (advanced) • 217
 Controller optimization disturbance and setpoint behavior (standard) • 215
 Controller optimization guiding transmission behavior • 220
 Controller optimization of toothed belt drive • 216
 Controller optimization standard • 215
 Correlation between the terms introduced • 187
 Course of the automatic commutation function • 204
 Current (Torque) Limit • 138
 Current control • 247
 Current jerk response • 209
 Current jerk response with the activated saturation characteristic line • 209
 Current setting operation (C3_Current) • 309
 Cut-off frequency for the field weakening range • 176
 Cycle time • 274
 Cyclic data channel for C3T30 and C3T40 • 328
 Cyclic process data channel • 362

D

D/A-Monitor • 438
 Data formats of the bus objects • 368, 386, 389
 Data transfer from Slave to Slave. • 408
 Data transfer Master - Slave and back • 397
 Data types supported • 273
 Deadband following error • 210
 Debouncing
 Limit switch, machine zero and input 0 • 137
 Defining jerk / ramps • 138
 Defining the reference system • 113
 Demand behavior • 182
 Description of jerk • 294
 Determination of the commutation settings • 176
 DeviceNet • 387
 DeviceNet Configuration • 387
 DeviceNet object classes • 388
 DeviceNet Stecker X23 • 66
 Devices with the STO (=safe torque off) safety function • 87
 Digital inputs/outputs • 75
 Digitale Ein-/Ausgänge (Stecker X12) • 74
 Dimensions of the braking resistors • 473
 Direktantriebe • 447

Display of the commutation error in incremental feedback systems • 203
 Display of the measurement point at the cursor position • 259
 Display of the measurement result • 258
 Distinction between signals and systems • 260
 Disturbance behavior • 182
 Disturbance jerk response • 186
 D-term of the KD velocity controller • 189
 Dynamic positioning • 289
 Dynamic stiffness • 185
 Dynamics of a control • 178

E

E/A-Schnittstelle X12 / X22 / SSK22 • 482
 EAM06
 Klemmenblock für Ein- und Ausgänge • 477
 Effect of the notch filter • 207
 Eingangssimulation • 223
 Einleitung • 9, 160
 Einsatzbedingungen für die UL-Zulassung Compax3H • 23
 Einsatzbedingungen für die UL-Zulassung Compax3S • 20
 Einsatzbedingungen für die UL-Zulassung PSUP • 22
 Electronic gearbox (MC_GearIn) • 306
 Electronic simulation of a disturbance torque jerk with the disturbance current jerk • 186
 EMC feedforward • 200
 EMC measures • 450
 Emergency stop and protective door monitoring without external safety switching device. • 103
 Encoder A/B 5V, step/direction or SSI feedback as signal source • 144
 Encoder bypass with Feedback module F12 (for direct drives) • 140
 Encoder cable • 462
 Encoderkopplung von 2 Compax3 - Achsen / SSK29 • 483
 Encodernachbildung • 140
 EnDat - Kabel • 460
 Endless positioning (MC_MoveVelocity) • 300
 Error
 Position difference between load mounted and motor feedback too high • 151
 Error handling • 312
 Error reaction of IEC61131-3 modules with Release < R5-0 • 314
 Error response • 141
 Ersatzschaltbild - Daten für eine Phase • 174
 Establishing PDO connection between 2 CANopen nodes (C3_CANopen_ConfigNode) • 376
 ETH • 310
 EtherCAT (Option I31) Bus-Adresse einstellen • 68
 Ethernet Powerlink (Option I30) / EtherCAT (option I31) X23, X24 • 67
 Ethernet Powerlink / EtherCAT • 390
 ETHERNET-RS485 NetCOM 113 adapter • 348

Example

- C3 powerPLmC Program & Compax3 Program • 330
- Changing the stiffness • 365
- Communication Master - Slave and back • 405
- Compax3 as CANopen Master with PIOs • 324
- Setting the Oscilloscope • 158

Example 1

- Communication Master - Slave and Slave - Slave. • 409

Example 2

- 4-axis application with HEDA • 412

Example in CFC

- Cycle mode • 336
- Positioning 1 • 333
- Positioning 2 • 334
- Positioning with set selection • 335
- Using Compax3-specific function modules and Compax3 objects • 332

Example in ST

- Cycle mode with a Move module • 337

Excitation Signal • 244

Extended cascade (structure variant 1) • 196

Extended cascade structure (structure variant 2 with disturbance variable observer) • 198

External braking resistors • 463

External Moment of Inertia • 173

external position correction • 149

External setpoint generation • 213

F

Feedback error compensation • 167

Feedforward channels • 194

Fehler • 439

Fehlerreaktion bei Busausfall • 362, 372, 387, 390, 393, 396

Fehlerreaktion festlegen

(C3_SetErrorReaction) • 314

Ferrite • 33

Fieldbus master • 147

Filter • 200

Fixed point format C4_3 • 369

Fixed point format E2_6 • 368

Flow chart controller optimization of a direct drive • 219

Following Error (Position Error) • 171

Following error limit • 139

Fremdmotor • 172

Frequency response of the notch filter. • 208

Frequency settings • 251

Frequenzgang des P-TE Gliedes (Betrag und Phase) • 181

Front connector • 40

Function of the Bus LEDs • 65, 67

Function of the Bus LEDs (Profibus I20) • 61

Function of the Bus LEDs (Profinet I32) • 63

Function principle of the automatic commutation with movement • 205

Function range supported • 270

Functionality of the measurement • 238, 241

G

Gain alignment • 230

Gebersysteme für Direktantriebe • 448

General Description • 85

General drive • 113

General rules / timing • 275

Gerätezuordnung • 9

GSD - File • 508

H

Hardware-Endgrenzen • 136

HEDA (motion bus) - Option M11 • 486

HEDA Bus • 392

HEDA expansion (HEDA advanced) • 395

HEDA Master signal source • 147

HEDA Standard • 393

HEDA-Master • 394

HEDA-Slave • 394

Homing modes with home switch (on X12/14) • 122

II²t - monitoring of the motor • 168

Identity Object (0x1018) • 384

IEC 61131-3 - Positioning with function modules based on PLCopen • 25

IEC examples • 332

Important terms and explanations • 85

Inbetriebnahme Compax3 • 107

Inbetriebnahmefenster • 211

Increased following error • 166

Influence of the feedforward measures • 194

Initializing the PIOs (PIO_Init) • 322

Input/output option M12 • 485

Insert new CANopen node (C3_CANopen_AddNode) • 375

Instable behavior • 167

Installation instructions Compax3M • 38

Installation und Freischaltung des ServoSignalAnalyzers • 233

Integer formats • 368

Integration of Parker I/Os (PIOs) • 322

Intended use • 86

Interface • 165

Interface cable • 480

Interface cable order code • 445

Interface module • 327

Interface to C3 powerPLmC • 327

Internal setpoint generation • 211

Internal virtual master • 147

Introduction observer • 200

J

Jerk value • 294

K

Kommunikation im Achsverbund (Stecker X30, X31) • 59

Kommutierungseinstellungen • 168

Kondensatormodul ModulC4 • 476

Konfiguration • 107, 162

Konformität • 387

Koppelobjekte • 413
 Force control • 310
 Force sensor • 310

L

Languages supported • 270
 Lastidentifikation • 211, 227
 Lastregelung • 149, 200
 Layout of the analog inputs of Option M21 • 489
 Leak effect and windowing • 239
 LEDs • 27, 28
 Level • 75
 Library constants • 277
 Limit and monitoring settings • 138, 174
 Limitation behavior • 184
 Limitation of the control voltage • 194
 Linear motors • 449
 Linear Systems (LTI System) • 261
 Linear two mass system • 264
 Linearized motor characteristic lien for different operating points • 169
 Load control signal image • 151
 Logic proximity switch types • 75
 Luenberg observer • 200

M

Machine Zero • 117
 Machine zero (MC_Home) • 304
 Machine zero modes overview • 120
 Machine zero modes without home switch • 128
 Machine zero only from motor reference • 130
 Machine zero speed and acceleration • 132
 Main flow chart of the controller optimization • 214
 Main voltage supply C3S connector X1 • 34
 Mains connection Compax3H • 56
 Mains filter • 450
 Mains filter for NFI01/03 • 452
 Mains filter for PSUP30 • 457
 Mains filter NFI01/01 • 451
 Mains filter NFI01/02 • 451
 Mains filter NFI02/0x • 452
 Mains filter NFI03/01& NFI03/03 • 453
 Mains filter NFI03/02 • 454
 Mains supply PSUP (mains module) X41 • 44
 Manual operation (C3_Jog) • 302
 Mass inertia • 163
 Master Receive Mapping Table (max. 4) • 402
 Master receive slots • 401
 Master transmission slots (Transmit Slots) • 400
 Master Transmit Mapping Table (max. 4) • 402
 Maximum operating speed • 139
 Maximum program size • 274
 MC_GearIn • 306
 MC_Home • 304
 MC_MoveAbsolute • 290
 MC_MoveAdditive • 298
 MC_MoveRelative • 295
 MC_MoveVelocity • 300
 MC_ReadActualPosition • 285
 MC_ReadAxisError • 313
 MC_ReadStatus • 288

MC_Reset • 312
 MC_Stop • 282
 Example 1 • 283
 Example 2 • 284
 Meaning of the Bus LEDs (EtherCAT) • 69
 Meaning of the Bus LEDs (Ethernet Powerlink) • 68
 Meaning of the status LEDs - Compax3 axis controller • 27
 Measure reference • 114
 Measurement of frequency responses • 241
 Measurement of frequency spectra • 238
 Measurement of the motor temperature of Compax3M (axis controller) • 49
 Mechanical system • 248, 262
 MN-M 1,2
 Limit switch as machine zero • 131
 MN-M 11...14
 With direction reversal switches on the negative side • 127
 MN-M 128/129
 Stromschwelle while moving to block • 128
 MN-M 130, 131
 Acquire absolute position via distance coding • 130
 MN-M 132, 133
 Determine absolute position via distance coding with direction reversal switches • 132
 MN-M 17,18
 Limit switch as machine zero • 129
 MN-M 19,20
 MN-Initiator = 1 on the positive side • 122
 MN-M 21,22
 MN Initiator = 1 on the negative side • 123
 MN-M 23...26
 Direction reversal switches on the positive side • 124
 MN-M 27...30
 Direction reversal switches on the negative side • 124
 MN-M 3,4
 MN-Initiator = 1 on the positive side • 125
 MN-M 33,34
 MN at motor zero point • 130
 MN-M 35
 MN (machine zero) at the current position • 128
 MN-M 5,6
 MN-Initiator = 1 auf der negativen Seite • 126
 MN-M 7...10
 Direction reversal switches on the positive side • 127
 Mode 1
 Time and maximum values are deduced from Compax3 input values • 265
 Mode 2
 Compax3 input values are deduced from times and maximum values • 266
 Modem cable SSK31 • 484
 Modem MB-Connectline MDH 500 / MDH 504 • 349
 Momenten- / Kraftregelung (C3_TorqueControl) • 310

Monitor information • 153
 Motion control • 268
 Motion cycle with feedforward measures • 195
 Motion profile at jerk-controlled setpoint generation • 212
 Motion set • 225
 Motor - Dauerauslastung: • 168
 Motor / Motor brake C3S connector X3 • 33
 Motor / motor brake Compax3M (axis controller) • 48
 Motor / Motorbremse C3H • 55
 Motor cable • 461
 Motor characteristic line of a synchronous servo motor (torque via velocity) • 164
 Motor Connection • 33
 Motor holding brake • 33
 Motor output filter • 455
 Motor output filter MDR01/01 • 455
 Motor output filter MDR01/02 • 456
 Motor output filter MDR01/04 • 455
 Motor parameters • 172, 200
 Motor parameters relevant for the control • 163
 Motor pulse usage • 170
 Motor reference point • 173
 Motor selection • 109
 Motor types supported • 173
 Mounting and dimensions • 76
 Mounting and dimensions C3H • 82
 Mounting and dimensions Compax3S • 76
 Mounting and dimensions Compax3S0xxV2 • 76
 Mounting and dimensions Compax3S100V2 and S0xxV4 • 77
 Mounting and dimensions Compax3S150V2 and S150V4 • 78
 Mounting and dimensions Compax3S300V4 • 79
 Mounting and dimensions PSUP/C3M • 80
 Mounting and dimensions PSUP10/C3M050D6, C3M100D6, C3M150D6 • 80
 Mounting and dimensions PSUP20/PSUP30/C3M300D6 • 81
 Mounting distances, air currents Compax3H050V4 • 83
 Mounting distances, air currents Compax3H090V4 • 83
 Mounting distances, air currents Compax3H1xxV4 • 84

N

Netzdrosseln • 457
 Noise • 166
 Nominal point • 169
 Nominal point data • 163
 Non-linearities and their effects • 244
 Normalization factors • 414
 Notch filter • 207
 Note on error switch-off • 91
 Notes on the STO function • 90

O

Object overview sorted by object groups (T30) • 428
 Object overview sorted by object name (T30) • 416
 Object types • 381
 Object Up-/Download via RS232 / RS485 • 386
 Object Upload/download via Profibus/Profinet • 366
 Offset alignment • 230
 Open/Closed Loop frequency response measurement • 243
 Opening the brake (C3_OpenBrake) • 284
 Operating and status field • 256
 Operating Principle • 223
 Operation with MultiTurn emulation • 119
 Operator control module BDM • 477
 Operators supported • 271
 Optimierung • 152
 Optimization parameter Advanced • 199
 Optimization window • 152
 Optimize motor reference point and switching frequency of the motor current • 109
 Option M10 = HEDA (M11) & I/Os (M12) • 487
 Options M1x • 485
 Order and response processing • 364
 Order code • 440
 Order Code braking resistors • 443
 Order code device Compax3 • 441
 Order code for mains module PSUP • 442
 Oscillating plant • 178
 Oscilloscope operating mode switch: • 155
 Other • 207
 Other settings • 253
 Overview of the DeviceNet object classes • 389
 Overview of the user interface • 247

P

Parameter access with DPV0 Required data channel • 363
 Parameterization by 3 objects. • 208
 Parker Motor • 172
 Parker Servomotoren • 447
 Path optimized positioning • 293
 PC - PSUP (Mains module) • 59
 PC <-> C3M device combination (USB) • 346
 PC <-> Compax3 (RS232) • 343
 PC <-> Compax3 (RS485) • 345
 Permissible braking pulse power
 BRM04/01 with C3S150V2 • 469
 BRM04/01 with C3S300V4 • 470
 BRM04/02 with C3S150V2 • 470
 BRM04/02 with C3S300V4 • 471
 BRM04/03 with C3S300V4 • 471
 BRM05/01 with C3S063V2 • 468
 BRM05/01 with C3S075V4 • 468
 BRM05/02 with C3S075V4 • 469
 BRM08/01 with C3S015V4 / C3S038V4 • 465
 BRM08/01 with C3S025V2 • 466
 BRM09/01 with C3S100V2 • 466
 BRM10/01 with C3S150V4 • 467

- BRM10/02 with C3S150V4 • 467
- BRM11/01 with C3H0xxV4 • 472
- BRM12/01 with C3H1xxV4 • 472
- BRM13/01 with PSUP10D6 • 473
- BRM14/01 with PSUP10D6 • 473
- Permissible braking pulse powers of the braking resistors • 464
- Physical Source • 143
- PIO
 - External Inputs/Outputs • 492
- PIO_Init • 322
- PIO_Inputx...y • 323
- PIO_Outputx...y • 324
- PKW parameter channel • 362
- Plug assignment Compax3S0xx V2 • 32, 33, 34, 35, 58, 71
- Position control • 249
- Position correction • 149
- Position measurement external • 149
- Position mode in reset operation • 293
- Positioning after homing run • 117, 133
- Positioning functions (standard) • 289
- Positioning window - Position reached • 138
- Possible PDO assignment • 372, 391
- Power supply • 34
- Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices • 36
- Power supply plug X1 for 1 AC 230VAC/240VAC devices • 34
- Power supply plug X1 for 3AC 230VAC/240VAC devices • 34
- Power supply voltage DC C3H • 57
- Prerequisites • 269
- Prerequisites for the automatic commutation • 204
- Principle • 227
- Proceeding during controller optimization • 213
- Process image • 316
- Process of the automatic determination of the load characteristic value (load identification) • 228
- Profibus
 - Profidriveprofil nachbilden (C3_ProfiDrive_Statemachine) • 339
- Profibus / Profinet configuration • 360
- Profibus connector X23 on Interface I20 • 61
- Profibus plug BUS08/01 • 490
- Profibus/Profinet • 360
- Profidrive profile • 339
- ProfileViewer for the optimization of the motion profile • 265
- Profinet connector X23, X24 on Interface I32 • 62
- Profinet Zertifikat • 10
- Program development and test • 270
- Programming based on IEC61131-3 • 268
- PSUP/Compax3M Connections • 40
- P-TE - Symbol • 180
- P-term KV position loop • 189

Q

- Quality of different feedback systems • 165

R

- Ramp upon error and stromlos schalten • 138
- Read access to the (C3_ReadArray) array • 287
- Reading an object in another node (C3_CANopen_SDO_Read4) • 378
- Reading axis errors (MC_ReadAxisError) • 313
- Reading digital inputs (C3_Input) • 316
- Reading the current position (MC_ReadActualPosition) • 285
- Reading the device status (MC_ReadStatus) • 288
- Reading the PIO inputs 0-15 (PIO_Inputx...y) • 323
- Reading values • 285
- Reading/writing optional inputs/outputs • 316
- Recipe management • 270
- Recipe table • 141
- Recipe table with 9 columns and 32 (120) lines • 273
- Recommendations for preparing the modem operation • 359
- Reduction of the current ripple • 172
- Ref X11 / SSK21 • 482
- Reference point 1
 - higher velocity at reduced torque • 169
- Reference point 2
 - Increased torque thanks to additional cooling • 170
- Regelungsmaßnahmen für reibungsbehaftete Antriebe • 210
- Reibungskompensation • 211
- Relative positioning (MC_MoveRelative) • 295
- Relevant application parameters • 171
- Remote diagnosis via Modem • 357
- Resolution • 165
- Resolver • 71
- Resolver / Feedback (connector X13) • 71
- Resolver cable • 459
- Resonance points and their causes • 263
- Response • 184
- Retain Variables • 273
- Rigidity • 185
- Rotary servo motors • 449
- Rotary two mass system • 263
- Rotor time constant • 176
- RS232 - Kabel / SSK1 • 480
- RS232 / RS485 interface (plug X10) • 58
- RS232 plug assignment • 58
- RS485 - Kabel zu Pop / SSK27 • 481
- RS485 plug assignment • 58
- RS485 settings values • 352

S

- Safe torque off • 85
- Safe torque off basic function • 93
- Safe torque off description • 93, 96
- Safe torque off layout with bus • 94
- Safe torque off with bus option • 94
- Safe torque off without bus option • 91
- Safety function - STO (=safe torque off) • 85
- Safety instructions • 14

- Safety instructions concerning the frequency response measurement • 241
 - Safety notes for the STO function in the Compax3M • 99
 - Safety switching circuits • 98
 - Safety technology option S3 for Compax3M (axis controller) • 49
 - Safety-conscious working • 14
 - Sättigungsverhalten • 175, 209
 - Saturation values • 165
 - Scope • 153
 - Scope of delivery • 11
 - Selection of the signal or system to be measured. • 247
 - Selection of the supply voltage used • 108
 - Sending NMT messages (C3_CANopen_NMT) • 377
 - Service Data Objekts (SDO) • 385
 - ServoSignalAnalyzer - function range • 231
 - Set Ethernet Powerlink (option I30) bus address • 68
 - Setpoint and disturbance behavior of a control loop • 182
 - Setpoint generation • 211
 - Setting baud rate and Node-ID • 64
 - Setting the axis function • 60
 - Setting the HEDA master • 399
 - Setting the HEDA slave • 403
 - Setting the positioning mode in reset mode • 293
 - Setting the time basis XDIV • 155
 - Settings for channels 1..4 • 156
 - Setup and optimization of the control • 190
 - Setup mode • 224
 - Shifting the working point into a linear range • 245
 - Signal analysis overview • 232
 - Signal filtering for external setpoint specification and electronic cam • 222
 - Signal processing of the analog input 0 • 146
 - Signal processing of the analog inputs • 230
 - Signal source of the load feedback system • 143
 - Signale zum Triggerereignis speichern (C3_TouchProbe) • 319
 - Signalfilterung bei externer Sollwertvorgabe • 220
 - Signalfilterung bei externer Sollwertvorgabe und elektronischem Getriebe • 221
 - Signalfussplan Luenberger-Beobachter • 201
 - Signalschnittstellen • 71
 - SinCos© cable • 460
 - Slave mit Konfiguration via Master • 390
 - Slave Receive Mapping table • 404
 - Slave receive slots • 403
 - Slave transmission slots (Transmit Slots) • 404
 - Slave Transmit Mapping table • 404
 - Slip • 149
 - Slip Frequency • 175
 - Software end limits • 134
 - Software zur Unterstützung der Konfiguration, Inbetriebnahme und Optimierung • 161
 - Special functions • 157
 - Special safety instructions • 15
 - Speed control • 252, 300
 - SSI - Konfiguration • 145
 - Stability problem in the high-frequency range: • 179
 - Stability problem in the low-frequency range: • 179
 - Stability, attenuation • 178
 - Standard • 190
 - Standard cascade structure • 191
 - Standard function modules supported • 272
 - Standard functions supported • 272
 - Standard optimization parameters • 192
 - Static stiffness • 185
 - Status diagram based on PLCopen • 278
 - Status LEDs • 27, 28
 - Status values • 438
 - Stecker- und Pinbelegung C3H • 53
 - Stecker- und Pinbelegung C3S • 30
 - Step response of a delay component • 180
 - Step response of the velocity loop depending on the optimization parameter • 188
 - STO (= safe torque off) with Compax3m (Option S1) • 98
 - STO (= safe torque off) with Compax3S • 88
 - STO delay times • 89, 100
 - STO function description • 102
 - STO function test • 104
 - STO function with safety switching device via Compax3M inputs • 101
 - STO Principle (= Safe Torque Off) with Compax3S • 88
 - STO Test-Protokoll-Vorschlag (Sicherheitsoption S1) • 105
 - Stop (MC_Stop) • 282
 - Storage • 13
 - Strom auf dem Netz-PE (Ableitstrom) • 24
 - Structure • 357
 - Structure of a cascade control • 184
 - Structure of a control • 178
 - Supply networks • 24
 - Supporting IEC modules • 373
 - Switching frequency of the motor current / motor reference point • 171
 - Switching off error messages (C3_ErrorMask) • 315
- ## T
- T30 Objects for the Process-Data-Channel / the Messages • 426
 - Teach machine zero • 128
 - Technical Characteristics STO Compax3S • 97
 - Technical data of the HEDA interface / overview • 395
 - Technische Daten • 493
 - Technische Daten der Compax3M S1-Option • 106
 - Temperature switch PSUP (mains module) • 47
 - Test functions • 183
 - The calculation of the physically possible acceleration • 212

The possibilities of the HEDA expansion • 395
 This module is used to determine the status during Nodeguarding (C3_CANopen_GuardingState) • 374
 This module is used to determine the status of the CANopen NMT status machine (C3_CANopen_State) • 373
 Time frame signal source master • 146
 Time function and power density spectrum of Compax3 setpoint generator with different jerk settings • 213
 Tips • 229
 Too high overshoot on velocity • 166
 Toothed belt drive as two mass system • 264
 Toroidal core ferrite • 33
 Torque motors • 449
 Tracking filter • 220
 Traditional generation of a disturbance torque/force jerk • 186
 Transmission cycle time • 373
 Travel Limit Settings • 134
 Trigger settings • 157
 Turning the motor holding brake on and off • 267
 Type specification plate • 12
 Type specification plate data • 174
 Typical application with Bus and IEC61131 • 360
 Typical problems of a non optimized control • 166

U

Unsigned - Formats • 368
 Usage in accordance with intended purpose • 14
 USB - RS232 converter • 58
 USB-RS485 Adapter Moxa Uport 1130 • 347
 User interface • 154

V

Velocity Loop P Term • 188
 Velocity, bandwidth • 179
 Verpackung, Transport, Lagerung • 13
 Voltage decoupling • 200
 Vorgehen bei der Konfiguration, Inbetriebnahme und Optimierung • 160

W

Warranty conditions • 16
 Wertebereiche für Positionier - Parameter • 289
 Wiring of analog interfaces • 73
 Wiring of the motor output filter • 456
 With direction reversal switches • 123, 126, 131
 With motor reference point • 125, 130
 With upper mounting, the housing design may be different • 81
 Without direction reversal switches • 122, 125
 Without motor reference point • 122, 128
 Write digital outputs (C3_Output) • 316
 Writing an object in another node (C3_CANopen_SDO_Write4) • 379

Writing the PIO outputs 0-15 (PIO_Outputx...y) • 324
 Wrongly set notch filter • 207

X

X1 • 34
 X10 • 58
 X11 • 73
 X12 • 74
 X13 • 71
 X14 Safety technology option S1 for Compax3M (axis controller) • 49
 X2 • 35
 X3 • 33
 X4 • 32

Z

Zubehör Compax3 • 447